

## FOREWORD

This wiring diagram manual has been prepared to provide information on the electrical system of the 2001 TOYOTA TACOMA.

Applicable models: VZN150,170,195 Series  
RZN140,150,161,  
RZN171,191,196 Series

For service specifications and repair procedures of the above models other than those listed in this manual, refer to the following manuals;

Manual Name	Pub. No.
▲ 2001 TOYOTA TACOMA Repair Manual	Volume 1 RM835U1 Volume 2 RM835U2
▲ 2001 TOYOTA New Car Features	NCF191U

All information in this manual is based on the latest product information at the time of publication. However, specifications and procedures are subject to change without notice.

**TOYOTA MOTOR CORPORATION**

### NOTICE

**When handling supplemental restraint system components (removal, installation or inspection, etc.), always follow the direction given in the repair manuals listed above to prevent accidents and supplemental restraint system malfunction.**

# A INTRODUCTION

This manual consists of the following 13 sections:

No.	Section	Description
A	INDEX	Index of the contents of this manual.
	INTRODUCTION	Brief explanation of each section.
B	HOW TO USE THIS MANUAL	Instructions on how to use this manual.
C	TROUBLE-SHOOTING	Describes the basic inspection procedures for electrical circuits.
D	ABBREVIATIONS	Defines the abbreviations used in this manual.
E	GLOSSARY OF TERMS AND SYMBOLS	Defines the symbols and functions of major parts.
F	RELAY LOCATIONS	Shows position of the Electronic Control Unit, Relays, Relay Block, etc. This section is closely related to the system circuit.
G	ELECTRICAL WIRING ROUTING	Describes position of Parts Connectors, Splice points, Ground points, etc. This section is closely related to the system circuit.
H	INDEX	Index of the system circuits.
	SYSTEM CIRCUITS	Electrical circuits of each system are shown from the power supply through ground points. Wiring connections and their positions are shown and classified by code according to the connection method. (Refer to the section, "How to use this manual"). The "System Outline" and "Service Hints" useful for troubleshooting are also contained in this section.
I	GROUND POINT	Shows ground positions of all parts described in this manual.
J	POWER SOURCE (Current Flow Chart)	Describes power distribution from the power supply to various electrical loads.
K	CONNECTOR LIST	Describes the form of the connectors for the parts appeared in this book. This section is closely related to the system circuit.
L	PART NUMBER OF CONNECTORS	Indicates the part number of the connectors used in this manual.
M	OVERALL ELECTRICAL WIRING DIAGRAM	Provides circuit diagrams showing the circuit connections.

This manual provides information on the electrical circuits installed on vehicles by dividing them into a circuit for each system.

The actual wiring of each system circuit is shown from the point where the power source is received from the battery as far as each ground point. (All circuit diagrams are shown with the switches in the OFF position.)

When troubleshooting any problem, first understand the operation of the circuit where the problem was detected (see System Circuit section), the power source supplying power to that circuit (see Power Source section), and the ground points (see Ground Point section). See the System Outline to understand the circuit operation.


When the circuit operation is understood, begin troubleshooting of the problem circuit to isolate the cause. Use Relay Location and Electrical Wiring Routing sections to find each part, junction block and wiring harness connectors, wiring harness and wiring harness connectors, splice points, and ground points of each system circuit. Internal wiring for each junction block is also provided for better understanding of connection within a junction block.

Wiring related to each system is indicated in each system circuit by arrows (from\_\_, to\_\_). When overall connections are required, see the Overall Electrical Wiring Diagram at the end of this manual.

# B HOW TO USE THIS MANUAL

\* The system shown here is an EXAMPLE ONLY. It is different to the actual circuit shown in the SYSTEM CIRCUITS SECTION.

## [A] STOP LIGHT



**[A]** : System Title


**[B]** : Indicates a Relay Block. No shading is used and only the Relay Block No. is shown to distinguish it from the J/B

Example: ① Indicates Relay Block No.1

**[C]** : ( ) is used to indicate different wiring and connector, etc. when the vehicle model, engine type, or specification is different.

**[D]** : Indicates related system.

**[E]** : Indicates the wiring harness and wiring harness connector. The wiring harness with male terminal is shown with arrows (↗). Outside numerals are pin numbers.




The first letter of the code for each wiring harness and wiring harness connector(s) indicates the component's location, e.g, "E" for the Engine Compartment, "I" for the Instrument Panel and Surrounding area, and "B" for the Body and Surrounding area.

When more than one code has the first and second letters in common, followed by numbers (e.g, IH1, IH2), this indicates the same type of wiring harness and wiring harness connector.

**[F]** : Represents a part (all parts are shown in sky blue). The code is the same as the code used in parts position.

**[G]** : Junction Block (The number in the circle is the J/B No. and the connector code is shown beside it). Junction Blocks are shaded to clearly separate them from other parts.



**[H]** : When 2 parts both use one connector in common, the parts connector name used in the wire routing section is shown in square brackets [ ] .


**[I]** : Indicates the wiring color.

Wire colors are indicated by an alphabetical code.

- B = Black    W = White    BR = Brown
- L = Blue    V = Violet    SB = Sky Blue
- R = Red    G = Green    LG = Light Green
- P = Pink    Y = Yellow    GR = Gray
- O = Orange


The first letter indicates the basic wire color and the second letter indicates the color of the stripe.

Example: L - Y



**[J]** : Indicates a wiring Splice Point (Codes are "E" for the Engine Room, "I" for the Instrument Panel, and "B" for the Body).

Example:




The Location of splice Point I 5 is indicated by the shaded section.

**[K]** : Indicates a shielded cable.



**[L]** : Indicates the pin number of the connector. The numbering system is different for female and male connectors.

Example: Numbered in order from upper left to lower right      Numbered in order from upper right to lower left



**[M]** : Indicates a ground point.

The first letter of the code for each ground point(s) indicates the component's location, e.g, "E" for the Engine Compartment, "I" for the Instrument Panel and Surrounding area, and "B" for the Body and Surrounding area.

**[N]** : Page No.

## B HOW TO USE THIS MANUAL

### [O] SYSTEM OUTLINE

Current is applied at all times through the STOP fuse to TERMINAL 2 of the stop light SW.  
When the ignition SW is turned on, current flows from the GAUGE fuse to TERMINAL 8 of the light failure sensor, and also flows through the rear lights warning light to TERMINAL 4 of the light failure sensor.

#### STOP LIGHT DISCONNECTION WARNING

When the ignition SW is turned on and the brake pedal is pressed (Stop light SW on), if the stop light circuit is open, the current flowing from TERMINAL 7 of the light failure sensor to TERMINALS 1, 2 changes, so the light failure sensor detects the disconnection and the warning circuit of the light failure sensor is activated.

As a result, the current flows from TERMINAL 4 of the light failure sensor to TERMINAL 11 to GROUND and turns the rear lights warning light on. By pressing the brake pedal, the current flowing to TERMINAL 8 of the light failure sensor keeps the warning circuit on and holds the warning light on until the ignition SW is turned off.

### [P] SERVICE HINTS

#### S6 STOP LIGHT SW

2-1 : Closed with the brake pedal depressed

#### L4 LIGHT FAILURE SENSOR

1, 2, 7-GROUND : Approx. 12 volts with the stop light SW on

4, 8-GROUND : Approx. 12 volts with the ignition SW at ON position

11-GROUND : Always continuity

### [Q] ○ : PARTS LOCATION

Code	See Page	Code	See Page	Code	See Page
C7	34	L4	36	R7	37
H17	36	R6	37	S6	35

### [R] ○ : RELAY BLOCKS

Code	See Page	Relay Blocks (Relay Block Location)
1	18	R/B No.1 (Instrument Panel Left)

### [S] ○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
IB	20	Instrument Panel Wire and Instrument Panel J/B (Lower Finish Panel)
3C	22	Instrument Panel Wire and J/B No.3 (Instrument Panel Left Side)

### [T] □ : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IE1	42	Floor Wire and Instrument Panel Wire (Left Kick Panel)
BV1	50	Luggage Room Wire and Floor Wire (Luggage Compartment Left)

### [U] ▽ : GROUND POINTS

Code	See Page	Ground Points Location
BL	50	Under the Left Quarter Pillar
BO	50	Back Panel Center

### [V] ○ : SPLICE POINTS

Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
I5	44	Cowl Wire	B18	50	Luggage Room Wire


**[O]** : Explains the system outline.

**[P]** : Indicates values or explains the function for reference during troubleshooting.

**[Q]** : Indicates the reference page showing the position on the vehicle of the parts in the system circuit.

Example : Part "L4" (Light Failure Sensor) is on page 36 of the manual.

\* The letter in the code is from the first letter of the part, and the number indicates its order in parts starting with that letter.

Example : L 4  


**[R]** : Indicates the reference page showing the position on the vehicle of Relay Block Connectors in the system circuit.

Example : Connector "1" is described on page 18 of this manual and is installed on the left side of the instrument panel.

**[S]** : Indicates the reference page showing the position on the vehicle of J/B and Wire Harness in the system circuit.

Example : Connector "3C" connects the Instrument Panel Wire and J/B No.3. It is described on page 22 of this manual, and is installed on the instrument panel left side.

**[T]** : Indicates the reference page describing the wiring harness and wiring harness connector (the female wiring harness is shown first, followed by the male wiring harness).

Example : Connector "IE1" connects the floor wire (female) and Instrument panel wire (male). It is described on page 42 of this manual, and is installed on the left side kick panel.

**[U]** : Indicates the reference page showing the position of the ground points on the vehicle.

Example : Ground point "BO" is described on page 50 of this manual and is installed on the back panel center.


**[V]** : Indicates the reference page showing the position of the splice points on the vehicle.

Example : Splice point "I5" is on the Cowl Wire Harness and is described on page 44 of this manual.

# B HOW TO USE THIS MANUAL

The ground points circuit diagram shows the connections from all major parts to the respective ground points. When troubleshooting a faulty ground point, checking the system circuits which use a common ground may help you identify the problem ground quickly. The relationship between ground points (  $\nabla_{EA}$ ,  $\nabla_{IB}$  and  $\nabla_{IC}$  shown below) can also be checked this way.

## I GROUND POINT




\* The system shown here is an EXAMPLE ONLY. It is different to the actual circuit shown in the SYSTEM CIRCUITS SECTION.



The "Current Flow Chart" section, describes which parts each power source (fuses, fusible links, and circuit breakers) transmits current to. In the Power Source circuit diagram, the conditions when battery power is supplied to each system are explained. Since all System Circuit diagrams start from the power source, the power source system must be fully understood.

### J POWER SOURCE (Current Flow Chart)


The chart below shows the route by which current flows from the battery to each electrical source (Fusible Link, Circuit Breaker, Fuse, etc.) and other parts.



### Engine Room R/B (See Page 20)

Fuse	System	Page
20A STOP	ABS	194
	ABS and Traction Control	187
	Cruise Control	180
	Electronically Controlled Transmission and A/T Indicator	166
	Multiplex Communication System	210
10A DOME	Cigarette Lighter and Clock	214
	Combination Meter	230
	Headlight	112
	Interior Light	122
	Key Reminder and Seat Belt Warning	
	Light Auto Turn Off	


### POWER SOURCE



\* The system shown here is an EXAMPLE ONLY. It is different to the actual circuit shown in the SYSTEM CIRCUITS SECTION.


# B HOW TO USE THIS MANUAL

## K CONNECTOR LIST



**[A]** : Indicates connector to be connected to a part. (The numeral indicates the pin No.)

**[B]** : Junction Connector  
Indicates a connector which is connected to a short terminal.



Junction connector in this manual include a short terminal which is connected to a number of wire harnesses. Always perform inspection with the short terminal installed. (When installing the wire harnesses, the harnesses can be connected to any position within the short terminal grouping. Accordingly, in other vehicles, the same position in the short terminal may be connected to a wire harness from a different part.)

Wire harness sharing the same short terminal grouping have the same color.

**[C]** : Parts Code  
The first letter of the code is taken from the first letter of part, and the numbers indicates its order in parts which start with the same letter.

**[D]** : Connector Color  
Connectors not indicated are milky white in color.

**L PART NUMBER OF CONNECTORS**

Code	Part Name	Part Number	Code	Part Name	Part Number
A 1	A/C Ambient Temp. Sensor	90980-11070	D 4	Diode (Door Courtesy Light)	90980-11608
A 2	A/C Condenser Fan Motor	90980-11237	D 5	Diode (Key Off Operation)	90980-10962
A 3	A/C Condenser Fan Relay	90980-10940	D 6	Diode (Luggage Compartment Light)	90980-11608
<b>A 4</b>	A/C Triple Pressure SW (A/C Dual and Single Pressure SW)	<b>90980-10943</b>	D 7	Door Lock Control Relay	90980-10848
<b>[A]</b>	A/T Oil Temp. Sensor <b>[B]</b>	90980-11413 <b>[C]</b>	D 8	Door Courtesy Light LH	90980-11148
A 6	ABS Actuator	90980-11151	D 9	Door Courtesy Light RH	
A 7	ABS Actuator	90980-11009	D10	Door Courtesy SW LH	90980-11097
A 8	ABS Speed Sensor Front LH	90980-10941	D11	Door Courtesy SW RH	
A 9	ABS Speed Sensor Front RH	90980-11002	D12	Door Courtesy SW Front LH	90980-11156
A 10	Airbag Sensor Front LH	90980-11856	D13	Door Courtesy SW Front RH	
A 11	Airbag Sensor Front RH		D14	Door Courtesy SW Rear LH	
A 12		90980-11194	D15	Door Courtesy SW Rear RH	
		90980-11170	D16	Door Courtesy SW Front LH	90980-11170


**[A]** : Part Code

**[B]** : Part Name

**[C]** : Part Number  
Toyota Part Number are indicated.

Not all of the above part numbers of the connector are established for the supply. In case of ordering a connector or terminal with wire, please confirm in advance if there is supply for it using "Parts Catalog News" (published by Parts Engineering Administration Dept.).

# C TROUBLESHOOTING



## VOLTAGE CHECK


- (a) Establish conditions in which voltage is present at the check point.

Example:

- [A] - Ignition SW on
- [B] - Ignition SW and SW 1 on
- [C] - Ignition SW, SW 1 and Relay on (SW 2 off)


- (b) Using a voltmeter, connect the negative lead to a good ground point or negative battery terminal, and the positive lead to the connector or component terminal.

This check can be done with a test light instead of a voltmeter.



## CONTINUITY AND RESISTANCE CHECK


- (a) Disconnect the battery terminal or wire so there is no voltage between the check points.
- (b) Contact the two leads of an ohmmeter to each of the check points.




If the circuit has diodes, reverse the two leads and check again.

When contacting the negative lead to the diode positive side and the positive lead to the negative side, there should be continuity.

When contacting the two leads in reverse, there should be no continuity.



- (c) Use a volt/ohmmeter with high impedance (10 k $\Omega$ /V minimum) for troubleshooting of the electrical circuit.



## FINDING A SHORT CIRCUIT

- Remove the blown fuse and disconnect all loads of the fuse.
- Connect a test light in place of the fuse.
- Establish conditions in which the test light comes on.

Example:

- [A] - Ignition SW on
  - [B] - Ignition SW and SW 1 on
  - [C] - Ignition SW, SW 1 and Relay on (Connect the Relay) and SW 2 off (or Disconnect SW 2)
- Disconnect and reconnect the connectors while watching the test light. The short lies between the connector where the test light stays lit and the connector where the light goes out.
  - Find the exact location of the short by lightly shaking the problem wire along the body.


## CAUTION:

- Do not open the cover or the case of the ECU unless absolutely necessary. (If the IC terminals are touched, the IC may be destroyed by static electricity.)
- When replacing the internal mechanism (ECU part) of the digital meter, be careful that no part of your body or clothing comes in contact with the terminals of leads from the IC, etc. of the replacement part (spare part).


## DISCONNECTION OF MALE AND FEMALE CONNECTORS

To pull apart the connectors, pull on the connector itself, not the wire harness.

HINT: Check to see what kind of connector you are disconnecting before pulling apart.



## C TROUBLESHOOTING



### HOW TO REPLACE TERMINAL (with terminal retainer or secondary locking device)

#### 1. PREPARE THE SPECIAL TOOL

HINT : To remove the terminal from the connector, please construct and use the special tool or like object shown on the left.

#### 2. DISCONNECT CONNECTOR


#### 3. DISENGAGE THE SECONDARY LOCKING DEVICE OR TERMINAL RETAINER.

(a) Locking device must be disengaged before the terminal locking clip can be released and the terminal removed from the connector.

(b) Use a special tool or the terminal pick to unlock the secondary locking device or terminal retainer.

#### NOTICE:

**Do not remove the terminal retainer from connector body.**




[A] For Non-Waterproof Type Connector

HINT : The needle insertion position varies according to the connector's shape (number of terminals etc.), so check the position before inserting it.


"Case 1"





Raise the terminal retainer up to the temporary lock position.



"Case 2"

Open the secondary locking device.





[B] For Waterproof Type Connector

HINT : Terminal retainer color is different according to connector body.

Example:

Terminal Retainer : Connector Body

Black or White : Gray

Black or White : Dark Gray

Gray or White : Black

"Case 1"

Type where terminal retainer is pulled up to the temporary lock position (Pull Type).


Insert the special tool into the terminal retainer access hole (▲Mark) and pull the terminal retainer up to the temporary lock position.

HINT : The needle insertion position varies according to the connector's shape (Number of terminals etc.), so check the position before inserting it.


"Case 2"

Type which cannot be pulled as far as Power Lock insert the tool straight into the access hole of terminal retainer as shown.


## C TROUBLESHOOTING



Push the terminal retainer down to the temporary lock position.



(c) Release the locking lug from terminal and pull the terminal out from rear.




### 4. INSTALL TERMINAL TO CONNECTOR

(a) Insert the terminal.

HINT:

1. Make sure the terminal is positioned correctly.
2. Insert the terminal until the locking lug locks firmly.
3. Insert the terminal with terminal retainer in the temporary lock position.



(b) Push the secondary locking device or terminal retainer in to the full lock position.

### 5. CONNECT CONNECTOR
























**ABBREVIATIONS**

















The following abbreviations are used in this manual.

ABS	=	Anti-Lock Brake System
A/C	=	Air Conditioning
ADD	=	Automatic Disconnecting Differential
A/T	=	Automatic Transmission
COMB.	=	Combination
DIFF.	=	Differential
ECU	=	Electronic Control Unit
EGR	=	Exhaust Gas Recirculation
ESA	=	Electronic Spark Advance
EVAP	=	Evaporative Emission
INT	=	Intermittent
J/B	=	Junction Block
LH	=	Left-Hand
M/T	=	Manual Transmission
O/D	=	Overdrive
R/B	=	Relay Block
RH	=	Right-Hand
SFI	=	Sequential Multiport Fuel Injection
SPEC.	=	Specification
SRS	=	Supplemental Restraint System
SW	=	Switch
TEMP.	=	Temperature
VSV	=	Vacuum Switching Valve
w/	=	With
w/o	=	Without
2WD	=	Two Wheel Drive
4WD	=	Four Wheel Drive

\* The titles given inside the components are the names of the terminals (terminal codes) and are not treated as being abbreviations.


# E GLOSSARY OF TERMS AND SYMBOLS

 <p><b>BATTERY</b> Stores chemical energy and converts it into electrical energy. Provides DC current for the auto's various electrical circuits.</p>	 <p><b>GROUND</b> The point at which wiring attaches to the Body, thereby providing a return path for an electrical circuit; without a ground, current cannot flow.</p>
 <p><b>CAPACITOR (Condenser)</b> A small holding unit for temporary storage of electrical voltage.</p>	<p><b>HEADLIGHTS</b> Current flow causes a headlight filament to heat up and emit light. A headlight may have either a single (1) filament or a double (2) filament</p> <p>1. SINGLE FILAMENT</p>  <p>2. DOUBLE FILAMENT</p> 
 <p><b>CIGARETTE LIGHTER</b> An electric resistance heating element.</p>	
 <p><b>CIRCUIT BREAKER</b> Basically a reusable fuse, a circuit breaker will heat and open if too much current flows through it. Some units automatically reset when cool, others must be manually reset.</p>	 <p><b>HORN</b> An electric device which sounds a loud audible signal.</p>
 <p><b>DIODE</b> A semiconductor which allows current flow in only one direction.</p>	 <p><b>IGNITION COIL</b> Converts low-voltage DC current into high-voltage ignition current for firing the spark plugs.</p>
 <p><b>DIODE, ZENER</b> A diode which allows current flow in one direction but blocks reverse flow only up to a specific voltage. Above that potential, it passes the excess voltage. This acts as a simple voltage regulator.</p>	 <p><b>LIGHT</b> Current flow through a filament causes the filament to heat up and emit light.</p>
 <p><b>PHOTODIODE</b> The photodiode is a semiconductor which controls the current flow according to the amount of light.</p>	 <p><b>LED (LIGHT EMITTING DIODE)</b> Upon current flow, these diodes emit light without producing the heat of a comparable light.</p>
 <p><b>DISTRIBUTOR, IIA</b> Channels high-voltage current from the ignition coil to the individual spark plugs.</p>	 <p><b>METER, ANALOG</b> Current flow activates a magnetic coil which causes a needle to move, thereby providing a relative display against a background calibration.</p>
 <p><b>FUSE</b> A thin metal strip which burns through when too much current flows through it, thereby stopping current flow and protecting a circuit from damage.</p>  <p><b>FUSIBLE LINK</b> A heavy-gauge wire placed in high amperage circuits which burns through on overloads, thereby protecting the circuit. The numbers indicate the cross-section surface area of the wires.</p>  <p>(for High Current Fuse or Fusible Link)</p>	 <p><b>METER, DIGITAL</b> Current flow activates one or many LED's, LCD's, or fluorescent displays, which provide a relative or digital display.</p>
	 <p><b>MOTOR</b> A power unit which converts electrical energy into mechanical energy, especially rotary motion.</p>


 <p><b>RELAY</b> Basically, an electrically operated switch which may be normally closed (1) or open (2). Current flow through a small coil creates a magnetic field which either opens or closes an attached switch.</p> <p><b>1. NORMALLY CLOSED</b></p> <p><b>2. NORMALLY OPEN</b></p>	 <p><b>SPEAKER</b> An electromechanical device which creates sound waves from current flow.</p>
 <p><b>RELAY, DOUBLE THROW</b> A relay which passes current through one set of contacts or the other.</p>	<p><b>SWITCH, MANUAL</b> Opens and closes circuits, thereby stopping (1) or allowing (2) current flow.</p>  <p><b>1. NORMALLY OPEN</b></p> <p><b>2. NORMALLY CLOSED</b></p>
 <p><b>RESISTOR</b> An electrical component with a fixed resistance, placed in a circuit to reduce voltage to a specific value.</p>	<p><b>SWITCH, DOUBLE THROW</b> A switch which continuously passes current through one set of contacts or the other.</p> 
 <p><b>RESISTOR, TAPPED</b> A resistor which supplies two or more different non adjustable resistance values.</p>	<p><b>SWITCH, IGNITION</b> A key operated switch with several positions which allows various circuits, particularly the primary ignition circuit, to become operational.</p> 
 <p><b>RESISTOR, VARIABLE or RHEOSTAT</b> A controllable resistor with a variable rate of resistance. Also called a potentiometer or rheostat.</p>	<p><b>SWITCH, WIPER PARK</b> Automatically returns wipers to the stop position when the wiper switch is turned off.</p> 
 <p><b>SENSOR (Thermistor)</b> A resistor which varies its resistance with temperature.</p>	<p><b>TRANSISTOR</b> A solidstate device typically used as an electronic relay; stops or passes current depending on the voltage applied at "base".</p> 
 <p><b>SENSOR, SPEED</b> Uses magnetic impulses to open and close a switch to create a signal for activation of other components. (Reed Switch Type)</p>	<p><b>WIRES</b></p> <p><b>(1) NOT CONNECTED</b> Wires are always drawn as straight lines on wiring diagrams. Crossed wires (1) without a black dot at the junction are not joined;</p> <p><b>(2) SPLICED</b> crossed wires (2) with a black dot or octagonal mark at the junction are spliced (joined) connections.</p> 
 <p><b>SHORT PIN</b> Used to provide an unbroken connection within a junction block.</p>	
 <p><b>SOLENOID</b> An electromagnetic coil which forms a magnetic field when current flows, to move a plunger, etc.</p>	

# F RELAY LOCATIONS

## [Engine Compartment]




## [Instrument Panel]




② : R/B No.2 Engine Compartment Left (See Page 20)


- \*1 : 50A J/B Fuse (for Medium Current)
- \*2 : 50A HEATER Fuse (for Medium Current)
- \*3 : 30A AM2 Fuse (for Medium Current)
- \*4 : 40A AM1 Fuse (for Medium Current)
- \*5 : HEAD(HI RH) (w/ Daytime Running Light) or HEAD(RH) (w/o Daytime Running Light)
- \*6 : HEAD(HI LH) (w/ Daytime Running Light) or HEAD(LH) (w/o Daytime Running Light)



# F RELAY LOCATIONS


○ : J/B No.1      Lower Finish Panel (See Page 20)





# F RELAY LOCATIONS


## [J/B No.1 Inner Circuit]



(Cont. next page)




(Cont' d)




# F RELAY LOCATIONS

○ : J/B No.3 Behind the Instrument Panel Left (See Page 20)




[J/B No.3 Inner Circuit]




# F RELAY LOCATIONS

○ : J/B No.3 Behind the Instrument Panel Center (See Page 20)




[J/B No.3 Inner Circuit]



# G ELECTRICAL WIRING ROUTING

## Position of Parts in Engine Compartment


[5VZ-FE]



- |  |   |
|--|---|
| A 5 A/C Magnetic Clutch                      | E 2 Electronically Controlled Transmission Solenoid |
| A 7 A/T Oil Temp. Sensor                     | E 3 Engine Coolant Temp. Sensor                     |
| A22 ABS Actuator with ECU                    | F 1 Front ABS Speed Sensor LH                       |
| A23 Air Fuel Ratio Sensor (Bank 1 Sensor 1)  | F 2 Front ABS Speed Sensor RH                       |
| A24 ADD Actuator                             | F 3 Front Turn Signal Light LH                      |
| B 1 Back-Up Light SW                         | F 4 Front Turn Signal Light RH                      |
| B 2 Brake Fluid Level Warning SW             | F 9 Front Airbag Sensor LH                          |
| C 1 Camshaft Position Sensor                 | F 10 Front Airbag Sensor RH                         |
| C 2 Crankshaft Position Sensor               | G 1 Generator                                       |
| C 3 Cruise Control Actuator                  | G 2 Generator                                       |
| D 1 Data Link Connector 1                    | H 1 Headlight LH                                    |
| D 3 Detection SW (Transfer L4 Position)      | H 2 Headlight RH                                    |
| D 4 Detection SW (Transfer Neutral Position) | H 5 Horn (Low)                                      |
| D 5 Detection SW (Transfer 4WD Position)     | H10 Horn (High)                                     |

## Position of Parts in Engine Compartment

### [5VZ-FE]



I 1 Idle Air Control Valve  
 I 2 Igniter  
 I 3 Ignition Coil No.1  
 I 4 Ignition Coil No.2  
 I 5 Ignition Coil No.3  
 I 6 Injector No.1  
 I 7 Injector No.2  
 I 8 Injector No.3  
 I 9 Injector No.4  
 I 10 Injector No.5  
 I 11 Injector No.6

J 9 Junction Connector  
 J 10 Junction Connector

K 2 Knock Sensor 1  
 K 3 Knock Sensor 2

M 1 Mass Air Flow Meter

O 2 Oil Pressure SW

P 1 Park/Neutral Position SW  
 P 2 Parking Light LH  
 P 3 Parking Light RH  
 P10 Power Steering Oil Pressure SW

S 1 Starter  
 S 2 Starter

T 1 Throttle Position Sensor  
 T 2 2-4 Select Motor

V 1 Vehicle Speed Sensor  
 (Electronically Controlled Transmission)  
 V 4 VSV (EVAP)  
 V 8 Vapor Pressure Sensor  
 V 9 VSV (Vapor Pressure Sensor)  
 V10 Vehicle Speed Sensor


W 1 Washer Motor and Washer Level Sensor  
 (Cold Area Spec.) or Washer Motor  
 (Except Cold Area Spec.)

W 2 Water Temp. Sender  
 W 3 Wiper Motor

# G ELECTRICAL WIRING ROUTING

## Position of Parts in Engine Compartment

[3RZ-FE, 2RZ-FE]




- |  |   |
|--|---|
| A 5 A/C Magnetic Clutch                      | E 1 EGR Gas Temp. Sensor                            |
| A 7 A/T Oil Temp. Sensor                     | E 2 Electronically Controlled Transmission Solenoid |
| A22 ABS Actuator with ECU                    | E 3 Engine Coolant Temp. Sensor                     |
| A23 Air Fuel Ratio Sensor (Bank 1 Sensor 1)  | F 1 Front ABS Speed Sensor LH                       |
| A24 ADD Actuator                             | F 2 Front ABS Speed Sensor RH                       |
| B 1 Back-Up Light SW                         | F 3 Front Turn Signal Light LH                      |
| B 2 Brake Fluid Level Warning SW             | F 4 Front Turn Signal Light RH                      |
| C 1 Camshaft Position Sensor                 | F 9 Front Airbag Sensor LH                          |
| C 2 Crankshaft Position Sensor               | F 10 Front Airbag Sensor RH                         |
| C 3 Cruise Control Actuator                  | G 1 Generator                                       |
| D 1 Data Link Connector 1                    | G 2 Generator                                       |
| D 3 Detection SW (Transfer L4 Position)      | H 1 Headlight LH                                    |
| D 4 Detection SW (Transfer Neutral Position) | H 2 Headlight RH                                    |
| D 5 Detection SW (Transfer 4WD Position)     | H 5 Horn (Low)                                      |
|  | H10 Horn (High)                                     |



## Position of Parts in Engine Compartment

### [3RZ-FE, 2RZ-FE]



I 1 Idle Air Control Valve  
 I 6 Injector No.1  
 I 7 Injector No.2  
 I 8 Injector No.3  
 I 9 Injector No.4  
 I 20 Ignition Coil and Igniter No.1  
 I 21 Ignition Coil and Igniter No.2  
 I 22 Ignition Coil and Igniter No.3  
 I 23 Ignition Coil and Igniter No.4

J 9 Junction Connector  
 J 10 Junction Connector

K 1 Knock Sensor

M 1 Mass Air Flow Meter

N 1 Noise Filter (Ignition System)

O 1 O/D Solenoid  
 O 2 Oil Pressure SW

P 1 Park/Neutral Position SW  
 P 2 Parking Light LH  
 P 3 Parking Light RH  
 P10 Power Steering Oil Pressure SW

S 1 Starter  
 S 2 Starter

T 1 Throttle Position Sensor

V 1 Vehicle Speed Sensor  
 (Electronically Controlled Transmission)


V 3 VSV (EGR)  
 V 4 VSV (EVAP)  
 V 8 Vapor Pressure Sensor  
 V 9 VSV (Vapor Pressure Sensor)  
 V10 Vehicle Speed Sensor

W 1 Washer Motor and Washer Level Sensor  
 (Cold Area Spec.) or Washer Motor  
 (Except Cold Area Spec.)

W 2 Water Temp. Sender  
 W 3 Wiper Motor


# G ELECTRICAL WIRING ROUTING

## Position of Parts in Instrument Panel



- |  |  |
|--|--|
| A 9 ABS Deceleration Sensor                        | C10 Combination Meter                    |
| A13 A/C Dual Pressure SW                           | C12 Combination Meter                    |
| A15 A/C Thermistor                                 | C13 Combination Meter                    |
| A18 Airbag Squib (Steering Wheel Pad)              | C14 Combination SW                       |
| A19 Ashtray Illumination                           | C15 Combination SW                       |
| A21 Airbag Squib (Front Passenger Airbag Assembly) | C16 Cruise Control Clutch SW             |
| A25 A/C Control Assembly                           | C17 Cruise Control ECU                   |
| A26 Air Inlet Control Servo Motor                  | C19 Combination SW                       |
| A27 Air Mix Control Servo Motor                    | C20 Center Airbag Sensor Assembly        |
| A28 Air Vent Mode Control Servo Motor              | C21 Center Airbag Sensor Assembly        |
|  | C22 Center Airbag Sensor Assembly        |
| B 4 Blower Motor                                   | D 7 Data Link Connector 3                |
| B 5 Blower Resistor                                | D 8 Daytime Running Light Relay (Main)   |
| C 4 Cigarette Lighter                              | D 9 Daytime Running Light Relay No.4     |
| C 5 Cigarette Lighter Illumination                 | D13 Diode (Daytime Running Light System) |
| C 6 Circuit Opening Relay                          | D15 Door Courtesy SW Front LH            |
| C 7 Clock  | D16 Door Courtesy SW Front RH            |
| C 8 Clutch Start Cancel SW                         | D25 Diode (A/T)                          |
| C 9 Clutch Start SW                                |  |

**Position of Parts in Instrument Panel**




\*1 : 5VZ-FE  
 \*2 : 3RZ-FE, 2RZ-FE  
 \*3 : w/ 2-4 Select SW  
 \*4 : 2RZ-FE A/T

- E 4 Electronically Controlled Transmission Pattern Select SW
- E 5 Engine Control Module
- E 6 Engine Control Module
- E 7 Engine Control Module
- E 8 Engine Control Module
- F 6 4WD ECU
- G 3 Glove Box Light
- H 6 Hazard SW
- H 7 Heater Blower SW
- H 9 Heated Oxygen Sensor (Bank 1 Sensor 2)
- I 14 Ignition SW
- J 1 Junction Connector
- J 11 Junction Connector
- J 13 Junction Connector
- O 6 O/D ECU
- P 4 Parking Brake SW
- P 13 Power Outlet
- P 14 Power Outlet
- P 19 Passenger Airbag Manual On/Off Indicator
- P 20 Passenger Airbag Manual On/Off SW
- R 1 Radio and Player
- R 2 Radio and Player
- R 3 Rheostat
- R 4 Rheostat
- R 15 Rear Diff. Lock SW
- R 16 Rear Diff. Lock ECU
- S 4 Shift Lock Control Relay and O/D Main SW
- S 5 Stop Light SW
- S 10 Short Connector (ADD)
- S 11 Short Connector (ADD)
- T 3 2-4 Select SW
- T 4 Transmission Control Relay
- U 1 Unlock Warning SW and Key Interlock Solenoid

# G ELECTRICAL WIRING ROUTING

## Position of Parts in Body

### [Double Cab]



\*1 : w/ Power Window  
\*2 : w/o Power Window

B 6 Buckle SW LH

D20 Door Lock Control SW RH  
D21 Door Lock Motor, Door Unlock Detection SW and Door Key Lock and Unlock SW Front LH  
D22 Door Lock Motor, Door Unlock Detection SW and Door Key Lock and Unlock SW Front RH  
D26 Door Courtesy SW Rear LH  
D27 Door Courtesy SW Rear RH  
D28 Door Lock Motor Rear LH  
D29 Door Lock Motor Rear RH

F 8 Fuel Pump and Sender

H 8 High Mounted Stop Light

I 16 Interior Light

L 1 License Plate Light LH  
L 2 License Plate Light RH

P 5 Personal Light  
P 6 Power Window Control SW Front RH  
P 7 Power Window Master SW and Door Lock Control SW LH  
P 8 Power Window Motor Front LH

P 9 Power Window Motor Front RH  
P21 Pretensioner LH  
P22 Pretensioner RH  
P25 Power Window Control SW Rear LH  
P26 Power Window Control SW Rear RH  
P27 Power Window Motor Rear LH  
P28 Power Window Motor Rear RH


R 6 Rear Combination Light LH  
R 7 Rear Combination Light RH  
R 8 Remote Control Mirror LH  
R 9 Remote Control Mirror RH  
R10 Remote Control Mirror SW  
R11 Rear ABS Speed Sensor LH  
R12 Rear ABS Speed Sensor RH  
R13 Rear Diff. Lock Detection SW  
R14 Rear Diff. Lock Motor

S 6 Speaker (Front Door LH)  
S 7 Speaker (Front Door RH)  
S 8 Speaker (Rear LH)  
S 9 Speaker (Rear RH)

T 5 Tweeter LH  
T 6 Tweeter RH

## Position of Parts in Body

**[Except Double Cab]**



- \*1 : w/ Power Window
- \*2 : w/o Power Window
- \*3 : Regular Cab
- \*4 : Extra Cab
- \*5 : w/ Personal Light

B 6 Buckle SW LH

D20 Door Lock Control SW RH

D21 Door Lock Motor, Door Unlock Detection SW and Door Key Lock and Unlock SW Front LH

D22 Door Lock Motor, Door Unlock Detection SW and Door Key Lock and Unlock SW Front RH

F 8 Fuel Pump and Sender

H 8 High Mounted Stop Light

I 16 Interior Light

L 1 License Plate Light LH

L 2 License Plate Light RH

P 5 Personal Light

P 6 Power Window Control SW Front RH

P 7 Power Window Master SW and Door Lock Control SW LH

P 8 Power Window Motor Front LH

P 9 Power Window Motor Front RH

P21 Pretensioner LH

P22 Pretensioner RH

R 6 Rear Combination Light LH

R 7 Rear Combination Light RH

R 8 Remote Control Mirror LH

R 9 Remote Control Mirror RH

R10 Remote Control Mirror SW

R11 Rear ABS Speed Sensor LH

R12 Rear ABS Speed Sensor RH

R13 Rear Diff. Lock Detection SW

R14 Rear Diff. Lock Motor

S 6 Speaker (Front Door LH)

S 7 Speaker (Front Door RH)

S 8 Speaker (Rear LH)


S 9 Speaker (Rear RH)

T 5 Tweeter LH

T 6 Tweeter RH

## G ELECTRICAL WIRING ROUTING

### Position of Parts in Seat




- P23 Power Seat Motor (Lumbar Support)
- P24 Power Seat SW (Lumbar Support)




# G ELECTRICAL WIRING ROUTING

□ : Location of Connector Joining Wire Harness and Wire Harness  
 ▽ : Location of Ground Points

[5VZ-FE]




○ : Location of Splice Points





## Connector Joining Wire Harness and Wire Harness




Code	Joining Wire Harness and Wire Harness (Connector Location)
EA1	Engine Room Main Wire and Engine No.2 Wire (Near the Battery)
EB3	Engine Wire and Differential Wire (Front Differential Upper Side)
ED1	Sensor Wire and Engine Wire (Over the Cylinder Head)
EE1	Engine Wire and Sensor Wire (Over the Cylinder Head)
EF1	Cowl Wire and Engine Room Main Wire (Front Right Fender)

# G ELECTRICAL WIRING ROUTING


□ : Location of Connector Joining Wire Harness and Wire Harness

▽ : Location of Ground Points


[3RZ-FE, 2RZ-FE]



○ : Location of Splice Points




## Connector Joining Wire Harness and Wire Harness




Code	Joining Wire Harness and Wire Harness (Connector Location)
EA1	Engine Room Main Wire and Engine No.2 Wire (Near the Battery)
EB3	Engine Wire and Differential Wire (Front Differential Upper Side)
EF1	Cowl Wire and Engine Room Main Wire (Front Right Fender)

# G ELECTRICAL WIRING ROUTING


□ : Location of Connector Joining Wire Harness and Wire Harness  
 ▽ : Location of Ground Points



○ : Location of Splice Points



# Connector Joining Wire Harness and Wire Harness




Code	Joining Wire Harness and Wire Harness (Connector Location)
IF1	
IF2	Engine Room Main Wire and Cowl Wire (Left Kick Panel)
IF3	
IG1	Cowl Wire and Roof Wire (Left Kick Panel)
IH1	
IH2	Front Door LH Wire and Cowl Wire (Left Kick Panel)
IH3	
IK2	
IK3	
IK6	Engine Wire and Cowl Wire (Above the Glove Box)
IK7	
IL1	
IL2	Front Door RH Wire and Cowl Wire (Right Kick Panel)


# G ELECTRICAL WIRING ROUTING

**□** : Location of Connector Joining Wire Harness and Wire Harness


**[Double Cab]**



**○** : Location of Splice Points



## Connector Joining Wire Harness and Wire Harness




Code	Joining Wire Harness and Wire Harness (Connector Location)
BN1	Frame Wire and Cowl Wire (Under the Driver's Seat)
BN6	Frame Wire and Diff. Lock Wire (Rear Side Member LH)
BO1	Rear Door No.2 Wire and Cowl Wire (Under the Left Center Pillar)
BO2	Rear Door No.1 Wire and Cowl Wire (Under the Right Center Pillar)
BQ1	Rear Door No.2 Wire and Cowl Wire (Under the Left Center Pillar)
BQ2	Rear Door No.1 Wire and Cowl Wire (Under the Right Center Pillar)
BR1	Rear Door No.2 Wire and Cowl Wire (Under the Left Center Pillar)
BR2	Rear Door No.1 Wire and Cowl Wire (Under the Right Center Pillar)


# G ELECTRICAL WIRING ROUTING

**□** : Location of Connector Joining Wire Harness and Wire Harness

[Except Double Cab]




**○** : Location of Splice Points






## Connector Joining Wire Harness and Wire Harness




Code	Joining Wire Harness and Wire Harness (Connector Location)
BN1	Frame Wire and Cowl Wire (Under the Driver's Seat)
BN6	Frame Wire and Cowl Wire (Under the Driver's Seat)
BO1	Frame Wire and Diff. Lock Wire (Rear Side Member LH)
BO2	Frame Wire and Diff. Lock Wire (Rear Side Member LH)
BS1	Rear Speaker LH Wire and Cowl Wire (Under the Left Center Pillar)
BT1	Rear Speaker RH Wire and Cowl Wire (Under the Right Center Pillar)

## G ELECTRICAL WIRING ROUTING

□ : Location of Connector Joining Wire Harness and Wire Harness




## Connector Joining Wire Harness and Wire Harness




Code	Joining Wire Harness and Wire Harness (Connector Location)
BU1	Cowl Wire and Seat No.1 Wire (Under the Driver's Seat)

# POWER SOURCE



\* 1 : W/O DAYTIME RUNNING LIGHT  
 \* 2 : W/ DAYTIME RUNNING LIGHT



# POWER SOURCE

## SERVICE HINTS

### HEATER RELAY

1-2 : Closed with ignition SW on and heater blower SW on

### HEAD RELAY

2-1 : Closed with light control SW at **HEAD** position or dimmer SW at **FLASH** position  
 Closed with engine running and parking brake lever released (w/ daytime running light)

### I14 IGNITION SW

2-3 : Closed with ignition key at **ACC** or **ON** position  
 2-4 : Closed with ignition key at **ON** or **ST** position  
 7-6 : Closed with ignition key at **ON** or **ST** position

### TAIL RELAY

5-3 : Closed with light control SW at **TAIL** or **HEAD** position

### DIMMER RELAY

4-3 : Closed with HEAD relay on and dimmer SW at **HIGH** or **FLASH** position

## ○ : PARTS LOCATION

Code	See Page	Code	See Page	Code	See Page
I14	35				

## ○ : RELAY BLOCKS

Code	See Page	Relay Blocks (Relay Block Location)
2	21	R/B No.2 (Engine Compartment Left)

## ○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR


Code	See Page	Junction Block and Wire Harness (Connector Location)
1I	23	Engine Room Main Wire and J/B No.1 (Lower Finish Panel)
1K		

## ○ : SPLICE POINTS


Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
E3	40 (5VZ-FE)	Engine Room Main Wire	E3	42 (3RZ-FE, 2RZ-FE)	Engine Room Main Wire



# STARTING AND IGNITION (5VZ-FE)







# STARTING AND IGNITION (5VZ-FE)

## SERVICE HINTS

### S1 (A), S2 (B) STARTER

Points closed with Park/Neutral position SW at **P** or **N** position and ignition SW at **ST** position (A/T)  
 Points closed with clutch start SW or clutch start cancel SW on and ignition SW at **ST** position (M/T)

### I14 IGNITION SW

7-6 : Closed with ignition SW at **ON** or **ST** position  
 2-1 : Closed with ignition SW at **ST** position

### P1 PARK/NEUTRAL POSITION SW (A/T)

9-6 : Closed with A/T shift lever in **P** or **N** position

### STARTER RELAY

5-3 : Closed with Park/Neutral position SW at **P** or **N** position and ignition SW at **ST** position (A/T)  
 5-3 : Closed with clutch start SW or clutch start cancel SW on and ignition SW at **ST** position (M/T)

### C8 CLUTCH START CANCEL SW (M/T)

1-3 : Closed with ignition SW on and cancel SW on

### C9 CLUTCH START SW (M/T)

1-2 : Closed with clutch pedal fully depressed

## ○ : PARTS LOCATION

Code	See Page	Code	See Page	Code	See Page
C8	34	I4	31 (5VZ-FE)	P1	31 (5VZ-FE)
C9	34	I5	31 (5VZ-FE)	S1	A 31 (5VZ-FE)
E8	35	I14	35	S2	B 31 (5VZ-FE)
I2	31 (5VZ-FE)	J9	A 31 (5VZ-FE)		
I3	31 (5VZ-FE)	J10	B 31 (5VZ-FE)		

## ○ : RELAY BLOCKS

Code	See Page	Relay Blocks (Relay Block Location)
2	21	R/B No.2 (Engine Compartment Left)

## ○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
1F	23	Cowl Wire and J/B No.1 (Lower Finish Panel)
1I	23	Engine Room Main Wire and J/B No.1 (Lower Finish Panel)
3A	24	Cowl Wire and J/B No.3 (Behind the Instrument Panel Left)
3D		
3E		

## □ : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
EA1	40 (5VZ-FE)	Engine Room Main Wire and Engine No.2 Wire (Near the Battery)
IF1	44	Engine Room Main Wire and Cowl Wire (Left Kick Panel)
IK2	44	Engine Wire and Cowl Wire (Above the Glove Box)
IK3		

## ▽ : GROUND POINTS


Code	See Page	Ground Points Location
EA	40 (5VZ-FE)	Front Left Fender
EB	40 (5VZ-FE)	Near the Throttle Body
IE	44	Around the Right Edge of the Reinforcement
IG	44	Around the Left Edge of the Reinforcement




**: SPLICE POINTS**

Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
I8	<a href="#">44</a>	Engine Room Main Wire	I13	<a href="#">44</a>	Engine Wire
I9	<a href="#">44</a>	Cowl Wire			

# STARTING (3RZ-FE, 2RZ-FE)



FROM POWER SOURCE SYSTEM (SEE PAGE 54)



# STARTING (3RZ-FE, 2RZ-FE)

## SERVICE HINTS

### S1 (A), S2 (B) STARTER

Points closed with Park/Neutral position SW at **P** or **N** position and ignition SW at **ST** position (A/T)  
Points closed with clutch start SW or clutch start cancel SW on and ignition SW at **ST** position (M/T)

### I14 IGNITION SW

2-1 : Closed with ignition SW at **ST** position

### P1 (A), (B) PARK/NEUTRAL POSITION SW (A/T)

(A) 9-(A) 6, (B) 6-(B) 5 : Closed with A/T shift lever in **P** or **N** position

### STARTER RELAY

5-3 : Closed with Park/Neutral position SW at **P** or **N** position and ignition SW at **ST** position (A/T)  
5-3 : Closed with clutch start SW or clutch start cancel SW on and ignition SW at **ST** position (M/T)

### C8 CLUTCH START CANCEL SW (M/T)

1-3 : Closed with ignition SW on and cancel SW on

### C9 CLUTCH START SW (M/T)

1-2 : Closed with clutch pedal fully depressed

## ○ : PARTS LOCATION

Code	See Page	Code	See Page	Code	See Page		
C8	34	J9	A	33 (3RZ-FE, 2RZ-FE)	P1	B	33 (2RZ-FE)
C9	34	J10	B	33 (3RZ-FE, 2RZ-FE)	S1	A	33 (3RZ-FE, 2RZ-FE)
I14	35	P1	A	33 (3RZ-FE)	S2	B	33 (3RZ-FE, 2RZ-FE)

## ○ : RELAY BLOCKS

Code	See Page	Relay Blocks (Relay Block Location)
2	21	R/B No.2 (Engine Compartment Left)

## ○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
1F	23	Cowl Wire and J/B No.1 (Lower Finish Panel)
1I	23	Engine Room Main Wire and J/B No.1 (Lower Finish Panel)
3A	24	Cowl Wire and J/B No.3 (Behind the Instrument Panel Left)
3D		
3E		

## □ : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
EA1	42 (3RZ-FE, 2RZ-FE)	Engine Room Main Wire and Engine No.2 Wire (Near the Battery)
IF1	44	Engine Room Main Wire and Cowl Wire (Left Kick Panel)
IK2	44	Engine Wire and Cowl Wire (Above the Glove Box)
IK3		

## ▽ : GROUND POINTS


Code	See Page	Ground Points Location
EA	42 (3RZ-FE, 2RZ-FE)	Front Left Fender
IE	44	Around the Right Edge of the Reinforcement
IG	44	Around the Left Edge of the Reinforcement

## ○ : SPLICE POINTS

Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
I8	44	Engine Room Main Wire	I9	44	Cowl Wire



# IGNITION (3RZ-FE, 2RZ-FE)





**SERVICE HINTS****I14 IGNITION SW**7-6 : Closed with ignition SW at **ON** or **ST** position : **PARTS LOCATION**

Code	See Page	Code	See Page	Code	See Page
E8	<a href="#">35</a>	I21	<a href="#">33 (3RZ-FE, 2RZ-FE)</a>	N1	<a href="#">33 (3RZ-FE, 2RZ-FE)</a>
I14	<a href="#">35</a>	I22	<a href="#">33 (3RZ-FE, 2RZ-FE)</a>		
I20	<a href="#">33 (3RZ-FE, 2RZ-FE)</a>	I23	<a href="#">33 (3RZ-FE, 2RZ-FE)</a>		

 : **RELAY BLOCKS**

Code	See Page	Relay Blocks (Relay Block Location)
2	<a href="#">21</a>	R/B No.2 (Engine Compartment Left)

 : **CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS**

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IF1	<a href="#">44</a>	Engine Room Main Wire and Cowl Wire (Left Kick Panel)
IK2	<a href="#">44</a>	Engine Wire and Cowl Wire (Above the Glove Box)

 : **GROUND POINTS**


Code	See Page	Ground Points Location
EB	<a href="#">42 (3RZ-FE, 2RZ-FE)</a>	Under the Data Link Connector 1
EF	<a href="#">42 (3RZ-FE, 2RZ-FE)</a>	Ignition Coil Bracket

 : **SPLICE POINTS**

Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
I13	<a href="#">44</a>	Engine Wire			

# CHARGING

\* 1 : W/ DAYTIME RUNNING LIGHT  
 \* 2 : W/O DAYTIME RUNNING LIGHT



**SERVICE HINTS****G2 (B) GENERATOR**

- (B) 3-GROUND : **13.9- 15.1** volts with engine running at **2000** rpm and **25° C (77° F)**  
**13.5- 14.3** volts with engine running at **2000** rpm and **115° C (239° F)**  
 (B) 1-GROUND : **0- 4** volts with ignition SW at **ON** position and engine not running

**○ : PARTS LOCATION**

Code		See Page	Code		See Page	Code	See Page
C13		34	G2	B	30 (5VZ-FE)	J9	33 (3RZ-FE, 2RZ-FE)
G1	A	30 (5VZ-FE)			32 (3RZ-FE, 2RZ-FE)		
		32 (3RZ-FE, 2RZ-FE)	J9	31 (5VZ-FE)			

**○ : RELAY BLOCKS**

Code	See Page	Relay Blocks (Relay Block Location)
2	21	R/B No.2 (Engine Compartment Left)


**○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR**


Code	See Page	Junction Block and Wire Harness (Connector Location)
1C	23	Cowl Wire and J/B No.1 (Lower Finish Panel)
1E	23	Engine Room Main Wire and J/B No.1 (Lower Finish Panel)
1F	23	Cowl Wire and J/B No.1 (Lower Finish Panel)
1K	23	Engine Room Main Wire and J/B No.1 (Lower Finish Panel)

**□ : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS**


Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
EA1	40 (5VZ-FE)	Engine Room Main Wire and Engine No.2 Wire (Near the Battery)
	42 (3RZ-FE,2RZ-FE)	
IF1	44	Engine Room Main Wire and Cowl Wire (Left Kick Panel)

# ENGINE CONTROL (5VZ-FE)






# ENGINE CONTROL (5VZ-FE)



FROM POWER SOURCE SYSTEM (SEE PAGE 54)



- \* 1 : 4WD
- \* 2 : W/ TACHOMETER
- \* 3 : W/O TACHOMETER
- \* 4 : 4WD W/ 2-4 SELECT SW
- \* 5 : 4WD W/O 2-4 SELECT SW

# ENGINE CONTROL (5VZ-FE)

## SYSTEM OUTLINE

The engine control system utilizes a microcomputer and maintains overall control of the engine, transmission, etc. An outline of engine control is given here.

### 1. INPUT SIGNAL

(1) Engine coolant temp. signal system

The engine coolant temp. sensor detects the engine coolant temp. and has a built-in thermistor with a resistance which varies according to the water temp. Thus the engine coolant temp. is input in the form of a control signal to TERMINAL THW of the engine control module.

(2) Intake air temp. signal system

The intake air temp. sensor is installed inside the mass air flow meter and detects the intake air temp., which is input as a control signal to TERMINAL THA of the engine control module.

(3) Heated oxygen sensor signal system

The oxygen density in the exhaust emissions is detected and input as a control signal to TERMINAL OXS of the engine control module. To maintain stable detection performance by the heated oxygen sensor, a heater is used for warming the sensor. The heater is also controlled by the engine control module (HTS).

(4) RPM signal system

Camshaft position and crankshaft position are detected by the camshaft position sensor and crankshaft position sensor, camshaft position is input as a control signal to TERMINAL G2 of the engine control module, and engine RPM is input to TERMINAL NE+.

(5) Throttle signal system

The throttle position sensor detects the throttle valve opening angle, which is input as a control signal to TERMINAL VTA of the engine control module.

(6) Vehicle speed signal system

The vehicle speed sensor detects the vehicle speed and inputs a control signal to TERMINAL SP1 of the engine control module via the combination meter.

(7) A/C SW signal system

The operating voltage of the A/C magnetic clutch is detected and input in the form of a control signal to TERMINAL AC1 of the engine control module.

(8) Battery signal system

Voltage is constantly applied to TERMINAL BATT of the engine control module. When the ignition SW is turned to on, voltage for engine control module operation is applied via the EFI relay to TERMINAL +B of the engine control module.

(9) Intake air volume signal system

Intake air volume is detected by the mass air flow meter and a signal is input into TERMINAL VG of the engine control module as a control signal.

(10) Stop light SW signal system

The stop light SW is used to detect whether or not the vehicle is braking and the information is input as a control signal to TERMINAL STP of the engine control module.

(11) Starter signal system

To confirm that the engine is cranking, the voltage applied to the starter motor during cranking is detected and is input as a control signal to TERMINAL STA of the engine control module.

(12) Engine knock signal system

Engine knocking is detected by the knock sensor 1 and 2 and the signals are input to TERMINALS KNK1 and KNK2 of the engine control module.

(13) 4WD signal system

Whether or not the vehicle is operating in 4WD mode is determined, and a control signal is input to TERMINAL 4WD of the engine control module.

(14) Air fuel ratio signal system

The air fuel ratio is detected and input as a control signal into TERMINAL AF1+ of the engine control module.



## **2. CONTROL SYSTEM**

### **\* SFI system**

The SFI system monitors the engine conditions through the signals (Input signals (1 to 13) ) input from each sensor to the engine control module. Based on this data and the program memorized in the engine control module, the most appropriate fuel injection timing is decided and current is output to TERMINALS #10, #20, #30, #40, #50 and #60 of the engine control module, causing the injectors to operate (to inject fuel). It is this system which, through the work of the engine control module, finely controls fuel injection in response to driving conditions.

### **\* Electronic Spark Advance system**

The ESA system monitors the engine conditions using the signals (input signals (1, 4, 5 to 7, 9, 11, 12) ) input to the engine control module from each sensor. Based on this data and the program memorized in the engine control module, the most appropriate ignition timing is decided and current is output to TERMINALS IGT1, IGT2 and IGT3 of the engine control module. This output controls the igniter to produce the most appropriate ignition timing for the driving conditions.

### **\* Heated oxygen sensor heater control system**

The heated oxygen sensor heater control system turns the heater to on when the intake air volume is low (Temp. of exhaust emissions low), and warms up the heated oxygen sensor to improve detection performance of the sensor. The engine control module evaluates the signals (Input signals (1, 4, 8, 9, 11) ) from each sensor, current is output to TERMINAL HTS and controls the heater.

## **3. DIAGNOSIS SYSTEM**

With the diagnosis system, when there is a malfunction in the ECU signal system, the malfunctioning system is recorded in the memory. The malfunctioning system can then be found by reading the display (Code) of the malfunction indicator lamp.

## **4. FAIL-SAFE SYSTEM**

When a malfunction occurs in any system, if there is a possibility of engine trouble being caused by continued control based on the signals from that system, the fail-safe system either controls the system by using data (Standard values) recorded in the engine control module memory or else stops the engine.

# ENGINE CONTROL (5VZ-FE)

## SERVICE HINTS

### EFI RELAY

5-3 : Closed with ignition SW at **ON** or **ST** position

### C6 CIRCUIT OPENING RELAY

5-3 : Closed with starter running or ignition SW at **ON** or **ST** position

### I6, I7, I8, I9, I10, I11 INJECTOR

1-2 : **13.4- 14.2** Ω

### T1 THROTTLE POSITION SENSOR

2-1 : **4- 9** kΩ

### E3 ENGINE COOLANT TEMP. SENSOR

1-2 : **10- 20** kΩ (-20 °C, -4 °F)

**4- 7** kΩ (0 °C, 32 °F)

**2- 3** kΩ (20 °C, 68 °F)

**0.9- 1.3** kΩ (40 °C, 104 °F)

**0.4- 0.7** kΩ (60 °C, 140 °F)

**0.2- 0.4** kΩ (80 °C, 176 °F)

### E5 (A), E6 (B), E7 (C), E8 (D) ENGINE CONTROL MODULE

Voltage at engine control module wiring connectors

+B-E1 : **9- 14** volts (Ignition SW on)

BATT-E1 : **9- 14** volts (Always)

VC-E2 : **4.5- 5.5** volts (Ignition SW on )

VTA-E2 : **0.3- 0.8** volts (Ignition SW on and throttle valve fully closed)

**3.2- 4.9** volts (Ignition SW on and throttle valve fully open)

STA-E1 : **6** volts or more (Ignition SW at **ST** position)

W-E1 : **9- 14** volts (No trouble and engine running)

THA-E2 : **0.5- 3.4** volts (Ignition SW on and intake air temp. **20 °C, 68 °F**)

THW-E2 : **0.2- 1.0** volts (Ignition SW on and coolant temp. **80 °C, 176 °F**)

SP1-E1 : Pulse generation with vehicle moving

STP-E1 : **7.5- 14** volts (Stop light SW on)

IGT1, IGT2, IGT3-E1 : Pulse generation (Cranking or idling)

#10, #20, #30, #40, #50, #60-E1 : **9- 14** volts (Ignition SW on)

### RESISTANCE AT ECU WIRING CONNECTOR

(Disconnect wiring connector)

VTA-E2 : **3.3- 10** kΩ (Throttle valve fully open)

**0.2- 0.8** kΩ (Throttle valve fully closed)

THA-E2 : **2- 3** kΩ (Intake air temp. **20 °C, 68 °F**)

THW-E2 : **0.2- 0.4** KΩ (Coolant temp. **80 °C, 178 °F**)

+B-E1 : **0.2- 0.4** kΩ

NE+ -E1 : **140- 180** Ω

## ○ : PARTS LOCATION

Code	See Page	Code	See Page	Code	See Page
A23	<a href="#">30 (5VZ-FE)</a>	F8	<a href="#">36 (Double Cab)</a>	J11	<a href="#">35</a>
A25	<a href="#">34</a>		<a href="#">37 (Except Double Cab)</a>	K2	<a href="#">31 (5VZ-FE)</a>
C1	<a href="#">30 (5VZ-FE)</a>	H9	<a href="#">35</a>	K3	<a href="#">31 (5VZ-FE)</a>
C2	<a href="#">30 (5VZ-FE)</a>	I1	<a href="#">31 (5VZ-FE)</a>	M1	<a href="#">31 (5VZ-FE)</a>
C6	<a href="#">34</a>	I2	<a href="#">31 (5VZ-FE)</a>	P1	<a href="#">31 (5VZ-FE)</a>
C9	<a href="#">34</a>	I6	<a href="#">31 (5VZ-FE)</a>	P10	<a href="#">31 (5VZ-FE)</a>
C10	<a href="#">34</a>	I7	<a href="#">31 (5VZ-FE)</a>	S5	<a href="#">35</a>
D1	<a href="#">30 (5VZ-FE)</a>	I8	<a href="#">31 (5VZ-FE)</a>	T1	<a href="#">31 (5VZ-FE)</a>
D7	<a href="#">34</a>	I9	<a href="#">31 (5VZ-FE)</a>	V4	<a href="#">31 (5VZ-FE)</a>
E3	<a href="#">30 (5VZ-FE)</a>	I10	<a href="#">31 (5VZ-FE)</a>	V8	<a href="#">31 (5VZ-FE)</a>
E5	A <a href="#">35</a>	I11	<a href="#">31 (5VZ-FE)</a>	V9	<a href="#">31 (5VZ-FE)</a>
E6	B <a href="#">35</a>	I14	<a href="#">35</a>	V10	<a href="#">31 (5VZ-FE)</a>
E7	C <a href="#">35</a>	J9	A <a href="#">31 (5VZ-FE)</a>		
E8	D <a href="#">35</a>	J10	B <a href="#">31 (5VZ-FE)</a>		

 : RELAY BLOCKS

Code	See Page	Relay Blocks (Relay Block Location)
2	21	R/B No.2 (Engine Compartment Left)

 : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
1F	23	Cowl Wire and J/B No.1 (Lower Finish Panel)
1I	23	Engine Room Main Wire and J/B No.1 (Lower Finish Panel)
3A	24	Cowl Wire and J/B No.3 (Behind the Instrument Panel Left)
3B		
3D		
3E		
3F		

 : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
ED1	40 (5VZ-FE)	Sensor Wire and Engine Wire (Over the Cylinder Head)
EE1	40 (5VZ-FE)	Engine Wire and Sensor Wire (Over the Cylinder Head)
IF1	44	Engine Room Main Wire and Cowl Wire (Left Kick Panel)
IK2	44	Engine Wire and Cowl Wire (Above the Glove Box)
IK3		
IK6		
BN1	46 (Double Cab) 48 (Except Double Cab)	Frame Wire and Cowl Wire (Under the Driver's Seat)


 : GROUND POINTS


Code	See Page	Ground Points Location
EA	40 (5VZ-FE)	Front Left Fender
EB	40 (5VZ-FE)	Near the Throttle Body
ID	44	Left Kick Panel
IE	44	Around the Right Edge of the Reinforcement
IG	44	Around the Left Edge of the Reinforcement

 : SPLICE POINTS


Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
E1	40 (5VZ-FE)	Sensor Wire	I13	44	Engine Wire
E2	40 (5VZ-FE)	Engine Wire	I14	44	Cowl Wire
I3	44	Cowl Wire	I15		


# ENGINE CONTROL (3RZ-FE)





# ENGINE CONTROL (3RZ-FE)





# ENGINE CONTROL (3RZ-FE)

## SYSTEM OUTLINE

The engine control system utilizes a microcomputer and maintains overall control of the engine, transmission, etc. An outline of engine control is given here.

### 1. INPUT SIGNAL

(1) Engine coolant temp. signal system

The engine coolant temp. sensor detects the engine coolant temp. and has a built-in thermistor with a resistance which varies according to the water temp. Thus the engine coolant temp. is input in the form of a control signal to TERMINAL THW of the engine control module.

(2) Intake air temp. signal system

The intake air temp. sensor is installed inside the mass air flow meter and detects the intake air temp., which is input as a control signal to TERMINAL THA of the engine control module.

(3) Heated oxygen sensor signal system

The oxygen density in exhaust emissions is detected and input as a control signal to TERMINAL OXS of the engine control module. To maintain stable detection performance by the heated oxygen sensor, a heater is used for warming the sensor. The heater is also controlled by the engine control module (HTS).

(4) RPM signal system

Camshaft position and crankshaft position are detected by the camshaft position sensor and crankshaft position sensor, camshaft position is input as a control signal to TERMINAL G2+ of the engine control module, and engine RPM is input to TERMINAL NE+.

(5) Throttle signal system

The throttle position sensor detects the throttle valve opening angle, which is input as a control signal to TERMINAL VTA of the engine control module.

(6) Vehicle speed signal system

The vehicle speed sensor detects the vehicle speed and inputs a control signal to TERMINAL SP1 of the engine control module via the combination meter.

(7) A/C SW signal system

The operating voltage of the A/C magnetic clutch is detected and input in the form of a control signal to TERMINAL AC1 of the engine control module.

(8) Battery signal system

Voltage is constantly applied to TERMINAL BATT of the engine control module. When the ignition SW is turned to on, voltage for engine control module operation is applied via the EFI relay to TERMINAL +B of the engine control module.

(9) Intake air volume signal system

Intake air volume is detected by the mass air flow meter and a signal is input into TERMINAL VG of the engine control module as a control signal.

(10) Stop light SW signal system

The stop light SW is used to detect whether or not the vehicle is braking and the information is input as a control signal to TERMINAL STP of the engine control module.

(11) Starter signal system

To confirm that the engine is cranking, the voltage applied to the starter motor during cranking is detected and is input as a control signal to TERMINAL STA of the engine control module.

(12) Engine knock signal system

Engine knocking is detected by the knock sensor and input as a control signal to TERMINAL KNK of the engine control module.

(13) 4WD signal system

Whether or not the vehicle is operating in 4WD mode is determined, and a control signal is input to TERMINAL 4WD of the engine control module.

(14) Air fuel ratio signal system

The air fuel ratio is detected and input as a control signal into TERMINAL AF+ of the engine control module.



## **2. CONTROL SYSTEM**

### **\* SFI system**

The SFI system monitors the engine conditions through the signals (Input signals (1 to 13) ) input from each sensor to the engine control module. Based on this data and the program memorized in the engine control module, the most appropriate fuel injection timing is decided and current is output to TERMINALS #10, #20, #30 and #40 of the engine control module, causing the injectors to operate (to inject fuel). It is this system which, through the work of the engine control module, finely controls fuel injection in response to driving conditions.

### **\* Electronic spark advance system**

The ESA system monitors the engine conditions using the signals (input signals (1, 4, 5 to 7, 9, 11, 12) ) input to the engine control module from each sensor. Based on this data and the program memorized in the engine control module, the most appropriate ignition timing is decided and current is output to TERMINALS IGT1, IGT2, IGT3 and IGT4 of the engine control module. This output controls the igniter to produce the most appropriate ignition timing for the driving conditions.

### **\* Heated oxygen sensor heater control system**

The heated oxygen sensor heater control system turns the heater to on when the intake air volume is low (Temp. of exhaust emissions low), and warms up the heated oxygen sensor to improve detection performance of the sensor. The engine control module evaluates the signals (Input signals (1, 4, 8, 9, 11) ) from each sensor, current is output to TERMINAL HTS and controls the heater.

## **3. DIAGNOSIS SYSTEM**

With the diagnosis system, when there is a malfunction in the ECU signal system, the malfunctioning system is recorded in the memory. The malfunctioning system can then be found by reading the display (Code) of the malfunction indicator lamp.

## **4. FAIL-SAFE SYSTEM**

When a malfunction occurs in any system, if there is a possibility of engine trouble being caused by continued control based on the signals from that system, the fail-safe system either controls the system by using data (Standard values) recorded in the engine control module memory or else stops the engine.

# ENGINE CONTROL (3RZ-FE)

## SERVICE HINTS

### EFI RELAY

5-3 : Closed with ignition SW at **ON** or **ST** position

### C6 CIRCUIT OPENING RELAY

5-3 : Closed with starter running or ignition SW at **ON** or **ST** position

### I6, I7, I8, I9 INJECTOR

1-2 : **13.4- 14.2** Ω

### T1 THROTTLE POSITION SENSOR

2-1 : **4- 9** kΩ

### E3 ENGINE COOLANT TEMP. SENSOR

1-2 : **10- 20** kΩ (-20 °C, -4 °F)

**4- 7** kΩ (0 °C, 32 °F)

**2- 3** kΩ (20 °C, 68 °F)

**0.9- 1.3** kΩ (40 °C, 104 °F)

**0.4- 0.7** kΩ (60 °C, 140 °F)

**0.2- 0.4** kΩ (80 °C, 176 °F)

### E5 (A), E6 (B), E7 (C), E8 (D) ENGINE CONTROL MODULE

Voltage at engine control module wiring connectors

+B-E1 : **9- 14** volts (Ignition SW on)

BATT-E1 : **9- 14** volts (Always)

VC-E2 : **4.5- 5.5** volts (Ignition SW on )

VTA-E2 : **0.3- 0.8** volts (Ignition SW on and throttle valve fully closed)

**3.2- 4.9** volts (Ignition SW on and throttle valve fully open)

STA-E1 : **6** volts or more (Ignition SW at **ST** position)

W-E1 : **9- 14** volts (No trouble and engine running)

THA-E2 : **0.5- 3.4** volts (Ignition SW on and intake air temp. **20 °C, 68 °F**)

THW-E2 : **0.2- 1.0** volts (Ignition SW on and coolant temp. **80 °C, 176 °F**)

SP1-E1 : Pulse generation with vehicle moving

STP-E1 : **7.5- 14** Volts (Stop light SW on)

### RESISTANCE AT ECU WIRING CONNECTOR

(Disconnect wiring connector)

VTA-E2 : **3.3- 10** kΩ (Throttle valve fully open)

**0.2- 0.8** kΩ (Throttle valve fully closed)

THA-E2 : **2- 3** kΩ (Intake air temp. **20 °C, 68 °F**)

THW-E2 : **0.2- 0.4** kΩ (Coolant temp. **80 °C, 178 °F**)

+B-E1 : **0.2- 0.4** kΩ

NE+-E1 : **140- 180** Ω

## ○ : PARTS LOCATION

Code	See Page	Code	See Page	Code	See Page
A23	<a href="#">32 (3RZ-FE)</a>	E8   D	<a href="#">35</a>	J9   A	<a href="#">33 (3RZ-FE)</a>
A25	<a href="#">34</a>	F8	<a href="#">36 (Double Cab)</a>	J10   B	<a href="#">33 (3RZ-FE)</a>
C1	<a href="#">32 (3RZ-FE)</a>		<a href="#">37 (Except Double Cab)</a>	J11	<a href="#">35</a>
C2	<a href="#">32 (3RZ-FE)</a>	H9	<a href="#">35</a>	K1	<a href="#">33 (3RZ-FE)</a>
C6	<a href="#">34</a>	I1	<a href="#">33 (3RZ-FE)</a>	M1	<a href="#">33 (3RZ-FE)</a>
C9	<a href="#">34</a>	I6	<a href="#">33 (3RZ-FE)</a>	P1	<a href="#">33 (3RZ-FE)</a>
C10	<a href="#">34</a>	I7	<a href="#">33 (3RZ-FE)</a>	P10	<a href="#">33 (3RZ-FE)</a>
D1	<a href="#">32 (3RZ-FE)</a>	I8	<a href="#">33 (3RZ-FE)</a>	S5	<a href="#">35</a>
D7	<a href="#">34</a>	I9	<a href="#">33 (3RZ-FE)</a>	T1	<a href="#">33 (3RZ-FE)</a>
E1	<a href="#">32 (3RZ-FE)</a>	I14	<a href="#">35</a>	V3	<a href="#">33 (3RZ-FE)</a>
E3	<a href="#">32 (3RZ-FE)</a>	I20	<a href="#">33 (3RZ-FE)</a>	V4	<a href="#">33 (3RZ-FE)</a>
E5   A	<a href="#">35</a>	I21	<a href="#">33 (3RZ-FE)</a>	V8	<a href="#">33 (3RZ-FE)</a>
E6   B	<a href="#">35</a>	I22	<a href="#">33 (3RZ-FE)</a>	V9	<a href="#">33 (3RZ-FE)</a>
E7   C	<a href="#">35</a>	I23	<a href="#">33 (3RZ-FE)</a>	V10	<a href="#">33 (3RZ-FE)</a>

 : RELAY BLOCKS

Code	See Page	Relay Blocks (Relay Block Location)
2	21	R/B No.2 (Engine Compartment Left)

 : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
1E	23	Engine Room Main Wire and J/B No.1 (Lower Finish Panel)
1F	23	Cowl Wire and J/B No.1 (Lower Finish Panel)
1I	23	Engine Room Main Wire and J/B No.1 (Lower Finish Panel)
3A	24	Cowl Wire and J/B No.3 (Behind the Instrument Panel Left)
3B		
3C		
3D		
3E		
3F		

 : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IF1	44	Engine Room Main Wire and Cowl Wire (Left Kick Panel)
IK2	44	Engine Wire and Cowl Wire (Above the Glove Box)
IK3		
IK7		
BN1	46 (Double Cab) 48 (Except Double Cab)	Frame Wire and Cowl Wire (Under the Driver's Seat)


 : GROUND POINTS


Code	See Page	Ground Points Location
EA	42 (3RZ-FE)	Front Left Fender
EF	42 (3RZ-FE)	Ignition Coil Bracket
ID	44	Left Kick Panel
IE	44	Around the Right Edge of the Reinforcement
IG	44	Around the Left Edge of the Reinforcement

 : SPLICE POINTS

Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
E4	42 (3RZ-FE)	Engine Wire	I14	44	Cowl Wire
I3	44	Cowl Wire	I15		
I13	44	Engine Wire			


# ENGINE CONTROL (2RZ-FE)






# ENGINE CONTROL (2RZ-FE)

FROM POWER SOURCE SYSTEM (SEE PAGE 54)



\* 1 : W/ TACHOMETER  
 \* 2 : W/O TACHOMETER



# ENGINE CONTROL (2RZ-FE)

## SYSTEM OUTLINE

The engine control system utilizes a microcomputer and maintains overall control of the engine, transmission, etc. An outline of engine control is given here.

### 1. INPUT SIGNAL

#### (1) Engine coolant temp. signal system

The engine coolant temp. sensor detects the engine coolant temp. and has a built-in thermistor with a resistance which varies according to the water temp. Thus the engine coolant temp. is input in the form of a control signal to TERMINAL THW of the engine control module.

#### (2) Intake air temp. signal system

The intake air temp. sensor is installed inside the mass air flow meter and detects the intake air temp., which is input as a control signal to TERMINAL THA of the engine control module.

#### (3) Heated oxygen sensor signal system

The oxygen density in the exhaust emissions is detected and input as a control signal to TERMINAL OXS of the engine control module. To maintain stable detection performance by the heated oxygen sensor, a heater is used for warming the sensor. The heater is also controlled by the engine control module (HTS).

#### (4) RPM signal system

Camshaft position and crankshaft position are detected by the camshaft position sensor and crankshaft position sensor, camshaft position is input as a control signal to TERMINAL G2+ of the engine control module, and engine RPM is input to TERMINAL NE-.

#### (5) Throttle signal system

The throttle position sensor detects the throttle valve opening angle, which is input as a control signal to TERMINAL VTA of the engine control module.

#### (6) Vehicle speed signal system

The vehicle speed sensor detects the vehicle speed and inputs a control signal to TERMINAL SP1 of the engine control module via the combination meter.

#### (7) A/C SW signal system

The operating voltage of the A/C magnetic clutch is detected and input in the form of a control signal to TERMINAL AC1 of the engine control module.

#### (8) Battery signal system

Voltage is constantly applied to TERMINAL BATT of the engine control module. When the ignition SW is turned to on, voltage for engine control module operation is applied via the EFI relay to TERMINAL +B of the engine control module.

#### (9) Intake air volume signal system

Intake air volume is detected by the mass air flow meter and a signal is input into TERMINAL VG of the engine control module as a control signal.

#### (10) Stop light SW signal system

The stop light SW is used to detect whether or not the vehicle is braking and the information is input as a control signal to TERMINAL STP of the engine control module.

#### (11) Starter signal system

To confirm that the engine is cranking, the voltage applied to the starter motor during cranking is detected and is input as a control signal to TERMINAL STA of the engine control module.

#### (12) Engine knock signal system

Engine knocking is detected by the knock sensor and input as a control signal to TERMINAL KNK of the engine control module.

#### (13) Air fuel ratio signal system

The air fuel ratio is detected and input as a control signal into TERMINAL AF+ of the engine control module.



## **2. CONTROL SYSTEM**

### **\* SFI system**

The SFI system monitors the engine conditions through the signals (Input signals (1 to 12) ) input from each sensor to the engine control module. Based on this data and the program memorized in the engine control module, the most appropriate fuel injection timing is decided and current is output to TERMINALS #10, #20, #30 and #40 of the engine control module, causing the injectors to operate (to inject fuel). It is this system which, through the work of the engine control module, finely controls fuel injection in response to driving conditions.

### **\* Electronic spark advance system**

The ESA system monitors the engine conditions using the signals (input signals (1, 4, 5 to 7, 9, 11, 12) ) input to the engine control module from each sensor. Based on this data and the program memorized in the engine control module, the most appropriate ignition timing is decided and current is output to TERMINALS IGT1, IGT2, IGT3 and IGT4 of the engine control module. This output controls the igniter to produce the most appropriate ignition timing for the driving conditions.

### **\* Heated oxygen sensor heater control system**

The heated oxygen sensor heater control system turns the heater to on when the intake air volume is low (Temp. of exhaust emissions low), and warms up the heated oxygen sensor to improve detection performance of the sensor. The engine control module evaluates the signals (Input signals (1, 4, 8, 9, 11) ) from each sensor, current is output to TERMINAL HTS and controls the heater.

## **3. DIAGNOSIS SYSTEM**

With the diagnosis system, when there is a malfunction in the ECU signal system, the malfunctioning system is recorded in the memory. The malfunctioning system can then be found by reading the display (Code) of the malfunction indicator lamp.

## **4. FAIL-SAFE SYSTEM**

When a malfunction occurs in any system, if there is a possibility of engine trouble being caused by continued control based on the signals from that system, the fail-safe system either controls the system by using data (Standard values) recorded in the engine control module memory or else stops the engine.

# ENGINE CONTROL (2RZ-FE)

## SERVICE HINTS

### EFI RELAY

5-3 : Closed with ignition SW at **ON** or **ST** position

### C6 CIRCUIT OPENING RELAY

5-3 : Closed with starter running or ignition SW at **ON** or **ST** position

### I6, I7, I8, I9 INJECTOR

1-2 : **13.4- 14.2** Ω

### T1 THROTTLE POSITION SENSOR

2-1 : **4- 9** kΩ

### E3 ENGINE COOLANT TEMP. SENSOR

1-2 : **10- 20** kΩ (**-20 °C, -4 °F**)

**4- 7** kΩ (**0 °C, 32 °F**)

**2- 3** kΩ (**20 °C, 68 °F**)

**0.9- 1.3** kΩ (**40 °C, 104 °F**)

**0.4- 0.7** kΩ (**60 °C, 140 °F**)

**0.2- 0.4** kΩ (**80 °C, 176 °F**)

### E5 (A), E6 (B), E7 (C), E8 (D) ENGINE CONTROL MODULE

Voltage at engine control module wiring connectors

+B-E1 : **9- 14** volts (Ignition SW on)

BATT-E1 : **9- 14** volts (Always)

VC-E2 : **4.5- 5.5** volts (Ignition SW on )

VTA-E2 **0.3- 0.8** volts (Ignition SW on and throttle valve fully closed)

**3.2- 4.9** volts (Ignition SW on and throttle valve fully open)

STA-E1 : **6** volts or more (Ignition SW at **ST** position)

W-E1 : **9- 14** volts (No trouble and engine running)

THA-E2 : **0.5- 3.4** volts (Ignition SW on and intake air temp. **20 °C, 68 °F**)

THW-E2 : **0.2- 1.0** volts (Ignition SW on and coolant temp. **80 °C, 176 °F**)

SP1-E1 : Plus generation with vehicle moving

STP-E1 : **7.5- 14** volts (Stop light SW on)

IGT1, IGT2-E1 : Plus generator (Cranking or idling)

#10, #20, #30, #40-E1 : **9- 14** volts (Ignition SW on)

### RESISTANCE AT ECU WIRING CONNECTOR

(Disconnect wiring connector)

VTA-E2 : **3.3- 10** kΩ (Throttle valve fully open)

**0.2- 0.8** kΩ (Throttle valve fully closed)

THA-E2 : **2- 3** kΩ (Intake air temp. **20 °C, 68 °F**)

THW-E2 : **0.2- 0.4** kΩ (Coolant temp. **80 °C, 178 °F**)

+B-E1 : **0.2- 0.4** kΩ

NE+-E1 : **140- 180** Ω

## ○ : PARTS LOCATION

Code	See Page	Code	See Page	Code	See Page
A23	<a href="#">32 (2RZ-FE)</a>	E8   D	<a href="#">35</a>	J9   A	<a href="#">33 (2RZ-FE)</a>
A25	<a href="#">34</a>	F8	<a href="#">37 (Except Double Cab)</a>	J10   B	<a href="#">33 (2RZ-FE)</a>
C1	<a href="#">32 (2RZ-FE)</a>	H9	<a href="#">35</a>	J11	<a href="#">35</a>
C2	<a href="#">32 (2RZ-FE)</a>	I1	<a href="#">33 (2RZ-FE)</a>	K1	<a href="#">33 (2RZ-FE)</a>
C6	<a href="#">34</a>	I6	<a href="#">33 (2RZ-FE)</a>	M1	<a href="#">33 (2RZ-FE)</a>
C9	<a href="#">34</a>	I7	<a href="#">33 (2RZ-FE)</a>	P1	<a href="#">33 (2RZ-FE)</a>
C10	<a href="#">34</a>	I8	<a href="#">33 (2RZ-FE)</a>	P10	<a href="#">33 (2RZ-FE)</a>
D1	<a href="#">32 (2RZ-FE)</a>	I9	<a href="#">33 (2RZ-FE)</a>	S5	<a href="#">35</a>
D7	<a href="#">34</a>	I14	<a href="#">35</a>	T1	<a href="#">33 (2RZ-FE)</a>
E3	<a href="#">32 (2RZ-FE)</a>	I20	<a href="#">33 (2RZ-FE)</a>	V4	<a href="#">33 (2RZ-FE)</a>
E5   A	<a href="#">35</a>	I21	<a href="#">33 (2RZ-FE)</a>	V8	<a href="#">33 (2RZ-FE)</a>
E6   B	<a href="#">35</a>	I22	<a href="#">33 (2RZ-FE)</a>	V9	<a href="#">33 (2RZ-FE)</a>
E7   C	<a href="#">35</a>	I23	<a href="#">33 (2RZ-FE)</a>	V10	<a href="#">33 (2RZ-FE)</a>

 : RELAY BLOCKS

Code	See Page	Relay Blocks (Relay Block Location)
2	21	R/B No.2 (Engine Compartment Left)

 : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
1E	23	Engine Room Main Wire and J/B No.1 (Lower Finish Panel)
1F	23	Cowl Wire and J/B No.1 (Lower Finish Panel)
1I	23	Engine Room Main Wire and J/B No.1 (Lower Finish Panel)
3A	24	Cowl Wire and J/B No.3 (Behind the Instrument Panel Left)
3B		
3C		
3D		
3E		
3F		

 : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IF1	44	Engine Room Main Wire and Cowl Wire (Left Kick Panel)
IK2	44	Engine Wire and Cowl Wire (Above the Glove Box)
IK3		
IK7		
BN1	48 (Except Double Cab)	Frame Wire and Cowl Wire (Under the Driver's Seat)


 : GROUND POINTS

Code	See Page	Ground Points Location
EA	42 (2RZ-FE)	Front Left Fender
EF	42 (2RZ-FE)	Ignition Coil Bracket
ID	44	Left Kick Panel
IE	44	Around the Right Edge of the Reinforcement
IG	44	Around the Left Edge of the Reinforcement

 : SPLICE POINTS

Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
E4	42 (2RZ-FE)	Engine Wire	I14	44	Cowl Wire
I3	44	Cowl Wire	I15		
I13	44	Engine Wire			

# HEADLIGHT (w/o DAYTIME RUNNING LIGHT)



## SERVICE HINTS

### HEAD RELAY

2-1 : Closed with light control SW at **HEAD** position or dimmer SW at **FLASH** position

### ○ : PARTS LOCATION

Code	See Page	Code	See Page	Code	See Page
C12	34	H2	30 (5VZ-FE)	J10	B
C14	34		32 (3RZ-FE, 2RZ-FE)		
H1	30 (5VZ-FE)	J9	A		
	32 (3RZ-FE, 2RZ-FE)				

### ○ : RELAY BLOCKS

Code	See Page	Relay Blocks (Relay Block Location)
2	21	R/B No.2 (Engine Compartment Left)

### ○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
1C	23	Cowl Wire and J/B No.1 (Lower Finish Panel)
1J		
1K	23	Engine Room Main Wire and J/B No.1 (Lower Finish Panel)
1L	22	Cowl Wire and J/B No.1 (Lower Finish Panel)
3A	24	Cowl Wire and J/B No.3 (Behind the Instrument Panel Left)
3F		

### □ : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IF1	44	Engine Room Main Wire and Cowl Wire (Left Kick Panel)


### ▽ : GROUND POINTS

Code	See Page	Ground Points Location
IE	44	Around the Right Edge of the Reinforcement
IG	44	Around the Left Edge of the Reinforcement


### ○ : SPLICE POINTS

Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
I9	44	Cowl Wire			

# HEADLIGHT (w/ DAYTIME RUNNING LIGHT)



FROM POWER SOURCE SYSTEM (SEE PAGE 54)



# HEADLIGHT (w/ DAYTIME RUNNING LIGHT)

## SYSTEM OUTLINE

### 1. DAYTIME RUNNING LIGHT OPERATION

When the engine is started, voltage generated at TERMINAL L of the generator is applied to TERMINAL 9 of the daytime running light relay (Main).

If the parking brake lever is pulled up (The parking brake SW on) at this time, the relay is not activated, so the daytime running light system does not operate. If the parking brake lever is then released (The parking brake SW off), a signal is input to TERMINAL 11 of the relay. This activates the relay, so current flows from battery to the HEAD relay (Point side) to TERMINAL 4 of the DIMMER relay to TERMINAL 1 to HEAD (LO LH), (LO RH) fuse to TERMINAL 1 of the headlights to TERMINAL 3 to TERMINAL 1 of the daytime running light relay (Main) to TERMINAL 2 to GROUND. This causes headlights to light up (Headlights light up dimmer than full brightness.).

Once the daytime running light system operates and headlights light up, headlights remain on even if the parking brake lever is pulled up (The parking brake SW on).

If the engine stalls and the ignition SW remains on, headlights remain lighted up even through current is no longer output from TERMINAL L of the generator. If the ignition SW is then turned off, the headlights go off. If the engine is started with the parking brake lever released (The parking brake SW off), the daytime running light system operates and headlights light up when the engine starts.

### 2. HEADLIGHT OPERATION

When the light control SW is switched to HEAD position, current flows from the DRL fuse to TERMINAL 4 of the daytime running light relay No.4 to TERMINAL 3 to TERMINAL 1 of the diode to TERMINAL 2 to body ECU to TERMINAL 13 of the light control SW to TERMINAL 16 to GROUND, activating the daytime running light relay No.4. Current then flows from the HEAD (LO LH), (LO RH) fuse to TERMINAL 1 of the headlights to TERMINAL 3 to TERMINAL 2 of the daytime running light relay No.4 to TERMINAL 1 to GROUND, causing headlights to light up at normal intensity.

When the dimmer SW is switched to HIGH position, the signal from the dimmer SW is input to the daytime running light relay (Main). This activates the relay and current flows from TERMINAL 4 of the DIMMER relay to TERMINAL 2 to TERMINAL 4 of the daytime running light relay (Main), activating the DIMMER relay.

This causes current to flow from TERMINAL 4 of the DIMMER relay to TERMINAL 3 to HEAD (HI LH), (HI RH) fuse to TERMINAL 2 of the headlights to TERMINAL 3 to TERMINAL 2 of the daytime running light relay No.4 to TERMINAL 1 to GROUND, causing headlights to light up at high beam.

When the dimmer SW is switched to FLASH position, the daytime running light relay (Main) is activated and current flows from TERMINAL 4 of the DIMMER relay to TERMINAL 2. Current from the DRL fuse flows TERMINAL 4 of the daytime running light relay No.4 to TERMINAL 3 to TERMINAL 1 of the diode to TERMINAL 2 to TERMINAL 8 of the dimmer SW to TERMINAL 16 to GROUND, and also flows from the HEAD (HI LH), (HI RH) fuse to TERMINAL 2 of the headlights to TERMINAL 3 to TERMINAL 2 of the daytime running light relay No.4 to TERMINAL 1 to GROUND, causing the high beam to operate.

## SERVICE HINTS

### HEAD RELAY

- 2-1 : Closed with light control SW at **HEAD** position or dimmer SW at **FLASH** position
- Closed with engine running and parking brake lever released

### DIMMER RELAY

- 4-3 : Closed with HEAD relay on and dimmer SW at **HIGH** or **FLASH** position

## ○ : PARTS LOCATION

Code	See Page	Code	See Page	Code	See Page	
B2	30 (5VZ-FE)	G2	30 (5VZ-FE)	J9	A	31 (5VZ-FE)
	32 (3RZ-FE, 2RZ-FE)		32 (3RZ-FE, 2RZ-FE)			33 (3RZ-FE, 2RZ-FE)
C12	34	H1	30 (5VZ-FE)	J10	B	31 (5VZ-FE)
C14	34		32 (3RZ-FE, 2RZ-FE)			33 (3RZ-FE, 2RZ-FE)
D8	34	H2	30 (5VZ-FE)	P4		35
D9	34		32 (3RZ-FE, 2RZ-FE)			
D13	34	J1	35			

## ○ : RELAY BLOCKS

Code	See Page	Relay Blocks (Relay Block Location)
2	21	R/B No.2 (Engine Compartment Left)



 : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
1B	23	Cowl Wire and J/B No.1 (Lower Finish Panel)
1C		
1D		
1E	23	Engine Room Main Wire and J/B No.1 (Lower Finish Panel)
1F	23	Cowl Wire and J/B No.1 (Lower Finish Panel)
1K	23	Engine Room Main Wire and J/B No.1 (Lower Finish Panel)
1L	22	Cowl Wire and J/B No.1 (Lower Finish Panel)
3A	24	Cowl Wire and J/B No.3 (Behind the Instrument Panel Left)
3D		
3F		

 : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
EA1	40 (5VZ-FE)	Engine Room Main Wire and Engine No.2 Wire (Near the Battery)
	42 (3RZ-FE, 2RZ-FE)	
IF1	44	Engine Room Main Wire and Cowl Wire (Left Kick Panel)


 : GROUND POINTS

Code	See Page	Ground Points Location
EA	40 (5VZ-FE)	Front Left Fender
	42 (3RZ-FE, 2RZ-FE)	
IE	44	Around the Right Edge of the Reinforcement
IG	44	Around the Left Edge of the Reinforcement

 : SPLICE POINTS

Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
E3	40 (5VZ-FE)	Engine Room Main Wire	I9	44	Cowl Wire
	42 (3RZ-FE, 2RZ-FE)				

# INTERIOR LIGHT



**SERVICE HINTS****D15, D16, D26, D27 DOOR COURTESY SW FRONT REAR LH, RH**

1-GROUND : Closed with door open

**○ : PARTS LOCATION**

Code	See Page	Code	See Page	Code	See Page
D15	34	D27	36 (Double Cab)	I16	B 37 (Except Double Cab)
D16	34	I16	A 37 (Except Double Cab)	P5	36 (Double Cab)
D26	36 (Double Cab)		B 36 (Double Cab)		37 (Except Double Cab)

**○ : RELAY BLOCKS**

Code	See Page	Relay Blocks (Relay Block Location)
2	21	R/B No.2 (Engine Compartment Left)

**○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR**

Code	See Page	Junction Block and Wire Harness (Connector Location)
1E	23	Engine Room Main Wire and J/B No.1 (Lower Finish Panel)
1H	23	Cowl Wire and J/B No.1 (Lower Finish Panel)
1L	22	


**□ : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS**


Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IG1	44	Cowl Wire and Roof Wire (Left Kick Panel)

**○ : SPLICE POINTS**

Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
I1	44	Cowl Wire	B1	46 (Double Cab)	Roof Wire
I2				48 (Except Double Cab)	

# TAILLIGHT AND ILLUMINATION





# TAILLIGHT AND ILLUMINATION

## SERVICE HINTS

### C14 LIGHT CONTROL SW [COMB. SW]

14-16 : Closed with light control SW at **TAIL** or **HEAD** position

### TAIL RELAY

3-5 : Closed with light control SW at **TAIL** or **HEAD** position

## ○ : PARTS LOCATION

Code	See Page	Code	See Page	Code	See Page	
A19	34	J10	B	33 (3RZ-FE, 2RZ-FE)	R2   B	35
A25	34	L1		36 (Double Cab)	R3	35
C5	34			37 (Except Double Cab)	R4	35
C13	34	L2		36 (Double Cab)	R6	36 (Double Cab)
C14	34			37 (Except Double Cab)		37 (Except Double Cab)
E4	35	P2		31 (5VZ-FE)	R7	36 (Double Cab)
G3	35			33 (3RZ-FE, 2RZ-FE)		37 (Except Double Cab)
H6	35	P3		31 (5VZ-FE)	R15	35
J9	A			33 (3RZ-FE, 2RZ-FE)	P19	33 (3RZ-FE, 2RZ-FE)
		31 (5VZ-FE)	35			
J10	B	31 (5VZ-FE)	R1   A	35		

## ○ : RELAY BLOCKS

Code	See Page	Relay Blocks (Relay Block Location)
2	21	R/B No.2 (Engine Compartment Left)

## ○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
1E	23	Engine Room Main Wire and J/B No.1 (Lower Finish Panel)
1F	23	Cowl Wire and J/B No.1 (Lower Finish Panel)
1L	22	
3A	24	Cowl Wire and J/B No.3 (Behind the Instrument Panel Left)
3C		
3F		
3H	26	Cowl Wire and J/B No.3 (Behind the Instrument Panel Center)
3I		

## □ : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IF1	44	Engine Room Main Wire and Cowl Wire (Left Kick Panel)
BN1	46 (Double Cab)	Frame Wire and Cowl Wire (Under the Driver's Seat)
	48 (Except Double Cab)	

## ▽ : GROUND POINTS


Code	See Page	Ground Points Location
EA	40 (5VZ-FE)	Front Left Fender
	42 (3RZ-FE, 2RZ-FE)	
IE	44	Around the Right Edge of the Reinforcement
IG	44	Around the Left Edge of the Reinforcement

## ○ : SPLICE POINTS

Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
E3	40 (5VZ-FE)	Engine Room Main Wire	I9	44	Cowl Wire
	42 (3RZ-FE, 2RZ-FE)				



# TURN SIGNAL AND HAZARD WARNING LIGHT





## SERVICE HINTS

### FLASHER RELAY

2-GROUND : Approx. **12** volts with ignition SW on or hazard SW on

1-GROUND : Changes from **12** to **0** volts with ignition SW on and turn signal SW left or right, or with hazard SW on

### ○ : PARTS LOCATION

Code	See Page	Code	See Page	Code	See Page
C12	34	F4	32 (3RZ-FE, 2RZ-FE)	J10	B
C14	34	H6	35	R6	33 (3RZ-FE, 2RZ-FE)
F3	30 (5VZ-FE)	J9	A		31 (5VZ-FE)
	32 (3RZ-FE, 2RZ-FE)			33 (3RZ-FE, 2RZ-FE)	37 (Except Double Cab)
F4	30 (5VZ-FE)	J10	B	R7	36 (Double Cab)
					37 (Except Double Cab)

### ○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
1C	23	Cowl Wire and J/B No.1 (Lower Finish Panel)
1D		
1E	23	Engine Room Main Wire and J/B No.1 (Lower Finish Panel)
1F	23	Cowl Wire and J/B No.1 (Lower Finish Panel)
1H		
1J		
3F	24	Cowl Wire and J/B No.3 (Behind the Instrument Panel Left)

### □ : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IF1	44	Engine Room Main Wire and Cowl Wire (Left Kick Panel)
BN1	46 (Double Cab)	Frame Wire and Cowl Wire (Under the Driver's Seat)
	48 (Except Double Cab)	

### ▽ : GROUND POINTS


Code	See Page	Ground Points Location
EA	40 (5VZ-FE)	Front Left Fender
	42 (3RZ-FE, 2RZ-FE)	
IE	44	Around the Right Edge of the Reinforcement
IG	44	Around the Left Edge of the Reinforcement

### ○ : SPLICE POINTS

Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
I9	44	Cowl Wire			

# STOP LIGHT

FROM POWER SOURCE SYSTEM (SEE PAGE 54)



**SERVICE HINTS****S5 STOP LIGHT SW**

2-1 : Closed with brake pedal depressed

**○ : PARTS LOCATION**

Code	See Page	Code	See Page	Code	See Page
H8	<a href="#">36 (Double Cab)</a>	R6	<a href="#">37 (Except Double Cab)</a>	S5	<a href="#">35</a>
	<a href="#">37 (Except Double Cab)</a>	R7	<a href="#">36 (Double Cab)</a>		
R6	<a href="#">36 (Double Cab)</a>		<a href="#">37 (Except Double Cab)</a>		

**○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR**

Code	See Page	Junction Block and Wire Harness (Connector Location)
1A	<a href="#">23</a>	Roof Wire and J/B No.1 (Lower Finish Panel)
1F	<a href="#">23</a>	Cowl Wire and J/B No.1 (Lower Finish Panel)
1J		
3F	<a href="#">24</a>	Cowl Wire and J/B No.3 (Behind the Instrument Panel Left)

**□ : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS**


Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IG1	<a href="#">44</a>	Cowl Wire and Roof Wire (Left Kick Panel)
BN1	<a href="#">46 (Double Cab)</a>	Frame Wire and Cowl Wire (Under the Driver's Seat)
	<a href="#">48 (Except Double Cab)</a>	

**▽ : GROUND POINTS**

Code	See Page	Ground Points Location
IE	<a href="#">44</a>	Around the Right Edge of the Reinforcement
IG	<a href="#">44</a>	Around the Left Edge of the Reinforcement

# BACK-UP LIGHT

FROM POWER SOURCE SYSTEM (SEE PAGE 54)



**SERVICE HINTS**

**P1 (A), (B) BACK-UP LIGHT SW [PARK/NEUTRAL POSITION SW] (A/T)**

(A) 3-(A) 2, (B) 4-(B) 8 : Closed with shift lever in **R** position

**B1 BACK-UP LIGHT SW (M/T)**

2-1 : Closed with shift lever in **R** position

 : PARTS LOCATION

Code	See Page	Code	See Page	Code	See Page	
B1	30 (5VZ-FE)	P1	A	33 (3RZ-FE)	R6	37 (Except Double Cab)
	32 (3RZ-FE, 2RZ-FE)		B	33 (2RZ-FE)	R7	36 (Double Cab)
P1	A	31 (5VZ-FE)	R6	36 (Double Cab)		37 (Except Double Cab)

 : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
1F	23	Cowl Wire and J/B No.1 (Lower Finish Panel)
3B	24	Cowl Wire and J/B No.3 (Behind the Instrument Panel Left)
3D		

 : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS


Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IK2	44	Engine Wire and Cowl Wire (Above the Glove Box)
BN1	46 (Double Cab)	Frame Wire and Cowl Wire (Under the Driver's Seat)
	48 (Except Double Cab)	

 : GROUND POINTS

Code	See Page	Ground Points Location
IG	44	Around the Left Edge of the Reinforcement

# LIGHT AUTO TURN OFF

FROM POWER SOURCE SYSTEM (SEE PAGE 54)



## SYSTEM OUTLINE

The light auto turn off system automatically turns the taillight or headlight off according to the door open or close on the driver's side, and prevent failing to turn off the lights.

If the ignition switch is turned to OFF from ON with the headlight or taillight is on, the signal is input in the body ECU. If the driver's seat door is opened at that time, the signal from the door courtesy SW front LH is sent to the body ECU. The signal turns the headlight or taillight off by the body ECU.

## SERVICE HINTS

### BODY ECU

10-GROUND : Approx. **12** volts with ignition SW at **ON** or **ST** position

4-GROUND : Always approx. **12** volts

8-GROUND : Always continuity

### : PARTS LOCATION

Code	See Page	Code	See Page	Code	See Page
C14	34	D15	34		
D8	34	J1	35		

### : RELAY BLOCKS

Code	See Page	Relay Blocks (Relay Block Location)
2	21	R/B No.2 (Engine Compartment Left)

### : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
1C	23	Cowl Wire and J/B No.1 (Lower Finish Panel)
1E	23	Engine Room Main Wire and J/B No.1 (Lower Finish Panel)
1J	23	Cowl Wire and J/B No.1 (Lower Finish Panel)
1K	23	Engine Room Main Wire and J/B No.1 (Lower Finish Panel)
1L	22	Cowl Wire and J/B No.1 (Lower Finish Panel)
3A	24	Cowl Wire and J/B No.3 (Behind the Instrument Panel Left)

### : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IF1	44	Engine Room Main Wire and Cowl Wire (Left Kick Panel)


### : GROUND POINTS

Code	See Page	Ground Points Location
IE	44	Around the Right Edge of the Reinforcement
IG	44	Around the Left Edge of the Reinforcement


### : SPLICE POINTS

Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
I9	44	Cowl Wire			


# ELECTRONICALLY CONTROLLED TRANSMISSION (5VZ-FE)







# ELECTRONICALLY CONTROLLED TRANSMISSION (5VZ-FE)



## SYSTEM OUTLINE

Previous automatic transmissions have selected each gear shift using mechanically controlled throttle hydraulic pressure, governor hydraulic pressure and lock-up hydraulic pressure. The electronically controlled transmission, however, electrically controls the governor pressure and lock-up sensor through the solenoid valve. Control of the solenoid valve by the engine control module based on the input signals from each sensor makes smooth driving possible by shift selection for each gear which is most appropriate to the driving conditions at that time.

### 1. GEAR SHIFT OPERATION

During driving, the engine control module selects the shift for each gear which is most appropriate to the driving conditions, based on input signals from the engine coolant temp. sensor to TERMINAL THW of the engine control module and also the input signals to TERMINAL SP2+ of the engine control module from the vehicle speed sensor devoted to the electronically controlled transmission. Current is then output to the electronically controlled transmission solenoid. When shifting to 1st speed, current flows from TERMINAL S1 of the engine control module to TERMINAL 1 of the electronically controlled transmission solenoid to GROUND, and continuity to the No.1 solenoid causes the shift.

For 2nd speed, current flows from TERMINAL S1 of the engine control module to TERMINAL 1 of the electronically controlled transmission solenoid to GROUND, and from TERMINAL S2 of the engine control module to TERMINAL 2 of the electronically controlled transmission solenoid to GROUND. And continuity to solenoid No.1 and No.2 causes the shift.

For 3rd speed, there is no continuity to No.1 solenoid, only to No.2 causing the shift. Shifting into 4th speed (Overdrive) takes place when there is no continuity to either No.1 or No.2 solenoid.

### 2. LOCK-UP OPERATION

When the engine control module judges from each signal that lock-up operation conditions have been met, current flows from TERMINAL SL of the engine control module to TERMINAL 3 of the electronically controlled transmission solenoid to GROUND, causing continuity to the lock-up solenoid and causing lock-up operation.

### 3. STOP LIGHT SW CIRCUIT

If the brake pedal is depressed (Stop light SW on) when driving in lock-up condition, a signal is input to TERMINAL STP of the engine control module, the engine control module operates and continuity to the lock-up solenoid is cut.

### 4. OVERDRIVE CIRCUIT

\* O/D main SW on

When the O/D main SW is turned on, a signal is input to TERMINAL ODMS of the engine control module and engine control module operation causes gear shift when the conditions for overdrive are met.

\* O/D main SW off

When the O/D main SW is turned off, a signal is input into TERMINAL ODMS of the engine control module, and turns on the O/D off indicator light. This activates the ECU, and the transmission system is controlled not to shift to overdrive.

### 5. A/T OIL TEMP. WARNING

When the A/T oil temp. sensor affixed to the transmission case detects that the fluid temp. is 150°C (302°F) or more, the engine control module operates and the current flowing through the GAUGE fuse flows to the A/T oil temp. warning light to TERMINAL OILW of the engine control module to GROUND, so that the warning light lights up, informing that the oil temp. is high. When the oil temp. drops to 120°C (248°F) or less, the engine control module stops operating and the warning light goes out.

# ELECTRONICALLY CONTROLLED TRANSMISSION (5VZ-FE)

## SERVICE HINTS

### E2 ELECTRONICALLY CONTROLLED TRANSMISSION SOLENOID

1, 2, 3-GROUND : Approx. 13 Ω

### P1 PARK/NEUTRAL POSITION SW

3-GROUND : Approx. 12 volts with ignition SW ON position

### S5 STOP LIGHT SW

1-2 : Closed with brake pedal depressed

### E5 (A), E6 (B), E7 (C), E8 (D) ENGINE CONTROL MODULE

S1-E1 : 9-14 volts

S2,SL-E1 : 0-1.5 volts

STP-E1 : 7.5- 14 volts with brake pedal depressed

: 0- 1.5 volts with brake pedal released

THW-E2 : 0.2- 1.0 volts with coolant temp. 80°C (176°F)

OIL-E2 : 4- 5 volts with fluid temp. 20°C (68°F)

VTA-E2 : 0.3- 0.8 volts with throttle valve fully closed

: 3.2- 4.9 volts with throttle valve fully open

VC-E2 : 4.5- 5.5 volts

OD1-E1 : 4.5- 5.5 volts

SP1-E1 : Pulse generation with vehicle moving

2-E1 : 10- 14 volts with shift lever at 2 position

: 0- 2 volts with shift lever at except 2 position

L-E1 : 10- 14 volts with shift lever at L position

: 0- 2 volts with shift lever at except L position

OILW-E1 : 0.1- 4.9 volts

+B-E1 : 9- 14 volts

BATT-E1 : 9- 14 volts

## ○ : PARTS LOCATION

Code	See Page	Code	See Page	Code	See Page
A7	30 (5VZ-FE)	E3	30 (5VZ-FE)	J11	35
C10	A 34	E4	35	J13	35
C12	C 34	E5	A 35	P1	31 (5VZ-FE)
C13	D 34	E6	B 35	S4	35
C17	34	E7	C 35	S5	35
D1	30 (5VZ-FE)	E8	D 35	T1	31 (5VZ-FE)
D25	34	J9	A 31 (5VZ-FE)	V1	31 (5VZ-FE)
E2	30 (5VZ-FE)	J10	B 31 (5VZ-FE)	V10	31 (5VZ-FE)

## ○ : RELAY BLOCKS

Code	See Page	Relay Blocks (Relay Block Location)
2	21	R/B No.2 (Engine Compartment Left)

## ○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
1F	23	Cowl Wire and J/B No.1 (Lower Finish Panel)
3B	24	Cowl Wire and J/B No.3 (Behind the Instrument Panel Left)
3D		
3E		
3F		
3G	26	Cowl Wire and J/B No.3 (Behind the Instrument Panel Center)

 : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
EE1	<a href="#">40 (5VZ-FE)</a>	Engine Wire and Sensor Wire (Over the Cylinder Head)
IF1	<a href="#">44</a>	Engine Room Main Wire and Cowl Wire (Left Kick Panel)
IK2	<a href="#">44</a>	Engine Wire and Cowl Wire (Above the Glove Box)
IK3		


 : GROUND POINTS


Code	See Page	Ground Points Location
EA	<a href="#">40 (5VZ-FE)</a>	Front Left Fender
EB	<a href="#">40 (5VZ-FE)</a>	Near the Throttle Body
ID	<a href="#">44</a>	Left Kick Panel
IE	<a href="#">44</a>	Around the Right Edge of the Reinforcement
IG	<a href="#">44</a>	Around the Left Edge of the Reinforcement

 : SPLICE POINTS


Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
I9	<a href="#">44</a>	Cowl Wire	I13	<a href="#">44</a>	Engine Wire
I12					

# ELECTRONICALLY CONTROLLED TRANSMISSION (3RZ-FE)





# ELECTRONICALLY CONTROLLED TRANSMISSION (3RZ-FE)





## SYSTEM OUTLINE

Previous automatic transmissions have selected each gear shift using mechanically controlled throttle hydraulic pressure, governor hydraulic pressure and lock-up hydraulic pressure. The electronically controlled transmission, however, electrically controls the governor pressure and lock-up pressure through the solenoid valve. Control of the solenoid valve by the engine control module based on the input signals from each sensor makes smooth driving possible by shift selection for each gear which is most appropriate to the driving conditions at that time.

### 1. GEAR SHIFT OPERATION

During driving, the engine control module selects the shift for each gear which is most appropriate to the driving conditions, based on input signals from the engine coolant temp. sensor to TERMINAL THW of the engine control module, and also the input signals to TERMINAL SP2+ of the engine control module from the vehicle speed sensor devoted to the electronically controlled transmission. Current is then output to the electronically controlled transmission solenoid. When shifting to 1st speed, current flows from TERMINAL S1 of the engine control module to TERMINAL 1 of the electronically controlled transmission solenoid to GROUND, and continuity to the No.1 solenoid causes the shift.

For 2nd speed, current flows from TERMINAL S1 of the engine control module to TERMINAL 1 of the electronically controlled transmission solenoid to GROUND, and from TERMINAL S2 of the engine control module to TERMINAL 2 of the electronically controlled transmission solenoid to GROUND, and continuity to solenoid No.1 and No.2 causes the shift.

For 3rd speed, there is no continuity to No.1 solenoid, only to No.2 causing the shift. Shifting into 4th speed (Overdrive) takes place when there is no continuity to either No.1 or No.2 solenoid.

### 2. LOCK-UP OPERATION

When the engine control module judges from each signal that lock-up operation conditions have been met, current flows from TERMINAL SL of the engine control module to TERMINAL 3 of the electronically controlled transmission solenoid to GROUND, causing continuity to the lock-up solenoid and causing lock-up operation.

### 3. STOP LIGHT SW CIRCUIT

If the brake pedal is depressed (Stop light SW on) when driving in lock-up condition, a signal is input to TERMINAL STP of the engine control module, the engine control module operates and continuity to the lock-up solenoid is cut.

### 4. OVERDRIVE CIRCUIT

\* O/D main SW on

When the O/D main SW is turned on, a signal is input to TERMINAL ODMS of the engine control module and engine control module operation causes gear shift when the conditions for overdrive are met.

\* O/D main SW off

When the O/D main SW is turned off, a signal is input into TERMINAL ODMS of the engine control module, and turns on the O/D off indicator light. This activates the ECU, and the transmission system is controlled not to shift to overdrive.

# ELECTRONICALLY CONTROLLED TRANSMISSION (3RZ-FE)

## SERVICE HINTS

### E2 ELECTRONICALLY CONTROLLED TRANSMISSION SOLENOID

1, 2, 3-GROUND : Approx. 13 Ω

### P1 PARK/NEUTRAL POSITION SW

3-GROUND : Approx. 12 volts with ignition SW **ON** position

### S5 STOP LIGHT SW

2-1 : Closed with brake pedal depressed

### E5 (A), E6 (B), E7 (C), E8 (D) ENGINE CONTROL MODULE

S1-E1 : 9- 14 volts

S2, SL-E1 : 0- 1.5 volts

STP-E1 : 7.5- 14 volts with brake pedal depressed  
: 0- 1.5 volts with brake pedal released

THW-E2 : 0.2- 1.0 volts with coolant temp. 80°C (176°F)

THO-E2 : 4- 5 volts with fluid temp. 20°C (68°F)

VTA-E2 : 0.3- 0.8 volts with throttle valve fully closed  
: 3.2- 4.9 volts with throttle valve fully open

VC-E2 : 4.5- 5.5 volts

OD1-E1 : 4.5- 5.5 volts

SP1-E1 : Pulse generation with vehicle moving

2-E1 : 10- 14 volts with shift lever at **2** position  
: 0- 2 volts with shift lever at except **2** position

L-E1 : 10- 14 volts with shift lever at **L** position  
: 0- 2 volts with shift lever at except **L** position

R-E1 : 10- 4 volts with shift lever at **R** position  
: 0- 2 volts with shift lever at except **R** position

PWR-E1 : 7.5- 14 volts with pattern select SW **PWR** position  
: 0- 1.5 volts with pattern select SW **NORM** position

+B-E1 : 9- 14 volts

BATT-E1 : 9- 14 volts

## ○ : PARTS LOCATION

Code	See Page	Code	See Page	Code	See Page
A7	32 (3RZ-FE)	E3	32 (3RZ-FE)	J11	35
C10	A 34	E4	35	J13	35
C12	C 34	E5	A 35	P1	33 (3RZ-FE)
C13	D 34	E6	B 35	S4	35
C17	34	E7	C 35	S5	35
D7	34	E8	D 35	T1	33 (3RZ-FE)
D25	34	J9	A 33 (3RZ-FE)	V1	33 (3RZ-FE)
E2	32 (3RZ-FE)	J10	B 33 (3RZ-FE)	V10	33 (3RZ-FE)

## ○ : RELAY BLOCKS

Code	See Page	Relay Blocks (Relay Block Location)
2	21	R/B No.2 (Engine Compartment Left)

## ○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
1F	23	Cowl Wire and J/B No.1 (Lower Finish Panel)
3B	24	Cowl Wire and J/B No.3 (Behind the Instrument Panel Left)
3D		
3E		
3F		
3G	26	Cowl Wire and J/B No.3 (Behind the Instrument Panel Center)

 : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IF1	44	Engine Room Main Wire and Cowl Wire (Left Kick Panel)
IK2	44	Engine Wire and Cowl Wire (Above the Glove Box)
IK3		


 : GROUND POINTS

Code	See Page	Ground Points Location
EA	42 (3RZ-FE)	Front Left Fender
EF	42 (3RZ-FE)	Ignition Coil Braket
ID	44	Left Kick Panel
IE	44	Around the Right Edge of the Reinforcement
IG	44	Around the Left Edge of the Reinforcement


 : SPLICE POINTS

Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
I9	44	Cowl Wire	I13	44	Engine Wire
I12					

# AUTOMATIC TRANSMISSION (2RZ-FE)




FROM POWER SOURCE SYSTEM (SEE PAGE 54)



# AUTOMATIC TRANSMISSION (2RZ-FE)

- \* 1 : W/ TACHOMETER
- \* 2 : W/O TACHOMETER



## SERVICE HINTS

### O6 O/D ECU

3-GROUND : Approx. 12 volts with ignition SW at **ON** position

5-GROUND : Always continuity

### ○ : PARTS LOCATION

Code	See Page	Code	See Page	Code	See Page
C10	A	34	E5	A	35
C12	C	34	E6	B	35
C13	D	34	E7	C	35
C17		34	J9	A	33 (2RZ-FE)
D7		34	J10	B	33 (2RZ-FE)
D25		34	J13		35
E3		32 (2RZ-FE)	O1		33 (2RZ-FE)
				O6	35
				P1	33 (2RZ-FE)
				S4	35
				S5	35
				T1	33 (2RZ-FE)
				V10	33 (2RZ-FE)

### ○ : RELAY BLOCKS

Code	See Page	Relay Blocks (Relay Block Location)
2	21	R/B No.2 (Engine Compartment Left)

### ○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
1F	23	Cowl Wire and J/B No.1 (Lower Finish Panel)
1G		
3B	24	Cowl Wire and J/B No.3 (Behind the Instrument Panel Left)
3D		
3E		
3F		
3G	26	Cowl Wire and J/B No.3 (Behind the Instrument Panel Center)

### □ : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IF1	44	Engine Room Main Wire and Cowl Wire (Left Kick Panel)
IK2	44	Engine Wire and Cowl Wire (Above the Glove Box)
IK3		


### ▽ : GROUND POINTS

Code	See Page	Ground Points Location
EA	42 (2RZ-FE)	Front Left Fender
EF	42 (2RZ-FE)	Ignition Coil Bracket
ID	44	Left Kick Panel
IE	44	Around the Right Edge of the Reinforcement
IG	44	Around the Left Edge of the Reinforcement

### ○ : SPLICE POINTS

Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
I11	44	Cowl Wire	I13	44	Engine Wire
I12					


# CRUISE CONTROL



2001 TOYOTA TACOMA (EWD440U)



FROM POWER SOURCE SYSTEM (SEE PAGE 54)



# CRUISE CONTROL

## SYSTEM OUTLINE

With the ignition SW turned to on, current flows from GAUGE fuse to TERMINAL 1 of the cruise control indicator light and from ECU-IG fuse to TERMINAL B of the cruise control ECU. When the ignition SW is on and the cruise control SW is turned on, a signal is input from TERMINAL 5 of the cruise control SW to TERMINAL CCS of the cruise control ECU. As a result, the cruise control ECU functions and the current to TERMINAL B of the cruise control ECU flows to TERMINAL GND to GROUND, and the cruise control system is ready for operation.

At the same time, the current from the GAUGE fuse flows to TERMINAL 1 of the cruise control indicator light to TERMINAL 8 to TERMINAL Pi of the cruise control ECU to TERMINAL GND to GROUND, causing the cruise control indicator light to light up, indicating that the cruise control is ready for operation.

### 1. SET OPERATION

When the cruise control main SW is turned on and the set SW is pushed with the vehicle speed within the set limit (Approx. 40 km/h, 25 mph to 200 km/h, 124 mph), a signal is input to TERMINAL CCS of the cruise control ECU and the vehicle speed at the time the set SW is released is memorized in the ECU as the set speed.

### 2. SET SPEED CONTROL

During cruise control driving, the ECU compares the set speed memorized in the ECU with the actual vehicle speed input into TERMINAL SPD of the cruise control ECU from the speedometer, and controls the cruise control actuator to maintain the set speed.

When the actual vehicle speed is lower than the set speed, the ECU causes the current to the cruise control actuator to flow from TERMINAL MO of the cruise control ECU to TERMINAL 1 of the cruise control actuator to TERMINAL 2 to TERMINAL MC of the cruise control ECU. As a result, the motor in the cruise control actuator is rotated to open the throttle valve and the throttle cable is pulled to increase the vehicle speed.

When the actual vehicle speed is higher than the set speed, the current to the cruise control actuator flows from TERMINAL MC of the ECU to TERMINAL 2 of the cruise control actuator to TERMINAL 1 to TERMINAL MO of the cruise control ECU. This causes the motor in the cruise control actuator to rotate to close the throttle valve and return the throttle cable to decrease the vehicle speed.

### 3. COAST CONTROL

During cruise control driving, while the coast SW is on, the cruise control actuator returns the throttle cable to close the throttle valve and decrease the driving speed. The vehicle speed when the coast SW is turned off is memorized and the vehicle continues at the new set speed.

### 4. ACCEL CONTROL

During cruise control driving, while the accel SW is turned on, the cruise control actuator pulls the throttle cable to open the throttle valve and increase the driving speed.

The vehicle speed when the accel SW is turned off is memorized and the vehicle continues at the new set speed.

### 5. RESUME CONTROL

Unless the vehicle speed falls below the minimum speed limit (Approx. 45 km/h, 25 mph) after canceling the set speed by the cancel SW, pushing the resume SW will cause the vehicle to resume the vehicle speed set before cancellation.

### 6. MANUAL CANCEL MECHANISM

If any of the following operations occurs during cruise control operation, the magnetic clutch of the actuator turns off and the motor rotates to close the throttle valve and the cruise control is released.

- \* Placing the shift lever in except D position (A/T) or cruise control clutch SW off (M/T). "A Signal is not input to TERMINAL D of the ECU"
- \* Depressing the brake pedal (Stop light SW on). "A Signal is input to TERMINAL STP- of the ECU"
- \* Pushing the cancel SW (Cancel SW on). "A Signal is input to TERMINAL CCS of the ECU"

## 7. AUTO CANCEL FUNCTION

A) If any of the following operating conditions occurs during cruise control operation, the set speed is erased, the current flowing to the magnetic clutch is stopped and the cruise control is released (Cruise SW turns off).

When this occurs, the ignition SW must be turned off once before the main SW will turn on.

- \* Over current to transistor driving motor and/or magnetic clutch.
- \* Current to control the throttle valve in motor becomes always ON.
- \* Open circuit in magnetic clutch.
- \* Momentary interruption of vehicle speed signal
- \* Short circuit in cruise control SW.
- \* Motor does not operate despite the motor drive signal being output.

B) If any of the following conditions occurs during cruise control operation, the set speed is erased and the cruise control is released. (The power of magnetic clutch is cut off until the set SW is ON again.)

- \* When the vehicle speed falls below the minimum speed limit (approx. 40 km/h, 25 mph)
- \* When the vehicle speed falls more than 16 km/h (10 mph) below the set speed, E.G. on an upward slope.
- \* When power to the cruise control system is momentarily cut off.

C) If any of the following condition occurs during cruise control operation, the cruise control is released. But in this case, the set speed is not erased. If the vehicle speed is more than the minimum speed limit (Approx. 40 km/h, 25 mph), cruise control operation is possible using SET or RESUME on the control SW.

- \* Open circuit between TERMINAL L of the cruise control ECU and TERMINAL 3 of the stop light SW.

## SERVICE HINTS

### C17 CRUISE CONTROL ECU

16-GROUND : Always continuity

9-GROUND : Approx. **12** volts with ignition SW at **ON** position

12-GROUND : **4** pulse with **1** rotation of the rotor shaft

2-GROUND : Approx. **12** volts with brake pedal depressed (One of the cancel SW)

### C19 CRUISE CONTROL SW [COMB. SW]

5-4 : Approx. **68**  $\Omega$  with RESUME/ACCEL SW on

Approx. **198**  $\Omega$  with SET/COAST SW on

Approx. **418**  $\Omega$  with CANCEL SW on

### C3 CRUISE CONTROL ACTUATOR

3-4 : Approx. **38.5**  $\Omega$

## ○ : PARTS LOCATION

Code	See Page	Code	See Page	Code	See Page	
C3	<a href="#">30 (5VZ-FE)</a>	D1	<a href="#">30 (5VZ-FE)</a>	P1	A	<a href="#">31 (5VZ-FE)</a>
	<a href="#">32 (3RZ-FE, 2RZ-FE)</a>		<a href="#">32 (3RZ-FE, 2RZ-FE)</a>		B	<a href="#">33 (3RZ-FE)</a>
C10	<a href="#">34</a>	E5	A	<a href="#">35</a>		
C13	<a href="#">34</a>	E6	B	<a href="#">35</a>	S5	<a href="#">35</a>
C16	<a href="#">34</a>	E8	D	<a href="#">35</a>	V10	<a href="#">31 (5VZ-FE)</a>
C17	<a href="#">34</a>	J11	<a href="#">35</a>	<a href="#">33 (3RZ-FE, 2RZ-FE)</a>		
C19	<a href="#">34</a>	O6	<a href="#">35</a>			

## ○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
1F	<a href="#">23</a>	Cowl Wire and J/B No.1 (Lower Finish Panel)
1G		
3B	<a href="#">24</a>	Cowl Wire and J/B No.3 (Behind the Instrument Panel Left)
3D		
3E		
3F		
3H	<a href="#">26</a>	Cowl Wire and J/B No.3 (Behind the Instrument Panel Center)

# CRUISE CONTROL

 : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IK2	44	Engine Wire and Cowl Wire (Above the Glove Box)
IK3		


 : GROUND POINTS

Code	See Page	Ground Points Location
EB	40 (5VZ-FE)	Near the Throttle Body
EF	42 (3RZ-FE, 2RZ-FE)	Ignition Coil Bracket
ID	44	Left Kick Panel
IE	44	Around the Right Edge of the Reinforcement
IG	44	Around the Left Edge of the Reinforcement

 : SPLICE POINTS


Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
I9	44	Cowl Wire	I17	44	Cowl Wire
I14					





FROM POWER SOURCE SYSTEM (SEE PAGE 54)

- \* 1 : 3RZ-FE, 2RZ-FE
- \* 2 : W/ REAR DIFF. LOCK
- \* 3 : W/O REAR DIFF. LOCK



## SYSTEM OUTLINE

This system controls the respective brake fluid pressures acting on the disc brake cylinders of the right front wheel, left front wheel, and rear wheels when the brakes are applied in a panic stop so that the wheels do not lock. This results in improved directional stability and steerability during panic braking.

### 1. INPUT SIGNAL

(1) Speed sensor signal

The speed of the wheels is detected and input to TERMINALS FL+, FR+, RL+ and RR+ of the ABS actuator with ECU.

(2) Stop light SW signal

A signal is input to TERMINAL STP of the ABS actuator with ECU when the brake pedal is depressed.

(3) Deceleration sensor signal (4WD)

Longitudinal acceleration is detected and a signal is input to the ABS actuator with ECU.

### 2. SYSTEM OPERATION

During sudden braking, the ABS actuator with ECU which has signals input from each sensor lets the hydraulic pressure acting on each wheel cylinder escape to the reservoir.

The pump inside the ABS actuator with ECU is also operating at this time and it returns the brake fluid from the reservoir to the master cylinder, thus preventing locking of vehicle wheels.

If the ABS actuator with ECU judges that the hydraulic pressure acting on the wheel cylinder is insufficient, the current acting on the solenoid is controlled and the hydraulic pressure is increased.

Holding of the hydraulic pressure is also controlled by the ECU, by the same method as above, by repeated pressure reduction. Holding and increase are repeated to maintain vehicle stability and to improve steerability during sudden braking.

## SERVICE HINTS

### F1, F2 FRONT ABS SPEED SENSOR LH, RH

1-2 : 0.92- 1.22 kΩ (20°C, 68°F) (2WD)

1.40- 1.80 kΩ (20°C, 68°F) (4WD)

### R11, R12 REAR ABS SPEED SENSOR LH, RH

1-2 : 0.89- 1.29 kΩ (20°C, 68°F)

### A22 ABS ACTUATOR WITH ECU

6-GROUND : 10- 14 volts with ignition SW on

24-GROUND : 10- 14 volts with stop light SW on (Brake pedal depressed)

2, 18-GROUND : Always continuity

### S5 STOP LIGHT SW

2-1 : Closed with brake pedal depressed

## ○ : PARTS LOCATION

Code	See Page	Code	See Page	Code	See Page
A9	34	D3	32 (3RZ-FE, 2RZ-FE)	R11	36 (Double Cab)
A22	30 (5VZ-FE)	F1	30 (5VZ-FE)		37 (Except Double Cab)
	32 (3RZ-FE, 2RZ-FE)		32 (3RZ-FE, 2RZ-FE)	R12	36 (Double Cab)
C13	34	F2	30 (5VZ-FE)		37 (Except Double Cab)
D1	30 (5VZ-FE)		32 (3RZ-FE, 2RZ-FE)	R16	35
		32 (3RZ-FE, 2RZ-FE)	J11	S5	35
D3	30 (5VZ-FE)	J13	35		

## ○ : RELAY BLOCKS

Code	See Page	Relay Blocks (Relay Block Location)
2	21	R/B No.2 (Engine Compartment Left)



 : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
1F	23	Cowl Wire and J/B No.1 (Lower Finish Panel)
1G		
3B	24	Cowl Wire and J/B No.3 (Behind the Instrument Panel Left)
3D		
3F		
3H	26	Cowl Wire and J/B No.3 (Behind the Instrument Panel Center)
3I		

 : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
EF1	40 (5VZ-FE)	Cowl Wire and Engine Room Main Wire (Front Right Fender)
	42 (3RZ-FE, 2RZ-FE)	
IF2	44	Engine Room Main Wire and Cowl Wire (Left Kick Panel)
IK2	44	Engine Wire and Cowl Wire (Above the Glove Box)
BN6	46 (Double Cab)	Frame Wire and Cowl Wire (Under the Driver's Seat)
	48 (Except Double Cab)	
BO2	46 (Double Cab)	Frame Wire and Diff. Lock Wire (Rear Side Member LH)
	48 (Except Double Cab)	

 : GROUND POINTS


Code	See Page	Ground Points Location
EB	40 (5VZ-FE)	Near the Throttle Body
EC	40 (5VZ-FE)	Front Right Fender
	42 (3RZ-FE, 2RZ-FE)	
EF	42 (3RZ-FE, 2RZ-FE)	Ignition Coil Bracket
IE	44	Around the Right Edge of the Reinforcement
IG	44	Around the Left Edge of the Reinforcement

 : SPLICE POINTS

Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
I9	44	Cowl Wire			

# HORN

FROM POWER SOURCE SYSTEM (SEE PAGE 54)



---

**SERVICE HINTS****BODY ECU**

13-GROUND : Continuity with horn SW on

**○ : PARTS LOCATION**

Code	See Page	Code	See Page	Code	See Page
C19	<a href="#">34</a>	H5	<a href="#">32 (3RZ-FE, 2RZ-FE)</a>	H10	<a href="#">32 (3RZ-FE, 2RZ-FE)</a>
H5	<a href="#">30 (5VZ-FE)</a>	H10	<a href="#">30 (5VZ-FE)</a>		

**○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR**

Code	See Page	Junction Block and Wire Harness (Connector Location)
1E	<a href="#">23</a>	Engine Room Main Wire and J/B No.1 (Lower Finish Panel)
1H	<a href="#">23</a>	Cowl Wire and J/B No.1 (Lower Finish Panel)





NOTICE: When inspecting or repairing the SRS, perform the operation in accordance with the following precautionary instructions and the procedure and precautions in the Repair Manual for the applicable model year.

- Malfunction symptoms of the SRS are difficult to confirm, so the DTCs become the most important source of information when troubleshooting. When troubleshooting the SRS, always inspect the DTCs before disconnecting the battery.
- **Work must be started after 90 seconds from when the ignition switch is turned to the "LOCK" position and the negative (-) terminal cable is disconnected from the battery.**  
**(The SRS is equipped with a back-up power source so that if work is started within 90 seconds from disconnecting the negative (-) terminal cable of the battery, the SRS may be deployed.)**
- When the negative (-) terminal cable is disconnected from the battery, the memory of the clock and audio system will be canceled. So before starting work, make a record of the contents memorized in the audio memory system. When work is finished, reset the audio systems as they were before and adjust the clock. To avoid erasing the memory in each memory system, never use a back-up power supply from outside the vehicle.
- Before repairs, remove the airbag sensor if shocks are likely to be applied to the sensor during repairs.
- Do not expose the steering wheel pad, front passenger airbag assembly, seat belt pretensioner, center airbag sensor assembly or front airbag sensor assembly directly to hot air or flames.
- Even in cases of a minor collision where the SRS does not deploy, the steering wheel pad, front passenger airbag assembly, seat belt pretensioner, center airbag sensor assembly and front airbag sensor assembly should be inspected.
- Never use SRS parts from another vehicle. When replacing parts, replace them with new parts.
- Never disassemble and repair the steering wheel pad, front passenger airbag assembly, seat belt pretensioner, center airbag sensor assembly or front airbag sensor assembly in order to reuse it.
- If the steering wheel pad, front passenger airbag assembly, seat belt pretensioner, center airbag sensor assembly or front airbag sensor assembly has been dropped, or if there are cracks, dents or other defects in the case, bracket or connector, replace them with new ones.
- Use a volt/ohmmeter with high impedance (10 k $\Omega$ /V minimum) for troubleshooting the system's electrical circuits.
- Information labels are attached to the periphery of the SRS components. Follow the instructions on the notices.
- After work on the SRS is completed, perform the SRS warning light check.
- If the vehicle is equipped with a mobile communication system, refer to the precaution in the IN section of the Repair Manual.

FROM POWER SOURCE SYSTEM (SEE PAGE 54)

\* 1 : DOUBLE CAB  
 \* 2 : EXCEPT DOUBLE CAB





## SYSTEM OUTLINE

The SRS is a driver protection device which has a supplemental role to the seat belts.

When the ignition SW is turned to ACC or ON, the current from the ACC fuse flows to TERMINAL (B) 6 of the center airbag sensor assembly. Only when the ignition SW on, the current from the IGN fuse flows to TERMINAL (B) 5 of the center airbag sensor assembly.

If an accident occurs while driving, deceleration caused by a frontal impact is detected (by sensor) and when the frontal impact exceeds a set level, the current from the ACC or IGN fuse flows to TERMINALS (B) 6 or (B) 5 of the center airbag sensor assembly. This current flows to TERMINAL (B) 14 to TERMINAL 1 of the airbag squib (Steering wheel pad) to TERMINAL 2 to TERMINAL (B) 13 of the center airbag sensor assembly, and also flows to TERMINAL (B) 10 of the center airbag sensor assembly to TERMINAL 2 of the airbag squib (Front passenger airbag assembly) to TERMINAL 1 of the center airbag assembly (Double cab) or TERMINAL (B) 10 of the center airbag sensor assembly to TERMINAL 1 of the passenger airbag manual on/off SW to TERMINAL 3 to TERMINAL 1 of the airbag squib (Front passenger airbag assembly) to TERMINAL 2 to TERMINAL 2 of the passenger airbag manual on/off SW to TERMINAL 4 to TERMINAL (B) 11 of the center airbag sensor assembly (Except double cab). Furthermore, the current flows to TERMINAL (B) 27 or (B) 28 to GROUND, causing the center airbag squibs to expand.

When the safing sensor built into the center airbag sensor assembly is on, airbag sensor is off and the current from the ACC or IGN fuse flows same as above-mentioned flowing, causing the airbag squibs to expand. When the safing sensor built into the center airbag sensor assembly is on, the airbag sensor on one of the above-mentioned circuits is activated so that current flows to the airbag squibs and causes them to operate.

The airbag stored inside the steering wheel pad is instantaneously expanded to soften the shock to the driver.

The airbag stored inside the passenger's instrument panel is instantaneously expanded to soften the shock to the passenger.

### 1. FRONT PASSENGER AIRBAG MANUAL ON/OFF OPERATION (EXCEPT DOUBLE CAB)

When the passenger airbag manual on/off SW is on, the current flowing from the ACC or IGN fuse to the airbag squib (Front passenger airbag assembly) is same as above, causing the airbag squib (Front passenger airbag assembly) to expand in an accident.

If the passenger airbag manual on/off SW is turned to off, the current flows from the ACC fuse to TERMINAL 1 of the passenger airbag manual on/off indicator to TERMINAL 2 to GROUND, lighting the indicator up. Then the current between TERMINAL (B) 11 of the airbag sensor assembly and the airbag squib (Front passenger airbag assembly) is cut off, so that it does not expand the airbag squib (Front passenger airbag assembly) in an accident.

## ○ : PARTS LOCATION

Code	See Page	Code	See Page	Code	See Page
A18	34	D1	30 (5VZ-FE)	P19	35
A21	34		32 (3RZ-FE, 2RZ-FE)	P20	35
B6	36 (Double Cab)	D7	34	P21	36 (Double Cab)
	37 (Except Double Cab)	F9	30 (5VZ-FE)		37 (Except Double Cab)
C12	34		32 (3RZ-FE, 2RZ-FE)	P22	36 (Double Cab)
C20	A 34	F10	30 (5VZ-FE)		37 (Except Double Cab)
C21	B 34	32 (3RZ-FE, 2RZ-FE)			
C22	C 34	J11	35		

## ○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
1G	23	Cowl Wire and J/B No.1 (Lower Finish Panel)
1M		
3A	24	Cowl Wire and J/B No.3 (Behind the Instrument Panel Left)
3F		
3G	26	Cowl Wire and J/B No.3 (Behind the Instrument Panel Center)
3H		

## □ : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IF3	44	Engine Room Main Wire and Cowl Wire (Left Kick Panel)
IK2	44	Engine Wire and Cowl Wire (Above the Glove Box)




**: GROUND POINTS**

Code	See Page	Ground Points Location
ID	<a href="#">44</a>	Left Kick Panel
IE	<a href="#">44</a>	Around the Right Edge of the Reinforcement
IG	<a href="#">44</a>	Around the Left Edge of the Reinforcement
IH	<a href="#">44</a>	Right Kick Panel


**: SPLICE POINTS**

Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
I9	<a href="#">44</a>	Cowl Wire			

# 4WD (w/ 2-4 SELECT SW)




- \* 1 : A/T
- \* 2 : W/ ADD
- \* 3 : W/ DAYTIME RUNNING LIGHT
- \* 4 : W/O DAYTIME RUNNING LIGHT



# 4WD (w/ 2-4 SELECT SW)

- \* 5 : W/ TACHOMETER
- \* 6 : W/O TACHOMETER



## SYSTEM OUTLINE

The 4WD ECU operates the 2-4 select motor in accordance with the conditions of the 2-4 select SW, the detection SW (Transfer 4WD position) and the detection SW (Transfer L4 position). It also controls the range over which shifting from H2 to H4 is possible based on the vehicle speed sensor. If the 2-4 select SW is pushed in while shifting is prohibited, it causes the 4WD indicator light to flash and sounds a warning buzzer to inform the driver. The warning buzzer is built into the ECU. The operation of the ECU is as follows.

### 2-4 SELECT SYSTEM

The 2-4 select system selects between 2WD and 4WD by means of a 2-4 select SW located in the transfer shift lever knob which provides good operability.

This system uses an ECU which drives the 2-4 select motor in accordance with signals from various sensors and accomplishes shifting between 2WD and 4WD. Shifting between H4 to L4 is accomplished by operating the transfer shift lever as before. This system also permits shifting between H2 and H4 without first shifting to H4. All models equipped with 2-4 select system are also equipped with the add, explained later.

#### (1) Shifting from H4 to H2

When the 2-4 select SW is turned off, a signal is input to the 2-4 select motor from the 4WD ECU, activating the 2-4 select motor so that the transfer changes to 2WD (H2 position).

At this time, the detection SW (Transfer 4WD position) and ADD indicator SW are off, so the 4WD indicator light goes off.

#### (2) Shifting from H2 to H4 (During normal driving)

When the 2-4 select SW is turned on, a signal is input to the 2-4 select motor from the 4WD ECU, activating the 2-4 select motor so that the transfer changes to 4WD (H4 position)

#### (3) Shifting from H2 to H4 (High speed driving)

The vehicle speed within below approx. 100 km/h, 62 mph, activating the 2-4 select motor so that the transfer changes to 4WD (H4 position)

The 4WD ECU stops the signal to the 2-4 select motor with the signal from the vehicle speed sensor. At the same time, it causes the 4WD indicator light to light up and the warning buzzer inside the 4WD ECU to sound.

#### (4) Shifting to L4

When the transfer shift lever is moved to L4 position, the transfer changes to LO position. This turns the detection SW (Transfer L4 position) on, so regardless of whether the 2-4 select SW is on or off, a signal is input to the 2-4 select motor from the 4WD ECU, activating the 2-4 select motor so that the transfer changes to 4WD (L4 position) in LO condition.

## SERVICE HINTS

### F6 4WD ECU

12-GROUND : Approx. 12 volts with ignition SW at **ON** position

25-GROUND : Always continuity

3-GROUND : 4 pulses with 1 rotation

4-GROUND : 2 volts or less with 2-4 select SW on

18-GROUND : 2 volts or less with detection SW (Transfer L4 position) on and transfer shift lever at **L4** position

### T3 2-4 SELECT SW

1-2 : Closed with 2-4 select SW on

### P1 A/T INDICATOR SW [PARK/NEUTRAL POSITION SW]

3-1 : Closed with A/T shift lever at **P** position

## ○ : PARTS LOCATION

Code	See Page	Code	See Page	Code	See Page
A22	<a href="#">30 (5VZ-FE)</a>	D5	<a href="#">30 (5VZ-FE)</a>	R16	<a href="#">35</a>
A24	<a href="#">30 (5VZ-FE)</a>	D25	<a href="#">34</a>	T2	<a href="#">31 (5VZ-FE)</a>
C10	<a href="#">34</a>	E6	<a href="#">35</a>	T3	<a href="#">35</a>
C13	<a href="#">34</a>	F6	<a href="#">35</a>	V10	<a href="#">31 (5VZ-FE)</a>
D3	<a href="#">30 (5VZ-FE)</a>	J13	<a href="#">35</a>		
D4	<a href="#">30 (5VZ-FE)</a>	P1	<a href="#">31 (5VZ-FE)</a>		

## 4WD (w/ 2-4 SELECT SW)

### : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
1F	23	Cowl Wire and J/B No.1 (Lower Finish Panel)
1J		
3A	24	Cowl Wire and J/B No.3 (Behind the Instrument Panel Left)
3B		
3D		
3F		
3G	26	Cowl Wire and J/B No.3 (Behind the Instrument Panel Center)
3H		
3I		

### : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
EB3	40 (5VZ-FE)	Engine Wire and Differential Wire (Front Differential Upper Side)
IK2	44	Engine Wire and Cowl Wire (Above the Glove Box)
IK3		
IK6		

### : GROUND POINTS


Code	See Page	Ground Points Location
ID	44	Left Kick Panel
IE	44	Around the Right Edge of the Reinforcement
IG	44	Around the Left Edge of the Reinforcement

### : SPLICE POINTS

Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
I9	44	Cowl Wire	I13	44	Engine Wire
I12			I14	44	Cowl Wire




# 4WD (w/o 2-4 SELECT SW)





FROM POWER SOURCE SYSTEM (SEE PAGE 54)



# 4WD (w/o 2-4 SELECT SW)

## SERVICE HINTS

### P1 A/T INDICATOR SW [PARK/NEUTRAL POSITION SW]

3-1 : Closed with A/T shift position at **P** position

### D4 DETECTION SW (TRANSFER NEUTRAL POSITION)

1-2 : Closed with transfer position at **N** position

## ○ : PARTS LOCATION

Code	See Page	Code	See Page	Code	See Page
A22	30 (5VZ-FE)	D4	30 (5VZ-FE)	P1	31 (5VZ-FE)
	32 (3RZ-FE)		32 (3RZ-FE)		33 (3RZ-FE)
A24	30 (5VZ-FE)	D5	30 (5VZ-FE)	R16	35
	32 (3RZ-FE)		32 (3RZ-FE)	S10   A	35
C10	34	D25	34	S11   B	35
C13	34	E5   A	35	T4	35
D3	30 (5VZ-FE)	E6   B	35		
	32 (3RZ-FE)	J13	35		

## ○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
1F	23	Cowl Wire and J/B No.1 (Lower Finish Panel)
1J		
3A	24	Cowl Wire and J/B No.3 (Behind the Instrument Panel Left)
3D		
3F		
3H	26	Cowl Wire and J/B No.3 (Behind the Instrument Panel Center)
3I		

## □ : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
EB3	40 (5VZ-FE)	Engine Wire and Differential Wire (Front Differential Upper Side)
	42 (3RZ-FE)	
IK2	44	Engine Wire and Cowl Wire (Above the Glove Box)
IK3		
IK6		
IK7		

## ▽ : GROUND POINTS


Code	See Page	Ground Points Location
IE	44	Around the Right Edge of the Reinforcement
IG	44	Around the Left Edge of the Reinforcement

## ○ : SPLICE POINTS


Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
I9	44	Cowl Wire	I13	44	Engine Wire
I12			I14	44	Cowl Wire



# REAR DIFFERENTIAL LOCK



- \* 1 : W/ ABS OR 2-4 SELECT SW
- \* 2 : W/ ABS
- \* 3 : W/ 2-4 SELECT SW
- \* 4 : W/O ABS, W/O 2-4 SELECT SW
- \* 5 : EXCEPT REGULAR CAB
- \* 6 : REGULAR CAB



# REAR DIFFERENTIAL LOCK

## SYSTEM OUTLINE

This system frees or locks the rear differential according to the position of the rear diff. lock SW. The differential will lock only when the rear diff. lock detection SW is on and the vehicle speed is at 8 km/h (5 mph) or less.

When the rear diff. lock SW is switched from OFF position to ON position, current flows to TERMINAL 4 of the rear diff. lock ECU. If the limit SW on the lock side inside the rear diff. lock motor is on at this time, until the limit SW is turned off, current flows from the 4WD fuse to TERMINAL 5 of the rear diff. lock ECU to TERMINAL 3 to TERMINAL 3 of the rear diff. lock motor to TERMINAL 2 to TERMINAL 2 of the rear diff. lock ECU to TERMINAL 7 to GROUND. This drives the rear diff. lock motor and locks the rear differential. When the rear differential locks, the rear diff. lock detection SW turns on, lighting up the rear diff. lock indicator light in the combination meter.

When the rear diff. lock SW is switched from ON position to OFF position, the current to TERMINAL 4 of the rear diff. lock ECU is cut off. If the limit SW on the free side inside the rear diff. lock motor is on, until the limit SW is turned off, current flows from the 4WD fuse to TERMINAL 5 of the rear diff. lock ECU to TERMINAL 2 to TERMINAL 2 of the rear diff. lock motor to TERMINAL 3 to TERMINAL 3 of the rear diff. lock ECU to TERMINAL 7 to GROUND. This drives the rear diff. lock motor and frees the rear differential. When the rear differential is free, the rear diff. lock detection SW and the rear diff. lock indicator light in the combination meter are turned off.

The rear diff. lock indicator light flashes when:

- \* The rear diff. lock SW is switched to ON position during differential lock prohibition conditions (Vehicle speed above 8 km/h (5 mph) ).
- \* The rear diff. lock detection SW is turned off during operation of the rear diff. lock motor.

## SERVICE HINTS

### R15 REAR DIFF. LOCK SW

5-2 : Closed with the diff. lock SW at **ON** position

### R16 REAR DIFF. LOCK ECU

(Disconnected wiring connector from ECU)

7-GROUND : Always continuity

10-GROUND : Pulse generation with vehicle moving

5-GROUND : **9- 14** volts with the ignition SW on

1-GROUND : About **0** volts with the rear diff. lock indicator light on  
: **9- 14** volts with the rear diff. lock indicator light off

### R14 REAR DIFF. LOCK MOTOR

2-3 : **0.3- 100** Ω

## ○ : PARTS LOCATION

Code	See Page	Code	See Page	Code	See Page
A22	30 (5VZ-FE)	E5	A	35	R14
	32 (3RZ-FE)	E6	B	35	
C10	A	34	F6	35	R15
C13	D	34	J13	35	R16
D3	30 (5VZ-FE)	R13	36 (Double Cab)	V10	31 (5VZ-FE)
	32 (3RZ-FE)		37 (Except Double Cab)		33 (3RZ-FE)

## ○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
1F	23	Cowl Wire and J/B No.1 (Lower Finish Panel)
1J		
3B	24	Cowl Wire and J/B No.3 (Behind the Instrument Panel Left)
3D		
3F		
3G	26	Cowl Wire and J/B No.3 (Behind the Instrument Panel Center)
3H		
3I		

 : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IK2	44	Engine Wire and Cowl Wire (Above the Glove Box)
BN1	46 (Double Cab)	Frame Wire and Cowl Wire (Under the Driver's Seat)
	48 (Except Double Cab)	
BN6	46 (Double Cab)	
	48 (Except Double Cab)	
BO1	46 (Double Cab)	Frame Wire and Diff. Lock Wire (Rear Side Member LH)
	48 (Except Double Cab)	

 : GROUND POINTS

Code	See Page	Ground Points Location
ID	44	Left Kick Panel
IE	44	Around the Right Edge of the Reinforcement
IG	44	Around the Left Edge of the Reinforcement

 : SPLICE POINTS

Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
I9	44	Cowl Wire	B4	48 (Except Double Cab)	Frame Wire
I12			B5		
B4	46 (Double Cab)	Frame Wire			





**SERVICE HINTS**

**S4 SHIFT LOCK CONTROL RELAY**

- 1-GROUND : Approx. **12** volts with the ignition SW at **ACC** or **ON** position
- 3-GROUND : Approx. **12** volts with the ignition SW at **ON** position
- 7-GROUND : Always continuity
- 8-GROUND : Approx. **12** volts with the brake pedal depressed

 : **PARTS LOCATION**

Code	See Page	Code	See Page	Code	See Page
S4	35	S5	35	U1	35

 : **JUNCTION BLOCK AND WIRE HARNESS CONNECTOR**

Code	See Page	Junction Block and Wire Harness (Connector Location)
1F	23	Cowl Wire and J/B No.1 (Lower Finish Panel)
1G		
1H		
3A	24	Cowl Wire and J/B No.3 (Behind the Instrument Panel Left)
3F		
3G	26	Cowl Wire and J/B No.3 (Behind the Instrument Panel Center)


 : **GROUND POINTS**

Code	See Page	Ground Points Location
IE	44	Around the Right Edge of the Reinforcement
IG	44	Around the Left Edge of the Reinforcement


 : **SPLICE POINTS**

Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
I9	44	Cowl Wire	I12	44	Cowl Wire

# DOOR LOCK CONTROL



- \* 1 : DOUBLE CAB
- \* 2 : EXCEPT DOUBLE CAB
- \* 3 : EXCEPT 5VZ-FE



# DOOR LOCK CONTROL

## SYSTEM OUTLINE

Current always flows to TERMINAL 3 of the body ECU through the POWER fuse.

### 1. MANUAL LOCK OPERATION

To push the door lock control SW or door key lock and unlock SW to LOCK position, a lock signal is input to the body ECU and causes the ECU to function. Current flows from TERMINAL 3 of the ECU to TERMINAL 14 to TERMINALS 3 (Front LH), 2 (Front RH, rear) of the door lock motors to TERMINALS 7 (Front LH), 6 (Front RH), 1 (Rear) to TERMINAL 15 of the ECU to TERMINAL 8 to GROUND and the door lock motor causes the door to lock.

### 2. MANUAL UNLOCK OPERATION

To push the door lock control SW or door key lock and unlock SW to UNLOCK position, an unlock signal is input to the body ECU and causes the ECU to function. Current flows from TERMINAL 3 of the ECU to TERMINAL 15 to TERMINALS 7 (Front LH), 6 (Front RH), 1 (Rear) of the door lock motors to TERMINALS 3 (Front LH), 2 (Front RH, rear) to TERMINAL 14 of the ECU to TERMINAL 8 to GROUND and the door lock motor causes the door to unlock.

### 3. IGNITION KEY REMINDER OPERATION

\* Operating door lock knob (in door lock motor operation)

With ignition key in cylinder (Unlock warning SW on), when any door is opened and locked using door lock knob (Door lock motor), all doors are locked once but each door is unlocked soon by the function of the body ECU. As a result, current flows from TERMINAL 3 of the ECU to TERMINAL 15 to TERMINALS 7 (Front LH), 6 (Front RH), 1 (Rear) of the door lock motors to TERMINALS 3 (LH), 2 (Front RH, rear) to TERMINAL 14 of the ECU to TERMINAL 8 to GROUND and causes all the doors to unlock.

\* Operating door lock control SW or door key lock and unlock SW

With ignition key in cylinder (Unlock warning SW on), when any door is opened and locked using the door lock control SW or door key lock and unlock SW, all doors are locked once but each door is unlocked by the function of the SW contained in motor, which inputs the signal to the body ECU. According to this input signal, current flows from TERMINAL 3 of the ECU to TERMINAL 15 to TERMINALS 7 (Front LH), 6 (Front RH), 1 (Rear) of the door lock motors to TERMINALS 3 (Front LH), 2 (Front RH, rear) to TERMINAL 14 of the ECU to TERMINAL 8 to GROUND and causes all the doors to unlock.

## SERVICE HINTS

### BODY ECU

8-GROUND : Always continuity.

3, 4-GROUND : Always approx. 12 volts

15-GROUND : Approx. 12 volts for 0.2 seconds with following operations.

\* Door lock control SW unlocked.

\* Door lock control SW locked with ignition key in cylinder and LH door open.

(Ignition key reminder function)

\* Door lock knob locked with ignition key in cylinder and LH door open. (Ignition key reminder function)

\* Unlocking the LH, RH door cylinder with key.

14-GROUND : Approx. 12 volts for 0.2 seconds with following operations.

\* Door lock control SW locked.

\* Locking the LH, RH door cylinder with key.

### D15, D16, D26, D27 DOOR COURTESY SW FRONT REAR LH, RH

1-GROUND : Closed with door open.

### D21, D22 DOOR LOCK MOTOR, DOOR UNLOCK DETECTION SW AND DOOR KEY LOCK AND UNLOCK SW LH, RH

4-8 (LH), 1-5 (RH) : Closed with UNLOCK position.

### U1 (A), (B) UNLOCK WARNING SW

(A) 1-(A) 2, (B) 1-(B) 2 : Closed with key in cylinder.

## ○ : PARTS LOCATION

Code	See Page	Code	See Page	Code	See Page
D15	34	D22	36 (Double Cab)	P7	A 36 (Double Cab)
D16	34		37 (Except Double Cab)		B 37 (Except Double Cab)
D20	36 (Double Cab)	D26	36 (Double Cab)	U1	A 35
	37 (Except Double Cab)	D27	36 (Double Cab)		B 35
D21	36 (Double Cab)	D28	36 (Double Cab)		
	37 (Except Double Cab)	D29	36 (Double Cab)		

 : RELAY BLOCKS

Code	See Page	Relay Blocks (Relay Block Location)
2	21	R/B No.2 (Engine Compartment Left)

 : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
1E	23	Engine Room Main Wire and J/B No.1 (Lower Finish Panel)
1H	23	Cowl Wire and J/B No.1 (Lower Finish Panel)
1J		
1L		
3B	24	Cowl Wire and J/B No.3 (Behind the Instrument Panel Left)
3E		
3F		

 : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IH2	44	Front Door LH Wire and Cowl Wire (Left Kick Panel)
IL2	44	Front Door RH Wire and Cowl Wire (Right Kick Panel)
BQ1	46 (Double Cab)	Rear Door No.2 Wire and Cowl Wire (Under the Left Center Pillar)
BR1	46 (Double Cab)	Rear Door No.1 Wire and Cowl Wire (Under the Right Center Pillar)


 : GROUND POINTS

Code	See Page	Ground Points Location
IE	44	Around the Right Edge of the Reinforcement
IG	44	Around the Left Edge of the Reinforcement


 : SPLICE POINTS

Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
I1	44	Cowl Wire	I18	44	Cowl Wire
I2			B2	46 (Double Cab)	Front Door LH Wire
I3				48 (Except Double Cab)	
I5			B3	46 (Double Cab)	Front Door RH Wire
I7				48 (Except Double Cab)	
I9					

# POWER WINDOW



\* 1 : DOUBLE CAB  
 \* 2 : EXCEPT DOUBLE CAB



# POWER WINDOW

## SYSTEM OUTLINE

With the ignition SW turned on, current flows through the ECU-IG fuse to TERMINAL 10 of the body ECU to TERMINAL 2 to TERMINAL 1 of the PWR relay to TERMINAL 2 to GROUND, activating the PWR relay, and the current flowing from TERMINAL 5 of the PWR relay flows to TERMINAL 3 to TERMINAL (A) 10 (Double cab), (B) 9 (Except double cab) of the power window master SW and TERMINAL 4 (Front RH), 3 (Rear) of the power window control SW.

### 1. MANUAL OPERATION (DRIVER'S WINDOW)

With the ignition SW turned on and with the power window master SW (Manual SW) in UP position, the current flowing to TERMINAL (A) 10 (Double cab), (B) 9 (Except double cab) of the power window master SW flows to TERMINAL (A) 1 (Double cab), (B) 3 (Except double cab) to TERMINAL 1 of the power window motor LH to TERMINAL 2 to TERMINAL (A) 5 (Double cab), (B) 4 (Except double cab) of the master SW to TERMINAL (A) 3 (Double cab), (B) 1 (Except double cab) to GROUND and causes the power window motor to rotate in the up direction. The window ascends only while the SW is being pushed.

In down operation, the current flowing from TERMINAL (A) 10 (Double cab), (B) 9 (Except double cab) of the power window master SW to TERMINAL (A) 5 (Double cab), (B) 4 (Except double cab) flows to TERMINAL 2 of the motor LH to TERMINAL 1 to TERMINAL (A) 1 (Double cab), (B) 3 (Except double cab) of the master SW to TERMINAL (A) 3 (Double cab), (B) 1 (Except double cab) to GROUND, flowing in the opposite direction to manual up operation, causing the motor to rotate in reverse and lowering the window.

### 2. AUTO DOWN OPERATION (DRIVER'S WINDOW)

With the ignition SW on and with the auto SW of the power window master SW in DOWN position, the current flowing to TERMINAL (A) 10 (Double cab), (B) 9 (Except double cab) of the master SW flows to TERMINAL (A) 5 (Double cab), (B) 4 (Except double cab) of the master SW to TERMINAL 2 of the power window motor LH to TERMINAL 1 to TERMINAL (A) 1 (Double cab), (B) 3 (Except double cab) of the master SW to TERMINAL (A) 3 (Double cab), (B) 1 (Except double cab) to GROUND, causing the motor to rotate towards the down side.

Then the solenoid in the master SW is activated and it locks the auto SW being pushed, causing the motor to continue to rotate in auto down operation.

When the window has completely descended, the current flowing between TERMINAL (A) 1 (Double cab), (B) 3 (Except double cab) of the master SW and TERMINAL (A) 3 (Double cab), (B) 1 (Except double cab) increases. As a result, the solenoid stops operating, the auto SW turns off and the flowing from TERMINAL (A) 10 (Double cab), (B) 9 (Except double cab) of the master SW to TERMINAL (A) 5 (Double cab), (B) 4 (Except double cab) is cut off, stopping the motor so that auto stop occurs.

### 3. STOPPING OF AUTO DOWN AT DRIVER'S WINDOW

When the manual SW (Driver's) is pushed to the up side during auto down operation, a ground circuit opens in the master SW and current does not flow from TERMINAL (A) 1 (Double cab), (B) 3 (Except double cab) of the master SW to TERMINAL (A) 3 (Double cab), (B) 1 (Except double cab), so the motor stops, causing auto down operation to stop. If the manual SW is pushed continuously, the motor rotates in the up direction in manual up operation.

### 4. MANUAL OPERATION BY POWER WINDOW CONTROL SW (FRONT RH WINDOW)

With the power window control SW front RH is pushed to the up side, the current flowing from TERMINAL 4 of the power window control SW front RH flows to TERMINAL 3 to TERMINAL 2 of the power window motor front RH to TERMINAL 1 to TERMINAL 1 of the power window control SW front RH to TERMINAL 2 to TERMINAL (A) 6 (Double cab), (B) 10 (Except double cab) of the master SW to TERMINAL (A) 3 (Double cab), (B) 1 (Except double cab) to GROUND. This causes the power window motor front RH to rotate in the up direction. Up operation is continuous only while the power window control SW RH is pushed to the up side. When the window descends, the current flowing to the motor flows in the opposite direction, from TERMINAL 1 to TERMINAL 2, and the motor rotates in reverse.

When the window lock SW is pushed to the lock side, the ground circuit to the front RH window becomes open. As a result, even if Open/Close operation of the front RH window is tried, the current from TERMINAL (A) 3 (Double cab), (B) 1 (Except double cab) of the power window master SW is not grounded and the motor does not rotate, so the front RH window can not be operated and window lock occurs.

### 5. MANUAL OPERATION (REAR LH, RH WINDOW) [DOUBLE CAB]

With the power window control SW rear LH, RH pulled to the up side, the current flowing from TERMINAL 3 of the power window control SW flows to TERMINAL 1 to TERMINAL 1 of the power window motor to TERMINAL 2 to TERMINAL 5 of the power window control SW to TERMINAL 4 to TERMINAL (A) 12 (LH) or (A) 13 (RH) of the master SW to TERMINAL (A) 3 (Double cab), (B) 1 (Except double cab) to GROUND and causes the power window motor rear LH, RH to rotate in the up direction. The up operation continues only while the power window control SW is pulled to the up side. When the window descends, the current flowing to the motor flows in the opposite direction, from TERMINAL 1 to TERMINAL 2, and the motor rotates in reverse. When the window lock SW is pushed to the lock side, the ground circuit to the rear LH, RH window becomes open.

As a result, even if Open/Close operation of the rear LH, RH window is tried, the current from TERMINAL (A) 3 (Double cab), (B) 1 (Except double cab) of the power window master SW is not grounded and the motor does not rotate, so the rear LH, RH window can not be operated and window lock occurs.



## 6. KEY OFF POWER WINDOW OPERATION

With the ignition SW turned from on to off, the body ECU operates for about 45 seconds and current flows from TERMINAL 1 of the PWR relay to TERMINAL 2 to GROUND. For this period, current also flows TERMINAL 5 to TERMINAL 3. This current flows to TERMINAL (A) 10 (Double cab), (B) 9 (Except double cab) of the power window master SW and to TERMINAL 4 (Front RH), 3 (Rear) of the power window control SW. As a result, for about 45 seconds after the ignition SW is turned off, it is possible to raise and lower the power window by the functioning of the body ECU. Also, by opening the door (Door courtesy SW on) within about 45 seconds after turning the ignition SW to off, a signal is input to the body ECU. As a result, the body ECU turns off, and up and down movement of the window stops.

### SERVICE HINTS

#### D15, D16 DOOR COURTESY SW LH, RH

1-GROUND : Continuity with door open

#### BODY ECU

10-GROUND : Approx. **12** volts with ignition SW at **ON** position

3, 4-GROUND : Always approx. **12** volts

#### P7 POWER WINDOW MASTER SW

(A) 3, (B) 1-GROUND : Always continuity

(A) 10, (B) 9-GROUND : Approx. **12** volts with ignition SW on and stays at **12** volts for **45** seconds after the ignition SW is turned off, but if a door is opened in this **45** seconds period, voltage will drop to **0** volts

(A) 1, (B) 3-GROUND : Approx. **12** volts with ignition SW at **ON** position and master SW at **UP** position

(A) 5, (B) 4-GROUND : Approx. **12** volts with ignition SW at **ON** position and master SW at **DOWN** or **AUTO DOWN** position

#### WINDOW LOCK SW

Open with window lock SW at **LOCK** position

### ○ : PARTS LOCATION

Code	See Page	Code	See Page	Code	See Page
D15	<a href="#">34</a>	P7	<a href="#">37 (Except Double Cab)</a>	P25	<a href="#">36 (Double Cab)</a>
D16	<a href="#">34</a>	P8	<a href="#">36 (Double Cab)</a>	P26	<a href="#">36 (Double Cab)</a>
P6	<a href="#">36 (Double Cab)</a>		<a href="#">37 (Except Double Cab)</a>	P27	<a href="#">36 (Double Cab)</a>
	<a href="#">37 (Except Double Cab)</a>	P9	<a href="#">36 (Double Cab)</a>	P28	<a href="#">36 (Double Cab)</a>
P7	A		<a href="#">36 (Double Cab)</a>		

### ○ : RELAY BLOCKS

Code	See Page	Relay Blocks (Relay Block Location)
2	<a href="#">21</a>	R/B No.2 (Engine Compartment Left)

### ○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
1C	<a href="#">23</a>	Cowl Wire and J/B No.1 (Lower Finish Panel)
1E	<a href="#">23</a>	Engine Room Main Wire and J/B No.1 (Lower Finish Panel)
1J	<a href="#">23</a>	Cowl Wire and J/B No.1 (Lower Finish Panel)
1L	<a href="#">22</a>	
3B	<a href="#">24</a>	Cowl Wire and J/B No.3 (Behind the Instrument Panel Left)

### □ : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IH2	<a href="#">44</a>	Front Door LH Wire and Cowl Wire (Left Kick Panel)
IH3		
IL2	<a href="#">44</a>	Front Door RH Wire and Cowl Wire (Right Kick Panel)
BQ1	<a href="#">46 (Double Cab)</a>	Rear Door No.2 Wire and Cowl Wire (Under the Left Center Pillar)
BR1	<a href="#">46 (Double Cab)</a>	Rear Door No.1 Wire and Cowl Wire (Under the Right Center Pillar)

# POWER WINDOW

---



## : GROUND POINTS

Code	See Page	Ground Points Location
IE	<a href="#">44</a>	Around the Right Edge of the Reinforcement
IG	<a href="#">44</a>	Around the Left Edge of the Reinforcement



## : SPLICE POINTS


Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
I9	<a href="#">44</a>	Cowl Wire	I18	<a href="#">44</a>	Cowl Wire



# REMOTE CONTROL MIRROR (w/ POWER WINDOW)

FROM POWER SOURCE SYSTEM (SEE PAGE 54)

\* 1 : DOUBLE CAB  
\* 2 : EXCEPT DOUBLE CAB



**SERVICE HINTS****R10 REMOTE CONTROL MIRROR SW**

- 8-GROUND : Approx. **12** volts with ignition SW at **ACC** or **ON** position  
 6-7 : Continuity with operation SW at **UP** or **LEFT** position  
 8-6 : Continuity with operation SW at **DOWN** or **RIGHT** position

**○ : PARTS LOCATION**

Code	See Page	Code	See Page	Code	See Page
R8	<a href="#">36 (Double Cab)</a>	R9	<a href="#">36 (Double Cab)</a>	R10	<a href="#">36 (Double Cab)</a>
	<a href="#">37 (Except Double Cab)</a>		<a href="#">37 (Except Double Cab)</a>		<a href="#">37 (Except Double Cab)</a>

**○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR**

Code	See Page	Junction Block and Wire Harness (Connector Location)
1G	<a href="#">23</a>	Cowl Wire and J/B No.1 (Lower Finish Panel)
3B	<a href="#">24</a>	Cowl Wire and J/B No.3 (Behind the Instrument Panel Left)
3G	<a href="#">26</a>	Cowl Wire and J/B No.3 (Behind the Instrument Panel Center)

**□ : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS**

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IH1	<a href="#">44</a>	Front Door LH Wire and Cowl Wire (Left Kick Panel)
IH2		
IH3		
IL1	<a href="#">44</a>	Front Door RH Wire and Cowl Wire (Right Kick Panel)


**▽ : GROUND POINTS**

Code	See Page	Ground Points Location
IE	<a href="#">44</a>	Around the Right Edge of the Reinforcement
IG	<a href="#">44</a>	Around the Left Edge of the Reinforcement

**○ : SPLICE POINTS**

Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
I9	<a href="#">44</a>	Cowl Wire	I20	<a href="#">44</a>	Front Door LH Wire

# REMOTE CONTROL MIRROR (w/o POWER WINDOW)



## SERVICE HINTS

### R10 REMOTE CONTROL MIRROR SW

- 8-GROUND : Approx. **12** volts with ignition SW at **ACC** or **ON** position
- 6-7 : Continuity with operation SW at **UP** or **LEFT** position
- 8-6 : Continuity with operation SW at **DOWN** or **RIGHT** position

### : PARTS LOCATION

Code	See Page	Code	See Page	Code	See Page
R8	<a href="#">36 (Double Cab)</a>	R9	<a href="#">36 (Double Cab)</a>	R10	<a href="#">36 (Double Cab)</a>
	<a href="#">37 (Except Double Cab)</a>		<a href="#">37 (Except Double Cab)</a>		<a href="#">37 (Except Double Cab)</a>

### : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
1G	<a href="#">23</a>	Cowl Wire and J/B No.1 (Lower Finish Panel)
3B	<a href="#">24</a>	Cowl Wire and J/B No.3 (Behind the Instrument Panel Left)
3G	<a href="#">26</a>	Cowl Wire and J/B No.3 (Behind the Instrument Panel Center)

### : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IH1	<a href="#">44</a>	Front Door LH Wire and Cowl Wire (Left Kick Panel)
IL1	<a href="#">44</a>	Front Door RH Wire and Cowl Wire (Right Kick Panel)

### : GROUND POINTS

Code	See Page	Ground Points Location
IE	<a href="#">44</a>	Around the Right Edge of the Reinforcement
IG	<a href="#">44</a>	Around the Left Edge of the Reinforcement


### : SPLICE POINTS

Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
I9	<a href="#">44</a>	Cowl Wire	I20	<a href="#">44</a>	Front Door LH Wire

# WIPER AND WASHER (w/ INT TIME SW MECHANISM)

FROM POWER SOURCE SYSTEM (SEE PAGE 54)

C15  
WIPER AND WASHER SW [COMB. SW]





## SYSTEM OUTLINE

With the ignition SW turned on, current flows to TERMINAL 17 of the wiper and washer SW, TERMINAL 2 of the washer motor and TERMINAL 2 of the wiper motor through the WIPER fuse.

### 1. LOW SPEED POSITION

With wiper SW turned to LOW position, current flows from TERMINAL 17 of the wiper and washer SW to TERMINAL 7 to TERMINAL 5 of the wiper motor to TERMINAL 4 to GROUND and causes the wiper motor to run at low speed.

### 2. HIGH SPEED POSITION

With wiper SW turned to HIGH position, current flows from TERMINAL 17 of the wiper and washer SW to TERMINAL 8 to TERMINAL 3 of the wiper motor to TERMINAL 4 to GROUND and causes the motor to run at high speed.

### 3. INT POSITION

With wiper SW turned to INT position, the relay operates and the current which is connected by relay function flows from TERMINAL 17 of the wiper and washer SW to TERMINAL 2 to GROUND. This flowing the intermittent circuit and current flows from TERMINAL 17 of the wiper and washer SW to TERMINAL 7 to TERMINAL 5 of the wiper motor to TERMINAL 4 to GROUND and the wiper functions.

The intermittent operation is controlled by charging and discharging of the condenser installed in the relay and the intermittent time is controlled by a time control SW to change the charging time of the condenser.

### 4. WASHER CONTINUOUS OPERATION

With the washer SW turned to on, current flows from TERMINAL 2 of the washer motor to TERMINAL 1 to TERMINAL 11 of the wiper and washer SW to TERMINAL 2 to GROUND and causes to the washer motor to run, and the window washer is jetted.

This causes current to flow to washer continuous operation circuit in TERMINAL 17 of the wiper and washer SW to TERMINAL 7 to TERMINAL 5 of the wiper motor to TERMINAL 4 to GROUND and the wiper functions.

## SERVICE HINTS

### C15 WIPER AND WASHER SW [COMB. SW]

2-GROUND : Always continuity

17-GROUND : Approx. 12 volts with ignition SW at **ON** position

7-GROUND : Approx. 12 volts with wiper and washer SW at **LOW** position

Approx. 12 volts every 3 to 12 seconds intermittently with wiper SW at **INT** position

16-GROUND : Approx. 12 volts with ignition SW on unless wiper motor at **STOP** position

8-GROUND : Approx. 12 volts with ignition SW on and wiper and washer SW at **HIGH** position

11-2 : Continuity with washer SW on

### W3 WIPER MOTOR

1-2 : Closed unless wiper motor at **STOP** position

## ○ : PARTS LOCATION

Code	See Page	Code	See Page	Code	See Page
C15	34	W1	33 (3RZ-FE, 2RZ-FE)	W3	33 (3RZ-FE, 2RZ-FE)
W1	31 (5VZ-FE)	W3	31 (5VZ-FE)		

## ○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
1G	23	Cowl Wire and J/B No.1 (Lower Finish Panel)
3D	24	Cowl Wire and J/B No.3 (Behind the Instrument Panel Left)
3F		

## ▽ : GROUND POINTS


Code	See Page	Ground Points Location
IE	44	Around the Right Edge of the Reinforcement
IG	44	Around the Left Edge of the Reinforcement

## ○ : SPLICE POINTS

Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
I9	44	Cowl Wire	I16	44	Cowl Wire

# WIPER AND WASHER (w/o INT TIME SW MECHANISM)

FROM POWER SOURCE SYSTEM (SEE PAGE 54)



## SYSTEM OUTLINE

With the ignition SW turned on, current flows to TERMINAL 17 of the wiper and washer SW, TERMINAL 2 of the washer motor and TERMINAL 2 of the wiper motor through the WIPER fuse.

### 1. LOW SPEED POSITION

With wiper SW turned to LOW position, current flows from TERMINAL 17 of the wiper and washer SW to TERMINAL 7 to TERMINAL 5 of the wiper motor to TERMINAL 4 to GROUND and causes the wiper motor to run at low speed.

### 2. HIGH SPEED POSITION

With wiper SW turned to HIGH position, current flows from TERMINAL 17 of the wiper and washer SW to TERMINAL 8 to TERMINAL 3 of the wiper motor to TERMINAL 4 to GROUND and causes the motor to run at high speed.

### 3. MIST POSITION

With the wiper SW turned to MIST position, current flows from TERMINAL 17 of the wiper and washer SW to TERMINAL 7 to TERMINAL 5 of the wiper motor to TERMINAL 4 to GROUND and causes the wiper motor to run at low speed.

### 4. WASHER CONTINUOUS OPERATION

With the washer SW turned to on, current flows from TERMINAL 2 of the washer motor to TERMINAL 1 to TERMINAL 11 of the wiper and washer SW to TERMINAL 2 to GROUND and causes the washer motor to run, and the window washer is jetted.

## SERVICE HINTS

### C15 WIPER AND WASHER SW [COMB. SW]

2-GROUND : Always continuity

17-GROUND : Approx. **12** volts with ignition SW at **ON** position

7-GROUND : Approx. **12** volts with wiper and washer SW at **LOW** or **MIST** position

16-GROUND : Approx. **12** volts with ignition SW on unless wiper motor at **STOP** position

8-GROUND : Approx. **12** volts with ignition SW on and wiper and washer SW at **HIGH** position

11-2 : Continuity with washer SW on

### W3 WIPER MOTOR

1-2 : Closed unless wiper motor at **STOP** position

## ○ : PARTS LOCATION

Code	See Page	Code	See Page	Code	See Page
C15	<a href="#">34</a>	W1	<a href="#">33 (3RZ-FE, 2RZ-FE)</a>	W3	<a href="#">33 (3RZ-FE, 2RZ-FE)</a>
W1	<a href="#">31 (5VZ-FE)</a>	W3	<a href="#">31 (5VZ-FE)</a>		

## ○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
1G	<a href="#">23</a>	Cowl Wire and J/B No.1 (Lower Finish Panel)
3D	<a href="#">24</a>	Cowl Wire and J/B No.3 (Behind the Instrument Panel Left)
3F		


## ▽ : GROUND POINTS

Code	See Page	Ground Points Location
IE	<a href="#">44</a>	Around the Right Edge of the Reinforcement
IG	<a href="#">44</a>	Around the Left Edge of the Reinforcement

## ○ : SPLICE POINTS

Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
I9	<a href="#">44</a>	Cowl Wire	I16	<a href="#">44</a>	Cowl Wire

# KEY REMINDER AND SEAT BELT WARNING



## SYSTEM OUTLINE

Current always flows to TERMINAL 4 of the body ECU through the DOME fuse.

### 1. SEAT BELT WARNING SYSTEM

When the ignition SW is turned on, current flows from the ECU-IG fuse to TERMINAL 10 of the body ECU. At the same time, current flows to the ECU from the GAUGE fuse through the seat belt warning light. This current activates the body ECU and, for approx. 4-8 seconds, the current flowing through the warning light flows from ECU to TERMINAL 8 to GROUND, causing the warning light to light up. At the same time as the warning light lights up, a buckle SW LH on signal is input to the body ECU, the current flowing from TERMINAL 4 of the body ECU flows to TERMINAL 8 to GROUND and the seat belt warning buzzer sounds for approx. 4-8 seconds. However, if the seat belt is put on (Buckle SW LH off) during this period (While the buzzer is sounding), a signal input to the body ECU stops and the current flowing from TERMINAL 4 of the body ECU to TERMINAL 8 to GROUND is cut, causing the buzzer to stop.

### 2. KEY REMINDER SYSTEM

With the ignition key inserted in the key cylinder (Unlock warning SW on), the ignition SW still off and front LH door open (Door courtesy SW on), a signal is input to the body ECU, the body ECU operates and current flows from TERMINAL 10 of the ECU to TERMINAL 8 to GROUND and the key reminder buzzer sounds.

## SERVICE HINTS

### B6 BUCKLE SW LH

1-2 : Open with driver's seat belt in use

### D15 DOOR COURTESY SW FRONT LH

1-GROUND : Closed with LH door open

### BODY ECU

10-GROUND : Approx. 12 volts with ignition SW on

4-GROUND : Always approx. 12 volts

8-GROUND : Always continuity

## ○ : PARTS LOCATION

Code	See Page	Code	See Page	Code	See Page
B6	<a href="#">36 (Double Cab)</a>	C13 D	<a href="#">34</a>	U1 B	<a href="#">35</a>
	<a href="#">37 (Except Double Cab)</a>	D15	<a href="#">34</a>		
C12 C	<a href="#">34</a>	U1 A	<a href="#">35</a>		

## ○ : RELAY BLOCKS

Code	See Page	Relay Blocks (Relay Block Location)
2	<a href="#">21</a>	R/B No.2 (Engine Compartment Left)

## ○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
1E	<a href="#">23</a>	Engine Room Main Wire and J/B No.1 (Lower Finish Panel)
1F	<a href="#">23</a>	Cowl Wire and J/B No.1 (Lower Finish Panel)
1J		
1L		
3A	<a href="#">24</a>	Cowl Wire and J/B No.3 (Behind the Instrument Panel Left)
3D		
3F		


## ▽ : GROUND POINTS

Code	See Page	Ground Points Location
IE	<a href="#">44</a>	Around the Right Edge of the Reinforcement
IG	<a href="#">44</a>	Around the Left Edge of the Reinforcement

## ○ : SPLICE POINTS

Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
I9	<a href="#">44</a>	Cowl Wire			

# POWER OUTLET



**SERVICE HINTS****P13, P14 POWER OUTLET**2-GROUND : Approx. 12 volts with the ignition SW at **ACC** or **ON** position

1-GROUND : Always continuity

 : **PARTS LOCATION**

Code		See Page	Code		See Page	Code		See Page
J9	A	<a href="#">31 (5VZ-FE)</a>	J10	B	<a href="#">33 (3RZ-FE, 2RZ-FE)</a>	P14	<a href="#">35</a>	
		<a href="#">33 (3RZ-FE, 2RZ-FE)</a>			J11			<a href="#">35</a>
J10	B	<a href="#">31 (5VZ-FE)</a>	P13		<a href="#">35</a>			

 : **RELAY BLOCKS**

Code	See Page	Relay Blocks (Relay Block Location)
2	<a href="#">21</a>	R/B No.2 (Engine Compartment Left)

 : **JUNCTION BLOCK AND WIRE HARNESS CONNECTOR**

Code	See Page	Junction Block and Wire Harness (Connector Location)
1G	<a href="#">23</a>	Cowl Wire and J/B No.1 (Lower Finish Panel)

 : **CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS**

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IF1	<a href="#">44</a>	Engine Room Main Wire and Cowl Wire (Left Kick Panel)


 : **GROUND POINTS**

Code	See Page	Ground Points Location
EA	<a href="#">40 (5VZ-FE)</a>	Front Left Fender
	<a href="#">42 (3RZ-FE, 2RZ-FE)</a>	
IE	<a href="#">44</a>	Around the Right Edge of the Reinforcement
IG	<a href="#">44</a>	Around the Left Edge of the Reinforcement

 : **SPLICE POINTS**

Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
I12	<a href="#">44</a>	Cowl Wire			

# CIGARETTE LIGHTER AND CLOCK





## SERVICE HINTS

### C4 CIGARETTE LIGHTER

2-GROUND : Approx. **12** volts with ignition SW at **ON** and **ACC** position

1-GROUND : Always continuity

### C7 CLOCK

1-GROUND : Always approx. **12** volts (Power for clock)

4-GROUND : Approx. **12** volts with ignition SW at **ON** or **ACC** position (Power for indication)

3-GROUND : Approx. **12** volts with light control SW at **TAIL** or **HEAD** position (Signal of indication)

2-GROUND : Always continuity

### ○ : PARTS LOCATION

Code	See Page	Code	See Page	Code	See Page
C4	34	C7	34		

### ○ : RELAY BLOCKS

Code	See Page	Relay Blocks (Relay Block Location)
2	21	R/B No.2 (Engine Compartment Left)

### ○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
1E	23	Engine Room Main Wire and J/B No.1 (Lower Finish Panel)
1F		
1G	23	Cowl Wire and J/B No.1 (Lower Finish Panel)
1H		
3C	24	Cowl Wire and J/B No.3 (Behind the Instrument Panel Left)
3F		
3G	26	Cowl Wire and J/B No.3 (Behind the Instrument Panel Center)

### ▽ : GROUND POINTS


Code	See Page	Ground Points Location
IE	44	Around the Right Edge of the Reinforcement
IG	44	Around the Left Edge of the Reinforcement

### ○ : SPLICE POINTS

Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
I9	44	Cowl Wire	I12	44	Cowl Wire

# POWER SEAT

FROM POWER SOURCE SYSTEM (SEE PAGE 54)



**SERVICE HINTS****P24 POWER SEAT SW (LUMBAR SUPPORT)**

1-GROUND : Always approx. 12 volts

2-GROUND : Always continuity

 : PARTS LOCATION

Code	See Page	Code	See Page	Code	See Page
P23	38	P24	38		

 : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
1C	23	Cowl Wire and J/B No.1 (Lower Finish Panel)

 : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
BU1	50	Cowl Wire and Seat No.1 Wire (Under the Driver's Seat)

 : GROUND POINTS


Code	See Page	Ground Points Location
IE	44	Around the Right Edge of the Reinforcement
IG	44	Around the Left Edge of the Reinforcement


 : SPLICE POINTS

Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
I5	44	Cowl Wire			

# RADIO AND PLAYER

FROM POWER SOURCE SYSTEM (SEE PAGE 54)





# RADIO AND PLAYER

## SERVICE HINTS

### R1 (A) RADIO AND PLAYER

- (A) 3-GROUND : Approx. 12 volts with ignition SW at **ON** or **ACC** position
- (A) 4-GROUND : Always approx. 12 volts
- (A) 7-GROUND : Always continuity

## ○ : PARTS LOCATION

Code	See Page	Code	See Page	Code	See Page
R1	A	35	S7	37 (Except Double Cab)	T5
R2	B	35	S8	36 (Double Cab)	
S6		36 (Double Cab)		37 (Except Double Cab)	T6
		37 (Except Double Cab)	36 (Double Cab)	37 (Except Double Cab)	
S7		36 (Double Cab)	S9	37 (Except Double Cab)	

## ○ : RELAY BLOCKS

Code	See Page	Relay Blocks (Relay Block Location)
2	21	R/B No.2 (Engine Compartment Left)

## ○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
1E	23	Engine Room Main Wire and J/B No.1 (Lower Finish Panel)
1G	23	Cowl Wire and J/B No.1 (Lower Finish Panel)
1H		
3C	24	Cowl Wire and J/B No.3 (Behind the Instrument Panel Left)
3H	26	Cowl Wire and J/B No.3 (Behind the Instrument Panel Center)

## □ : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS


Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IH1	44	Front Door LH Wire and Cowl Wire (Left Kick Panel)
IH3		
IL1	44	Front Door RH Wire and Cowl Wire (Right Kick Panel)
BQ1	46 (Double Cab)	Rear Door No.2 Wire and Cowl Wire (Under the Left Center Pillar)
BQ2		
BR1	46 (Double Cab)	Rear Door No.1 Wire and Cowl Wire (Under the Right Center Pillar)
BR2		
BS1	48 (Except Double Cab)	Rear Speaker LH Wire and Cowl Wire (Under the Left Center Pillar)
BT1	48 (Except Double Cab)	Rear Speaker RH Wire and Cowl Wire (Under the Right Center Pillar)

## ▽ : GROUND POINTS

Code	See Page	Ground Points Location
IH	44	Right Kick Panel




# COMBINATION METER (w/ TACHOMETER)






- \* 1 : W/ CRUISE CONTROL
- \* 2 : 5VZ- FE
- \* 3 : 3RZ- FE, 2RZ- FE




# COMBINATION METER (w/ TACHOMETER)



- \* 4 : COLD AREA SPEC.
- \* 5 : W/ DAYTIME RUNNING LIGHT
- \* 6 : W/O DAYTIME RUNNING LIGHT
- \* 7 : W/ 2-4 SELECT SW
- \* 8 : W/O 2-4 SELECT SW W/ ADD
- \* 9 : W/O 2-4 SELECT SW W/O ADD

FROM POWER SOURCE SYSTEM (SEE PAGE 54)



# COMBINATION METER (w/ TACHOMETER)

## SERVICE HINTS

### B2 BRAKE FLUID LEVEL WARNING SW

1-2 : Closed with float down

### C10 (A), C12 (C), C13 (D) COMBINATION METER

(A) 5, (D)1-GROUND : Approx. 12 volts with ignition SW on

(A) 7, (C) 1, (D)12-GROUND : Always continuity

### P4 PARKING BRAKE SW

1-2 : Closed with parking brake lever pulled up

## ○ : PARTS LOCATION

Code	See Page	Code	See Page	Code	See Page	
B2	30 (5VZ-FE)	F8	37 (Except Double Cab)	P4	35	
	32 (3RZ-FE, 2RZ-FE)		J9		A	31 (5VZ-FE)
C10	A	34		J10		B
C12	C	34	W1		31 (5VZ-FE)	
C13	D	34		33 (3RZ-FE, 2RZ-FE)	33 (3RZ-FE, 2RZ-FE)	
D8	34	O2	31 (5VZ-FE)	W2	A	31 (5VZ-FE)
F8	36 (Double Cab)		33 (3RZ-FE, 2RZ-FE)		B	33 (3RZ-FE, 2RZ-FE)

## ○ : RELAY BLOCKS

Code	See Page	Relay Blocks (Relay Block Location)
2	21	R/B No.2 (Engine Compartment Left)

## ○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
1D	23	Cowl Wire and J/B No.1 (Lower Finish Panel)
1E	23	Engine Room Main Wire and J/B No.1 (Lower Finish Panel)
1F	23	Cowl Wire and J/B No.1 (Lower Finish Panel)
1H		
1M		
3A	24	Cowl Wire and J/B No.3 (Behind the Instrument Panel Left)
3B		
3C		
3D		
3F		
3G	26	Cowl Wire and J/B No.3 (Behind the Instrument Panel Center)

## □ : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IK2	44	Engine Wire and Cowl Wire (Above the Glove Box)
BN1	46 (Double Cab)	Frame Wire and Cowl Wire (Under the Driver's Seat)
	48 (Except Double Cab)	

**: GROUND POINTS**


Code	See Page	Ground Points Location
EA	<a href="#">40 (5VZ-FE)</a>	Front Left Fender
	<a href="#">42 (3RZ-FE, 2RZ-FE)</a>	
EB	<a href="#">40 (5VZ-FE)</a>	Near the Throttle Body
EF	<a href="#">42 (3RZ-FE, 2RZ-FE)</a>	Ignition Coil Bracket
ID	<a href="#">44</a>	Left Kick Panel
IE	<a href="#">44</a>	Around the Right Edge of the Reinforcement
IG	<a href="#">44</a>	Around the Left Edge of the Reinforcement

**: SPLICE POINTS**


Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
I9	<a href="#">44</a>	Cowl Wire	I12	<a href="#">44</a>	Cowl Wire

# COMBINATION METER (w/o TACHOMETER)


FROM POWER SOURCE SYSTEM (SEE PAGE 54)



- \* 1 : W/ CRUISE CONTROL
- \* 2 : 5VZ- FE
- \* 3 : 3RZ- FE, 2RZ- FE
- \* 4 : W/ DAYTIME RUNNING LIGHT
- \* 5 : W/O DAYTIME RUNNING LIGHT




# COMBINATION METER (w/o TACHOMETER)





FROM POWER SOURCE SYSTEM (SEE PAGE 54)

- \* 1 : W/ CRUISE CONTROL
- \* 6 : COLD AREA SPEC.
- \* 7 : W/ 2-4 SELECT SW
- \* 8 : W/O 2-4 SELECT SW W/ ADD
- \* 9 : W/O 2-4 SELECT SW W/O ADD



# COMBINATION METER (w/o TACHOMETER)

## SERVICE HINTS

### B2 BRAKE FLUID LEVEL WARNING SW

1-2 : Closed with float down

### C10 (A), C12 (C), C13 (D) COMBINATION METER

(A) 5, (D)1-GROUND : Approx. 12 volts with ignition SW on

(A) 7, (C) 1, (D)12-GROUND : Always continuity

### P4 PARKING BRAKE SW

1-2 : Closed with parking brake lever pulled up

## ○ : PARTS LOCATION

Code	See Page	Code	See Page	Code	See Page	
B2	30 (5VZ-FE)	F8	37 (Except Double Cab)	P4	35	
	32 (3RZ-FE, 2RZ-FE)		J9		A	31 (5VZ-FE)
C10	A	34		J10		B
C12	C	34	W1		31 (5VZ-FE)	
C13	D	34		33 (3RZ-FE, 2RZ-FE)	33 (3RZ-FE, 2RZ-FE)	
D8	34	O2	31 (5VZ-FE)	W2	A	31 (5VZ-FE)
F8	36 (Double Cab)		33 (3RZ-FE, 2RZ-FE)		B	33 (3RZ-FE, 2RZ-FE)

## ○ : RELAY BLOCKS

Code	See Page	Relay Blocks (Relay Block Location)
2	21	R/B No.2 (Engine Compartment Left)

## ○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
1D	23	Cowl Wire and J/B No.1 (Lower Finish Panel)
1E	23	Engine Room Main Wire and J/B No.1 (Lower Finish Panel)
1F	23	Cowl Wire and J/B No.1 (Lower Finish Panel)
1M		
3A	24	Cowl Wire and J/B No.3 (Behind the Instrument Panel Left)
3B		
3C		
3D		
3F		
3G	26	Cowl Wire and J/B No.3 (Behind the Instrument Panel Center)

## □ : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IK2	44	Engine Wire and Cowl Wire (Above the Glove Box)
BN1	46 (Double Cab)	Frame Wire and Cowl Wire (Under the Driver's Seat)
	48 (Except Double Cab)	

## ▽ : GROUND POINTS


Code	See Page	Ground Points Location
EA	40 (5VZ-FE)	Front Left Fender
	42 (3RZ-FE, 2RZ-FE)	
EB	40 (5VZ-FE)	Near the Throttle Body
EF	42 (3RZ-FE, 2RZ-FE)	Ignition Coil Bracket
ID	44	Left Kick Panel
IE	44	Around the Right Edge of the Reinforcement
IG	44	Around the Left Edge of the Reinforcement




**: SPLICE POINTS**

Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
I9	<a href="#">44</a>	Cowl Wire	I12	<a href="#">44</a>	Cowl Wire

# AIR CONDITIONING





# AIR CONDITIONING

## SYSTEM OUTLINE

### 1. HEATER BLOWER MOTOR OPERATION

With the ignition SW on, the current from the GAUGE fuse flows to TERMINAL 5 of the HEATER relay to TERMINAL 3 to TERMINAL 8 of the heater blower SW.

(Low speed operation)

When the heater blower SW is moved to the low speed position, the current applied to TERMINAL 8 of the heater blower SW flows from TERMINAL 1 to GROUND, causing the HEATER relay to come on. Then the current flowing from the HEATER fuse flows to TERMINAL 1 of the HEATER relay to TERMINAL 2 to TERMINAL 1 of the blower motor to TERMINAL 2 to TERMINAL 1 of the blower resistor to TERMINAL 4 to GROUND, causing the blower motor to rotate.

At this time, current flows against the full resistance of the blower resistor, so the motor rotates slowly at low speed.

(Operation at speed M1, M2)

When the heater blower SW is moved to the speed M1 position, the current applied to TERMINAL 8 of the heater blower SW flows to TERMINAL 1 to GROUND, turning the HEATER relay to on. Then, the same as with low speed, current passes from the blower motor to TERMINAL 1 of the blower resistor to TERMINAL 2 to TERMINAL 6 of the heater blower SW to TERMINAL 1 to GROUND. At this time, the resistance of the blower resistor is less than it is for low speed, so the blower motor rotates faster than it does at low speed. With the heater blower SW in the M2 position, current flowing through the motor flows from TERMINAL 1 of the blower resistor to TERMINAL 3 to TERMINAL 5 of the heater blower SW to TERMINAL 1 to GROUND. At this time, the resistance of the blower resistor is less than for speed M1, so the blower motor rotates faster than for speed M1.

(High speed operation)

With the heater blower SW in high speed position, until the HEATER relay comes on and current flows to the blower motor, operation is the same as for speed M1 and M2. The current passing through the blower motor flows to TERMINAL 4 of the heater blower SW to TERMINAL 1 to GROUND without flowing through the blower resistor, so that the blower motor rotates at the fastest speed, high speed.

### 2. AIR INLET CONTROL SERVO MOTOR OPERATION

(Switching from FRESH to RECIRC)

With the ignition SW turned on, the current flows from GAUGE fuse to TERMINAL 7 of the air inlet control servo motor to TERMINAL 3 to TERMINAL 6 of the A/C control assembly to TERMINAL 25 to GROUND, the motor rotates and the damper moves to the RECIRC side. When the damper operates with the A/C SW at RECIRC position, the damper position signal is input from TERMINAL 1 of the servo motor to TERMINAL 7 of the A/C control assembly. As a result, current to the servo motor circuit is cut off by the A/C control assembly, so the damper stops at that position.

(Switching from RECIRC to FRESH)

With the ignition SW turned on, when the RECIRC/FRESH SW is switched to the FRESH side, the current flows from TERMINAL 7 of the air inlet control servo motor to TERMINAL 3 to TERMINAL 6 of the A/C control assembly to TERMINAL 25 to GROUND, the motor rotates and the damper stops at that position.

### 3. AIR VENT MODE CONTROL SERVO MOTOR OPERATION

When the ignition SW turned on, the current flows from GAUGE fuse to TERMINAL 2 of the A/C control assembly.

(Switching from DEF to FACE)

The current flows from TERMINAL 17 of the A/C control assembly to TERMINAL 4 of the air vent mode control servo motor to TERMINAL 8 to TERMINAL 21 of the A/C control assembly to TERMINAL 25 to GROUND. The motor rotates and the damper moves to the FACE side. When the damper operates with the A/C SW at FACE position, the damper position signal is input from TERMINAL 8 of the servo motor to the TERMINAL 21 of the A/C control assembly. As a result, current to the servo motor circuit is cut off by the A/C control assembly, so the damper stops at that position.

(Switching from FACE to DEF)

The current flows from TERMINAL 21 of the A/C control assembly to TERMINAL 8 of the air vent control servo motor to TERMINAL 4 to TERMINAL 17 of the A/C control assembly to TERMINAL 25 to GROUND, the motor rotates and the damper stops at that position.

### 4. AIR MIX CONTROL SERVO MOTOR CONTROL

When the temperature control SW is pressed, the A/C control assembly sends a signal to the air mix control servo motor. This signal drives the motor to reach the temperature set by the temperature control SW, and moves the film damper.

### 5. AIR CONDITIONING OPERATION

When the blower SW is set to on, current from the HEATER fuse flows through the HEATER relay (Point side) to A.C fuse to TERMINAL 2 of the A/C dual pressure SW to TERMINAL 1 to TERMINAL 3 of the A/C control assembly. The evaporator temp. signal from the A/C thermistor are all supplied to the A/C control assembly. When the A/C SW is turned on, the A/C SW on signal is sent to activate the A/C control assembly. Current flows from the A/C control assembly to the magnetic clutch, turning the compressor on. The A/C operation is shut off when a signal indicating low evaporator temp., or abnormally high or low refrigerant pressure, is supplied while the engine high speed signal exists. When one of these signals is received, the assembly shuts off the A/C operation.

## SERVICE HINTS

### HEATER RELAY

1-2 : Closed with ignition SW on and blower SW on.

### A13 A/C DUAL PRESSURE SW

1-2 : Open with refrigerant pressure at less than approx. **2.0 kgf/cm<sup>2</sup> (28.4 psi, 196 kpa)** or more than approx. **32 kgf/cm<sup>2</sup> (455 psi, 3138 kpa)**.

## ○ : PARTS LOCATION

Code	See Page	Code	See Page	Code	See Page
A5	<a href="#">30 (5VZ-FE)</a>	A27	<a href="#">34</a>	H7	<a href="#">35</a>
	<a href="#">32 (3RZ-FE, 2RZ-FE)</a>	A28	<a href="#">34</a>	J9	A
A13	<a href="#">34</a>	B4	<a href="#">34</a>		
A15	<a href="#">34</a>	B5	<a href="#">34</a>	J10	B
A25	<a href="#">34</a>	E5	A		
A26	<a href="#">34</a>	E6	B		<a href="#">33 (3RZ-FE, 2RZ-FE)</a>

## ○ : RELAY BLOCKS

Code	See Page	Relay Blocks (Relay Block Location)
2	<a href="#">21</a>	R/B No.2 (Engine Compartment Left)

## ○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
1B	<a href="#">23</a>	Cowl Wire and J/B No.1 (Lower Finish Panel)
1E	<a href="#">23</a>	Engine Room Main Wire and J/B No.1 (Lower Finish Panel)
1F	<a href="#">23</a>	Cowl Wire and J/B No.1 (Lower Finish Panel)
3F	<a href="#">24</a>	Cowl Wire and J/B No.3 (Behind the Instrument Panel Left)
3I	<a href="#">26</a>	Cowl Wire and J/B No.3 (Behind the Instrument Panel Center)

## □ : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IF1	<a href="#">44</a>	Engine Room Main Wire and Cowl Wire (Left Kick Panel)
IK2	<a href="#">44</a>	Engine Wire and Cowl Wire (Above the Glove Box)


## ▽ : GROUND POINTS

Code	See Page	Ground Points Location
EA	<a href="#">40 (5VZ-FE)</a>	Front Left Fender
	<a href="#">42 (3RZ-FE, 2RZ-FE)</a>	
IE	<a href="#">44</a>	Around the Right Edge of the Reinforcement
IG	<a href="#">44</a>	Around the Left Edge of the Reinforcement


## ○ : SPLICE POINTS

Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
E3	<a href="#">40 (5VZ-FE)</a>	Engine Room Main Wire	I10	44	Cowl Wire
	<a href="#">42 (3RZ-FE, 2RZ-FE)</a>		I16		
I7	44	Cowl Wire	I19		
I9					

# I GROUND POINT








# I GROUND POINT

- \* 1 : 5VZ-FE
- \* 2 : 3RZ-FE, 2RZ-FE
- \* 7 : W/ ADD
- \* 8 : W/O ADD



 : PARTS LOCATION

Code		See Page	Code		See Page	Code		See Page
J9	A	33 (3RZ-FE, 2RZ-FE)	J10	B	33 (3RZ-FE, 2RZ-FE)	S10	A	35
		31 (5VZ-FE)			31 (5VZ-FE)			S11

 : RELAY BLOCKS

Code	See Page	Relay Blocks (Relay Block Location)
2	21	R/B No.2 (Engine Compartment Left)

 : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
1A	23	Roof Wire and J/B No.1 (Lower Finish Panel)
1J	23	Cowl Wire and J/B No.1 (Lower Finish Panel)
3A	24	Cowl Wire and J/B No.3 (Behind the Instrument Panel Left)
3B		
3E		
3F		
3G	26	Cowl Wire and J/B No.3 (Behind the Instrument Panel Center)

 : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
EB3	40 (5VZ-FE)	Engine Wire and Differential Wire (Front Differential Upper Side)
	42 (3RZ-FE, 2RZ-FE)	
IF1	44	Engine Room Main Wire and Cowl Wire (Left Kick Panel)
IH2	44	Front Door LH Wire and Cowl Wire (Left Kick Panel)
IK2	44	Engine Wire and Cowl Wire (Above the Glove Box)
IK6		
IK7		
IL2	44	Front Door RH Wire and Cowl Wire (Right Kick Panel)
BN1	46 (Double Cab)	Frame Wire and Cowl Wire (Under the Driver's Seat)
	48 (Except Double Cab)	
BO1	46 (Double Cab)	Frame Wire and Diff. Lock Wire (Rear Side Member LH)
	48 (Except Double Cab)	
BU1	50	Cowl Wire and Seat No.1 Wire (Under the Driver's Seat)

 : GROUND POINTS

Code	See Page	Ground Points Location
EA	40 (5VZ-FE)	Front Left Fender
	42 (3RZ-FE, 2RZ-FE)	
EB	40 (5VZ-FE)	Near the Throttle Body
	42 (3RZ-FE, 2RZ-FE)	Under the Data Link Connector 1
EC	40 (5VZ-FE)	Front Right Fender
	42 (3RZ-FE, 2RZ-FE)	
EF	42 (3RZ-FE, 2RZ-FE)	Ignition Coil Bracket
ID	44	Left Kick Panel
IE	44	Around the Right Edge of the Reinforcement
IG	44	Around the Left Edge of the Reinforcement
IH	44	Right Kick Panel

# I GROUND POINT




: SPLICE POINTS

Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
I1	44	Cowl Wire	B2	46 (Double Cab)	Front Door LH Wire
I5				48 (Except Double Cab)	
I9			B3	46 (Double Cab)	Front Door RH Wire
I12				48 (Except Double Cab)	
I13	44	Engine Wire	B4	46 (Double Cab)	Frame Wire
I14	44	Cowl Wire		48 (Except Double Cab)	
I16			B5	48 (Except Double Cab)	
I17					



# J POWER SOURCE (Current Flow Chart)




The chart below shows the route by which current flows from the battery to each electrical source (Fusible Link, Circuit Breaker, Fuse, etc.) and other parts.



[LOCATION] ① : J/B No.1 (See page 22)

② : R/B No.2 (See page 21)

\*1 : w/o Daytime Running Light  
 \*2 : w/ Daytime Running Light



## J POWER SOURCE (Current Flow Chart)

### R/B No.2 (See Page 21)

Fuse		System	Page
7.5A	ALT-S	Charging	68
7.5A	DRL	Headlight (w/ Daytime Running Light)	96
7.5A	OBD	Engine Control (2RZ-FE)	86
		Engine Control (3RZ-FE)	78
		Engine Control (5VZ-FE)	70
10A	A.C	Air Conditioning	206
10A	HEAD (HI LH)	Headlight (w/ Daytime Running Light)	96
10A	HEAD (HI RH)	Headlight (w/ Daytime Running Light)	96
10A	HEAD (LH)	Headlight (w/o Daytime Running Light)	94
10A	HEAD (LO LH)	Headlight (w/ Daytime Running Light)	96
10A	HEAD (LO RH)	Headlight (w/ Daytime Running Light)	96
10A	HEAD (RH)	Headlight (w/o Daytime Running Light)	94
10A	TAIL	Cigarette Lighter and Clock	186
		Combination Meter (w/ Tachometer)	194
		Combination Meter (w/o Tachometer)	200
		Engine Control (2RZ-FE)	86
		Engine Control (3RZ-FE)	78
		Taillight and Illumination	102
15A	DOME	Cigarette Lighter and Clock	186
		Combination Meter (w/ Tachometer)	194
		Door Lock Control	164
		Interior Light	100
		Key Reminder and Seat Belt Warning	182
		Light Auto Turn Off	112
		Power Window	168
		Radio and Player	190
15A	PWR OUTLET	Power Outlet	184
20A	EFI	Automatic Transmission (2RZ-FE)	126
		Electronically Controlled Transmission (3RZ-FE)	120
		Electronically Controlled Transmission (5VZ-FE)	114
		Engine Control (2RZ-FE)	86
		Engine Control (3RZ-FE)	78
		Engine Control (5VZ-FE)	70
30A	AM2	Engine Control (2RZ-FE)	86
		Engine Control (3RZ-FE)	78
		Engine Control (5VZ-FE)	70
		Ignition (3RZ-FE, 2RZ-FE)	66
		Starting and Ignition (5VZ-FE)	58
40A	AM1	Engine Control (2RZ-FE)	86
		Engine Control (3RZ-FE)	78
		Engine Control (5VZ-FE)	70

\* These are the page numbers of the first page on which the related system is shown.



Fuse		System	Page
40A	AM1	Starting (3RZ-FE, 2RZ-FE)	62
		Starting and Ignition (5VZ-FE)	58
50A	HEATER	Air Conditioning	206
60A	ABS	ABS	136
120A	ALT	Charging	68
		Engine Control (2RZ-FE)	86
		Engine Control (3RZ-FE)	78
		Engine Control (5VZ-FE)	70
		Light Auto Turn Off	112
		Power Outlet	184
		Starting (3RZ-FE, 2RZ-FE)	62
		Starting and Ignition (5VZ-FE)	58
		Taillight and Illumination	102

### J/B No.1 (See Page 22)

Fuse		System	Page
7.5A	ECU-B	Air Conditioning	206
		Combination Meter (w/ Tachometer)	194
		Combination Meter (w/o Tachometer)	200
		Headlight (w/ Daytime Running Light)	96
		SRS	143
7.5A	ECU-IG	ABS	136
		Automatic Transmission (2RZ-FE)	126
		Cruise Control	130
		Door Lock Control	164
		Interior Light	100
		Key Reminder and Seat Belt Warning	184
		Light Auto Turn Off	112
		Power Window	168
		Shift Lock	162
7.5A	IGN	Automatic Transmission (2RZ-FE)	126
		Charging	68
		Combination Meter (w/ Tachometer)	196
		Combination Meter (w/o Tachometer)	200
		Electronically Controlled Transmission (3RZ-FE)	120
		Electronically Controlled Transmission (5VZ-FE)	114
		Engine Control (2RZ-FE)	86
		Engine Control (3RZ-FE)	78
		Engine Control (5VZ-FE)	70
		SRS	143
7.5A	STA	Automatic Transmission (2RZ-FE)	126
		Electronically Controlled Transmission (3RZ-FE)	120
		Electronically Controlled Transmission (5VZ-FE)	114
		Engine Control (2RZ-FE)	86

\* These are the page numbers of the first page on which the related system is shown.

## J POWER SOURCE (Current Flow Chart)























Fuse		System	Page
7.5A	STA	Engine Control (3RZ-FE)	78
		Engine Control (5VZ-FE)	70
		Starting (3RZ-FE, 2RZ-FE)	62
		Starting and Ignition (5VZ-FE)	58
10A	GAUGE	ABS	136
		Air Conditioning	206
		Automatic Transmission (2RZ-FE)	126
		Back-Up Light	110
		Charging	68
		Combination Meter (w/ Tachometer)	194
		Combination Meter (w/o Tachometer)	200
		Cruise Control	130
		Electronically Controlled Transmission (3RZ-FE)	120
		Electronically Controlled Transmission (5VZ-FE)	114
		Engine Control (2RZ-FE)	86
		Engine Control (3RZ-FE)	78
		Engine Control (5VZ-FE)	70
		Headlight (w/ Daytime Running Light)	96
		Key Reminder and Seat Belt Warning	182
Rear Differential Lock	158		
Starting (3RZ-FE, 2RZ-FE)	62		
Starting and Ignition (5VZ-FE)	58		
4WD (w/ 2-4 Select SW)	148		
4WD (w/o 2-4 Select SW)	154		
10A	STOP	ABS	136
		Automatic Transmission (2RZ-FE)	126
		Cruise Control	130
		Electronically Controlled Transmission (3RZ-FE)	120
		Electronically Controlled Transmission (5VZ-FE)	114
		Engine Control (2RZ-FE)	86
		Engine Control (3RZ-FE)	78
		Engine Control (5VZ-FE)	70
		Shift Lock	162
Stop Light	108		
10A	TURN	Turn Signal and Hazard Warning Light	106
15A	ACC	Cigarette Lighter and Clock	186
		Power Outlet	184
		Radio and Player	190
		Remote Control Mirror (w/ Power Window)	174
		Remote Control Mirror (w/o Power Window)	176
		Shift Lock	162
SRS	143		
15A	HORN. HAZ	Horn	140
		Turn Signal and Hazard Warning Light	106

\* These are the page numbers of the first page on which the related system is shown.


Fuse		System	Page
20A	4WD	Rear Differential Lock	<a href="#">158</a>
		4WD (w/ 2-4 Select SW)	<a href="#">148</a>
		4WD (w/o 2-4 Select SW)	<a href="#">154</a>
20A	WIPER	Wiper and Washer (w/ INT Time SW Mechanism)	<a href="#">178</a>
		Wiper and Washer (w/o INT Time SW Mechanism)	<a href="#">180</a>
30A	POWER	Door Lock Control	<a href="#">164</a>
		Power Seat	<a href="#">188</a>
		Power Window	<a href="#">168</a>

\* These are the page numbers of the first page on which the related system is shown.


# K CONNECTOR LIST




**C12**  
BLUE




**C13**




**C14**




**C15**  
BLACK




**C16**




**C17**  
GRAY




**C19**  
BLACK




**C20**  
YELLOW




**C21**  
YELLOW




**C22**  
YELLOW




**D1**  
(5VZ-FE) BLACK




**D1**  
(3RZ-FE, 2RZ-FE) BLACK




**D3**  
BLUE




**D4**  
GRAY




**D5**  
(w/ 2-4 Select SW) GRAY




**D5**  
(w/o 2-4 Select SW) BLUE




**D7**  
BLACK



**D8**



**D9**



**D13**  
BLACK




**D15**




**D16**




**D20**




**D21**  
GRAY




# K CONNECTOR LIST






# K CONNECTOR LIST







# L PART NUMBER OF CONNECTORS

Code	Part Name	Part Number	Code	Part Name	Part Number
A 5	A/C Magnetic Clutch	90980-11271	D 5	Detection SW (Transfer 4WD Position) [w/ 2-4 Select SW]	90980-11250
A 7	A/T Oil Temp. Sensor	90980-10498		Detection SW (Transfer 4WD Position) [w/o 2-4 Select SW]	90980-11156
A 9	ABS Deceleration Sensor	90080-98028	D 7	Data Link Connector 3	90080-98010
A13	A/C Dual Pressure SW	90980-10825	D 8	Daytime Running Light Relay (Main)	90980-12034
A15	A/C Thermistor	90980-10860	D 9	Daytime Running Light Relay No.4	82602-35160
A18	Airbag Squib (Steering Wheel Pad)	90980-10850	D13	Diode (Daytime Running Light System)	90980-10962
A19	Ashtray Illumination	81945-33010	D15	Door Courtesy SW Front LH	90980-10433
A21	Airbag Squib (Front Passenger Airbag Assembly)	90980-11884	D16	Door Courtesy SW Front RH	
A22	ABS Actuator with ECU	90980-11861	D20	Door Lock Control SW RH	90980-11013
A23	Air Fuel Ratio Sensor (Bank 1 Sensor 1)	90980-11178	D21	Door Lock Motor, Door Unlock Detection SW and Door Key Lock and Unlock SW Front LH	90980-10897
A24	ADD Actuator	90980-11858		D22	
A25	A/C Control Assembly	90980-11877	D25	Diode (A/T)	90980-10962
A26	Air Inlet Control Servo Motor	90980-11165	D26	Door Courtesy SW Rear LH	90980-10433
A27	Air Mix Control Servo Motor	90980-10789	D27	Door Courtesy SW Rear RH	
A28	Air Vent Mode Control Servo Motor	90980-11321	D28	Door Lock Motor Rear LH	90980-11019
B 1	Back-Up Light SW	90980-11250	D29	Door Lock Motor Rear RH	
B 2	Brake Fluid Level Warning SW	90980-11207	E 1	EGR Gas Temp. Sensor	90980-10899
B 4	Blower Motor	90980-10214	E 2	Electronically Controlled Transmission Solenoid	90980-10919
B 5	Blower Resistor	90980-10171	E 3	Engine Coolant Temp. Sensor	90980-10737
B 6	Buckle SW LH	90980-10859	E 4	Electronically Controlled Transmission Pattern Select SW	90980-10601
C 1	Camshaft Position Sensor	90980-10947	E 5	Engine Control Module	90980-11638
C 2	Crankshaft Position Sensor (5VZ-FE)		E 6	Engine Control Module	90980-11637
	Crankshaft Position Sensor (3RZ-FE, 2RZ-FE)	90980-11016	E 7	Engine Control Module	90980-11476
C 3	Cruise Control Actuator	90980-11150	E 8	Engine Control Module	90980-11421
C 4	Cigarette Lighter	90980-10760	F 1	Front ABS Speed Sensor LH	90980-11075
C 5	Cigarette Lighter Illumination	90980-11148	F 2	Front ABS Speed Sensor RH	
C 6	Circuit Opening Relay	82602-35150	F 3	Front Turn Signal Light LH	90980-11020
C 7	Clock	90980-11013	F 4	Front Turn Signal Light RH	
C 8	Clutch Start Cancel SW	90980-11533	F 6	<b>4WD ECU</b>	90980-11423
C 9	Clutch Start SW	90980-10825	F 8	Fuel Pump and Sender	90980-11077
C10	Combination Meter	90980-11115	F 9	Front Airbag Sensor LH	90980-11898
C12	Combination Meter	90980-11114	F10	Front Airbag Sensor RH	
C13	Combination Meter	90980-11113	G 1	Generator	90980-09212
C14	Combination SW	90980-11672	G 2	Generator	90980-11349
C15	Combination SW	90980-11594	G 3	Glove Box Light	90980-11148
C16	Cruise Control Clutch SW	90980-10906	H 1	Headlight LH	90980-11314
C17	Cruise Control ECU	90980-11391	H 2	Headlight RH	
C19	Combination SW	90980-11616	H 5	Horn (Low)	90980-10619
C20	Center Airbag Sensor Assembly	90980-11871	H 6	Hazard SW	90980-10801
C21	Center Airbag Sensor Assembly	90980-11872	H 7	Heater Blower SW	90980-10877
C22	Center Airbag Sensor Assembly	90980-11873	H 8	High Mounted Stop Light	90980-11436
D 1	Data Link Connector 1 (5VZ-FE)	90980-11195			
	Data Link Connector 1 (3RZ-FE, 2RZ-FE)	90980-11323			
D 3	Detection SW (Transfer L4 Position)	90980-11156			
D 4	Detection SW (Transfer Neutral Position)	90980-10923			

Note: Not all of the above part numbers of the connector are established for the supply.

Code	Part Name	Part Number	Code	Part Name	Part Number
H 9	Heated Oxygen Sensor (Bank 1 Sensor 2)	90980-11028	P 8	Power Window Motor Front LH	90980-11248
H10	Horn (High)	90980-10619	P 9	Power Window Motor Front RH	
I 1	Idle Air Control Valve	90980-11145	P10	Power Steering Oil Pressure SW	90980-11428
I 2	Igniter	90980-11653	P13	Power Outlet	90980-10760
I 3	Ignition Coil No.1	90980-11246	P14	Power Outlet	
I 4	Ignition Coil No.2				
I 5	Ignition Coil No.3				
I 6	Injector No.1		90980-11153	P19	Passenger Airbag Manual On/Off Indicator
I 7	Injector No.2				
I 8	Injector No.3				
I 9	Injector No.4				
I10	Injector No.5				
I11	Injector No.6				
I14	Ignition SW	90980-11615	P20	Passenger Airbag Manual On/Off SW	90980-12017
I16	Interior Light (Double, Extra Cab)	90980-10935	P21	Pretensioner LH	90980-12138
	Interior Light (Regular Cab)	90980-10121	P22	Pretensioner RH	
I20	Ignition Coil and Igniter No.1	90980-11885	P23	Power Seat Motor (Lumbar Support)	90980-10935
I21	Ignition Coil and Igniter No.2				
I22	Ignition Coil and Igniter No.3				
I23	Ignition Coil and Igniter No.4				
J 1	Junction Connector	90980-10803	P24	Power Seat SW (Lumbar Support)	90980-10127
J 9	Junction Connector	90980-11661	P25	Power Window Control SW Rear LH	90980-10631
J10	Junction Connector				
J11	Junction Connector	90980-11542	P26	Power Window Control SW Rear RH	90980-10860
J13	Junction Connector	90980-10803	P27	Power Window Motor Rear LH	
K 1	Knock Sensor	90980-11166	P28	Power Window Motor Rear RH	90980-10997
K 2	Knock Sensor 1				
K 3	Knock Sensor 2				
L 1	License Plate Light LH	90980-11162	R 1	Radio and Player	90980-10996
L 2	License Plate Light RH				
M 1	Mass Air Flow Meter	90980-11317	R 2	Radio and Player	90980-10216
N 1	Noise Filter (Ignition System)	90980-10843	R 3	Rheostat	90980-10214
O 1	O/D Solenoid	90980-11156	R 4	Rheostat	90980-10173
O 2	Oil Pressure SW	90980-11363	R 6	Rear Combination Light LH	
O 6	O/D ECU	90980-10799	R 7	Rear Combination Light RH	90980-11169
P 1	Park/Neutral Position SW (A/T Except 2RZ-FE)	90980-11784	R 8	Remote Control Mirror LH	
	Park/Neutral Position SW (2RZ-FE A/T)	90980-11332	R 9	Remote Control Mirror RH	
P 2	Parking Light LH	90980-11149	R10	Remote Control Mirror SW	90980-11657
P 3	Parking Light RH				
P 4	Parking Brake SW	90980-10825	R11	Rear ABS Speed Sensor LH	90980-11467
P 5	Personal Light	90980-10935	R12	Rear ABS Speed Sensor RH	
P 6	Power Window Control SW Front RH	90980-10789	R13	Rear Diff. Lock Detection SW	90980-11250
P 7	Power Window Master SW and Door Lock Control SW LH (Double Cab)	90980-10807	R14	Rear Diff. Lock Motor	90980-10631
	Power Window Master SW and Door Lock Control SW LH (Except Double Cab)	90980-10997	R15	Rear Diff. Lock SW	90980-10801
			R16	Rear Diff. Lock ECU	90980-11400
			S 1	Starter	90980-09584
			S 2	Starter (5VZ-FE)	90980-09506
				Starter (3RZ-FE, 2RZ-FE)	
			S 4	Shift Lock Control Relay and O/D Main SW	90980-11118
			S 5	Stop Light SW	90980-10916
			S 6	Speaker (Front Door LH)	
			S 7	Speaker (Front Door RH)	90980-11299
			S 8	Speaker (Rear LH) (Extra Cab)	
				Speaker (Rear LH) (Double Cab, Regular Cab)	90980-10825
			S 9	Speaker (Rear RH) (Extra Cab)	90980-10825
				Speaker (Rear RH) (Double Cab, Regular Cab)	
			S10	Short Connector (ADD)	90980-10799
			S11	Short Connector (ADD)	90980-11261
			T 1	Throttle Position Sensor	

## L PART NUMBER OF CONNECTORS

Code	Part Name	Part Number	Code	Part Name	Part Number
T 2	2-4 Select Motor	90980-11858			
T 3	2-4 Select SW	90980-10355			
T 4	Transmission Control Relay	90980-10801			
T 5	Tweeter LH	90980-10906			
T 6	Tweeter RH				
U 1	Unlock Warning SW and Key Interlock Solenoid (A/T)	90980-10795			
	Unlock Warning SW (M/T)	90980-10860			
V 1	Vehicle Speed Sensor (Electronically Controlled Transmission)	90980-11156			
V 3	VSV (EGR)	90980-11162			
V 4	VSV (EVAP)	90980-11156			
V 8	Vapor Pressure Sensor	90980-11143			
V 9	VSV (Vapor Pressure Sensor)	90980-11156			
V10	Vehicle Speed Sensor	90980-11143			
W 1	Washer Motor and Washer Level Sensor (Cold Area Spec.) or Washer Motor (Except Cold Area Spec.)	90980-10942			
W 2	Water Temp. Sender (5VZ-FE)	90980-10359			
	Water Temp. Sender (3RZ-FE, 2RZ-FE)	90980-11428			
W 3	Wiper Motor	90980-11599			


Note: Not all of the above part numbers of the connector are established for the supply.



# M OVERALL ELECTRICAL WIRING DIAGRAM

\* The system shown here is an EXAMPLE ONLY. It is different to the actual circuit shown in the wiring diagram section.

## HOW TO READ THIS SECTION



**[A]** : System Title


**[B]** : Indicates the wiring color.

Wire colors are indicated by an alphabetical code.

- |           |            |                  |
|-----------|------------|------------------|
| B = Black | W = White  | BR = Brown       |
| L = Blue  | V = Violet | SB = Sky Blue    |
| R = Red   | O = Orange | LG = Light Green |
| P = Pink  | Y = Yellow | GR = Gray        |
| G = Green |            |                  |

The first letter indicates the basic wire color and the second letter indicates the color of the stripe.

Example: L - Y




**[C]** : The position of the parts is the same as shown in the wiring diagram and wire routing.


**[D]** : Indicates the pin number of the connector. The numbering system is different for female and male connectors.

Example : Numbered in order from upper left to lower right

Numbered in order from upper right to lower left



Female



Male


The numbering system for the overall wiring diagram is the same as above

**[E]** : Indicates a Relay Block. No shading is used and only the Relay Block No. is shown to distinguish it from the J/B.

Example : ① Indicates Relay Block No.1


**[F]** : Junction Block (The number in the circle is the J/B No. and the connector code is shown beside it). Junction Blocks are shaded to clearly separate them from other parts.

Example:



**[G]** : Indicates related system.

**[H]** : Indicates the wiring harness and wiring harness connector. The wiring harness with male terminal is shown with arrows (↘). Outside numerals are pin numbers.



**[I]** : ( ) is used to indicate different wiring and connector, etc. when the vehicle model, engine type, or specification is different.

**[J]** : Indicates a shielded cable.



**[K]** : Indicates and located on ground point.

**[L]** : The same code occurring on the next page indicates that the wire harness is continuous.


# SYSTEM INDEX

<b>SYSTEMS</b>	<b>LOCATION</b>	<b>SYSTEMS</b>	<b>LOCATION</b>
ABS .....	16-2	Key Reminder and Belt Warning .....	11-2
Air Conditioning .....	29-2	Light Auto Turn Off .....	11-3
Automatic Transmission (2RZ-FE) .....	14-2	Power Outlet .....	25-4
Back-Up Light .....	17-4	Power Seat .....	24-4
Charging .....	2-4	Power Source .....	1~29-1
Cigarette Lighter and Clock .....	26-4	Power Window .....	19-2
Combination Meter (w/ Tachometer) .....	27-2	Radio and Player .....	26-2
Combination Meter (w/o Tachometer) .....	28-2	Rear Differential Lock .....	22-2
Cruise Control .....	15-2	Remote Control Mirror (w/ Power Window) .....	23-3
Door Lock Control .....	18-2	Remote Control Mirror (w/o Power Window) .....	24-2
Electronically Controlled Transmission (3RZ-FE) .....	13-2	Shift Lock .....	25-2
Electronically Controlled Transmission (5VZ-FE) .....	12-2	SRS .....	17-2
Engine Control (2RZ-FE) .....	6-2	Starting (3RZ-FE, 2RZ-FE) .....	2-2
Engine Control (3RZ-FE) .....	5-2	Starting (5VZ-FE) .....	1-2
Engine Control (5VZ-FE) .....	4-2	Stop Light .....	15-4
Headlight (w/ Daytime Running Light) .....	8-2	Taillight and Illumination .....	9-2
Headlight (w/o Daytime Running Light) .....	7-2	Turn Signal and Hazard Warning Light .....	10-2
Horn .....	10-4	Wiper and Washer .....	23-2
Ignition (3RZ-FE, 2RZ-FE) .....	3-2	4WD (w/ 2-4 Select SW) .....	20-2
Ignition (5VZ-FE) .....	1-4	4WD (w/o 2-4 Select SW) .....	21-2
Interior Light .....	11-4		




1 TOYOTA TACOMA ELECTRICAL WIRING DIAGRAM

2001 TOYOTA TACOMA (EWD440U)




# M OVERALL ELECTRICAL WIRING DIAGRAM

2 TOYOTA TACOMA



3 TOYOTA TACOMA




2001 TOYOTA TACOMA (EWD440U)

# M OVERALL ELECTRICAL WIRING DIAGRAM


4 TOYOTA TACOMA

(Cont. next page)



Engine Control (5VZ-FE)

- \* 1 : 4WD
- \* 2 : 4WD w/ 2-4 Select SW
- \* 3 : 4WD w/o 2-4 Select SW




2001 TOYOTA TACOMA (EWD440J)

# M OVERALL ELECTRICAL WIRING DIAGRAM


5 TOYOTA TACOMA

(Cont. next page)



Engine Control (3RZ- FE)

\* 1 : 4WD  
 \* 2 : Shielded



2001 TOYOTA TACOMA (EWD440U)


# M OVERALL ELECTRICAL WIRING DIAGRAM

(Cont. next page)

6 TOYOTA TACOMA

## Engine Control (2RZ-FE)


## Power Source






Engine Control (2RZ- FE)


\* 1: Shielded



# M OVERALL ELECTRICAL WIRING DIAGRAM

7 TOYOTA TACOMA







2001 TOYOTA TACOMA (EWD440J)

# M OVERALL ELECTRICAL WIRING DIAGRAM


9 TOYOTA TACOMA





# M OVERALL ELECTRICAL WIRING DIAGRAM

11 TOYOTA TACOMA






# M OVERALL ELECTRICAL WIRING DIAGRAM

(Cont. next page)


12 TOYOTA TACOMA





Electronically Controlled Transmission (5VZ- FE)

\* 1: 4WD  
\* 2: 2WD




2001 TOYOTA TACOMA (EWD440J)

# M OVERALL ELECTRICAL WIRING DIAGRAM


13 TOYOTA TACOMA

(Cont. next page)



Electronically Controlled Transmission (3RZ-FE)


\* 1: 4WD  
 \* 2: 2WD




2001 TOYOTA TACOMA (EWD440U)

# M OVERALL ELECTRICAL WIRING DIAGRAM


14 TOYOTA TACOMA






# M OVERALL ELECTRICAL WIRING DIAGRAM


16 TOYOTA TACOMA






# M OVERALL ELECTRICAL WIRING DIAGRAM

18 TOYOTA TACOMA









2001 TOYOTA TACOMA (EWD440J)


# M OVERALL ELECTRICAL WIRING DIAGRAM

20 TOYOTA TACOMA






# M OVERALL ELECTRICAL WIRING DIAGRAM





2001 TOYOTA TACOMA (EWD440U)



# M OVERALL ELECTRICAL WIRING DIAGRAM


24 TOYOTA TACOMA





# M OVERALL ELECTRICAL WIRING DIAGRAM

26 TOYOTA TACOMA








# M OVERALL ELECTRICAL WIRING DIAGRAM


(Cont. next page)

27 TOYOTA TACOMA



Combination Meter (w/ Tachometer)


- \* 4 : w/ Daytime Running Light
- \* 5 : w/o Daytime Running Light
- \* 6 : Cold Area Spec.



# M OVERALL ELECTRICAL WIRING DIAGRAM


(Cont. next page)

28 TOYOTA TACOMA



Combination Meter (w/o Tachometer)


\* 6 : Cold Area Spec.




# M OVERALL ELECTRICAL WIRING DIAGRAM

(Cont. next page)

29 TOYOTA TACOMA



Air Conditioning



2001 TOYOTA TACOMA (EWD440U)