

DTC	P0340	Camshaft Position Sensor Circuit Malfunction
------------	--------------	---

CIRCUIT DESCRIPTION

Camshaft position sensor (G signal) consists of a magnet, iron core and pickup coil. The G signal plate has 1 tooth, on its outer circumference and is mounted on the RH camshaft timing pulley. When the camshafts rotate, the protrusion on the signal plate and the air gap on the pickup coil change, causing fluctuations in the magnetic field and generating an electromotive force in the pickup coil. The NE signal plate has 34 teeth and is mounted on the crankshaft timing pulley. The NE signal sensor generates 34 signals at every engine revolution. The ECM detects the standard crankshaft angle based on the G signal and the actual crankshaft angle and the engine speed by the NE signal.

DTC No.	DTC Detection Condition	Trouble Area
P0340	No signal of camshaft position sensor to ECM during cranking (2 trip detection logic)	<ul style="list-style-type: none"> • Open or short in camshaft position sensor circuit • Camshaft position sensor • RH camshaft timing pulley • ECM
	No signal of camshaft position sensor to ECM with engine speed 600 rpm or more	

WIRING DIAGRAM

Refer to DTC P0335 on page [DI-207](#) .

INSPECTION PROCEDURE


HINT:

Read freeze frame data using TOYOTA hand-held tester or OBD II scan tool, as freeze frame data records the engine conditions when a malfunction is detected. When troubleshooting, it is useful for determining whether the vehicle was running or stopped, the engine was warmed up or not, the air-fuel ratio was lean or rich, etc. at the time of the malfunction.


1	Check resistance of camshaft position sensor (See page IG-1).
----------	---

Reference: INSPECTION USING OSCILLOSCOPE

Refer to DTC P0335 on page [DI-207](#) .



2	Check for open and short in harness and connector between ECM and camshaft position sensor (See page IN-28).
----------	--



3	Inspect sensor installation and signal plate tooth of RH camshaft timing pulley.
---	--

NG

Tighten sensor. Replace RH camshaft timing pulley.

OK

Check and replace ECM (See page [IN-28](#)).