


DISASSEMBLY


1. REMOVE VALVE BRACKET

- (a) Remove the nut, bolt and 2 plate washers.
- (b) 2WD (except pre runner):
Remove the 2 nuts and flexible hose bracket, and remove the valve bracket and set plate from the valve body.
- (c) 4WD and Pre runner:
Remove the 2 nuts, and remove the valve bracket and set plate from the valve body.




2. DISCONNECT SPRING FROM VALVE

Using pliers, remove the clip, and remove the spring from the valve.



3. REMOVE SHACKLES NO.1 AND NO.2

- (a) Remove the nut and bolt, and remove the load sensing spring and 2 plate washers.
- (b) Loosen the 2 nuts and washer, and remove the shackle No. 1 from the shackle No. 2.



4. DISASSEMBLE LOAD SENSING SPRING

- (a) Remove the 4 bushings, 2 collars and 2 rubber plates.
- (b) Remove the load sensing valve boot and load sensing spring boot.