

DTC	C1241 / 41	IG Power Source Circuit
------------	-------------------	--------------------------------

CIRCUIT DESCRIPTION


This is the power source for the ECU, hence the actuators.

DTC No.	DTC Detecting Condition	Trouble Area
C1241 / 41	Vehicle speed is 3 km/h (1.9 mph) or more and voltage of ECU terminal IG1 remains at more than 17 V or below 9.5 V for more than 10 sec.	<ul style="list-style-type: none"> • Battery • IC regulator • Open or short in power source circuit • Skid control ECU • Wire harness

Fail safe function:

If trouble occurs in the power source circuit, the ECU cuts off current to the ABS control (solenoid) relay and prohibits ABS control.

WIRING DIAGRAM





INSPECTION PROCEDURE

1	Check battery positive voltage.
----------	--

OK:

Voltage: 10 – 14 V



2	Check voltage of the ECU IG power source.
----------	--

In case of using hand-held tester:**PREPARATION:**


- (a) Connect the hand-held tester to the DLC3.
- (b) Turn the ignition switch ON and push the hand-held tester main switch ON.
- (c) Select the DATA LIST mode on the hand-held tester.

CHECK:

Check the voltage condition output from the ECU displayed on the hand-held tester.

OK:

"Normal" is displayed.

**In case of not using hand-held tester:****PREPARATION:**


Disconnect skid control ECU connector.

CHECK:


- (a) Turn the ignition switch ON.
- (b) Measure voltage between terminals IG1 (25) and GND (2, 24) of skid control ECU harness side connector.

OK:

Voltage: 10 – 14 V



3 Check continuity between terminals GND of skid control ECU connector and body ground.



CHECK:
Measure resistance between terminals GND (2, 24) of skid control ECU harness side connector and body ground.

OK:
Resistance: 1 Ω or less

NG → **Repair or replace harness or connector.**


OK

4 Check for open circuit in harness and connector between skid control ECU and battery (See page IN-28).

NG → **Repair or replace harness or connector.**

OK

5 Check ECU-IG fuse.



PREPARATION:
Remove ECU-IG fuse from J/B No.1.

CHECK:
Check continuity of ECU-IG fuse.

OK:
Continuity

NG → **Check for short in all the harness and components connected to ECU-IG fuse (See attached wiring diagram).**

OK

Check and replace brake actuator ASSY.