

DISASSEMBLY

1. INSPECT EACH GEAR THRUST CLEARANCE

Measure the thrust clearance of each gear.

Standard clearance:

1st gear:

0.20 – 0.45 mm (0.0079 – 0.0177 in.)


2nd and 3rd gears:

0.10 – 0.25 mm (0.0039 – 0.0098 in.)

Maximum clearance:

1st gear: 0.45 mm (0.0177 in.)

2nd and 3rd gears: 0.25 mm (0.0098 in.)



2. INSPECT EACH GEAR RADIAL CLEARANCE

Using a dial indicator, measure the radial clearance of each gear.

Standard clearance:

1st gear:

0.020 – 0.073 mm (0.0008 – 0.0029 in.)

2nd and 3rd gears:



0.015 – 0.068 mm (0.0006 – 0.0027 in.)

Maximum clearance:

1st gear: 0.073 mm (0.0029 in.)


2nd and 3rd gears: 0.068 mm (0.0027 in.)

If the clearance exceeds the maximum, replace the gear, needle roller bearing or shaft.




3. REMOVE 5TH GEAR, OUTPUT SHAFT CENTER BEARING AND 1ST GEAR ASSEMBLY

- (a) Using a press, remove the 5th gear, center bearing, thrust washer and 1st gear assembly.
- (b) Remove the straight pin and needle roller bearing.
- (c) Remove the spacer.




4. REMOVE REVERSE GEAR ASSEMBLY AND 2ND GEAR ASSEMBLY

- (a) Using 2 screwdrivers and a hammer, tap out the snap ring.
- (b) Using a press, remove the reverse gear assembly and 2nd gear assembly.
- (c) Remove the needle roller bearing.



5. REMOVE REVERSE GEAR, SHIFTING KEY AND SPRING FROM CLUTCH HUB NO.1

- (a) Remove the reverse gear from the clutch hub No.1.
- (b) Push the shifting key spring with a screwdriver, remove the 3 shifting keys and key springs.



6. REMOVE HUB SLEEVE NO.2 ASSEMBLY AND 3RD GEAR ASSEMBLY

- (a) Using a snap ring expander, remove the snap ring.
- (b) Using a press, remove the hub sleeve No.2 assembly and 3rd gear assembly.
- (c) Remove the needle roller bearing.

7. REMOVE SHIFTING KEY AND SPRING FROM HUB SLEEVE NO.2 ASSEMBLY

Using a screwdriver, remove the 3 shifting keys and 2 springs.