



## INSPECTION

### INSPECT UPPER BALL JOINT FOR ROTATION CONDITION

- As shown in the illustration, flip the ball joint stud back and forth 5 times, before installing the nut.
- Using a torque wrench, turn the nut continuously 1 turn each 2 – 4 seconds and take the torque reading on the 5th turn.

#### Turning torque:

**0.5 – 3.5 N·m (5 – 35 kgf·cm, 4 – 30 in.-lbf)**