

HAYNES SERVICE & REPAIR MANUAL

# KAWASAKI

**ZX900, 1000 & 1100**  
**Liquid-cooled Fours**  
**'83 to '97**



**"Haynes Manuals just cannot be beaten"**


<http://manuals.magnamatic.com>

• Model history • Fitment checks • Wiring diagrams • Tools and workshop tips  
**IN FULL COLOUR**



This manual is brought to you by:

[www.magnamania.com](http://www.magnamania.com)



#### Removing gearbox cover

- Unfasten screw (1) for idle speed detent and remove coil.
- Remove retaining screws from gearbox cover.
- Heat gearbox cover to 100 °C at the bearing seats.
- Place sliding sleeve, BMW No. 23 4 632, on the input shaft.
- Press off gearbox cover evenly.
- Remove ball (3) from neutral chain spacers.

Here you can find Service Manuals for over 200 different motorcycles





# Kawasaki ZX900, 1000 & 1100 Liquid-cooled Fours

## Service and Repair Manual

by Mark Coombs and Penny Cox

### Models covered

(1681-248-10Y4)

ZX900 A (GPZ900R). 908cc. UK April 1984 to 1996  
ZX900 A (Ninja). 908cc. US November 1983 to 1986  
ZX1000 A (GPZ1000RX). 997cc. UK November 1985 to September 1989  
ZX1000 A (Ninja 1000R). 997cc. US September 1985 to 1987  
ZX1000 B (ZX-10). 997cc. UK December 1987 to April 1991  
ZX1000 B (Ninja ZX-10). 997cc. US April 1988 to 1990  
ZX1100 C (ZZ-R1100). 1052cc. UK March 1990 to December 1992  
ZX1100 C (Ninja ZX-11C). 1052cc. US 1990 to 1993  
ZX1100 D (ZZ-R1100). 1052cc. UK December 1992 to 1997  
ZX1100 D (Ninja ZX-11D). 1052cc. US 1993 to 1997

© Haynes Publishing 1999

AB

Printed in the USA

A book in the **Haynes Service and Repair Manual Series**

**Haynes Publishing**

Sparkford, Nr Yeovil, Somerset BA22 7JJ, England

**All rights reserved. No part of this book may be reproduced or transmitted in any form or by any means, electronic or mechanical, including photocopying, recording or by any information storage or retrieval system, without permission in writing from the copyright holder.**

**Haynes North America, Inc**

861 Lawrence Drive, Newbury Park, California 91320, USA

ISBN 1 85960 355 6

**Editions Haynes S.A.**

Tour Aurore - IBC, 18 Place des Reflets,  
92975 Paris la Défense 2, Cedex, France

**Library of Congress Catalog Card Number 96-79989**

**British Library Cataloguing in Publication Data**

A catalogue record for this book is available from the British Library.

**Haynes Publishing Nordiska AB**

Box 1504, 751 45 UPPSALA, Sweden

<http://manuals.magnamaniac.com>



# Kawasaki The Green Meanies

*by Julian Ryder*

## Kawasaki Heavy Industries

**K**awasaki is a company of contradictions. It is the smallest of the big four Japanese manufacturers but the biggest company, it was the last of the four to make and market motorcycles yet it owns the oldest name in the Japanese industry, and it was the first to set up a factory in the USA. Kawasaki Heavy Industries, of which the motorcycle operation is but a small component, is a massive company with its heritage firmly in the old heavy industries like shipbuilding and railways; nowadays it is as much involved in aerospace as in motorcycles.

In fact it may be because of this that Kawasaki's motorcycles have always been quirky, you get the impression that they are designed by a small group of enthusiasts who are given an admirably free hand. More realistically, it may be that Kawasaki's designers have experience with techniques and materials from other engineering disciplines. Either way, Kawasaki have managed to be the factory who surprise us more than the rest. Quite often, they do this by totally ignoring a market segment the others are scrabbling over, but more often they hit us with pure, undiluted performance.

The origins of the company, and its name, go back to 1878 when Shozo Kawasaki set up a dockyard in Tokyo. By the late 1930s, the company was making its own steel in massive steelworks and manufacturing railway locos and rolling stock. In the run up to war, the Kawasaki Aircraft Company was set up in 1937 and it was this arm of the now giant operation that would look to motorcycle engine manufacture in post-war Japan.

They bought their high-technology experience to bear first on engines which were sold on to a number of manufacturers as

original equipment. Both two- and four-stroke units were made, a 58 cc and 148 cc OHC unit. One of the customer companies was Meihatsu Heavy Industries, another company within the Kawasaki group, which in 1961 was shaken up and renamed Kawasaki Auto Sales. At the same time, the Akashi factory which was to be Kawasaki's main production facility until the Kobe earthquake of 1995, was opened. Shortly afterwards, Kawasaki took over the ailing Meguro company, Japan's oldest motorcycle maker, thus instantly obtaining a range of bigger bikes which were marketed as Kawasaki-Meguros. The following year, the first bike to be made and sold as a Kawasaki was produced, a 125 cc single called the B8 and in 1963 a motocross version, the B8M appeared.



<http://manuals.magnamaniac.com>

The three cylinder two-stroke 750



## Model development

Kawasaki's first appearance on a road-race circuit came in 1965 with a batch of disc-valve 125 twins. They were no match for the opposition from Japan in the shape of Suzuki and Yamaha or for the fading force of the factory MZs from East Germany. Only after the other Japanese factories had pulled out of the class did Kawasaki win, with British rider Dave Simmonds becoming World 125 GP Champion in 1969 on a bike that looked astonishingly similar to the original racer. That same year Kawasaki reorganised once again, this time merging three companies to form Kawasaki Heavy Industries. One of the new organisation's objectives was to take motorcycle production forward and exploit markets outside Japan.

KHI achieved that target immediately and set out their stall for the future with the astonishing and frightening H1. This three-cylinder air-cooled 500 cc two-stroke was arguably the first modern pure performance bike to hit the market. It hypnotised a whole generation of motorcyclists who'd never before encountered such a ferocious, wheelie inducing power band or such shattering straight-line speed allied to questionable handling. And as for the 750 cc version ...

The triples perfectly suited the late '60s, fitting in well with the student demonstrations of 1968 and the anti-establishment ethos of the Summer of Love. Unfortunately, the oil crisis would put an end to the thirsty strokers but Kawasaki had another high-performance ace up their corporate sleeve. Or rather they thought they did.

The 1968 Tokyo Show saw probably the single most significant new motorcycle ever made unveiled: the Honda CB750. At Kawasaki it caused a major shock, for they also had a 750 cc four, code-named New York Steak, almost ready to roll and it was a double, rather than single, overhead cam motor. Bravely, they took the decision to go ahead - but with the motor taken out to 900 cc. The result was the Z1, unveiled at the 1972 Cologne Show. It was a bike straight out of the same mould as the H1, scare stories spread about unmanageable power, dubious straight-line stability and frightening handling, none of which stopped the sales graph rocketing upwards and led to the coining of the term 'superbike'. While rising fuel prices cut short development of the big two-strokes, the Z1 went on to found a dynasty, indeed its genes can still be detected in Kawasaki's latest products like the ZZ-R1100 (Ninja ZX-11).

This is another characteristic of the way Kawasaki operates. Models quite often have very long lives, or gradually evolve. There is no major difference between that first Z1 and the air-cooled GPz range. Add water-cooling and you have the GPZ900, which in turn metamorphosed into the GPZ1000RX, then the ZX-10 and the ZZ-R1100. Indeed, the



The first Superbike, Kawasaki's 900 cc Z1



One of the two-stroke engined KH and KE range - the KE100B





The GT750 - a favourite hack for despatch riders

last three models share the same 58 mm stroke. The bikes are obviously very different but it's difficult to put your finger on exactly why.

Other models have remained effectively untouched for over a decade: the KH and KE

single-cylinder air-cooled two-stroke learner bikes, the GT550 and 750 shaft-drive hacks favoured by big city despatch riders and the GPz305 being prime examples. It's only when they step outside the performance field that Kawasaki seems less sure. Their first factory

customs were dire, you simply got the impression that the team that designed them didn't have their heart in the job. Only when the Classic range appeared in 1995 did they get it right.

## Racing success

Kawasaki also have a more focused approach to racing than the other factories. The policy has always been to race the road bikes and with just a couple of exceptions that's what they've done. Even Simmonds' championship winner bore a strong resemblance to the twins they were selling in the late '60s and racing versions of the 500 and 750 cc triples were also sold as over-the-counter racers, the H1R and H2R. The 500 was in the forefront of the two-stroke assault on MV Agusta but wasn't a Grand Prix winner. It was the 750 that made the impact and carried the factory's image in F750 racing against the Suzuki triples and Yamaha fours.

The factory's decision to use green, usually regarded as an unlucky colour in sport, meant its bikes and personnel stood out and the phrase 'Green Meanies' fitted them perfectly. The Z1 motor soon became a full 1000 cc and powered Kawasaki's assault in F1 racing, notably in endurance which Kawasaki saw as being most closely related to its road bikes.

That didn't stop them dominating 250 and 350 cc GPs with a tandem twin two-stroke in the late '70s and early '80s, but their path-breaking monocoque 500 while a race winner never won a world title. When Superbike arrived, Kawasaki's road 750s weren't as track-friendly as the opposition's out-and-out race replicas. This makes Scott Russell's World title on the ZXR750 in 1993 even more praiseworthy, for the homologation bike, the ZXR750RR, was much heavier and much more of a road bike than the Italian and Japanese competition.

The company's Supersport 600 contenders have similarly been more sports-tourers than race-replicas, yet they too have been competitive on the track. Indeed, the flagship bike, the ZZ-R1100, is most definitely a sports tourer capable of carrying two people and their luggage at high speed in comfort all day and then doing it again the next day. Try that on one of the race replicas and you'll be in need of a course of treatment from a chiropractor.

Through doing it their way Kawasaki developed a brand loyalty for their performance bikes that kept the Z1's derivatives in production until the mid-'80s and turned the bike into a classic in its model life. You could even argue that the Z1 lives on in the shape of the 1100 Zephyr's GPz1100-derived motor. And that's another Kawasaki invention, the retro bike. But when you look at what many commentators refer to as the retro boom, especially in Japan, you find that it is no such thing. It is the Zephyr boom. Just another example of Japan's most surprising motorcycle manufacturer getting it right again.



The high-performance ZXR750



## The ZX900, 1000 and 1100 liquid-cooled fours

When the world's motorcycle press turned up at Laguna Seca race track in December 1983 for the riding launch of the GPZ900R there was an instant run on global reserves of superlatives. Here was that rarest of things, a genuine quantum leap forwards, a new design that instantly rendered most of its competition redundant - notably the GPZ1100 and Z750 Turbo which at the time were top of Kawasaki's range. Here was a bike that packed the power of an 1100 into a 750-size package with state-of-the-art suspension and striking looks. The Production TT proved the bike was track-worthy and the road tests showed it was a comfortable, practical roadster. At the time, it was seen as an out-and-out sportster but not a race-replica, which made its TT victories even more noteworthy.

It didn't take Kawasaki long to try and improve on the first Ninja as the 900 was called everywhere except the UK, the GPZ1000RX (Ninja 1000R in the US) arrived in 1986 to mixed reviews because most journalists could not see how it was in any way an improvement on the 900. The RX motor was basically a bored-out 900 motor with revised breathing arrangements, but the chassis was completely new. Gone was the spine frame that used the motor as a load-bearing member and in came a full cradle frame which made the bike bigger and heavier.

The RX was certainly one of the fastest - if not the fastest - bikes available in the mid-'80s but it didn't take long for it to be superseded, this time by the ZX-10. Although the bore and stroke dimensions stayed the same, the motor was heavily modified and lightened. Valve lash adjustment changed from screw and tappet to shim, and the motor lost over 37 lb of weight. Only the crankcases remained the same. The chassis changed completely again, this time to an aluminium frame in the Deltabox configuration that was now becoming the industry standard. The steering was



The ZZ-R1100 sports tourer

sharpened up and the styling made less slabby. Everyone agreed, here was a major step forward compared to the 1000RX - but was it really better than the original 900? Probably not.

The genuine leap forward came in 1990 with the ZZ-R1100 (Ninja ZX-11 in the US). All sporting pretensions were abandoned and the bike was presented as an unashamed sports tourer, but also as the fastest bike money could buy. These seemingly mutually exclusive requirements were somehow resolved in a package that like the first Z1 and the first Ninja, is much more than the sum of its parts. It's fast, it's comfortable, it's easy to ride, it simply has no faults. The motor was bored out again and heavily modified and installed in a much better looking bike. It was

heavier than the ZX-10 but just worked better, refined is the best word to describe it. It is astonishingly fast yet very civilised to live with. Like all the great Kawasakis, the ZZ-R1100 enjoys a long model life.

The original GPZ900 went through six model changes (A1 to A8) but the last one lived on in importers ranges for years after it first appeared in 1991. In the UK, it was even reintroduced as a bargain bike. The RX and ZX-10 only went through three model changes, A1 to A3 and B1 to B3, respectively. Seven years into its model life the ZZ-R1100 is still going strong, still being updated annually and still winning comparison tests with all its rivals - remarkably you can still detect the heritage of the original Kawasaki superbike, the Z1, in the thing.

## Acknowledgements

Our thanks are due to CW Motorcycles of Dorchester and TVM Motorcycles of Newton Abbot who supplied the machines featured in the photographs throughout this manual. Thanks are also due to Kawasaki Motors (UK) Ltd for supply of technical information and permission to use some of the line drawings featured. The Avon Rubber Company supplied information on tyre fitting, and NGK Spark plugs (UK) Ltd provided information on spark plug maintenance and electrode conditions.

Thanks are also due to Kawasaki Information Service and Kel Edge for supplying transparencies, and to Phil Flowers who carried out the front cover photography.

The introduction "Kawasaki - The Green Meanies" was written by Julian Ryder.

## About this Manual

The aim of this manual is to help you get the best value from your motorcycle. It can do so in several ways. It can help you decide what work must be done, even if you choose to have it done by a dealer; it provides information and procedures for routine maintenance and servicing; and it offers diagnostic and repair procedures to follow when trouble occurs.

We hope you use the manual to tackle the work yourself. For many simpler jobs, doing it yourself may be quicker than arranging an appointment to get a motorcycle fixed at a dealer and making the trips to leave it and

pick it up. More importantly, a lot of money can be saved by avoiding the expense the shop must pass on to you to cover its labour and overhead costs. An added benefit is the sense of satisfaction and accomplishment that you feel after doing the job yourself.

References to the left or right side of the motorcycle assume you are sitting on the seat, facing forward.

We take great pride in the accuracy of information given in this manual, but motorcycle manufacturers make alterations and design changes during the production run of a particular motorcycle of which they do not inform us. No liability can be accepted by the authors or publishers for loss, damage or injury caused by any errors in, or omissions from, the information given.



## Frame and engine numbers

The frame number is stamped into the right-hand side of the steering head. The engine number is stamped into the top of the crankcase, on the right-hand side, just below no. 4 carburettor. Both of these numbers should be recorded and kept in a safe place

so they can be furnished to law enforcement officials in the event of a theft. There is also a carburettor identification number on the side of each carburettor body.

Machines in this manual are identified by their model code rather than popular name. If

not known, the model code can be established from the engine and frame numbers (see following list). Note that the dates given are Kawasaki's production years and these will not necessarily coincide with the date of registration.

Popular name / year	Model code	Frame number	Engine number
<b>UK GPZ900R:</b>			
1984	ZX900 A1	ZX900A-000001-015000	ZX900AE000001 on
		ZX900A-015004-015500	ZX900AE000001 on
1985	ZX900 A2	ZX900A-015001-015003	ZX900AE019001 on
		ZX900A-015501 on	ZX900AE019001 on
1986	ZX900 A3	ZX900A-031001 on	ZX900AE040001 on
1987	ZX900 A4	ZX900A-035101 on	ZX900AE046001 on
1988	ZX900 A5/ASA	ZX900A-038501 on	ZX900AE048501 on
1989	ZX900 A6	ZX900A-042001 on	ZX900AE048501 on
1990	ZX900 A7	ZX900A-048001 on	ZX900AE048501 on
1991-96	ZX900 A8	ZX900A-056001 on	ZX900AE048501 on
<b>UK GPZ1000RX:</b>			
1986	ZX1000 A1	ZXT00A-000001 on	ZXT00AE000001 on
1987	ZX1000 A2	ZXT00A-014801 on	ZXT00AE021001 on
1988	ZX1000 A3/A3A	ZXT00A-022401 on	ZXT00AE028501 on
<b>UK ZX-10:</b>			
1988	ZX1000 B1	ZXT00B-000001-012000	ZXT00AE027801 on
		ZXT00B-012452-017000	ZXT00AE028501 on
1989	ZX1000 B2	ZXT00B-012001-012451	ZXT00AE028501 on
		ZXT00B-017001-028000	ZXT00AE028501 on
1990-91	ZX1000 B3	ZXT00B-028001 on	ZXT00AE028501 on
<b>UK ZZ-R1100:</b>			
1990	ZX1100 C1	ZXT10C-000001-013000	ZXT10CE000001 on
1991	ZX1100 C2	ZXT10C-013001 on	ZXT10CE000001 on
1992	ZX1100 C3	ZXT10C-024001 on	ZXT10CE000001 on
1993	ZX1100 D1	ZXT10D-000001-020000	ZXT10CE000001 on
1994	ZX1100 D2	ZXT10D-020001 on	ZXT10CE000001 on
1995	ZX1100 D3	ZXT10D-032001 on	ZXT10CE000001 on
1996	ZX1100 D4	ZXT10D-039001 on	ZXT10CE000001 on
1997	ZX1100 D5	ZXT10D-045001 on	ZXT10CE000001 on
<b>US Ninja (J - made in Japan, US - made in US):</b>			
1984	ZX900 A1 (J)	JKAZX2A1-EA000001 on	ZX900AE000001 on
	ZX900 A1 (US)	JKAZX2A1-EB000001 on	ZX900AE000001 on
1985	ZX900 A2 (J)	JKAZX2A1-FA015001 on	ZX900AE019001 on
	ZX900 A2 (US)	JKAZX2A1-FB505301 on	ZX900AE019001 on
1986	ZX900 A3 (J)	JKAZX2A1-GA031001 on	ZX900AE040001 on
	ZX900 A3 (US)	JKAZX2A1-GB512701 on	ZX900AE040001 on
<b>US Ninja 1000R (J - made in Japan, US - made in US):</b>			
1986	ZX1000 A1 (J)	JKAZXCA1-GA000001 on	ZXT00AE000001 on
	ZX1000 A1 (US)	JKAZXCA1-GB500001 on	ZXT00AE000001 on
1987	ZX1000 A2 (J)	JKAZXCA1-HA014801 on	ZXT00AE021001 on
	ZX1000 A2 (US)	JKAZXCA1-HB508401 on	ZXT00AE021001 on
<b>US Ninja ZX-10:</b>			
1988	ZX1000 B1	JKAZXCB1-JA000001 on	ZXT00AE028501 on
1989	ZX1000 B2	JKAZXCB1-KA012001 on	ZXT00AE040301 on
1990	ZX1000 B3	JKAZXCB1-LA028001 on	N/A
<b>US Ninja ZX11 (J - made in Japan, US - made in US):</b>			
1990	ZX1100 C1 (J)	JKAZXBC1-LA000001 on	ZXT10CE000001 on
1990	ZX1100 C1 (US)	JKAZXBC1-LB000001 on	ZXT10CE000001 on
1991	ZX1100 C2 (J)	JKAZXBC1-MA013001-024000	ZXT10CE000001 on
1991	ZX1100 C2 (US)	JKAZXBC1-MB501701-504600	ZXT10CE000001 on
1992	ZX1100 C3 (J)	JKAZXBC1-NA024001 on	ZXT10CE000001 on
1992	ZX1100 C3 (US)	JKAZXBC1-NB504601 on	ZXT10CE000001 on
1993	ZX1100 C4 (US)	JKAZXBC1-PB508201 on	ZXT10CE000001 on
1993	ZX1100D1 (J)	JKAZXBD1-PA000001 on	ZXT10CE000001 on
1993	ZX1100 D1 (US)	JKAZXBD1-PB500001 on	ZXT10CE000001 on
1994	ZX1100 D2 (J)	JKAZXBD1-RA020001 on	ZXT10CE000001 on
1994	ZX1100 D2 (US)	JKAZXBD1-RB502701 on	ZXT10CE000001 on
1995	ZX1100 D3 (J)	JKAZXBD1-SA032001 on	ZXT10CE000001 on
1995	ZX1100 D3 (US)	JKAZXBD1-SB505101 on	ZXT10CE000001 on
1996	ZX1100 D4 (J)	JKAZXBD1-TA039001-045000	ZXT10CE000001 on
1996	ZX1100 D4 (US)	JKAZXBD1-TB506951-509100	ZXT10CE000001 on
1997	ZX1100 D5 (J)	JKAZXBD1-VA045001 on	ZXT10CE000001 on
1997	ZX1100 D5 (US)	JKAZXBD1-VB509101 on	ZXT10CE000001 on



## Buying spare parts

Once you have found all the identification numbers, record them for reference when buying parts. Since the manufacturers change specifications, parts and vendors (companies that manufacture various components on the machine), providing the ID numbers is the only way to be reasonably sure that you are buying the correct parts.

Whenever possible, take the worn part to the dealer so direct comparison with the new

component can be made. Along the trail from the manufacturer to the parts shelf, there are numerous places that the part can end up with the wrong number or be listed incorrectly.

The two places to purchase new parts for your motorcycle - the accessory store and the franchised dealer - differ in the type of parts they carry. While dealers can obtain virtually every part for your motorcycle, the accessory dealer is usually limited to normal high wear items such as shock absorbers, tune-up parts, various engine gaskets, cables, chains,

brake parts, etc. Rarely will an accessory outlet have major suspension components, cylinders, transmission gears, or cases.

Used parts can be obtained for roughly half the price of new ones, but you can't always be sure of what you're getting. Once again, take your worn part to the wrecking yard (breaker) for direct comparison.

Whether buying new, used or rebuilt parts, the best course is to deal directly with someone who specializes in parts for your particular make.



Engine number location



Frame number location





Professional mechanics are trained in safe working procedures. However enthusiastic you may be about getting on with the job at hand, take the time to ensure that your safety is not put at risk. A moment's lack of attention can result in an accident, as can failure to observe simple precautions.

There will always be new ways of having accidents, and the following is not a comprehensive list of all dangers; it is intended rather to make you aware of the risks and to encourage a safe approach to all work you carry out on your bike.

## Asbestos

● Certain friction, insulating, sealing and other products - such as brake pads, clutch linings, gaskets, etc. - contain asbestos. Extreme care must be taken to avoid inhalation of dust from such products since it is hazardous to health. If in doubt, assume that they do contain asbestos.

## Fire

● Remember at all times that petrol is highly flammable. Never smoke or have any kind of naked flame around, when working on the vehicle. But the risk does not end there - a spark caused by an electrical short-circuit, by two metal surfaces contacting each other, by careless use of tools, or even by static electricity built up in your body under certain conditions, can ignite petrol vapour, which in a confined space is highly explosive. Never use petrol as a cleaning solvent. Use an approved safety solvent.

● Always disconnect the battery earth terminal before working on any part of the fuel or electrical system, and never risk spilling fuel on to a hot engine or exhaust.

● It is recommended that a fire extinguisher of a type suitable for fuel and electrical fires is kept handy in the garage or workplace at all times. Never try to extinguish a fuel or electrical fire with water.

## Fumes

● Certain fumes are highly toxic and can quickly cause unconsciousness and even death if inhaled to any extent. Petrol vapour comes into this category, as do the vapours from certain solvents such as trichloroethylene. Any draining or pouring of such volatile fluids should be done in a well ventilated area.

● When using cleaning fluids and solvents, read the instructions carefully. Never use materials from unmarked containers - they may give off poisonous vapours.

● Never run the engine of a motor vehicle in an enclosed space such as a garage. Exhaust fumes contain carbon monoxide which is extremely poisonous; if you need to run the engine, always do so in the open air or at least have the rear of the vehicle outside the workplace.

## The battery

● Never cause a spark, or allow a naked light near the vehicle's battery. It will normally be giving off a certain amount of hydrogen gas, which is highly explosive.

● Always disconnect the battery ground (earth) terminal before working on the fuel or electrical systems (except where noted).

● If possible, loosen the filler plugs or cover when charging the battery from an external source. Do not charge at an excessive rate or the battery may burst.

● Take care when topping up, cleaning or carrying the battery. The acid electrolyte, even when diluted, is very corrosive and should not be allowed to contact the eyes or skin. Always wear rubber gloves and goggles or a face shield. If you ever need to prepare electrolyte yourself, always add the acid slowly to the water; never add the water to the acid.

## Electricity

● When using an electric power tool, inspection light etc., always ensure that the appliance is correctly connected to its plug and that, where necessary, it is properly grounded (earthed). Do not use such appliances in damp conditions and, again, beware of creating a spark or applying excessive heat in the vicinity of fuel or fuel vapour. Also ensure that the appliances meet national safety standards.

● A severe electric shock can result from touching certain parts of the electrical system, such as the spark plug wires (HT leads), when the engine is running or being cranked, particularly if components are damp or the insulation is defective. Where an electronic ignition system is used, the secondary (HT) voltage is much higher and could prove fatal.

## Remember...

✗ **Don't** start the engine without first ascertaining that the transmission is in neutral.

✗ **Don't** suddenly remove the pressure cap from a hot cooling system - cover it with a cloth and release the pressure gradually first, or you may get scalded by escaping coolant.

✗ **Don't** attempt to drain oil until you are sure it has cooled sufficiently to avoid scalding you.

✗ **Don't** grasp any part of the engine or exhaust system without first ascertaining that it is cool enough not to burn you.

✗ **Don't** allow brake fluid or antifreeze to contact the machine's paintwork or plastic components.

✗ **Don't** siphon toxic liquids such as fuel, hydraulic fluid or antifreeze by mouth, or allow them to remain on your skin.

✗ **Don't** inhale dust - it may be injurious to health (see Asbestos heading).

✗ **Don't** allow any spilled oil or grease to remain on the floor - wipe it up right away, before someone slips on it.

✗ **Don't** use ill-fitting spanners or other tools which may slip and cause injury.

✗ **Don't** lift a heavy component which may be beyond your capability - get assistance.

✗ **Don't** rush to finish a job or take unverified short cuts.

✗ **Don't** allow children or animals in or around an unattended vehicle.

✗ **Don't** inflate a tyre above the recommended pressure. Apart from overstressing the carcass, in extreme cases the tyre may blow off forcibly.

✓ **Do** ensure that the machine is supported securely at all times. This is especially important when the machine is blocked up to aid wheel or fork removal.

✓ **Do** take care when attempting to loosen a stubborn nut or bolt. It is generally better to pull on a spanner, rather than push, so that if you slip, you fall away from the machine rather than onto it.

✓ **Do** wear eye protection when using power tools such as drill, sander, bench grinder etc.

✓ **Do** use a barrier cream on your hands prior to undertaking dirty jobs - it will protect your skin from infection as well as making the dirt easier to remove afterwards; but make sure your hands aren't left slippery. Note that long-term contact with used engine oil can be a health hazard.

✓ **Do** keep loose clothing (cuffs, ties etc. and long hair) well out of the way of moving mechanical parts.

✓ **Do** remove rings, wristwatch etc., before working on the vehicle - especially the electrical system.

✓ **Do** keep your work area tidy - it is only too easy to fall over articles left lying around.

✓ **Do** exercise caution when compressing springs for removal or installation. Ensure that the tension is applied and released in a controlled manner, using suitable tools which preclude the possibility of the spring escaping violently.

✓ **Do** ensure that any lifting tackle used has a safe working load rating adequate for the job.

✓ **Do** get someone to check periodically that all is well, when working alone on the vehicle.

✓ **Do** carry out work in a logical sequence and check that everything is correctly assembled and tightened afterwards.

✓ **Do** remember that your vehicle's safety affects that of yourself and others. If in doubt on any point, get professional advice.

● If in spite of following these precautions, you are unfortunate enough to injure yourself, seek medical attention as soon as possible.



# 1 Clutch and brake fluid level check



**Warning:** Brake hydraulic fluid can harm your eyes and damage painted surfaces, so use extreme caution when handling and pouring it and cover surrounding surfaces with rag. Do not use fluid that has been standing open for some time, as it absorbs moisture from the air which can cause a dangerous loss of braking/clutch effectiveness.

## Before you start:

- ✓ Make sure you have the correct hydraulic fluid - DOT 4.
- ✓ With the motorcycle held level, turn the handlebars until the top of the master cylinder is as level as possible. If necessary, loosen the brake lever clamp bolts and rotate the master cylinder assembly slightly to make it level.
- ✓ On the rear brake reservoir, located behind the right-hand sidepanel (ZX900 and 1000 models) or under the seat (ZX1100 C/D models), the fluid level is visible through the translucent material of the reservoir; it should be between the upper and lower level marks on the side of the reservoir.

## Bike care:

- In order to ensure proper operation of the hydraulic disc brake, the fluid level in the master cylinder reservoir must be properly maintained. If the brake fluid level was low, inspect the brake system for leaks.
- The fluid in the brake master cylinder reservoir will drop slightly as the brake pads wear down.
- Check the operation of the brakes before taking the machine on the road; if there is evidence of air in the system (spongy feel to lever), it must be bled.
- Before removing the master cylinder cap, protect the motorcycle from brake fluid spills (which will damage the paint) and remove all dust and dirt from the area around the cap.



- 1** Check that the fluid level, as seen through the sightglass in the reservoir body, is not below the lower level mark. The mark is in the form of a raised line cast into the reservoir body.




- 2** Remove both the retaining screws and lift off the cover, or unscrew the reservoir cap (as applicable), and remove the diaphragm; note that later models have a plate fitted above the diaphragm on the front reservoir.



- 3** Using a good quality brake fluid, from a freshly opened container, top up the reservoir to the upper level mark. On the front brake and clutch reservoirs the upper level mark is in the form of a line, cast on the inside of the front face of the reservoir.



- 4** When the fluid level is correct, clean and dry the diaphragm, fold it into its compressed state and refit it, together with the plate (later models), to the reservoir. Refit the reservoir cover and retaining screws or the reservoir cap and tighten it securely.



- 5** Rear brake fluid level should be between the upper and lower lines on the side of the reservoir. Unscrew the cap to allow topping up.



## 2 Coolant level check

### Before you start:

- ✓ The engine must be cold for the results to be accurate, so always perform this check before starting the engine for the first time each day.
- ✓ Place the motorcycle on the centerstand. Make sure the motorcycle is on level ground.

### Bike care:


- Use only the specified coolant mixture. It is important that antifreeze is used in the cooling system all year round, not just during the winter months.
- In emergency cases distilled water alone may be used to top up the system, but remember that this will dilute the coolant and reduce its degree of protection against freezing.

● On ZX900 models the tank is behind the right-hand sidepanel, which must be removed to gain access to it. On ZX1000 A models the expansion tank is behind the lower fairing section, the coolant level marks being on the fairing section rather than the expansion tank itself. The ZX1000 B and ZX1100 C models have the expansion tank mounted in the right-hand side of the upper fairing, the coolant level marks being visible from the inside of the fairing. On ZX1100 D models the expansion tank is beneath the tail section on the right-hand side. Its coolant level can be checked by observing the level marks on the front portion of the tank once the seat has been removed. If the marks are indistinct, remove the tail section for a better view.


- If the coolant level falls steadily, check the system for leaks as described in Chapter 3. If no leaks are found and the level still continues to fall, it is recommended that the machine be taken to an authorized Kawasaki dealer who will pressure test the system.
- Do not overfill the coolant reservoir.
- If the coolant is significantly above the higher mark at any time, the surplus coolant should be siphoned off to prevent it from being expelled out of the breather hose once the engine has warmed up.



**Warning: Antifreeze is poisonous – don't siphon by mouth.**




**1** The ZX1000 B and ZX1100 C models have the expansion tank mounted in the right-hand side of the upper fairing, the coolant level marks being visible from the inside of the fairing.



**2** If the level is below the lower mark, it should be topped right up to the higher mark using a coolant mixture of the required strength, and using only the specified ingredients as described in Chapter 3.



**3** On ZX1100D models remove the seat to view the coolant level marks. If the level is below the LOW line.



**4** ... unscrew the reservoir cap and use a coolant mixture of the required strength and specification (see Chapter 3) to bring it up above the LOW line.



### 3 Engine/transmission oil level

#### Before you start:

- ✓ Place the motorcycle on the centerstand, then start the engine and allow it to reach normal operating temperature.

**Caution:** Do not run the engine in an enclosed space such as a garage or shop.

- ✓ Stop the engine and allow the machine to sit undisturbed for about five minutes.


#### Bike care:

- If you have to add oil frequently, you should check whether you have any oil leaks. If there is no sign of oil leakage from the joints and gaskets the engine could be burning oil (see Fault Finding in the Reference section).


#### The correct oil

- Modern, high-revving engines place great demands on their oil. It is very important that the correct oil for your bike is used.
- Always top up with a good quality oil of the specified type and viscosity and do not overfill the engine.

Oil type	API grade SE or SF (minimum)
Oil viscosity	SAE 10W/40, 10W/50, 20W/40 or 20W/50



- The oil level is checked via the oil sightglass set in the left-hand outer casing. The oil should be visible half way up the plastic window, between the level marks (arrowed).



- Top up using the recommended oil by way of the filler cap at the top of the casing.

### 4 Suspension, steering and drive chain

#### Suspension and steering:

- Make sure the steering operates smoothly, without looseness and without binding.
- Check front and rear suspension for smooth operation.

#### Drive chain:

- Make sure the drive chain isn't out of adjustment.
- Although the chain fitted as standard equipment is of the O-ring type, grease being sealed into the internal bearing surfaces by O-rings at each end of the rollers, lubrication is still required to prevent the rollers from wearing on the sprocket teeth and to prevent the O-rings from drying up. A heavy (SAE 90) gear oil or one of the proprietary aerosol applied chain lubricants is best.



**Warning:** some propellants used in aerosols cause the O-rings to deteriorate very rapidly, so make certain that the product is marked as being suitable for use with O-ring type chains.



Apply chain lubricant to the joints between the side plates, pins, bushings and rollers to provide lubrication of the internal load bearing areas - not the middle of the rollers. With the bike on its centerstand, hold the plastic nozzle near the edge of the chain and turn the wheel by hand as the lubricant sprays out; repeat this procedure on the inside edge of the chain.



Whilst spinning the back wheel, spray chain lube onto the top of the chain's lower run - centrifugal force will work the lube into the chain when the bike is moving.



## 5 Tyres

### Tyre care:

- Check the condition of the tyre valve and ensure the dust cap is in place.
- Pick out any stones or nails which may have become embedded in the tyre tread. If left, they will eventually penetrate through the casing and cause a puncture.
- If tyre damage is apparent, or unexplained loss of pressure is experienced, seek the advice of a tyre fitting specialist without delay.
- Check the tyres carefully for cuts, tears, embedded nails or other sharp objects and excessive wear. Operation of the motorcycle with excessively worn tyres is extremely hazardous, as traction and handling are directly affected.

### Tyre tread depth:

- At the time of writing UK law requires that tread depth must be at least 1 mm over 3/4 of the tread breadth all the way around the tyre, with no bald patches. Many riders, however, consider 2 mm tread depth minimum to be a safer limit.
- Many tyres now incorporate wear indicators in the tread. Identify the triangular pointer on the tyre sidewall to locate the indicator bar and replace the tyre if the tread has worn down to the bar.

### The correct pressures:

- The tyres must be checked when **cold**, not immediately after riding. Note that low tyre pressures may cause the tyre to slip on the rim or come off. High tyre pressures will cause abnormal tread wear and unsafe handling.

- Use an accurate pressure gauge.

- Proper air pressure will increase tyre life and provide maximum stability and ride comfort.


Tyre pressures	Front	Rear
UK ZX900 A1 to A6 models		
Up to 215 lb load, below 130 mph	32 psi (2.25 kg/cm <sup>2</sup> )	36 psi (2.50 kg/cm <sup>2</sup> )
215 to 399 lb load, below 130 mph	36 psi (2.50 kg/cm <sup>2</sup> )	36 psi (2.50 kg/cm <sup>2</sup> )
Above 130 mph	36 psi (2.50 kg/cm <sup>2</sup> )	41 psi (2.90 kg/cm <sup>2</sup> )
UK ZX900 A7-on models	36 psi (2.50 kg/cm <sup>2</sup> )	41 psi (2.90 kg/cm <sup>2</sup> )
US ZX900 A1 to A3 models		
Up to 215 lb load	32 psi (2.25 kg/cm <sup>2</sup> )	36 psi (2.50 kg/cm <sup>2</sup> )
215 to 397 lb load	36 psi (2.50 kg/cm <sup>2</sup> )	36 psi (2.50 kg/cm <sup>2</sup> )
UK ZX1000 A models		
Below 130 mph	36 psi (2.50 kg/cm <sup>2</sup> )	36 psi (2.50 kg/cm <sup>2</sup> )
Above 130 mph	36 psi (2.50 kg/cm <sup>2</sup> )	41 psi (2.90 kg/cm <sup>2</sup> )
UK ZX1000 B models		
Up to 215 lb load, below 130 mph	36 psi (2.50 kg/cm <sup>2</sup> )	36 psi (2.50 kg/cm <sup>2</sup> )
215 to 399 lb load, below 130 mph	36 psi (2.50 kg/cm <sup>2</sup> )	41 psi (2.90 kg/cm <sup>2</sup> )
Above 130 mph	36 psi (2.50 kg/cm <sup>2</sup> )	41 psi (2.90 kg/cm <sup>2</sup> )
US ZX1000 A and ZX1000 B models	36 psi (2.50 kg/cm <sup>2</sup> )	41 psi (2.90 kg/cm <sup>2</sup> )
ZX1100 C/D models	41 psi (2.90 kg/cm <sup>2</sup> )	41 psi (2.90 kg/cm <sup>2</sup> )



- 1** Check the tyre pressures when the tyres are **cold** and keep them properly inflated.



- 2** Measure the tread depth at the centre of the tyre using a tread depth gauge.



- 3** Tyre tread wear indicator bar and its location marking on the sidewall (arrowed).

## 6 Legal and safety checks

### Lighting and signalling:

- Take a minute to check that the headlight, taillight, brake light and turn signals all work correctly.
- Check that the horn sounds when the switch is operated.
- A working speedometer is a statutory requirement in the UK.

### Safety:

- Check that the throttle grip rotates smoothly and snaps shut when released, in all steering positions.
- Check that the engine shuts off when the kill switch is operated.
- Check that sidestand return spring holds the stand securely up when retracted. The same applies to the centerstand (where fitted).
- Following the procedure in your owner's manual check the operation of the sidestand switch.

### Fuel:

- This may seem obvious, but check that you have enough fuel to complete your journey. If you notice signs of fuel leakage - rectify the cause immediately.
- Ensure you use the correct grade fuel - see Chapter 4 Specifications.



# Kawasaki ZX900, 1000 & 1100 Liquid-cooled Fours

## Service and Repair Manual

by Mark Coombs and Penny Cox

### Models covered

(1681-248-10Y4)

ZX900 A (GPZ900R). 908cc. UK April 1984 to 1996  
ZX900 A (Ninja). 908cc. US November 1983 to 1986  
ZX1000 A (GPZ1000RX). 997cc. UK November 1985 to September 1989  
ZX1000 A (Ninja 1000R). 997cc. US September 1985 to 1987  
ZX1000 B (ZX-10). 997cc. UK December 1987 to April 1991  
ZX1000 B (Ninja ZX-10). 997cc. US April 1988 to 1990  
ZX1100 C (ZZ-R1100). 1052cc. UK March 1990 to December 1992  
ZX1100 C (Ninja ZX-11C). 1052cc. US 1990 to 1993  
ZX1100 D (ZZ-R1100). 1052cc. UK December 1992 to 1997  
ZX1100 D (Ninja ZX-11D). 1052cc. US 1993 to 1997

© Haynes Publishing 1999

AB

Printed in the USA

A book in the **Haynes Service and Repair Manual Series**

**Haynes Publishing**

Sparkford, Nr Yeovil, Somerset BA22 7JJ, England

**All rights reserved. No part of this book may be reproduced or transmitted in any form or by any means, electronic or mechanical, including photocopying, recording or by any information storage or retrieval system, without permission in writing from the copyright holder.**

**Haynes North America, Inc**

861 Lawrence Drive, Newbury Park, California 91320, USA

ISBN 1 85960 355 6

**Editions Haynes S.A.**

Tour Aurore - IBC, 18 Place des Reflets,  
92975 Paris la Défense 2, Cedex, France

**Library of Congress Catalog Card Number 96-79989**

**British Library Cataloguing in Publication Data**

A catalogue record for this book is available from the British Library.

**Haynes Publishing Nordiska AB**

Box 1504, 751 45 UPPSALA, Sweden

<http://manuals.magnamaniac.com>



## Frame and engine numbers

The frame number is stamped into the right-hand side of the steering head. The engine number is stamped into the top of the crankcase, on the right-hand side, just below no. 4 carburettor. Both of these numbers should be recorded and kept in a safe place

so they can be furnished to law enforcement officials in the event of a theft. There is also a carburettor identification number on the side of each carburettor body.

Machines in this manual are identified by their model code rather than popular name. If

not known, the model code can be established from the engine and frame numbers (see following list). Note that the dates given are Kawasaki's production years and these will not necessarily coincide with the date of registration.

Popular name / year	Model code	Frame number	Engine number
<b>UK GPZ900R:</b>			
1984	ZX900 A1	ZX900A-000001-015000	ZX900AE000001 on
		ZX900A-015004-015500	ZX900AE000001 on
1985	ZX900 A2	ZX900A-015001-015003	ZX900AE019001 on
		ZX900A-015501 on	ZX900AE019001 on
1986	ZX900 A3	ZX900A-031001 on	ZX900AE040001 on
1987	ZX900 A4	ZX900A-035101 on	ZX900AE046001 on
1988	ZX900 A5/ASA	ZX900A-038501 on	ZX900AE048501 on
1989	ZX900 A6	ZX900A-042001 on	ZX900AE048501 on
1990	ZX900 A7	ZX900A-048001 on	ZX900AE048501 on
1991-96	ZX900 A8	ZX900A-056001 on	ZX900AE048501 on
<b>UK GPZ1000RX:</b>			
1986	ZX1000 A1	ZXT00A-000001 on	ZXT00AE000001 on
1987	ZX1000 A2	ZXT00A-014801 on	ZXT00AE021001 on
1988	ZX1000 A3/A3A	ZXT00A-022401 on	ZXT00AE028501 on
<b>UK ZX-10:</b>			
1988	ZX1000 B1	ZXT00B-000001-012000	ZXT00AE027801 on
		ZXT00B-012452-017000	ZXT00AE028501 on
1989	ZX1000 B2	ZXT00B-012001-012451	ZXT00AE028501 on
		ZXT00B-017001-028000	ZXT00AE028501 on
1990-91	ZX1000 B3	ZXT00B-028001 on	ZXT00AE028501 on
<b>UK ZZ-R1100:</b>			
1990	ZX1100 C1	ZXT10C-000001-013000	ZXT10CE000001 on
1991	ZX1100 C2	ZXT10C-013001 on	ZXT10CE000001 on
1992	ZX1100 C3	ZXT10C-024001 on	ZXT10CE000001 on
1993	ZX1100 D1	ZXT10D-000001-020000	ZXT10CE000001 on
1994	ZX1100 D2	ZXT10D-020001 on	ZXT10CE000001 on
1995	ZX1100 D3	ZXT10D-032001 on	ZXT10CE000001 on
1996	ZX1100 D4	ZXT10D-039001 on	ZXT10CE000001 on
1997	ZX1100 D5	ZXT10D-045001 on	ZXT10CE000001 on
<b>US Ninja (J - made in Japan, US - made in US):</b>			
1984	ZX900 A1 (J)	JKAZX2A1-EA000001 on	ZX900AE000001 on
	ZX900 A1 (US)	JKAZX2A1-EB000001 on	ZX900AE000001 on
1985	ZX900 A2 (J)	JKAZX2A1-FA015001 on	ZX900AE019001 on
	ZX900 A2 (US)	JKAZX2A1-FB505301 on	ZX900AE019001 on
1986	ZX900 A3 (J)	JKAZX2A1-GA031001 on	ZX900AE040001 on
	ZX900 A3 (US)	JKAZX2A1-GB512701 on	ZX900AE040001 on
<b>US Ninja 1000R (J - made in Japan, US - made in US):</b>			
1986	ZX1000 A1 (J)	JKAZXCA1-GA000001 on	ZXT00AE000001 on
	ZX1000 A1 (US)	JKAZXCA1-GB500001 on	ZXT00AE000001 on
1987	ZX1000 A2 (J)	JKAZXCA1-HA014801 on	ZXT00AE021001 on
	ZX1000 A2 (US)	JKAZXCA1-HB508401 on	ZXT00AE021001 on
<b>US Ninja ZX-10:</b>			
1988	ZX1000 B1	JKAZXCB1-JA000001 on	ZXT00AE028501 on
1989	ZX1000 B2	JKAZXCB1-KA012001 on	ZXT00AE040301 on
1990	ZX1000 B3	JKAZXCB1-LA028001 on	N/A
<b>US Ninja ZX11 (J - made in Japan, US - made in US):</b>			
1990	ZX1100 C1 (J)	JKAZXBC1-LA000001 on	ZXT10CE000001 on
1990	ZX1100 C1 (US)	JKAZXBC1-LB000001 on	ZXT10CE000001 on
1991	ZX1100 C2 (J)	JKAZXBC1-MA013001-024000	ZXT10CE000001 on
1991	ZX1100 C2 (US)	JKAZXBC1-MB501701-504600	ZXT10CE000001 on
1992	ZX1100 C3 (J)	JKAZXBC1-NA024001 on	ZXT10CE000001 on
1992	ZX1100 C3 (US)	JKAZXBC1-NB504601 on	ZXT10CE000001 on
1993	ZX1100 C4 (US)	JKAZXBC1-PB508201 on	ZXT10CE000001 on
1993	ZX1100D1 (J)	JKAZXBD1-PA000001 on	ZXT10CE000001 on
1993	ZX1100 D1 (US)	JKAZXBD1-PB500001 on	ZXT10CE000001 on
1994	ZX1100 D2 (J)	JKAZXBD1-RA020001 on	ZXT10CE000001 on
1994	ZX1100 D2 (US)	JKAZXBD1-RB502701 on	ZXT10CE000001 on
1995	ZX1100 D3 (J)	JKAZXBD1-SA032001 on	ZXT10CE000001 on
1995	ZX1100 D3 (US)	JKAZXBD1-SB505101 on	ZXT10CE000001 on
1996	ZX1100 D4 (J)	JKAZXBD1-TA039001-045000	ZXT10CE000001 on
1996	ZX1100 D4 (US)	JKAZXBD1-TB506951-509100	ZXT10CE000001 on
1997	ZX1100 D5 (J)	JKAZXBD1-VA045001 on	ZXT10CE000001 on
1997	ZX1100 D5 (US)	JKAZXBD1-VB509101 on	ZXT10CE000001 on



# Dimensions and weights



	ZX900 A1 to A6	ZX900 A7-on	ZX1000 A
<b>Overall length:</b>			
UK models	2200 mm (86.6 in)	2200 mm (86.6 in)	2230 mm (88.0 in)
US models	2150 mm (84.6 in)	2150 mm (84.6 in)	2180 mm (85.8 in)
<b>Overall width</b>	750 mm (29.5 in)	730 mm (27.8 in)	725 mm (28.5 in)
<b>Overall height</b>	1215 mm (47.8 in)	1220 mm (48.0 in)	1215 mm (47.8 in)
<b>Seat height</b>	780 mm (30.7 in)	Not available	805 mm (31.7 in)
<b>Wheelbase:</b>			
UK models	1495 mm (58.9 in)	1500 mm (59.1 in)	1505 mm (59.3 in)
US models	1495 mm (58.9 in)	1500 mm (59.1 in)	1500 mm (59.0 in)
<b>Ground clearance</b>	140 mm (5.5 in)	140 mm (5.5 in)	140 mm (5.5 in)
<b>Dry weight*</b>	228 kg (503 lb)	234 kg (516 lb)	238 kg (525 lb)
	ZX1000 B	ZX1100 C	ZX1100 D
<b>Overall length</b>	2170 mm (85.4 in)	2165 mm (85.2 in)	2165 mm (85.2 in)
<b>Overall width</b>	715 mm (28.1 in)	720 mm (28.4 in)	730 mm (28.7 in)
<b>Overall height</b>	1240 mm (48.8 in)	1210 mm (47.6 in)	1205 mm (47.4 in)
<b>Seat height</b>	790 mm (31.1 in)	780 mm (30.7 in)	780 mm (30.7 in)
<b>Wheelbase</b>	1490 mm (58.7 in)	1480 mm (58.3 in)	1495 mm (58.9 in)
<b>Ground clearance</b>	125 mm (4.9 in)	110 mm (4.3 in)	110 mm (4.3 in)
<b>Dry weight*</b>	222 kg (490 lb)	228 kg (503 lb)	233 kg (514 lbs)

\*Add 0.5 kg (1 lb) for California models



# Specifications

## Engine

### Oil capacity:

#### At oil change:

ZX1100 C/D .....	3.2 lit (5.7 Imp pt/3.4 US qt)
All other models .....	2.7 lit (4.8 Imp pt/2.9 US qt)

#### At oil and filter change:

ZX1100 C/D models .....	3.5 lit (6.2 Imp pt/3.7 US qt)
All other models .....	3.0 lit (5.3 Imp pt/3.2 US qt)

### Spark plug type:

#### ZX900 and ZX1000 A models:

UK models .....	DR8ES
US models .....	D8EA

#### ZX1000 B and ZX1100 C/D models:

UK models .....	CR9E
US models .....	C9E

### Spark plug gap:

ZX900 and ZX1000 A models .....	0.6 - 0.7 mm (0.024 - 0.028 in)
ZX1000 B and ZX1100 C/D models .....	0.7 - 0.8 mm (0.028 - 0.032 in)

### Valve clearances - engine cold:

#### Inlet:

ZX900 and ZX1000 A models .....	0.13 - 0.18 mm (0.005 - 0.007 in)
ZX1000B and ZX1100 C/D models .....	0.13 - 0.19 mm (0.005 - 0.007in)

#### Exhaust:

ZX900 and ZX1000 A models .....	0.18 - 0.23 mm (0.007 - 0.009 in)
ZX1000 B and ZX1100 C/D models .....	0.18 - 0.24 mm (0.007 - 0.009 in)

### Idle speed:

ZX1000 A and ZX1100 D California models .....	1150 - 1250 rpm
All other models .....	950 - 1050 rpm

Throttle cable free play - measured at twistgrip ..... 2 - 3 mm (0.08 - 0.12 in)

Choke lever free play - measured at the base of lever ..... 2 - 3 mm (0.08 - 0.12 in)

### NGK

### Nippon-denso

X27ESR-U  
X24ES-U

U27ESR-N  
U27ES-N



## Cycle parts

Brake pad friction material thickness:

ZX900 A1 to A6 and ZX1000 A models	4.85 mm (0.191 in)
ZX1000 B models	4.50 mm (0.177 in)
ZX900 A7-on and ZX1100 C/D models:	
Front	4.00 mm (0.157 in)
Rear	4.50 mm (0.177 in)
Service limit all - models	1.00 mm (0.039 in)

Rear brake pedal height (below top of footrest):

ZX900 models	29 - 39 mm (1.14 - 1.54 in)
ZX1000 A models	Approx 37 mm (1.46 in)
ZX1000 B and ZX1100 models	Approx 45 mm (1.77 in)

Drive chain free play:

ZX1000 B models	30 - 40 mm (1.18 - 1.57 in)
All other models	35 - 40 mm (1.38 - 1.57 in)

Drive chain length - 20 link length:

ZX1000 A models	381.0 - 381.8 mm (15.00 - 15.04 in)
Service limit	389.0 mm (15.31 in)
All other models	317.5 - 318.4 mm (12.50 - 12.54 in)
Service limit	323.0 mm (12.72 in)

Front forks:

Oil capacity (approx) per leg at oil change:	cc	Imp fl oz	US fl oz
ZX900 A1 to A6 models	270	9.5	9.1
ZX900 A7-on models	420	14.8	14.2
ZX1000 A models	295	10.4	10.0
ZX1000 B models	360	12.7	12.2
ZX1100 C models	390	13.7	13.2
ZX1100 D models	410	14.4	13.9

Fork oil level\*:

ZX900 A1 to A6 models	357 ± 2 mm (14.1 ± 0.08 in)
ZX900 A7-on models	110 ± 2 mm (4.3 ± 0.08 in)
ZX1000 A models	348 ± 4 mm (13.7 ± 0.16 in)
ZX1000 B models	130 ± 2 mm (5.1 ± 0.08 in)
ZX1100 C models	149 ± 2 mm (5.9 ± 0.08 in)
ZX1100 D models	133 ± 2 mm (5.2 ± 0.08 in)

\* Oil level is measured from the top of the stanchion with the fork spring removed. Measurement is taken with fork leg either fully compressed or extended - see text

Tyre pressures tyres - cold:

	Front	Rear
UK ZX900 A1 to A6 models:		
Up to 97.5 kg (215 lb) load, below 130 mph (210 kmh)	2.25 kg/cm <sup>2</sup> (32 psi)	2.50 kg/cm <sup>2</sup> (36 psi)
97.5 - 181 kg (215 399 lb) load, below 130 mph (210 kmh)	2.50 kg/cm <sup>2</sup> (36 psi)	2.50 kg/cm <sup>2</sup> (36 psi)
Above 130 mph (210 kmh)	2.50 kg/cm <sup>2</sup> (36 psi)	2.90 kg/cm <sup>2</sup> (41 psi)
UK ZX900 A7-on models	2.50 kg/cm <sup>2</sup> (36 psi)	2.90 kg/cm <sup>2</sup> (41 psi)
US ZX900 A1 to A3 models:		
Up to 97.5 kg (215 lb) load	2.25 kg/cm <sup>2</sup> (36 psi)	2.50 kg/cm <sup>2</sup> (36 psi)
97.5 - 180 kg (215 - 397 lb) load	2.50 kg/cm <sup>2</sup> (36 psi)	2.50 kg/cm <sup>2</sup> (36 psi)
UK ZX1000 A models:		
Below 130 mph (210 kmh)	2.50 kg/cm <sup>2</sup> (36 psi)	2.50 kg/cm <sup>2</sup> (36 psi)
Above 130 mph (210 kmh)	2.50 kg/cm <sup>2</sup> (36 psi)	2.90 kg/cm <sup>2</sup> (41 psi)
UK ZX1000 B models:		
Up to 97.5 kg (215 lb) load, below 130 mph (210 kmh)	2.50 kg/cm <sup>2</sup> (36 psi)	2.50 kg/cm <sup>2</sup> (36 psi)
97.5 - 181 kg (215 - 399 lb) load, below 130 mph (210 kmh)	2.50 kg/cm <sup>2</sup> (36 psi)	2.90 kg/cm <sup>2</sup> (41 psi)
Above 130 mph (210 kmh)	2.50 kg/cm <sup>2</sup> (36 psi)	2.90 kg/cm <sup>2</sup> (41 psi)
US ZX1000 A and ZX1000 B models	2.50 kg/cm <sup>2</sup> (36 psi)	2.90 kg/cm <sup>2</sup> (41 psi)
ZX1100 C/D models	2.90 kg/cm <sup>2</sup> (41 psi)	2.90 kg/cm <sup>2</sup> (41 psi)

## Recommended fluids and lubricants

Engine:

Recommended oil	SAE 10W/40, 10W/50, 20W/40 or 20W/50 SE or SF class (minimum)
Fuel grade	Unleaded or leaded. Minimum octane rating 91 (Research method/RON)
Air filter	SAE 30 engine oil, SE class

Front forks:

ZX900 A1 to A6 and ZX1000 A models	SAE 10W fork oil
ZX900 A7-on, ZX1000 B and ZX1100 C/D models	SAE 10W/20 fork oil

Brake and clutch fluid

DOT 4 specification

Final drive chain

SAE 90 gear oil

Wheel bearings and speedometer drive gearbox

High melting-point grease

Steering head bearings

General purpose grease

Swinging arm and suspension linkage pivots

Molybdenum-disulphide grease

All control pivots, stand, stand pivots and throttle twistgrip

Good quality general purpose grease

Control cables

Engine oil



# Specifications

## Engine

Type .....	DOHC, 16 valve, 4-cylinder, liquid-cooled
Capacity:	
ZX900 models .....	908 cc (55 cu in)
ZX1000 models .....	997 cc (60 cu in)
ZX1100 C/D models .....	1052 cc (64 cu in)
Bore:	
ZX900 models .....	72.5 mm (2.85 in)
ZX1000 models .....	74.0 mm (2.91 in)
ZX1100 C/D models .....	76.0 mm (2.99 in)
Stroke:	
ZX900 models .....	55.0 mm (2.17 in)
ZX1000 and ZX1100 C/D models .....	58.0 mm (2.28 in)
Compression ratio:	
ZX1000 A models .....	10.2 : 1
All other models .....	11.0 : 1

<http://manuals.magnamaniac.com>



**Engine (continued)**

Engine output - UK models:	Maximum power bhp @ rpm	Maximum torque kgf m (lbf ft) @ rpm
ZX900 models	115 @ 9500	8.7 (62.9) @ 8500
ZX1000 A models	125 @ 9500	10.1 (73.1) @ 8500
ZX1000 B models	125 @ 10000	Not available
ZX1100 C/D models	125 @ 9500	Not available
Engine output - US models:		
ZX900 models	110 @ 9500	8.7 (62.9) @ 8500
ZX1000 A models	125 @ 9500	10.1 (73.1) @ 8500
ZX1000 B models	137 @ 10000	10.5 (76.0) @ 9000
ZX1100 C/D models	147 @ 10500	9.0 (81.0) @ 8500
Cylinder identification	Left to right, 1-2-3-4	
Firing order	1-2-4-3	
Compression pressure at cranking speed with engine fully warmed up:		
ZX900 models	9.4 - 14.5 kg/cm <sup>2</sup> (134 - 206 psi)	
ZX1000 A models	8.4 - 13.0 kg/cm <sup>2</sup> (119 - 185 psi)	
ZX1000 B models	8.8 - 13.5 kg/cm <sup>2</sup> (125 - 192 psi)	
ZX1100 C/D models	9.0 - 13.8 kg/cm <sup>2</sup> (128 - 196 psi)	

**Note** - compression pressure must not vary excessively between any two cylinders

**Camshafts, followers and cam chain**

Cam lobe height:	
ZX900 and ZX1000 A models	35.824 - 35.940 mm (1.410 - 1.414 in)
Service limit	35.710 mm (1.406 in)
ZX1000 B models	21.687 - 21.787 mm (0.854 - 0.858 in)
Service limit	21.590 mm (0.850 in)
ZX1100 C/D models:	
Inlet	36.872 - 36.972 mm (1.452 - 1.456 in)
Service limit	36.770 mm (1.448 in)
Exhaust	36.687 - 36.787 mm (1.444 - 1.448 in)
Service limit	36.590 mm (1.441 in)
Camshaft journal OD	24.900 - 24.922 mm (0.980 - 0.981 in)
Service limit	24.870 mm (0.979 in)
Camshaft bearing ID	25.000 - 25.021 mm (0.984 - 0.985 in)
Service limit	25.080 mm (0.987 in)
Camshaft journal/cylinder head bearing clearance	0.078 - 0.121 mm (0.003 - 0.005 in)
Service limit	0.210 mm (0.008 in)
Camshaft standard runout	Less than 0.02 mm (0.001 in)
Service limit	0.1 mm (0.004 in)
Cam follower ID:	
ZX900 and ZX1000 A models	12.500 - 12.518 mm (0.492 - 0.493 in)
Service limit	12.550 mm (0.494 in)
ZX1000 B and ZX1100 C/D models	12.000 - 12.018 mm (0.472 - 0.473 in)
Service limit	12.050 mm (0.474 in)
Cam follower shaft ID:	
ZX900 and ZX1000 A models	12.466 - 12.484 mm (0.490 - 0.491 in)
Service limit	12.440 mm (0.489 in)
ZX1000 B models	11.976 - 11.994 mm (0.471 - 0.472 in)
Service limit	11.950 mm (0.470 in)
ZX1100 C/D models	11.966 - 11.984 mm (0.470 - 0.471 in)
Service limit	11.940 mm (0.469 in)
Camchain standard length of 20 links	158.8 - 159.2 mm (6.252 - 6.268 in)
Service limit	161.5 mm (6.358 in)

**Cylinder head**

Maximum warp	0.050 mm (0.002 in)
--------------	---------------------

**Cylinder block**

Cylinder bore ID:	
ZX900 models	72.494 - 72.506 mm (2.854 - 2.855 in)
Service limit	72.600 mm (2.858 in)
ZX1000 models	73.994 - 74.006 mm (2.913 - 2.914 in)
Service limit	74.110 mm (2.918 in)
ZX1100 C/D models	75.994 - 76.006 mm (2.991 - 2.992 in)
Service limit	76.100 mm (2.996 in)
Piston/cylinder clearance:	
ZX900 and ZX1000 models	0.044 - 0.074 mm (0.002 - 0.003 in)
ZX1100 C/D models	0.056 - 0.088 mm (0.002 - 0.004 in)



## Valves guides and springs

### Inlet valve clearances:

ZX900 and ZX1000 A models	0.13 - 0.18 mm (0.005 - 0.007 in)
ZX1000 B and ZX1100 C/D models	0.13 - 0.19 mm (0.005 - 0.007 in)

### Exhaust valve clearances:

ZX900 and ZX1000 A models	0.18 - 0.23 mm (0.007 - 0.009 in)
ZX1000 B and ZX1100 C/D models	0.18 - 0.24 mm (0.007 - 0.009 in)

### Valve head thickness:

Inlet	0.50 mm (0.20 in)
Service limit	0.25 mm (0.10 in)
Exhaust:	
ZX900 and ZX1000 A models	1.00 mm (0.40 in)
Service limit	0.70 mm (0.28 in)
ZX1000 B and ZX1100 C/D models	0.80 mm (0.31 in)
Service limit	0.50 mm (0.20 in)
Valve stem maximum runout	0.05 mm (0.002 in)

### Inlet valve stem OD:

ZX900 and ZX1000 A models	5.475 - 5.490 mm (0.215 - 0.216 in)
Service limit	5.460 mm (0.214 in)
ZX1000 B and ZX1100 C/D models	4.975 - 4.990 mm (0.195 - 0.196 in)
Service limit	4.960 mm (0.194 in)

### Exhaust valve stem OD:

ZX900 and ZX1000 A models	5.455 - 5.470 mm (0.214 - 0.215 in)
Service limit	5.440 mm (0.213 in)
ZX1000 B and ZX1100 C/D models	4.955 - 4.970 mm (0.194 - 0.195 in)
Service limit	4.940 mm (0.193 in)

### Valve seat width

	0.5 - 1.0 mm (0.02 - 0.04 in)
--	-------------------------------

### Valve seat OD:

ZX900 and ZX1000 A models - inlet	28.3 - 28.5 mm (1.114 - 1.122 in)
ZX900 and ZX1000 A models - exhaust	24.0 - 24.2 mm (0.945 - 0.953 in)
ZX1000 B model - inlet	29.3 - 29.5 mm (1.154 - 1.161 in)
ZX1000 B model - exhaust	25.3 - 25.5 mm (0.996 - 1.004 in)
ZX1100 C/D model - inlet	30.8 - 31.0 mm (1.213 - 1.220 in)
ZX1100 C/D model - exhaust	26.3 - 26.5 mm (1.035 - 1.043 in)

### Valve guide ID:

ZX900 and ZX1000 A models	5.500 - 5.512 mm (0.216 - 0.217 in)
Service limit	5.580 mm (0.219 in)
ZX1000 B and ZX1100 C/D models	5.000 - 5.012 mm (0.197 - 0.198 in)
Service limit	5.080 mm (0.200 in)

### Inlet valve/guide clearance - valve installed, using dial gauge:

ZX900 and ZX1000 A models	0.02 - 0.08 mm (0.001 - 0.003 in)
Service limit	0.22 mm (0.008 in)
ZX1000 B and ZX1100 C/D models	0.02 - 0.07 mm (0.001 - 0.003 in)
Service limit	0.18 mm (0.007 in)

### Exhaust valve/guide clearance - valve installed, using dial gauge:

ZX900 and ZX1000 A models	0.07 - 0.14 mm (0.003 - 0.006 in)
Service limit	0.27 mm (0.011 in)
ZX1000 B and ZX1100 C/D models	0.06 - 0.11 mm (0.002 - 0.004 in)
Service limit	0.21 mm (0.008 in)

### Inner valve spring free length:

ZX900 and ZX1000 A models	37.2 mm (1.46 in)
Service limit	36.0 mm (1.42 in)
ZX1000 B and ZX1100 C/D models	35.5 mm (1.40 in)
Service limit	33.6 mm (1.32 in)

### Outer valve spring free length:

ZX900 and ZX1000 A models	40.4 mm (1.58 in)
Service limit	39.0 mm (1.54 in)
ZX1000 B and ZX1100 C/D models	40.5 mm (1.59 in)
Service limit	38.6 mm (1.52 in)

## Pistons

### Piston OD:

ZX900 models	72.435 - 72.450 mm (2.851 - 2.852 in)
Service limit	72.300 mm (2.846 in)
ZX1000 models	73.935 - 73.964 mm (2.911 - 2.912 in)
Service limit	73.790 mm (2.905 in)
ZX1100 C/D models	75.918 - 75.938 mm (2.988 - 2.989 in)
Service limit	75.770 mm (2.983 in)



## Pistons (continued)

### Top compression ring groove width:

ZX900 and ZX1000A models	1.02 - 1.04 mm (0.040 - 0.041 in)
Service limit	1.12 mm (0.044 in)
ZX1000 B models	0.82 - 0.84 mm (0.032 - 0.033 in)
Service limit	0.92 mm (0.036 in)
ZX1100 C/D models	0.84 - 0.86 mm (0.033 - 0.034 in)
Service limit	0.94 mm (0.037 in)

### Second compression ring groove width:

ZX900 and ZX1000 models	1.01 - 1.03 mm (0.039 - 0.040 in)
Service limit	1.12 mm (0.044 in)
ZX1100 C models	1.02 - 1.04 mm (0.040 - 0.041 in)
Service limit	1.12 mm (0.044 in)
ZX1100 D models	0.82 - 0.84 mm (0.032 - 0.033 in)
Service limit	0.92 mm (0.036 in)

### Oil scraper ring groove width

Service limit	2.51 - 2.53 mm (0.098 - 0.099 in)
---------------	-----------------------------------

### Top compression ring/groove clearance

Service limit	2.60 mm (0.102 in)
---------------	--------------------

### Second compression ring/groove clearance

All models except ZX1100 D	0.03 - 0.07 mm (0.001 - 0.003 in)
Service limit	0.17 mm (0.007 in)
ZX1100 D models	0.02 - 0.06 mm (0.001 - 0.002 in)
Service limit	0.16 mm (0.006 in)
ZX1100 D models	0.03 - 0.07 mm (0.001 - 0.003 in)
Service limit	0.17 mm (0.007 in)

## Piston rings

### Top compression ring thickness:

ZX900 and ZX1000 A models	0.97 - 0.99 mm (0.038 - 0.039 in)
Service limit	0.90 mm (0.035 in)
ZX1000 B and ZX1100 C/D models	0.77 - 0.79 mm (0.030 - 0.031 in)
Service limit	0.70 mm (0.027 in)

### Second compression ring thickness

All models except ZX1100 D	0.97 - 0.99 mm (0.038 - 0.039 in)
Service limit	0.90 mm (0.035 in)
ZX1100 D models	0.77 - 0.79 mm (0.030 - 0.031 in)
Service limit	0.70 mm (0.027 in)

### Top compression ring end gap - installed:

ZX900 and ZX1000 models	0.20 - 0.35 mm (0.007 - 0.013 in)
ZX1100 C/D models	0.20 - 0.32 mm (0.007 - 0.012 in)
Service limit - all models	0.70 mm (0.027 in)

### Second compression ring end gap - installed

Service limit	0.20 - 0.35 mm (0.007 - 0.013 in)
---------------	-----------------------------------

### Oil scraper ring end gap - installed:

ZX900 and ZX1000 models	0.70 mm (0.027 in)
Service limit	0.20 - 0.70 mm (0.007 - 0.027 in)
ZX1100 C/D models	1.00 mm (0.039 in)

## Connecting rod and bearings

### Connecting rod maximum distortion

Service limit	0.2/100 mm (0.008/3.94 in)
---------------	----------------------------

### Big-end bearing standard ID:

ZX900 and ZX1000 models	38.000 - 38.016 mm (1.4961 - 1.4967 in)
ZX1100 C/D models	39.000 - 39.016 mm (1.5354 - 1.5361 in)

### Size groups - ZX900 and ZX1000 models:

Connecting rod unmarked	38.000 - 38.008 mm (1.4961 - 1.4963 in)
Connecting rod marked 'O'	38.009 - 38.016 mm (1.4964 - 1.4967 in)

### Size groups - ZX1100 C/D models:

Connecting rod unmarked	39.000 - 39.008 mm (1.5354 - 1.5357 in)
Connecting rod marked 'O'	39.009 - 39.016 mm (1.5358 - 1.5361 in)

### Crankpin standard OD:

ZX900 and ZX1000 models	34.984 - 35.000 mm (1.3773 - 1.3779 in)
Service limit	34.970 mm (1.3767 in)
ZX1100 C/D models	35.984 - 36.000 mm (1.4167 - 1.4173 in)
Service limit	35.970 mm (1.4161 in)

### Size groups - ZX900 and ZX1000 models:

Crankshaft unmarked	34.984 - 34.992 mm (1.3773 - 1.3776 in)
Crankshaft marked 'O'	34.993 - 35.000 mm (1.3777 - 1.3780 in)

### Size groups - ZX1100 C/D models:

Crankshaft unmarked	35.984 - 35.992 mm (1.4167 - 1.4170 in)
Crankshaft marked 'O'	35.993 - 36.000 mm (1.4171 - 1.4173 in)



		Thickness	Colour code
<b>Big-end rod bearing insert size:</b>			
ZX900 models:			
Thin		1.475 - 1.480 mm (0.0581 - 0.0583 in)	Brown
Medium		1.480 - 1.485 mm (0.0583 - 0.0585 in)	Black
Thick		1.485 - 1.490 mm (0.0585 - 0.0587 in)	Blue
ZX1000 A models:			
Thin		1.470 - 1.475 mm (0.0579 - 0.0581 in)	Brown
Medium		1.475 - 1.480 mm (0.0581 - 0.0583 in)	Black
Thick		1.480 - 1.485 mm (0.0583 - 0.0585 in)	Blue
ZX1000 B and ZX1100 C/D models:			
Thin		1.475 - 1.480 mm (0.0581 - 0.0583 in)	Black
Medium		1.480 - 1.485 mm (0.0583 - 0.0585 in)	Blue
Thick		1.485 - 1.490 mm (0.0585 - 0.0587 in)	White
<b>Bearing insert/crankpin clearance:</b>			
ZX900 and ZX1000 B models			
Service limit		0.036 - 0.066 mm (0.0014 - 0.0026 in)	
ZX1000 A models			
Service limit		0.10 mm (0.0039 in)	
ZX1100 C/D models			
Service limit		0.046 - 0.076 mm (0.0018 - 0.0030 in)	
ZX1100 C/D models			
Service limit		0.11 mm (0.0043 in)	
ZX1100 C/D models			
Service limit		0.037 - 0.065 mm (0.0015 - 0.0025 in)	
ZX1100 C/D models			
Service limit		0.10 mm (0.0039 in)	
<b>Big-end bearing side clearance:</b>			
ZX900 and ZX1000 models			
Service limit		0.13 - 0.33 mm (0.0051 - 0.0130 in)	
ZX1100 C/D models			
Service limit		0.50 mm (0.0197 in)	
ZX1100 C/D models			
Service limit		0.13 - 0.38 mm (0.0051 - 0.0150 in)	
ZX1100 C/D models			
Service limit		0.60 mm (0.0236 in)	
<b>Crankshaft runout</b>			
Service limit		Less than 0.05 mm (0.0020 in)	
<b>Crankshaft endfloat</b>			
Service limit		0.05 - 0.20 mm (0.0020 - 0.0079 in)	
<b>Crankcase main bearing ID</b>			
Service limit		0.40 mm (0.0157 in)	
<b>Crankcase main bearing ID</b>			
Service limit		39.000 - 39.016 mm (1.5354 - 1.5361 in)	
<b>Size groups:</b>			
Crankcase marked 'O'			
Service limit		39.000 - 39.008 mm (1.5354 - 1.5357 in)	
Crankcase unmarked			
Service limit		39.009 - 39.016 mm (1.5358 - 1.5361 in)	
Crankshaft journal OD			
Service limit		35.984 - 36.000 mm (1.4167 - 1.4173 in)	
Crankshaft journal OD			
Service limit		35.960 mm (1.4157 in)	
<b>Size groups:</b>			
Crankshaft unmarked			
Service limit		35.984 - 35.992 mm (1.4167 - 1.4170 in)	
Crankshaft marked '1'			
Service limit		35.993 - 36.000 mm (1.4171 - 1.4173 in)	
<b>Main bearing insert size:</b>			
Thin			
Service limit		1.490 - 1.494 mm (0.0587 - 0.0588 in)	Brown
Medium			
Service limit		1.494 - 1.498 mm (0.0588 - 0.0590 in)	Black
Thick			
Service limit		1.498 - 1.502 mm (0.0590 - 0.0591 in)	Blue
<b>Bearing insert/journal clearance</b>			
Service limit		0.020 - 0.044 mm (0.0008 - 0.0017 in)	
<b>Service limit:</b>			
ZX900 and ZX1000 models			
Service limit		0.080 mm (0.0031 in)	
ZX1100 C/D models			
Service limit		0.070 mm (0.0027 in)	

## Gearbox

Type	6 speed, constant mesh
<b>Ratios:</b>	
1st	2.800 : 1 (42/15 T)
2nd (except ZX1100 C/D4, D5)	2.000 : 1 (38/19 T)
2nd (ZX1100 C/D4, D5)	2.055 : 1 (37/18 T)
3rd	1.590 : 1 (35/22 T)
4th	1.333 : 1 (32/24 T)
5th	1.153 : 1 (30/26 T)
6th	1.035 : 1 (29/28 T)
<b>Gear backlash - all pinions</b>	
Service limit	0.06 - 0.23 mm (0.0024 - 0.0091 in)
<b>Gear pinion selector fork groove width</b>	
Service limit	0.30 mm (0.0118 in)
<b>Selector fork end thickness</b>	
Service limit	5.05 - 5.15 mm (0.199 - 0.203 in)
<b>Selector fork guide pin thickness</b>	
Service limit	5.3 mm (0.209 in)
<b>Selector drum groove width</b>	
Service limit	4.9 - 5.0 mm (0.193 - 0.197 in)
<b>Selector drum groove width</b>	
Service limit	4.8 mm (0.189 in)
<b>Selector drum groove width</b>	
Service limit	7.9 - 8.0 mm (0.311 - 0.315 in)
<b>Selector drum groove width</b>	
Service limit	7.8 mm (0.307 in)
<b>Selector drum groove width</b>	
Service limit	8.05 - 8.20 mm (0.317 - 0.323 in)
<b>Selector drum groove width</b>	
Service limit	8.30 mm (0.327 in)



## Clutch

Type .....	Wet, multi-plate
Friction plates:	
Number:	
ZX900 models .....	8
ZX1000 and ZX1100 C/D models .....	9
Thickness:	
ZX900 and ZX1000 B models .....	2.9 - 3.1 mm (0.114 - 0.122 in)
Service limit .....	2.75 mm (0.108 in)
ZX1000 A models .....	2.9 - 3.1 mm (0.114 - 0.122 in)
Service limit .....	2.8 mm (0.110 in)
ZX1100 C/D models .....	2.7 - 3.0 mm (0.106 - 0.118 in)
Service limit .....	2.5 mm (0.098 in)
Plain plates:	
Number:	
ZX900 models .....	7
ZX1000 and ZX1100 C/D models .....	8
Friction and plain plate warpage .....	Less than 0.2 mm (0.008 in)
Service limit .....	0.3 mm (0.012 in)
Clutch springs:	
Number:	
ZX900 models .....	5
ZX1000 and ZX1100 C/D models .....	6
Free length:	
ZX900 models .....	33.0 - 34.2 mm (1.30 - 1.35 in)
Service limit .....	32.1 mm (1.26 in)
ZX1000 models .....	33.2 mm (1.31 in)
Service limit .....	32.1 mm (1.26 in)
ZX1100 C/D models .....	46.3 mm (1.82 in)
Service limit .....	42.7 mm (1.68 in)
Primary gear/clutch drum backlash .....	0.03 - 0.10 mm (0.0011 - 0.0039 in)
Service limit .....	0.14 mm (0.0055 in)

## Alternator/starter clutch

Drive chain - 20 link length .....	158.8 - 159.2 mm (6.25 - 6.27 in)
Service limit .....	161.5 mm (6.36 in)

## Final drive

Type .....	Chain and sprockets
Ratio:	
ZX900 models:	
UK models .....	2.882 : 1 (49/17 T)
US models .....	2.941 : 1 (50/17 T)
ZX1000 A models:	
UK models .....	2.666 : 1 (40/15 T)
US models .....	2.733 : 1 (41/15 T)
ZX1000 B and ZX1100 C/D models .....	2.647 : 1 (45/17 T)

## Torque settings

	kgf m	lbf ft
Cylinder head cover bolts .....	1.0	7.0
Top camchain guide bolts:		
ZX900 and ZX1000 A models .....	1.0	7.0
ZX1000 B and ZX1100 C/D models .....	Not available	
Cam follower shaft retaining bolts - ZX900 and ZX1000 A models only .....	1.0	7.0
Camshaft cap bolts .....	1.2	9.0
Camshaft sprocket retaining bolts .....	1.5	11.0
Cam follower locknuts .....	2.5	18.0
Cylinder head oil pipe union bolts - ZX900 and ZX1000 A models only .....	1.0	7.0
Main cylinder head oil pipe union bolts .....	2.5	18.0
Sump to crankcase metal oil pipe union bolts:		
ZX900 and ZX1100 C/D models .....	2.5	18.0
ZX1000 models .....	1.8	13.0



<b>Torque settings (continued)</b>	<b>kgf m</b>	<b>lbf ft</b>
<b>Cylinder head bolts:</b>		
ZX900 and ZX1000 A models:*		
New head bolt and washer:		
Flat-headed bolts	4.0	29.0
Taper-headed bolts	5.2	38.0
Old head bolt and washer:		
Flat-headed bolts	3.7	27.0
Taper-headed bolts	4.9	35.0
ZX1000 B and ZX1100 C/D models:		
Initial torque setting	2.0	14.5
Final torque setting:		
Flat-headed bolts	4.0	29.0
Taper-headed bolts	5.2	38.0
6 mm cylinder head/block retaining bolt	1.0	7.0
7 mm block/crankcase retaining bolts	1.5	11.0
Camchain tensioner mounting bolts	1.0	7.0
Camchain blade mounting bolt	2.0	14.5
<b>Clutch spring retaining bolts:</b>		
ZX900 and ZX1000 models	1.0	7.0
ZX1100 C/D model	1.1	8.0
Clutch centre nut	13.5	98.0
Ignition rotor retaining bolt	2.5	18.0
Alternator mounting bolts	2.5	18.0
Alternator/starter clutch drive sprocket bolt	2.5	18.0
Alternator/starter clutch shaft cush drive coupling nut	6.0	43.0
Alternator drive coupling/shaft retaining bolt	1.0	7.0
<b>Starter clutch bolts:</b>		
ZX900 and ZX1000 A models	3.5	25.0
ZX1000 B and ZX1100 C/D models	1.2	9.0
Engine sprocket nut	10.0	72.0
Gearchange mechanism cover bolts - ZX1100 C/D model	1.0	7.0
<b>Crankcase fastening bolts:</b>		
6 mm	1.5	11.0
7 mm - ZX1100 C/D and late ZX900 A7-on models only	1.8	13.0
8 mm	2.8	20.0
8 mm main bearing bolts - ZX900 and ZX1000 models:		
Initial setting	1.4	10.0
Final setting	2.8	20.0
9 mm main bearing bolts - ZX1100 C/D and late ZX900 A7-on models:		
Initial setting	1.0	7.0
Final setting	3.3	24.0
<b>Connecting rod bolts (see text):</b>		
ZX900 models	3.7	27.0
ZX1000 A models:		
With new nuts	3.0	22.0
With old nuts	2.7	19.5
ZX1000 B models:		
New connecting rod and new nuts	2.0	14.5
New connecting rod and old nuts	1.8	13.0
Old connecting rod and new nuts	2.6	18.8
Old connecting rod and old nuts	2.4	17.4
ZX1100 C/D models	1.5	11.0
Oil drain plugs in sump	3.0	22.0
Oil filter mounting bolt	2.0	14.5
<b>Engine mounting bolts:</b>		
ZX900 models	6.0	43.0
ZX1000 A models:		
Front mounting bolts	4.5	33.0
Rear mounting bolts	5.3	38.0
ZX1000 B, ZX1100 C/D models	4.5	33.0
<b>Frame cradle retaining bolts:</b>		
ZX1000 A models	5.3	38.0
ZX1000 B, ZX1100 C/D models	4.5	33.0
Rear mounting bolt collar Allen screws - ZX1100 D models	2.0	14.5

<http://manuals.magnamaniac.com>

\*On ZX900 and 1000 A models initial torque setting is approximately half of the final torque settings.



# Specifications

## Coolant

Mixture type .....	Distilled water, and corrosion-inhibited ethylene-glycol antifreeze suitable for use in aluminium engines
Standard recommended mixture ratio down to -35°C (-31 °F) .....	50% antifreeze/50% distilled water
Total capacity of system:	
ZX900 models .....	2.9 lit (5.1 Imp pt, 3.0 US qt)
ZX1000 models .....	3.1 lit (5.5 Imp pt, 3.2 US qt)
ZX1100 C/D models .....	2.5 lit (4.4 Imp pt, 2.6 US qt)

## Thermostat

Valve opening temperature:	
ZX1000 B UK models .....	69 - 73°C (156 - 163°F)
All other models .....	80 - 84°C (176 - 183°F)
Valve lift @ 95°C (203°F) .....	More than 8 mm (0.31 in)

## Radiator

Cap valve opening pressure:	
ZX900 and ZX1000 A models .....	0.75 - 1.05 kg/cm <sup>2</sup> (11 - 15 psi)
ZX1000 B and ZX1100 C/D models .....	0.95 - 1.25 kg/cm <sup>2</sup> (14 - 18 psi)

## Torque settings

	kgf m	lbf ft
Coolant drain plug:		
ZX1100 D models .....	1.0	7.0
Other models .....	0.8	6.0
Cooling fan switch unit:		
ZX900 and ZX1000 A models .....	0.75	5.5
ZX1000 B and ZX1100 C/D models .....	1.8	13.0
Temperature sender unit:		
ZX900 and ZX1000 A models .....	0.8	6.0
ZX1000 B and ZX1100 C/D models .....	1.5	11.0
Thermostat housing bleed valve .....	0.8	6.0
Water pump mounting bolts:		
ZX1100 C/D models .....	1.0	7.0
Other models .....	Not available	



# Specifications

## Fuel tank capacity

ZX900 models:

	Litre	Imp gal	US gal
Overall .....	22.0	4.85	5.8
Reserve .....	4.4	0.97	1.2

ZX1000 A models:

Overall .....	21.0	4.63	5.5
Reserve .....	3.0	0.66	0.8

ZX1000 B models:

Overall .....	22.0	4.85	5.8
Reserve .....	4.0	0.88	1.1

ZX1100 C models - overall .....

21.0	4.63	5.5
------	------	-----

ZX1100 D models:

Overall .....	24.0	5.28	6.34
Reserve .....	6.5	1.43	1.72

**Fuel grade** .....

Unleaded or leaded, minimum octane rating 91 (Research method/RON)

## Carburettors

Make .....

**ZX900**

Keihin

Type .....

CVK34

Main jet:

UK models .....

132 (100 - A7-on)

US models .....

135

Main air jet .....

100

Jet needle:

UK models .....

N27B

US models .....

N27A

<http://manuals.magnamaniac.com>



## Carburettors (continued)

**ZX900**

Pilot jet:	
UK models	35
US models	35
Pilot air jet	160
Starter jet:	
UK models	42
US 49-state models	42
California models	38
Pilot screw - turns out:	
UK models	2 1/2 (1 1/2 - A7-on)
US models	Preset
Fuel level - below mark	0.5 mm (0.02 in)
Float height	17 mm (0.67 in)
Idle speed - rpm	950 - 1050

## Carburettors

**ZX1000 A**

Make	Keihin
Type	CVK36
Main jet:	
UK models	132
US 49-state models	132 (130*)
California models	138 (135*)
Main air jet	100
Jet needle:	
Cylinders 1 and 4	N36D
Cylinders 2 and 3	N36E
Pilot jet:	
UK models	35
US models	35 (32*)
Pilot air jet	140
Starter jet:	
UK models	50
US 49-state models	50
California models	45
Pilot screw - turns out:	
UK models	1 3/4
US models	Preset
Fuel level - below mark	2.0 mm (0.08 in)
Float height	17 mm (0.67 in)
Idle speed - rpm:	
UK and US 49-state models	950 - 1050
California models	1150 - 1250

## Carburettors

**ZX1000 B**

Make	Keihin
Type	CVKD36
Main jet:	
UK models	130
US models	130 (128*)
Main air jet	100
Jet needle:	
UK models	N54D
US models	N14C
Pilot jet:	
UK models	38
US models	38 (35*)
Pilot air jet	130
Starter jet:	
UK models	55
US 49-state models	52
California models	52
Pilot screw - turns out:	
UK models	2
US models	Preset
Fuel level - below mark	5.0 mm (0.20 in)
Float height	13 mm (0.51 in)
Idle speed - rpm	950 - 1050



**Carburettors**

Make .....	<b>ZX1100 C</b> Keihin
Type .....	CVKD40
Main jet:	
UK models .....	155 - C1, 140 - C2-on
US models .....	155 (152*) - C1, 140 (152 *) - C2-on
Main air jet .....	70
Jet needle .....	N60U
Pilot jet:	
UK models .....	38
US models .....	38 (35*)
Pilot air jet .....	130
Starter jet .....	55
Pilot screw - turns out:	
UK models .....	2
US models .....	Preset
Fuel level - below mark .....	4.5 mm $\pm$ 1 mm (0.18 $\pm$ 0.04 in)
Float height .....	13 mm $\pm$ 2 mm (0.51 $\pm$ 0.08 in)
Idle speed - rpm .....	950 - 1050

**Carburettors**

Make .....	<b>ZX1100 D</b> Keihin
Type .....	CVKD40
Main jet:	
Cylinders 1 and 4 .....	160 (158*)
Cylinders 2 and 3 .....	158 (155*)
Main air jet .....	70
Jet needle .....	N96X
Pilot jet .....	38 (35*)
Pilot air jet:	
UK models .....	130
US models .....	120
Starter jet .....	58
Pilot screw - turns out:	
UK models .....	2
US models .....	Preset
Fuel level - below mark .....	4.5 $\pm$ 1 mm (0.177 $\pm$ 0.040 in)
Float height .....	13 $\pm$ 2 mm (0.512 $\pm$ 0.080 in)
Idle speed:	
UK and US 49-state models .....	950 - 1050 rpm
California models .....	1150 - 1250 rpm

**Note** - specifications denoted by the asterisk (\*) apply when the machine is used above 4000 ft (1216 m).

<b>Cylinder identification</b> .....	Left to right, 1-2-3-4
--------------------------------------	------------------------

**Lubrication system**

Recommended oil grade .....	SAE 10W/40, 10W/50, 20W/40 or 20W/50 SE or SF class
Capacity:	
Oil change only:	
ZX1100 C/D models .....	3.2 lit (5.7 Imp pt/3.4 US qt)
All other models .....	2.7 lit (4.8 Imp pt/2.9 US qt)
Oil and filter change:	
ZX1100 C/D models .....	3.5 lit (6.2 Imp pt/3.7 US qt)
All other models .....	3.0 lit (5.3 Imp pt/3.2 US qt)
After engine rebuild:	
ZX1000 B models .....	4.0 lit (7.1 Imp pt/4.3 US qt)
All other models .....	Not available
Oil pressure - oil temperature 90°C (194°F):	
ZX900 and ZX1000 A models .....	2.7 - 3.3 kg/cm <sup>2</sup> (38 - 47 psi) @ 4000 rpm
ZX1000 B and ZX1100 C/D models .....	4.0 - 5.0 kg/cm <sup>2</sup> (24 - 43 psi) @ 4000 rpm
Relief valve opening pressure .....	4.4 - 6.0 kg/cm <sup>2</sup> (63 - 85 psi)



## 4•4 Fuel system and lubrication

---

### Torque settings

	kgf m	lbf ft
Oil pump mounting bolts .....	1.2	8.5
Oil filter retaining bolt .....	2.0	14.5
Oil drain plug(s) .....	3.0	22.0
Oil pressure switch .....	1.5	11.0
Oil temperature switch - ZX900 only .....	0.8	5.8
Oil pressure passage blanking plug .....	1.8	13.0
Oil cooler hose to matrix union bolts .....	2.5	18.0
Oil cooler hose to sump union bolts (14 mm) .....	3.5	25.0
Oil cooler hose to sump union bolt (8 mm) - ZX1100 G/D only .....	1.5	11.0

<http://manuals.magnamaniac.com>



# Specifications

## Ignition timing

ZX900 and ZX1000 A models	10° BTDC @ 1000 rpm - 35° BTDC @ 3500 rpm
ZX1000 B models	10° BTDC @ 1000 rpm - 35° BTDC @ 7500 rpm
ZX1100 C/D models:	
UK models	10° BTDC @ 1000 rpm - 40° BTDC @ 6000 rpm
US 49-state models	7.5° BTDC @ 1000 rpm - 40° BTDC @ 6000 rpm
US California models	7.5° BTDC @ 1200 rpm - 40° BTDC @ 6000 rpm

## Pulser coil

Resistance:	
ZX900 models	390 - 590 ohms
ZX1000 models	400 - 490 ohms
ZX1100 C/D models	380 - 570 ohms
Air gap:	
ZX900 and ZX1000 A models	0.5 - 0.9 mm (0.020 - 0.036 in)
ZX1000 B and ZX1100 C/D models	0.7 mm (0.028 in)

## Ignition HT coil

Primary windings resistance:	
ZX900 and ZX1000 A models	1.8 - 2.8 ohms
ZX1000 B models	2.6 - 3.2 ohms
ZX1100 C/D models	2.3 - 3.5 ohms
Secondary windings resistance:	
ZX900 and ZX1000 A models	10 - 16 k ohms
ZX1000 B models	13 - 17 k ohms
ZX1100 C/D models	12 - 18 k ohms
Minimum sparking distance:	
ZX900 and ZX1000 A models	7 mm (0.28 in)
ZX1000 B and ZX1100 C/D models	6 mm (0.24 in)
Cylinder identification	Left to right 1-2-3-4

## 5•2 Ignition system

Firing order	1-2-4-3
--------------	---------

## Spark plugs

Recommended grade:	NGK	Nippon-denso
ZX900 and ZX1000 A models:		
UK models	DR8ES	X27ESR-U
US models	D8EA	X24ES-U
ZX1000 B and ZX1100 C/D models:		
UK models	CR9E	U27ESR-N
US models	C9E	U27ES-N
Electrode gap:		
ZX900 and ZX1000 A models	0.6 - 0.7 mm (0.024 - 0.028 in)	
ZX1000 B and ZX1100 C/D models	0.7 - 0.8 mm (0.028 - 0.032 in)	

## Torque settings

	kgf m	lbf ft
Spark plugs	1.4	10
Ignition rotor retaining bolt	2.5	18



# Specifications

## Front forks

Wheel travel:

ZX900 models	140 mm (5.51 in)
ZX1000 models	135 mm (5.31 in)
ZX1100 C models	125 mm (4.92 in)
ZX1100 D models	120 mm (4.72 in)

Air pressure ZX900 A1 to A6 and ZX1000 A models:

Standard	0.5 kg/cm <sup>2</sup> (7.1 psi)
Usable range	0.4 - 0.6 kg/cm <sup>2</sup> (5.7 - 8.6 psi)

Fork spring free length:

	Standard	Service limit
ZX900 A1 to A6 models	522 mm (20.6 in)	511 mm (20.1 in)
ZX900 A7-on models	430.5 mm (16.9 in)	421 mm (16.6 in)
ZX1000 A models	504.5 mm (19.9 in)	494 mm (19.4 in)
ZX1000 B models	488 mm (19.2 in)	478 mm (18.8 in)
ZX1100 C models	438 mm (17.2 in)	429 mm (16.9 in)
ZX1100 D models	295 mm (11.6 in)	289 mm (11.4 in)

Fork oil capacity per leg - after reassembly:

	cc	Imp fl oz	US fl oz
ZX900 A1 to A6 models	318 ± 4	11.2 ± 0.14	10.7 ± 0.13
ZX900 A7-on models	496 ± 4	17.5 ± 0.14	16.8 ± 0.13
ZX1000 A models	348 ± 4	12.2 ± 0.14	11.7 ± 0.13
ZX1000 B models	418 ± 4	14.7 ± 0.14	14.1 ± 0.13
ZX1100 C models	458 ± 4	16.1 ± 0.14	15.5 ± 0.13
ZX1100 D models	465 ± 4	16.4 ± 0.14	15.7 ± 0.13

Fork oil capacity (approx) per leg - at oil change:

ZX900 A1 to A6 models	270	9.5	9.1
ZX900 A7-on models	420	14.8	14.2
ZX1000 A models	295	10.4	10.0
ZX1000 B models	360	12.7	12.2
ZX1100 C models	390	13.7	13.2
ZX1100 D models	410	14.4	13.9

## 6•2 Frame and forks

### Front forks (continued)

Fork oil level:\*

ZX900 A1 to A6 models	357 ± 2 mm (14.1 ± 0.08 in) fork fully extended
ZX900 A7-on models	110 ± 2 mm (4.3 ± 0.08 in) fork fully compressed
ZX1000 A models	348 ± 4 mm (13.7 ± 0.16 in) fork fully extended
ZX1000 B models	130 ± 2 mm (5.1 ± 0.08 in) fork fully compressed
ZX1100 C models	149 ± 2 mm (5.9 ± 0.08 in) fork fully compressed
ZX1100 D models	133 ± 2 mm (5.2 ± 0.08 in) fork fully compressed

\*Oil level is measured from the top of the stanchion with fork spring removed.

Recommended fork oil:

ZX900 A1 to A6 and ZX1000 A models	SAE 10W fork oil
ZX900 A7-on, ZX1000 B and ZX1100 C/D models	SAE 10W/20 fork oil

### Rear suspension

Wheel travel:

ZX900 models	115 mm (4.53 in)
ZX1000 A models	130 mm (5.12 in)
ZX1000 B and ZX1100 C models	120 mm (4.72 in)
ZX1100 D models	112 mm (4.41 in)

Air pressure:

	Standard	Usable range
ZX900 models	0.5 kg/cm <sup>2</sup> (7 psi)	0.5 - 1.5 kg/cm <sup>2</sup> (7 - 21 psi)
ZX1000 A models	0.5 kg/cm <sup>2</sup> (7 psi)	0 - 1.5 kg/cm <sup>2</sup> (0 - 21 psi)
ZX1000 B models	Atmospheric pressure	0.1 kg/cm <sup>2</sup> (0 - 14 psi)
ZX1100 C models	10 kg/cm <sup>2</sup> (142 psi)	Non adjustable
ZX1100 D models	Not applicable	

### Torque settings

Handlebar to top yoke mounting bolts:

	kgf m	lbf ft
ZX900 A7-on models	1.9	13.5
All other models	2.0	14.5
Top yoke retaining nut	4.0	29.0

Yoke pinch bolts:

ZX900 and ZX1000 A models - top and bottom	2.1	15.0
ZX1000 B models - top and bottom	2.9	21.0
ZX1100 C/D models:		
Top	2.9	21.0
Bottom	2.1	15.0

Front fork top bolts

	2.3	16.5
--	-----	------

Front fork damper rod retaining bolt:

ZX900 A1 to A6 models	3.0	22.0
ZX1000 models	4.0	29.0
ZX900 A7-on and ZX1100 C/D models	6.2	45.0
Swinging arm pivot shaft nut(s)	9.0	65.0

Suspension unit and linkage pivot bolts:

All suspension unit and linkage bolts except ZX900 upper suspension unit mounting bolt	6.0	43.0
--	-----	------

ZX900 upper suspension unit mounting bolt:

ZX900 A2-on models	3.0	22.0
ZX900 A1 model	4.0	29.0



# Specifications

## Wheels

Type .....	Cast alloy
Rim maximum runout:	
Radial .....	0.8 mm (0.032 in)
Axial .....	0.5 mm (0.020 in)

## Brakes

Minimum disc thickness:	
Front:	
ZX900 A7-on models .....	4.0 mm (0.16 in)
All other models .....	4.5 mm (0.18 in)
Rear:	
ZX900 A1 to A6 models .....	6.0 mm (0.24 in)
All other models .....	5.0 mm (0.20 in)
Disc maximum warpage .....	0.3 mm (0.0118 in)
Recommended brake fluid .....	DOT 4 specification

## Tyres

Type .....	Tubeless	
Size:	<b>Front</b>	<b>Rear</b>
ZX900 A1 to A6 models .....	120/80V16-V250	130/80V18-V250
ZX900 A7-on models .....	120/70V17-V250	150/70V18-V250
ZX1000 A models .....	120/80V16-V270	150/80V16-V270
ZX1000 B models .....	120/70VR17-V280	160/60VR18-V280
ZX1100 C models .....	120/70VR17-V290	170/60VR17-V290
ZX1100 D models .....	120/70ZR17	185/55ZR17



## Tyre pressures

## UK ZX900 A1 to A6 models:

Up to 97.5 kg (215 lb) load, below 130 mph (210 kmh)	2.25 kg/cm <sup>2</sup> (32 psi)	2.50 kg/cm <sup>2</sup> (36 psi)
97.5 - 181 kg (215 - 399 lb) load, below 130 mph (210 kmh)	2.50 kg/cm <sup>2</sup> (36 psi)	2.50 kg/cm <sup>2</sup> (36 psi)
Above 130 mph (210 kmh)	2.50 kg/cm <sup>2</sup> (36 psi)	2.90 kg/cm <sup>2</sup> (41 psi)
UK ZX900 A7-on models	2.50 kg/cm <sup>2</sup> (36 psi)	2.90 kg/cm <sup>2</sup> (41 psi)

## US ZX900 A1 to A3 models:

Up to 97.5 kg (215 lb) load	2.25 kg/cm <sup>2</sup> (32 psi)	2.50 kg/cm <sup>2</sup> (36 psi)
97.5 - 180 kg (215 - 397 lb) load	2.50 kg/cm <sup>2</sup> (36 psi)	2.50 kg/cm <sup>2</sup> (36 psi)

## UK ZX1000 A models:

Below 130 mph (210 kmh)	2.50 kg/cm <sup>2</sup> (36 psi)	2.50 kg/cm <sup>2</sup> (36 psi)
Above 130 mph (210 kmh)	2.50 kg/cm <sup>2</sup> (36 psi)	2.90 kg/cm <sup>2</sup> (41 psi)

## UK ZX1000 B models:

Up to 97.5 kg (215 lb) load, below 130 mph (210 kmh)	2.50 kg/cm <sup>2</sup> (36 psi)	2.50 kg/cm <sup>2</sup> (36 psi)
97.5 - 181 kg (215 - 399 lb) load, below 130 mph (210 kmh)	2.50 kg/cm <sup>2</sup> (36 psi)	2.90 kg/cm <sup>2</sup> (41 psi)
Above 130 mph (210 kmh)	2.50 kg/cm <sup>2</sup> (36 psi)	2.90 kg/cm <sup>2</sup> (41 psi)

## US ZX1000 A and ZX1000 B models

	2.50 kg/cm <sup>2</sup> (36 psi)	2.90 kg/cm <sup>2</sup> (41 psi)
--	----------------------------------	----------------------------------

## ZX1100 C/D models

	2.90 kg/cm <sup>2</sup> (41 psi)	2.90 kg/cm <sup>2</sup> (41 psi)
--	----------------------------------	----------------------------------

## Torque settings

kgf m

lbf ft

## Wheel spindles:

ZX900 models - front and rear	9.0	65.0
-------------------------------	-----	------

## ZX1000 A models:

Front	6.5	47.0
Rear	9.0	65.0

## ZX1000 B models:

Front	9.0	65.0
Rear	11.0	80.0

## ZX1100 C models - front and rear

	11.0	80.0
--	------	------

## ZX1100 D models:

Front	15.0	110.0
Rear	11.0	80.0

## Front spindle pinch bolts:

ZX900 and ZX1000 A models	2.1	15.0
All other models	2.0	14.5

## Rear wheel chain adjuster pinch bolts

	4.0	29.0
--	-----	------

## Rear sprocket retaining nuts:

ZX900 A1 to A6 models:		
Before Frame No. ZX900A-016130	7.0	51.0
After Frame No. ZX900A-016131	8.8	64.0
ZX1000 A models	11.0	80.0
ZX900 A7-on, ZX1000 B and ZX1100 C/D models	7.5	54.0

## Brake disc bolts:

ZX900, ZX1000 A and ZX1100 C models	2.3	17.0
-------------------------------------	-----	------

## ZX1000 B models:

Front disc	3.5	25.0
Rear disc	2.3	17.0

## ZX1100 D models:

Front disc	2.3	17.0
Rear disc	2.5	18.0

## Brake caliper mounting bolts:

ZX900 A1 to A6 and ZX1000 A models	3.4	24.0
ZX900 A7-on, ZX1000 B and ZX1100 C models	3.5	25.0

## Front brake caliper joining bolts - ZX900 A7-on and ZX1100 C models

	2.1	15.0
--	-----	------

## Brake caliper - ZX1100 D models:

Front:		
Mounting bolts	3.5	25.0
Joining bolts	2.1	15.0

Rear:		
Mounting bolts	2.5	15.0
Joining bolts	Not available	

## Front master cylinder clamp bolts:

ZX900 A1 to A6 and ZX1000 A models	0.9	6.5
ZX900 A7-on, ZX1000 B and ZX1100 C/D models	1.1	8.0

## Brake hose union bolts

	2.5	18.0
--	-----	------

## Torque arm nuts/bolts

	2.5	18.0
--	-----	------

## Metal brake pipe gland nuts anti-dive models only

	1.5	11.0
--	-----	------

## Anti-dive plunger housing bolts

	0.45	3.3
--	------	-----

## Bleed nipples

	0.8	5.8
--	-----	-----



# Specifications

## Electrical system

Voltage .....	12
Earth (ground) .....	Negative

## Battery

Capacity:	
ZX1100 D models .....	12 Ah
All other models .....	14 Ah
Electrolyte specific gravity .....	1.280 @ 20°C (68°F)

## Alternator

Type .....	Three-phase AC
Rated output:	
ZX900 and ZX1000 A models .....	25A @ 6000 rpm, 14 volts
ZX1000 B models .....	24A @ 6000 rpm, 14 volts
ZX1100 C/D models .....	28.6A @ 6000 rpm, 14 volts
Charging voltage - headlight on:	
ZX900 and ZX1000 A models .....	13.5 volts @ 4000 rpm
ZX1000 B and ZX1100 C/D models .....	14.5 volts @ 4000 rpm
Stator coil resistance .....	Less than 1 ohm
Rotor coil resistance:	
ZX1000 B2 and B3 models .....	Approximately 6 ohms
All other models .....	Approximately 4 ohms
Slip ring diameter .....	14.4 mm (0.57 in)
Service limit .....	14.0 mm (0.55 in)
Carbon brush projection length .....	10.5 mm (0.41 in)
Service limit .....	4.5 mm (0.18 in)



## Starter motor

Carbon brush length:

ZX900 and ZX1000 B models	12 mm (0.47 in)
Service limit	8.5 mm (0.33 in)
ZX1000 A and ZX1100 C/D models	12 - 12.5 mm (0.47 - 0.49 in)
Service limit	6 mm (0.24 in)
Commutator diameter	28 mm (1.10 in)
Service limit	27 mm (1.06 in)

Commutator groove depth:

ZX900 models and ZX1000 A models	0.45 - 0.75 mm (0.018 - 0.030 in)
Service limit	0.2 mm (0.008 in)
ZX1000 B and ZX1100 C/D models	0.7 mm (0.028 in)
Service limit	0.2 mm (0.008 in)

## Fuel level sender unit resistances

ZX900 models:

Empty	70 - 120 ohms
Full	3 - 12 ohms

ZX1000 models:

Empty	90 - 100 ohms
Full	4 - 10 ohms

ZX1100 C models

see text

ZX1100 D models:

Empty	90 - 100 ohms
Full	4 - 10 ohms

## Fuses

ZX900 and ZX1000 A models:

Main	30A
Horn	10A
Tail	10A
Lights	10A
Turn signals	10A
Fan	10A
Accessory - ZX900 only	10A x 2

ZX1000 B and ZX1100 C models:

Main	30A
Headlamp	10A
Fan	10A
Accessory	10A

ZX1100 D1 and D2 models:

Main	30A
Headlamp	10A
Tail lamp	10A
Fan	10A
Accessory (US models only)	10A

ZX1100 D3, D4 and D5 models:

Main	30A
Horn	10A
Ignition	10A
Tail lamp	10A
Headlamp	10A
Fan	10A
Accessory (clock)	10A
Turn signal	10A

## Bulbs

Headlamp	12V 60/55W
Parking lamp - UK models only	12V 4W (ZX1100 D: 5W)
Stop/tail lamp:	
UK models	12V 5/21W
US models	12V 8/27W
Turn signal lamps:	
UK models	12V 21W
US models	12V 23W (ZX1100 D: 8/23W front, 12V 23W rear)
Instrument illuminating lamps	12V 3W (ZX1100 D: 1.7W)
Warning lamps	12V 3.4W
Licence plate lamp	12V 5W



**Torque settings**

	kgf m	lbf ft
Alternator coupling bolt .....	1.0	7.0
Radiator mounted fan switch:		
ZX900 and ZX1000 A models .....	0.75	5.5
ZX1000 B and ZX1100 C/D models .....	1.8	13.0
Coolant temperature sender unit:		
ZX900 and ZX1000 A models .....	0.8	6.0
ZX1000 B and ZX1100 C/D models .....	1.5	11.0
Thermostat housing fan switch - ZX900 models .....	0.8	6.0
Oil pressure switch .....	1.5	11.0
Oil temperature switch - ZX900 models .....	0.8	6.0



# Specifications

## Engine

### Oil capacity:

#### At oil change:

ZX1100 C/D .....	3.2 lit (5.7 Imp pt/3.4 US qt)
All other models .....	2.7 lit (4.8 Imp pt/2.9 US qt)

#### At oil and filter change:

ZX1100 C/D models .....	3.5 lit (6.2 Imp pt/3.7 US qt)
All other models .....	3.0 lit (5.3 Imp pt/3.2 US qt)

### Spark plug type:

#### ZX900 and ZX1000 A models:

UK models .....	DR8ES
US models .....	D8EA

#### ZX1000 B and ZX1100 C/D models:

UK models .....	CR9E
US models .....	C9E

### Spark plug gap:

ZX900 and ZX1000 A models .....	0.6 - 0.7 mm (0.024 - 0.028 in)
ZX1000 B and ZX1100 C/D models .....	0.7 - 0.8 mm (0.028 - 0.032 in)

### Valve clearances - engine cold:

#### Inlet:

ZX900 and ZX1000 A models .....	0.13 - 0.18 mm (0.005 - 0.007 in)
ZX1000B and ZX1100 C/D models .....	0.13 - 0.19 mm (0.005 - 0.007in)

#### Exhaust:

ZX900 and ZX1000 A models .....	0.18 - 0.23 mm (0.007 - 0.009 in)
ZX1000 B and ZX1100 C/D models .....	0.18 - 0.24 mm (0.007 - 0.009 in)

### Idle speed:

ZX1000 A and ZX1100 D California models .....	1150 - 1250 rpm
All other models .....	950 - 1050 rpm

Throttle cable free play - measured at twistgrip ..... 2 - 3 mm (0.08 - 0.12 in)

Choke lever free play - measured at the base of lever ..... 2 - 3 mm (0.08 - 0.12 in)

### NGK

### Nippon-denso

X27ESR-U  
X24ES-U

U27ESR-N  
U27ES-N



## Cycle parts

Brake pad friction material thickness:

ZX900 A1 to A6 and ZX1000 A models	4.85 mm (0.191 in)
ZX1000 B models	4.50 mm (0.177 in)
ZX900 A7-on and ZX1100 C/D models:	
Front	4.00 mm (0.157 in)
Rear	4.50 mm (0.177 in)
Service limit all - models	1.00 mm (0.039 in)

Rear brake pedal height (below top of footrest):

ZX900 models	29 - 39 mm (1.14 - 1.54 in)
ZX1000 A models	Approx 37 mm (1.46 in)
ZX1000 B and ZX1100 models	Approx 45 mm (1.77 in)

Drive chain free play:

ZX1000 B models	30 - 40 mm (1.18 - 1.57 in)
All other models	35 - 40 mm (1.38 - 1.57 in)

Drive chain length - 20 link length:

ZX1000 A models	381.0 - 381.8 mm (15.00 - 15.04 in)
Service limit	389.0 mm (15.31 in)
All other models	317.5 - 318.4 mm (12.50 - 12.54 in)
Service limit	323.0 mm (12.72 in)

Front forks:

Oil capacity (approx) per leg at oil change:	cc	Imp fl oz	US fl oz
ZX900 A1 to A6 models	270	9.5	9.1
ZX900 A7-on models	420	14.8	14.2
ZX1000 A models	295	10.4	10.0
ZX1000 B models	360	12.7	12.2
ZX1100 C models	390	13.7	13.2
ZX1100 D models	410	14.4	13.9

Fork oil level\*:

ZX900 A1 to A6 models	357 ± 2 mm (14.1 ± 0.08 in)
ZX900 A7-on models	110 ± 2 mm (4.3 ± 0.08 in)
ZX1000 A models	348 ± 4 mm (13.7 ± 0.16 in)
ZX1000 B models	130 ± 2 mm (5.1 ± 0.08 in)
ZX1100 C models	149 ± 2 mm (5.9 ± 0.08 in)
ZX1100 D models	133 ± 2 mm (5.2 ± 0.08 in)

\* Oil level is measured from the top of the stanchion with the fork spring removed. Measurement is taken with fork leg either fully compressed or extended - see text

Tyre pressures tyres - cold:

	Front	Rear
UK ZX900 A1 to A6 models:		
Up to 97.5 kg (215 lb) load, below 130 mph (210 kmh)	2.25 kg/cm <sup>2</sup> (32 psi)	2.50 kg/cm <sup>2</sup> (36 psi)
97.5 - 181 kg (215 399 lb) load, below 130 mph (210 kmh)	2.50 kg/cm <sup>2</sup> (36 psi)	2.50 kg/cm <sup>2</sup> (36 psi)
Above 130 mph (210 kmh)	2.50 kg/cm <sup>2</sup> (36 psi)	2.90 kg/cm <sup>2</sup> (41 psi)
UK ZX900 A7-on models	2.50 kg/cm <sup>2</sup> (36 psi)	2.90 kg/cm <sup>2</sup> (41 psi)
US ZX900 A1 to A3 models:		
Up to 97.5 kg (215 lb) load	2.25 kg/cm <sup>2</sup> (36 psi)	2.50 kg/cm <sup>2</sup> (36 psi)
97.5 - 180 kg (215 - 397 lb) load	2.50 kg/cm <sup>2</sup> (36 psi)	2.50 kg/cm <sup>2</sup> (36 psi)
UK ZX1000 A models:		
Below 130 mph (210 kmh)	2.50 kg/cm <sup>2</sup> (36 psi)	2.50 kg/cm <sup>2</sup> (36 psi)
Above 130 mph (210 kmh)	2.50 kg/cm <sup>2</sup> (36 psi)	2.90 kg/cm <sup>2</sup> (41 psi)
UK ZX1000 B models:		
Up to 97.5 kg (215 lb) load, below 130 mph (210 kmh)	2.50 kg/cm <sup>2</sup> (36 psi)	2.50 kg/cm <sup>2</sup> (36 psi)
97.5 - 181 kg (215 - 399 lb) load, below 130 mph (210 kmh)	2.50 kg/cm <sup>2</sup> (36 psi)	2.90 kg/cm <sup>2</sup> (41 psi)
Above 130 mph (210 kmh)	2.50 kg/cm <sup>2</sup> (36 psi)	2.90 kg/cm <sup>2</sup> (41 psi)
US ZX1000 A and ZX1000 B models	2.50 kg/cm <sup>2</sup> (36 psi)	2.90 kg/cm <sup>2</sup> (41 psi)
ZX1100 C/D models	2.90 kg/cm <sup>2</sup> (41 psi)	2.90 kg/cm <sup>2</sup> (41 psi)

## Recommended fluids and lubricants

Engine:

Recommended oil	SAE 10W/40, 10W/50, 20W/40 or 20W/50 SE or SF class (minimum)
Fuel grade	Unleaded or leaded. Minimum octane rating 91 (Research method/RON)
Air filter	SAE 30 engine oil, SE class

Front forks:

ZX900 A1 to A6 and ZX1000 A models	SAE 10W fork oil
ZX900 A7-on, ZX1000 B and ZX1100 C/D models	SAE 10W/20 fork oil

Brake and clutch fluid

DOT 4 specification

Final drive chain

SAE 90 gear oil

Wheel bearings and speedometer drive gearbox

High melting-point grease

Steering head bearings

General purpose grease

Swinging arm and suspension linkage pivots

Molybdenum-disulphide grease

All control pivots, stand, stand pivots and throttle twistgrip

Good quality general purpose grease

Control cables

Engine oil



**Note:** The pre-ride inspection outlined in the owner's manual covers checks and maintenance that should be carried out on a daily basis. It's condensed and included at the beginning of this Manual to remind you of its importance. Always perform the pre-ride inspection at every maintenance interval (in addition to the procedures listed). The intervals listed below are the shortest intervals recommended by the manufacturer for each particular operation during the model years covered in this manual. Your owner's manual may have different intervals for your model.

## Daily or before riding

- ☐ See 'Daily (pre-ride) checks' at the beginning of this Manual.

## After the initial 500 miles (800 km)

**Note:** This check is usually performed by a Kawasaki dealer after the first 500 miles from new. Thereafter, maintenance is carried out according to the following intervals of the schedule.

## Monthly or every 500 miles (800 km)

- ☐ Adjust the drive chain (Section 1)
- ☐ Check the suspension settings (Section 2)
- ☐ Check the battery (Section 3)

## Every 3000 miles (5000 km)

- ☐ Check the spark plugs (Section 4)
- ☐ Check the fuel and oil lines (Section 5)
- ☐ Check the air suction valves (US and ZX1100 D models) (Section 6)
- ☐ Check and synchronise the carburettors (Section 7)
- ☐ Check the brake pads (Section 8)
- ☐ Check the drive chain (Section 9)
- ☐ Check the steering (Section 10)
- ☐ Lubricate the cables, stands and controls (Section 11)
- ☐ Check the headlamp alignment (Section 12)

## Every 6000 miles (10 000 km)

All of the 3000 miles maintenance tasks plus the following

- ☐ Change the engine/transmission oil and filter (Section 13)
- ☐ Clean the air filter element (Section 14)
- ☐ Renew the spark plugs (Section 15)
- ☐ Check and adjust the valve clearances (Section 16)
- ☐ Clean/renew the fuel filter (Section 17)
- ☐ Change the fork oil (Section 18)
- ☐ Check the cooling system (Section 19)
- ☐ Clean the coolant filter (Section 20)
- ☐ Lubricate the swinging arm and suspension linkage bearings (Section 21)
- ☐ Check fastener security (Section 22)
- ☐ Check the wheels (Section 23)

## Every 12 000 miles (20 000 km)

All of the 6000 miles maintenance tasks plus the following

- ☐ Renew the air filter element (Section 24)
- ☐ Renew the brake and clutch fluid renewal (Section 25)
- ☐ Lubricate the steering head bearings (Section 26)

## Every 24 000 miles (40 000 km)

All of the 12 000 miles maintenance tasks plus the following

- ☐ Renew the coolant (Section 27)

## Every 2 years


- ☐ Overhaul the brake and clutch components (Section 28)
- ☐ Renew the anti-dive unit seals (ZX900 A1 to A6 and ZX1000 A models) (Section 29)

## Every 4 years

- ☐ Renew the hydraulic hoses and fuel lines (Section 30)




# 1•4 Component locations



**ZX900 A component locations on left-hand side**


- |                          |                       |                               |                   |
|--------------------------|-----------------------|-------------------------------|-------------------|
| 1 Clutch fluid reservoir | 4 Idle speed adjuster | 7 Air filter                  | 10 Brake pads     |
| 2 Valves and spark plugs | 5 Battery             | 8 Engine oil level sightglass | 11 Anti-dive unit |
| 3 Fuel tap filter        | 6 Drive chain         | 9 Engine oil filler plug      |                   |



**ZX900 A component locations on right-hand side**


- |                              |                           |                               |                          |
|------------------------------|---------------------------|-------------------------------|--------------------------|
| 1 Brake pads                 | 4 Coolant filter (UK)     | 7 Front brake fluid reservoir | 9 Engine oil drain plugs |
| 2 Coolant reservoir          | 5 Air suction valves (US) | 8 Fork oil drain plug         | 10 Engine oil filter     |
| 3 Rear brake fluid reservoir | 6 Steering head bearings  |                               |                          |





**ZX1000 A component locations on left-hand side**

- |                          |                       |                               |                   |
|--------------------------|-----------------------|-------------------------------|-------------------|
| 1 Clutch fluid reservoir | 4 Idle speed adjuster | 7 Engine oil level sightglass | 10 Brake pads     |
| 2 Valves and spark plugs | 5 Battery             | 8 Engine oil filler plug      | 11 Anti-dive unit |
| 3 Fuel tap filter        | 6 Drive chain         | 9 Coolant reservoir           |                   |




**ZX1000 A component locations on right-hand side**

- |                              |                           |                               |                          |
|------------------------------|---------------------------|-------------------------------|--------------------------|
| 1 Brake pads                 | 4 Coolant filter (UK)     | 7 Front brake fluid reservoir | 9 Engine oil drain plugs |
| 2 Rear brake fluid reservoir | 5 Air suction valves (US) | 8 Fork oil drain plug         | 10 Engine oil filter     |
| 3 Air filter                 | 6 Steering head bearings  |                               |                          |




# 1.6 Component locations



**ZX1000 B component locations on left-hand side**


- |                          |                              |                               |                        |
|--------------------------|------------------------------|-------------------------------|------------------------|
| 1 Clutch fluid reservoir | 4 Fuel tank and pump filters | 7 Engine oil level sightglass | 9 Brake pads           |
| 2 Valves and spark plugs | 5 Battery                    | 8 Engine oil filler cap       | 10 Fork oil drain plug |
| 3 Idle speed adjuster    | 6 Drive chain                |                               |                        |



**ZX1000 B component locations on right-hand side**

- |                              |                               |                     |                          |
|------------------------------|-------------------------------|---------------------|--------------------------|
| 1 Rear brake fluid reservoir | 4 Air suction valves (US)     | 7 Coolant reservoir | 9 Engine oil drain plugs |
| 2 Air filter                 | 5 Steering head bearings      | 8 Brake pads        | 10 Engine oil filter     |
| 3 Coolant filter (UK)        | 6 Front brake fluid reservoir |                     |                          |






**ZX1100 C/D component locations on left-hand side**

- 1 Clutch fluid reservoir  
2 Air suction valves  
3 Air filter

- 4 Idle speed adjuster  
5 Fuel tank and pump filters  
6 Battery

- 7 Drive chain  
8 Engine oil level sightglass

- 9 Engine oil filler plug  
10 Brake pads



**ZX1100 C/D component locations on right-hand side**

- 1 Coolant reservoir  
2 Rear brake fluid reservoir  
3 Coolant filter (UK)

- 4 Valves and spark plugs  
5 Steering head bearings

- 6 Front brake fluid reservoir  
7 Brake pads

- 8 Engine oil drain plugs  
9 Engine oil filter



## Introduction

Periodic routine maintenance is a continuous process which should commence immediately the machine is used. The object is to maintain all adjustments and to diagnose and rectify minor defects before they develop into more extensive, and often more expensive, problems.

It follows that if the machine is maintained properly, it will both run and perform with optimum efficiency, and be less prone to unexpected breakdowns. Regular inspection of the machine will show up any parts which are wearing, and with a little experience, it is possible to obtain the maximum life from any one component, renewing it when it becomes so worn that it is liable to fail.

Regular cleaning can be considered as important as mechanical maintenance. This

will ensure that all the cycle parts are inspected regularly and are kept free from accumulations of road dirt and grime. Cleaning is especially important during the winter months, despite its appearance of being a thankless task which very soon seems pointless. On the contrary, it is during these months that the paintwork, chromium plating, and the alloy casings suffer the ravages of abrasive grit, rain and road salt. A couple of hours spent weekly on cleaning the machine will maintain its appearance and value, and highlight small points, such as chipped paint, before they become a serious problem.

It should be noted that the intervals between each maintenance task serve only as a guide. As the machine gets older, or if it is used under particularly arduous conditions, it

is advisable to reduce the period between each check.

For ease of reference, most service operations are described in detail under the relevant heading. However, if further general information is required, this can be found under the pertinent section heading and chapter in the main text.

Although no special tools are required for routine maintenance, a good selection of general workshop tools is essential; refer to *Tools and Workshop Tips* in the Reference section

It will also be noted that Allen screws are used extensively on these machines, and it follows that a selection of metric Allen keys (wrenches) will be required. These are available from most auto accessory shops and are not expensive.

## Monthly, or every 500 miles (800 km)

### 1 Drive chain adjustment



1 The exact interval at which the final drive chain will require adjustment and renewal is entirely dependent on the usage to which the machine is put. However, Kawasaki do recommend that the chain freeplay is checked, and if necessary adjusted, every 500 miles (800 km) and checked for wear every 3000 miles (5000 km).

2 The amount of wear in the chain can be assessed by measuring a 20 link length of the chain, ie the distance from any one pin to the


21st pin along. Note that the distance measured should be from the centre of the first pin to the centre of the other (21st) pin. This can be done with the chain in place on the machine as follows.

3 Remove the chainguard and hang a weight of approximately 10 kg (22 lbs) on the bottom run of the chain to keep the chain taut, then measure the specified length of the chain along the top run of the chain (see illustration). Since the chain is likely to wear unevenly, measure several different sections of the chain. If any one measurement exceeds the limit given in the Specifications, the chain is worn out and must be renewed.

4 Chain renewal will require the removal of the swinging arm, unless a chain with a connecting link has been fitted previously. Refer to the relevant Sections of Chapter 6 for details of swinging arm removal. If a connecting link is fitted, the spring clip must be refitted with its closed end facing the normal direction of chain travel.

A more accurate check of wheel alignment can be made by laying a plank of wood or drawing a length of string parallel to the machine so that it touches both walls of the rear tyre. Wheel alignment is correct when the plank or string is equidistant from both walls of the front tyre when tested on both sides of the machine, as shown (see illustration). If the wheel alignment is found to be incorrect, it can be adjusted as follows.

6 Place the machine on its centre stand and slacken the rear brake caliper and collar fixing bolts on ZX900 models, or the caliper to torque arm mounting bolt on all other models. Remove either the left or right-hand side wheel spindle retaining circlip and slacken the wheel spindle and chain adjuster pinch bolts. Rotate the adjusters until the same notch on each one is aligned with the mark on the swinging arm, then tighten both the chain adjuster pinch bolts. Check that the notches on the chain adjusters are still aligned and then tighten the wheel spindle to the specified torque setting, and refit its retaining circlip.




1.3 Final drive chain wear measurement check

- 1 10 kg weight
- 2 Top run of chain
- 3 Ruler
- 4 Distance between 1st and 21st pins

**HAYNES**  
**HiNT** If the chain is to be renewed, this must always be done in conjunction with both sprockets to prevent the increased wear that would result from the running together of new and part-worn components.


5 Before the chain tension can be checked it is necessary to ensure that the wheel alignment is correct. This can be checked using the notches on the outside of the chain adjusters. Identify which notch aligns with, or is closest to the mark on the swinging arm and ensure that the corresponding notch on the opposite adjuster is in the same position.




1.5 Wheel alignment check

A and C Incorrect B Correct







1.6a Set wheel alignment using the notches in the adjusters . . .




1.6b . . . then tighten spindle to the specified torque setting and refit circlip




1.8a Rotate both chain adjusters until chain tension is correct . . .



1.8b . . . then tighten both chain adjuster pinch bolts to specified torque setting . . .



1.8c . . . followed by the rear brake caliper and collar fixing bolts on ZX900 models . . .



1.8d . . . or the torque arm mounting bolt on ZX1000 and ZX1100 C/D models

(see illustrations). Once the wheel alignment is correct proceed to check the chain tension as follows before securing the caliper bolts.

7 Chain tension is adjusted with the machine on its centre stand and with the rear wheel clear of the ground. Find the tightest spot of the chain by rotating the rear wheel and feeling the amount of freeplay present on the bottom run of the chain, midway between the sprockets, testing along the complete length of the chain. When the tightest spot has been found, measure the total amount of up and down movement available. This measurement should be within the limits given in the Specifications.

8 To adjust the chain, slacken the rear brake caliper and collar fixing bolts on ZX900 models, and the caliper to torque arm mounting bolt on all other models. Slacken the chain adjuster pinch bolts and rotate the adjusters by an equal amount until the correct amount of freeplay required is obtained (see illustration). Once the chain is correctly adjusted tighten the chain adjuster pinch bolts to their specified torque setting, followed by the rear brake caliper and collar fixing bolts or the caliper to torque arm mounting bolt (as applicable) (see illustrations). Finally lubricate the chain as described in 'Daily (pre-ride) checks' at the beginning of this manual and check the operation of the rear brake before taking the machine out on the road.

## 2 Suspension settings check

1 To ensure the machine handles well and is safe to ride, it is essential that both front and rear suspension settings (as applicable) are regularly checked. **Note:** when checking the air pressures do not use a tyre pressure gauge as they are not accurate enough and lose too much air when disconnected. Kawasaki produce a suitable gauge under Part Number 52005-1003. When adding air to the suspension components NEVER use an airline, because they operate at far too high a pressure and could damage the seals. It is recommended that only a bicycle pump or one of the specialist aftermarket kits is used to add air, the latter usually comes equipped with its own built-in gauge and is extremely accurate in use. Note that the standard settings given are recommended for solo riding with a rider of average build, weighing approximately 68 kg (150 lb).

### Front forks

#### ZX900 A1 - A6 and ZX1000 A models


2 The front forks fitted to these models are air-assisted and feature a 3 position adjustable anti-dive unit. When checking the air pressure raise the front wheel clear of the ground to prevent the pressure in the fork

being artificially increased due to the weight of the machine. To achieve this, it will be necessary to position the machine on its centre stand, then remove the lower fairing section as described in Chapter 6, and place a suitably-sized block or stand underneath the crankcases.


3 The fork legs on ZX900 A1 to A6 models and early ZX1000 A1 models are linked by an air balance pipe, fitted just above the bottom yoke, and are adjusted via the valve at the top of the right-hand stanchion. On later ZX1000 A1 and all A2, A3 models, the pressure in each fork leg is adjusted separately via a valve at the top of each stanchion; it is essential to ensure that equal pressure exists in each fork leg. Take the pressure reading when the forks are cold. The standard air pressure is 0.5 kg/cm<sup>2</sup> (7 psi), with a usable range of 0.4 - 0.6 kg/cm<sup>2</sup> (5.7 - 8.5 psi). On no account should the air pressure in the forks ever exceed 2.5 kg/cm<sup>2</sup> (36 psi) as this will almost certainly damage the fork seals. Refit the valve dust cap when complete.

4 On both models ensure that the anti-dive units, fitted on the front of each lower fork leg, are set to the same position. They are adjusted using the thumb-wheel situated at the bottom of the unit. The present position is indicated by the index mark on the front of the unit which aligns with a number on the thumb-wheel. Position 1 is the softest setting and position 3 the strongest. To make adjustment, turn the thumb-wheel until it clicks and the






**2.5 Front fork damping adjuster position – ZX1100 C/D model**



**2.6 Adjusting the front fork preload – ZX1100 C/D models**



**2.7 Adjusting the front fork damping – ZX1100 C/D models**

required number (setting) is aligned with the index mark on the front of the unit. Set each unit to the same position.

#### ZX1100 C/D models

**5** The front forks feature an 8 position spring preload adjuster and a 4 position damping adjuster (see illustration). Both the preload and damping adjusters are an integral part of the fork top bolts.

**6** Preload is adjusted by turning the large hexagon-headed bolt that protrudes out of the top bolt (see illustration). The position in which the adjuster is set is indicated by the marks on the side of the adjuster, ie the number of marks or lines visible above the surface of the top bolt. Position 8 (adjuster fully extended) is the softest setting and position 1 (adjuster fully in) is the hardest. The standard setting is position 6 (6th mark from the top).

**7** The damping adjuster is situated in the centre of the preload adjuster and is adjusted using a flat-bladed screwdriver (see illustration). As there are no marks on the preload adjuster to indicate the four positions, the only way to identify its present position is to count the number of clicks the adjuster makes whilst being rotated. The 4 adjuster positions are all situated within 180° (half a turn) of the adjuster (see illustration 2.5). Therefore, whilst rotating the adjuster it should click 4 times in 180° and not at all for another 180°. The first click after the 180° break is position 1. **Note:** always turn the damping adjuster clockwise and never anti-clockwise (counter-clockwise).

**8** Once position 1 has been identified the other positions will click into place with further turning of the adjuster in a clockwise direction. After position 4 there should be an 180° break after which the adjuster will click back into the number 1 position. Set the adjuster to the required position noting that position 1 is the softest setting and position 4 the hardest. The standard recommended setting is position 2.

**9** Once both preload and damping adjusters are set to the required settings, repeat the procedure on the other fork leg, ensuring that both fork legs are set to identical positions;

failure to do so will lead to the machine's handling being impaired.

#### Rear suspension unit

##### ZX900 and ZX1000 models

**10** The rear suspension unit is air-assisted and has a 4 position remote damping adjuster. The air pressure valve and damping adjuster are situated behind the right-hand sidepanel, with the exception of the damping adjuster on ZX1000 B models, which is located in the right-hand frame member.

**11** Air pressure should be checked with the machine on its centre stand and the suspension unit cold, ie at room temperature. Remove the right-hand sidepanel and check the air pressure in the unit via the frame mounted valve. Take note of the figures given in the table below, and adjust as necessary. Note that on no account must the pressure in the suspension unit ever exceed 5 kg/cm<sup>2</sup> (71 psi) as this will almost certainly damage the seals.

	Standard pressure	Usable range
ZX900	0.5 kg/cm <sup>2</sup> (7 psi)	0.5 - 1.5 kg/cm <sup>2</sup> (7 - 21 psi)
ZX1000 A	0.5 kg/cm <sup>2</sup> (7 psi)	0 - 1.5 kg/cm <sup>2</sup> (0 - 21 psi)
ZX1000 B	Atmospheric	0 - 1 kg/cm <sup>2</sup> (0 - 14 psi)

**12** Damping is adjusted using the frame-mounted remote adjuster. The unit has 4 positions, position 1 being the softest and position 4 the hardest. The recommended position to comply with the standard air pressure is No 3 for ZX900 models and No.2 for ZX1000 models.

**13** On ZX900 models the adjuster positions are indicated by the numbers on the top surface of the knob, the highest number visible being the present position. The settings are adjusted either by pushing or pulling the knob until the desired setting is reached. Position 4 is when the knob is fully extended and position 1 when the knob is fully pushed in. Positions 2 and 3 are the two click stops in between.

**14** On ZX1000 models the damping setting is adjusted by rotating the knob until the required number aligns with the triangular


indicator mark. On ZX1000 A models the indicator mark is situated at the bottom of the adjuster mounting bracket and the numbers are on the wheel, whereas on ZX1000 B models the indicator mark is on the knob and the numbers are situated on the outer edge. *Note that on ZX1000 A models the adjusting knob will only rotate in an anti-clockwise (counter-clockwise) direction. Do not attempt to turn it in a clockwise direction.*

**15** Ensure both the damping and air pressure are set to the required settings and refit the sidepanel.

##### ZX1100 C/D models

**16** The rear suspension unit is linked to a pressurised remote oil reservoir and features a 4 position damping adjuster. The spring preload can also be adjusted but this is a complicated and time-consuming job which requires the removal of the suspension unit from the frame (see below). Therefore, it is recommended that it should only be carried out if absolutely necessary.

**17** The damping adjuster is situated on the lower end of the suspension unit, and can be adjusted from underneath the machine. Position the machine on its centre stand. Access to the adjuster wheel can be gained from the right-hand side of the machine after removing the plastic cover situated just above the suspension unit lower mounting bolt (see illustration). The present position is indicated by the Roman numeral visible on the edge of



**2.17 Remove plastic cover to gain access to rear suspension damping adjuster on ZX1100 C/D models**



the adjuster wheel. Position I is the softest setting and position III the hardest; the standard setting being position II. If necessary, adjust the setting by turning the wheel until it clicks into the required position. Note that the adjuster wheel will turn in one direction only, towards the front of the machine. *Do not attempt to force it in the opposite direction.* Once the adjuster is correctly set, refit the plastic cover to prevent the entry of dirt and water.

18 As mentioned previously, it is not necessary to check the spring preload adjustment unless handling problems have occurred. Remove the rear suspension unit from the machine as described in Chapter 6. Accurately measure the length of the suspension unit spring and note this measurement down. Slacken the large locknut and spring adjusting nut, using a suitable C-spanner, until all spring pressure acting on the adjusting nut is released. Measure the free length of the spring at this point. Subtract the first measurement (compressed length) from the second measurement (free length) to obtain the present spring preload distance; this can then be compared with the standard setting and, if necessary, adjusted.

19 The recommended standard setting for the spring preload is:

ZX1100 C models 18 mm (0.71 in)

ZX1100 D models 19.5 mm (0.76 in)

A tolerance is allowed for further adjustment:

ZX1100 C models 14 - 30 mm  
(0.55 - 1.18 in)

ZX1100 D models 19 - 31 mm  
(0.75 - 1.22 in)

The actual amount of preload will depend very much on the use to which the machine is put. To increase the preload and stiffen the ride the spring preload distance should be increased, and to decrease the preload and soften the ride the preload should be decreased. The extent of adjustment is very much a case of trial and error, and it may be worth seeking the advice of an authorised Kawasaki dealer in this respect.

20 Set the spring compression to the required distance using the adjusting nut, and then tighten the large locknut securely. Refit the suspension unit to the machine as described in Chapter 6.

### 3 Battery check

1 The battery is situated under the seat, which must be removed to gain access to it. Due to its location, it will be necessary to remove the battery from the machine to check the electrolyte level. On the ZX1100 C/D model the seat hook bracket must first be removed. Release the rubber retaining strap, disconnect the leads from the battery terminals and lift the battery out of the machine. Note that whenever the battery leads are disconnected, always disconnect the negative (-) terminal first to prevent the possibility of short circuits.

2 The electrolyte level, visible through the translucent casing, should be between the two level marks on the battery casing (see illustration). If not, remove the cell caps and top up to the upper level mark using only distilled water.



**The battery cell holes are quite small, so it may help to use a plastic squeeze bottle with a small spout to add the water.**

3 Check the battery for any signs of pale grey sediment at the bottom of the casing. This is caused by sulphation of the plates as a result of recharging at too high a rate or as a result of the battery being left discharged for long periods. A good battery should have little or no sediment visible and its plates should be straight and pale grey or brown in colour. If sediment deposits are deep enough to reach



**3.2 Electrolyte level must be between marks on casing**

the bottom of the plates, or if the plates are buckled and have whitish deposits on them, the battery is faulty and must be renewed. Remember that a poor battery will give rise to a large number of minor electrical faults.

4 On refitting, check that the breather hose is not blocked and is correctly routed, and secure the battery with its retaining strap. Connect up the battery terminals, remembering to connect the negative (-) terminal last. Ensure the terminals are clean and tight, and that the rubber cover is correctly fitted over the positive (+) terminal. Check the junction box fuses are of the correct ratings and in good condition, and that spare fuses of both ratings (10 and 30A) are available on the machine should the need arise.



**Battery terminal corrosion can be minimised by applying a layer of petroleum jelly to the terminals after the leads have been connected.**

5 If the machine is not in regular use, disconnect the battery and give it a refresher charge every month to six weeks, as described in Chapter 8.

## Every 3000 miles (5000 km)

### 4 Spark plugs check


1 Remove the fuel tank as described in Chapter 4. On ZX1100 C models remove the front section of the air filter housing and on ZX1000 A models the top section of the air filter housing, each being retained by four screws. On ZX1100 D models, remove the air filter housing as described in Chapter 4, Section 7. Carefully pull off the spark plug caps and remove any dirt or other foreign matter from the spark plug channels. Using only the correct tool, unscrew and remove the spark plugs



**Since the plugs are recessed, slip a short length of hose over the end of the plug to use as a tool to thread it into place. The hose will grip the plug well enough to turn it, but will start to slip if the plug begins to cross-thread in the hole - this will prevent damaged threads and the accompanying repair costs.**

whilst keeping them clearly defined by their cylinder number (see illustration).

2 Using feeler gauges, preferably of the wire type for greater accuracy, measure the gap



**4.1 Spark plugs can be removed using plug spanner supplied in machine's tool kit**



between the electrodes and compare it with the figure given in the Specifications. If adjustment is required this can be carried out as described below, assuming that the plug is otherwise undamaged. In the event that any plug is heavily fouled or damaged in any way renewal is required; renew the plugs as a set. On UK models always ensure that the plugs are of the resistor type (indicated by the letter R) so that its resistance value is correct for the ignition system. The same applies to the suppressor caps if these are ever renewed.

**3** If the spark plugs are still serviceable, carefully compare the appearance of their electrodes with the colour section inside the rear cover and note any information which can be obtained from this. If any plug appears to show a fault, seek expert advice as soon as possible. The standard grade of spark plug should prove adequate in all normal use and a change of specification (such as fitting a hotter or colder grade of plug) should not be made without expert advice from an authorized Kawasaki dealer.

**4** Clean the plug electrodes by carefully scraping away the accumulated carbon deposits using a small knife blade or small files and abrasive paper; take care not to bend the centre electrode or to chip or damage the ceramic insulator. The cleaning of spark plugs on commercial sandblasting equipment is **not** recommended due to the risk of abrasive particles being jammed in the gap between the insulator and the plug metal body, only to fall clear later and drop into the engine; any plug that is so heavily fouled should be renewed.

**5** Once clean, file the opposing faces of the electrodes flat using a small fine file. A magnetite file or even a nail file can be used for this purpose. Whichever method is chosen, make sure that every trace of abrasive and loose carbon is removed before the plug is refitted. If this is not done, the debris will enter the engine and cause damage or rapid wear.

**6** Whether a cleaned or new plug is to be fitted, always check the electrode gap before it is installed. Use a spark plug adjusting tool or feeler gauges to measure the gap, and if adjustment is required, bend the outer, earth electrode only. *Never bend the centre electrode or the ceramic insulator nose will be damaged.*

**7** Before the plugs are fitted, apply a fine coat of PBC or molybdenum disulphide grease to their threads. This will help prevent thread wear and damage on refitting and make their subsequent removal easier. Fit each plug finger-tight, then tighten it by a further 1/4 turn only, to ensure a gastight seal. Beware of overtightening, and always use a plug spanner or socket of the correct size; tighten all plugs to the specified torque setting, where possible.

**8** Never overtighten a spark plug, otherwise there is a risk of stripping the thread from the cylinder head, especially as it is cast in light alloy. A stripped thread can be repaired

without having to scrap the cylinder head by using a 'Helicoil' thread insert. This is a low-cost service, operated by a number of dealers.


**9** When refitting the spark plug suppressor caps, ensure that the HT leads are correctly routed; note that the leads are numbered as an aid to identification.

## 5 Fuel and oil lines check

**1** Give all the fuel hoses a close visual examination checking for cracks or any sign of leakage. In time, the synthetic rubber pipe will tend to deteriorate, and will eventually leak. Apart from the obvious fire risk, the leaking fuel will affect fuel economy. The pipe will usually split only at the ends; if there is sufficient spare length the damaged portion can be cut off and the pipe refitted. The seal is effected by the interference fit of the pipe on the spigot; although the wire clips are only an additional security measure they should always be refitted correctly and should be renewed if damaged, twisted or no longer effective. If the pipe is to be renewed, always use the correct replacement type and size of neoprene tubing to ensure a good leak-proof fit. Never use natural rubber tubing, as this tends to break up when in contact with petrol (gasoline) and will obstruct carburettor jets, or clear plastic tubing which stiffens to the point of being brittle when in contact with petrol and will produce leaks that are difficult to cure.

**2** Also give the oil cooler hoses a close inspection for signs of deterioration or leakage. If any hose is damaged it must be renewed as described in Chapter 4.

**3** Owners of US machines should also examine the clean air system hoses, and on California models, the emission control system. Check the transparent reservoir on the left-hand side of the engine. It lies next to the air filter oil reservoir and runs from the T-piece connection between the vacuum valve and canister. Remove the plug from the pipe end and drain off any fluid from the reservoir. Any faulty component must be renewed using only genuine Kawasaki replacement parts.



7.1 Throttle cable freeplay is measured in terms of twistgrip rotation

Refer to Chapter 4 for further information on the clean air and emission control systems.

## 6 Air suction valves (US and ZX1100 D models) check

**1** In order to gain access to the valves on US models it is necessary to remove the lower and side fairing sections and the fuel tank. On ZX 1100 D models remove the fairing side sections and air filter housing.

**2** Slacken their spring clips and pull the vacuum valve switch pipes off the air suction valve covers. Remove each air suction valve after releasing its two bolts. Inspect the reeds for distortion, cracks or any other damage and their contact surface on the cover for scratches or deterioration; if found, the assembly should be renewed. If carbon deposits have built up in the assembly, these must be cleaned off with a high flash-point solvent.

**3** On reassembly install new gaskets and tighten the bolts securely.

## 7 Carburettors check and synchronisation

**1** Start by ensuring that the throttle cable(s) operate smoothly and are correctly adjusted. There should be 2 - 3 mm (0.08 - 0.12 in) of free play which is measured in terms of twistgrip rotation (see illustration).

**2** As ZX900 A1 and A2 models only use one throttle cable the freeplay is adjusted simply by slackening the locknut on the handlebar mounted adjuster and turning the adjuster until the required amount of freeplay is obtained (see illustration). If there is insufficient adjustment at the handlebar adjuster it will be necessary to use the lower adjuster situated midway along the cable's length. This adjuster should be accessible from the left-hand front edge of the fuel tank, if not it will be necessary to remove the fuel tank as described in Chapter 4. Screw the



7.2 Handlebar-mounted upper throttle cable adjuster






**7.3** On ZX1100 C/D models lower throttle and choke cable adjusters are just in front of air filter housing



**7.6** Choke mechanism is on the left-hand side of carburettor bank - plunger must operate smoothly



**7.7** Choke lever free play measurement

1 Choke lever 2 Free play of 2 - 3 mm

handlebar adjuster fully in and tighten its locknut. Loosen the locknut on the lower cable adjuster and rotate the adjuster until the required amount of free play is obtained, then tighten its locknut securely.

3 All other models use two throttle cables, an accelerator and decelerator cable. If adjustment is needed, first try to obtain the required amount of free play by slackening the locknut and turning the handlebar-mounted adjuster on the accelerator cable. If this fails to give enough free play it will be necessary to remove the fuel tank, as described in Chapter 4, and adjust the cables using the lower adjusters. Note that on ZX1000 A models access to the adjusters will be greatly improved if the top section of the air filter housing is also removed. On ZX900 A3 onwards and ZX1000 models these adjusters are at the bottom of the cables and are located on the carburettor mounting brackets, the rear adjuster is for the accelerator cable and the front one for the decelerator cable. On ZX1100 C/D models the adjusters are situated midway along the length of the cables and are accessible from the front of the air filter housing, the right-hand adjuster is for the accelerator cable and the centre one for the decelerator cable (see illustration).

4 Release their locknuts and fully slacken all the cable adjusters to obtain the maximum free play possible. Whilst holding the twistgrip closed, slowly turn the decelerator cable adjuster until all the slack has been removed and the cable is just becoming tight, then tighten its locknut securely. Rotate the lower accelerator cable adjuster until the correct amount of free play is obtained at the twistgrip, and securely tighten both the lower and handlebar adjuster locknuts. On ZX1000 A models refit the air filter top cover.

5 On all models start the engine and allow it to idle, then move the handlebars from lock to lock. If the idle speed rises and falls as the handlebars are turned the throttle cable(s) are incorrectly routed. To remedy, remove the retaining screws from the right-hand handlebar switch and separate the two halves of the switch. Disconnect the cable(s) from the twistgrip and reroute them along the

smoothest possible route, ensuring that they are not kinked or could foul any other component. Before connecting the throttle cable(s) lubricate them, then reconnect the cable(s) and check the free play, adjusting again if necessary.

6 Once the throttle cable adjustment is correctly set, go on to check the operation of the choke mechanism, especially if the machine has been difficult to start when cold, or a rich fuel mixture is indicated. This can be checked by operating the handlebar mounted choke lever whilst observing the choke mechanism of the left-hand carburettor. The choke mechanism should extend smoothly when the lever is pulled, and return fully home when the lever is returned (see illustration). If the choke does not operate smoothly this is probably due to a cable fault. Remove the retaining screws from the left-hand handlebar switch and disconnect the cable at its upper end. Reroute the cable so it takes the smoothest route possible and lubricate it. Reconnect the cable and tighten the handlebar switch screws securely. If this fails to improve the operation of the choke the cable must be renewed. Note that in very extreme cases the fault could be in the carburettors rather than the cable, necessitating the removal of the carburettors and examination of the choke plungers as described in Chapter 4.

7 Once the choke is operating smoothly it is necessary to check the amount of cable free play. The free play is measured at the base of



**7.9** Idle speed adjuster is situated on left-hand side carburettors - ZX1100 C/D shown

the operating lever where there should be 2 - 3 mm (0.08 - 0.12 in) of travel in the lever before the choke mechanism on the left-hand carburettor begins to move (see illustration). The cable is adjusted by slackening the locknut and turning the adjuster until the correct amount of free play is obtained. On most models the adjuster is situated at the mid-point of the cable, although on some early ZX900 A1 models it is situated on the underside of the left-hand handlebar switch. Once the cable is correctly adjusted securely tighten the adjuster locknut.

8 When both the throttle and choke cables are correctly adjusted and operating smoothly check that the carburettors are correctly synchronised, as described in Chapter 4, and then check the idle speed.

9 Idle speed should be checked with the engine at its normal running temperature, preferably after the machine has been on a short run. Allow the engine to idle and check that it runs at the specified speed given in the Specifications. Make any adjustment to the idle speed using the adjuster knob situated on the left-hand side of the carburettors (see illustration). Open and close the throttle a few times to check that the setting has not changed.


## 8 Brake pads check

1 The hydraulic brake requires no regular adjustment as pad wear is compensated for by the entry of more fluid into the system from the fluid reservoir. All that is necessary is to keep a regular check on the fluid level (see 'Daily (pre-ride) checks' at the beginning of this Manual) and the degree of pad wear. To check the condition of the brake pads it is necessary to remove the caliper from the machine.


### Front brake

2 On all models except the ZX900 A1 to A6, the front brake calipers can be removed by simply removing their mounting bolts and






**8.2** Front brake calipers are retained by two bolts



**8.4a** On ZX900 A7 and ZX1100 C/D models, remove its screws and lift off pad spring ...



**8.4b** ... withdraw R-clip and slide out pad retaining pin ...

lifting them off the discs (see illustration). On ZX900 A1 to A6 models, however, it is first necessary to remove the front wheel, as described in Chapter 7. Once the caliper is free from its mountings note that it is not necessary to disconnect the hydraulic hose if care is taken not to place any strain on the hose, such as allowing the caliper to hang by its hose without support.

**3** To remove the brake pads on ZX900 A1 to A6 and ZX1000 models, first detach the piston-side pad and remove it from the caliper mounting bracket. Remove both the small pad springs that are fitted to the bracket on each side of the brake pad. Make a note of the way these springs are fitted to ensure they are positioned correctly on reassembly. Push the caliper bracket towards the caliper itself and manoeuvre the second brake pad off the pins of the caliper bracket.

**4** On ZX900 A7-on and ZX1100 C/D models, release both the pad spring retaining screws from the top of the caliper and lift off the pad spring. Remove the R-clip from the pad retaining pin and withdraw the pin from the caliper. The pads can then be slid out of the caliper body for inspection (see illustrations).

**5** On all models, inspect the surface of each pad for contamination and measure the thickness of the friction material. If either pad is worn to or beyond the service limit at any point, fouled with oil or grease, or heavily scored or damaged by dirt and debris, they must be renewed as a set. Note that it is not possible to degrease the friction material; if

the pads are contaminated in any way they must be renewed. If the pads are in good condition clean them carefully, using a fine wire brush which is completely free of oil or grease, to remove all traces of road dirt and corrosion. *Take great care not to inhale any brake dust during the operation, and read the notes given in 'Safety first!' concerning asbestos.* Use a pointed instrument to clean out the grooves in the friction material and to dig out any embedded particles of foreign matter (as applicable). Any areas of glazing may be removed using emery cloth.

**6** On ZX900 A1 to A6 and ZX1000 models, before refitting the pads check that the caliper slides easily along its mounting bracket and that the rubber dust boots are in a good condition. If not, separate the caliper and mounting bracket, remove any traces of old grease or corrosion from the sliding pins of the bracket and examine them for wear. If the pins are bent or damaged in any way the mounting bracket must be renewed. If necessary, also renew the dust boots. On reassembly apply PBC (Poly Butyl Cuprysil) grease to all sliding surfaces and refit the bracket to the caliper, ensuring that the rubber dust boots are correctly seated and the large pad spring fitted to the roof of the caliper is in position. Refit the pad springs to the caliper bracket, using the notes made on dismantling to position them correctly, and push the caliper bracket towards the caliper. Push the piston(s) as far back into the caliper as possible by hand only; this is especially

important if new pads are being fitted, due to the increased friction material thickness. Fit the larger pad over the pins of the bracket (friction material facing the piston) and then fit the smaller pad into the bracket whilst ensuring the pad springs remain in position.


**7** On ZX900 A7-on and ZX1100 C/D models, remove all traces of corrosion from the pad retaining pin and smear a small amount of PBC grease along it. Slide the pads back into the caliper, noting that if new pads are being fitted the pistons must be pushed back into their bores to provide sufficient room. Insert the pad retaining pin and secure it with the R-clip. Ensure that the pin is fitted with the small hole for the R-clip facing the outside edge of the caliper and that the R-clip does not trap the outside pad when in position. Check that both pads move freely along the retaining pin, then refit the pad spring and tighten its retaining screws securely.

**8** On all models, refit the calipers to the machine and tighten the mounting bolts to the specified torque setting. On ZX900 A1 to A6 models refit the wheel as described in Chapter 7. Pump the brake lever repeatedly until the pads are pushed back against the discs and normal operation of the brake lever has returned. Check the fluid level in the reservoir, noting that if new brake pads have been fitted it may be necessary to remove fluid from the reservoir.


**9** Before taking the machine on the road, check the hydraulic system for leaks and ensure that the braking system is operating correctly. Remember that new pads, and to a lesser extent, cleaned pads will not function at peak efficiency until they have bedded in. Where new pads have been fitted, use the brake gently but firmly for the first 50 - 100 miles.

## Rear brake

**10** On all models it is necessary to remove the brake caliper to gain access to the pads, although the hydraulic hose can be left attached if care is taken not to place any strain on it. On ZX900 and ZX1000 A models, it will first be necessary to remove the right-hand silencer. On all models, remove the caliper mounting bolts and slide the caliper off the disc (see illustration).




**8.4c** ... pads can then be removed from caliper




**8.10** Remove rear caliper mounting bolts and slide caliper off disc






8.11a Remove the piston side pad ..



8.11b ... followed by the larger inner pad



8.11c Ensure pad springs are correctly fitted. Do not omit the piston insulators (where fitted)

11 The rear caliper fitted to ZX900 A1 to A6 and ZX1000 models is identical to the front caliper, and the rear caliper fitted to ZX900 A7-on and ZX1100 C models is identical to that fitted to the ZX1000 B model. Therefore the rear brake pads can be removed and inspected as described above for the ZX900 A1 to A6 and ZX1000 front brake caliper (see illustrations).

12 On ZX1100 D models it is possible to remove the pads without removing the caliper from its mountings, but access is difficult due to the caliper's location (see Chapter 6). Pry free the black plastic cover from the base of the caliper and using pliers, extract the two R-pins (pad retaining pin clips). While releasing pressure from the pad springs, pull the pad retaining pins from the caliper and lift out the brake pads (see illustrations).

13 After the pads have been examined (see above for front brakes) and the caliper is refitted to the machine it will be necessary to check the rear brake pedal height and the operation of the rear stop lamp switch.


14 Measure the vertical distance between the top of the footrest and the tip of the brake pedal. If this measurement differs greatly from the figure given in the Specifications, it should be adjusted. The pedal height is adjusted by altering the length of the rod which connects the pedal and master cylinder.

15 On ZX900 models, due to the location of the rod it will be necessary to remove the right-hand footrest bracket assembly to gain sufficient access (see illustration). To remove the bracket, remove the right-hand sidepanel,


slacken and remove the rear brake master cylinder and reservoir bolts and right-hand silencer mounting bolts, and disconnect the rear stop lamp switch wires. Then remove all the footrest bracket mounting bolts, including the swinging arm pivot nut, and remove the bracket assembly from the machine. Make adjustment by slackening the locknut (situated at the pedal end of the rod) and turning the adjusting nut, situated at the master cylinder end of the rod, until the correct pedal height is obtained. Once the pedal height is correct tighten the locknut securely and adjust the stop lamp switch as described below. Refit the footrest bracket to the machine, tightening all mounting nuts and bolts to the specified torque settings, where given, and reconnect the stop lamp switch wires.

16 On all other models the task is simplified because the adjuster is accessible without


removing the footrest bracket. Remove the split pin from the clevis pin at the end of the master cylinder rod and withdraw the clevis pin to disconnect the rod from the brake pedal. Slacken the locknut which secures the forked end of the master cylinder rod, remove the master cylinder mounting bolts and partially remove the master cylinder. The rod length is adjusted by screwing the forked end of the rod either in or out to obtain the correct pedal height. On ZX1000 B and ZX1100 C/D models Kawasaki actually specify a measurement for the length of the rod. This measurement is taken parallel to the rod itself from the centre of the hole in the forked end of the rod to the centre of the first mounting bolt hole on the master cylinder, and should be  $119 \pm 1$  mm ( $4.68 \pm 0.04$  in) for ZX1000B and ZX1100 C models, or  $80 \pm 1$  mm ( $3.15 \pm 0.04$  in) for ZX1100 D models (see illustration). On



8.12a Install the pads in the caliper ...




8.12b ... slide one pad retaining pin into place, then install the springs and fit the other retaining pin ...



8.12c ... secure with the R-pins (retaining pin clips)



8.15 On ZX900 models remove the footrest bracket to adjust the brake pedal and stop lamp switch



8.16 Pedal height adjustment locknut (A), bottom mounting (B) and clevis pin (C)



ZX1000 A models it is simply a case of trial and error to find the correct length, temporarily installing the master cylinder mounting bolts and clevis pin and rechecking after each adjustment until the pedal height is correct. Once the pedal height or rod length is correct, refit the master cylinder mounting bolts and install the clevis pin. Tighten the master cylinder mounting bolts and the connecting rod locknut securely, and secure the clevis pin with a new split pin.

**17** On all models, once the brake pedal height is known to be correct it is necessary to check that the rear stop lamp switch is functioning correctly. This is done by measuring the amount of travel there is at the brake pedal tip before the stop lamp is illuminated. The stop lamp should come on after the brake pedal travels approximately 10 mm (0.4 in). The stop lamp is altered by turning the adjusting nut which is fitted to the switch whilst holding the body of the switch to prevent it from turning.

## 9 Drive chain check



The manufacturer recommends that the chain be checked for wear at this interval. Refer to the Monthly (500 mile/800 km) service operations for details.

## 10 Steering check



**1** Place the machine on its centre stand and remove the lower fairing section (see Chapter 6). Raise the front wheel clear of the ground by placing a stand or some suitably sized blocks beneath the crankcase. Grasp the front fork legs near the wheel spindle and push and pull them firmly in a fore and aft direction to check for any free play in the steering head bearings. Check for overtightened bearings by placing the forks in the straight ahead position and tapping lightly on one end of the handlebars. The forks should move smoothly and easily to the opposite lock, taking into account the effect of the cables and wiring, with no trace of notchiness. If adjustment is required proceed as follows:

**2** Remove the fuel tank as described in Chapter 4. On ZX900 A7-on and ZX1100 C/D models, prise out the large circular cap which covers the top yoke retaining nut, and on all other models remove the top yoke cover retaining screws and lift off the cover. On all models, slacken the top yoke retaining nut and all the bottom yoke pinch bolts.

**3** Tighten or slacken (as applicable) the steering stem adjuster nut situated under the top yoke, using a suitable C-spanner, by approximately 1/8 of a turn at a time until the


handlebars turn freely from lock to lock and no free play can be felt when pushing and pulling the fork legs. Once the steering head bearings are correctly adjusted, tighten the top yoke retaining nut and all the bottom yoke pinch bolts to their specified torque settings. Refit the top yoke cover or cap (as applicable), and refit the fuel tank as described in Chapter 4. Finally remove the stand from beneath the crankcases and refit the lower fairing section.

## 11 Cables, stands and controls lubrication



**1** Check the outer cables for signs of damage, then examine the exposed portions of the inner cables. Any signs of kinking or fraying will indicate that renewal is required. To obtain maximum life and reliability from the cables they should be thoroughly lubricated. To do the job properly and quickly use one of the hydraulic cable oilers available from most motorcycle shops. Free one end of the cable and assemble the cable oiler as described by the manufacturer's instructions. Operate the oiler until oil emerges from the lower end, indicating that the cable is lubricated throughout its length. This process will expel any dirt or moisture and will prevent its subsequent ingress.

**2** If a cable oiler is not available, an alternative is to remove the cable from the machine. Hang the cable upright and make up a small funnel arrangement using plasticine or by taping a plastic bag around the upper end as shown (see illustration). Fill the funnel with oil and leave it overnight to drain through. Note that where nylon-lined cables are fitted, they should be used dry or lubricated with a silicone-based lubricant suitable for this application. On no account use ordinary engine oil because this will cause the liner to swell, pinching the cable.



11.2 Method of oiling a control cable

**3** When refitting the cables, ensure that they are routed in easy curves and that full use is made of any guides or clamps that have been provided to secure the cable out of harm's way. Adjustment of the individual cables is described under the relevant routine maintenance headings.

**4** The speedometer cable should be removed for examination and lubrication as described in Chapter 6.

**5** Check all pivots and the control levers, cleaning and lubricating them to prevent wear and corrosion. Where necessary, dismantle and clean any moving part which may have become stiff in operation. Similarly clean and check both the centre and side stand pivot bolts for security and signs of wear, renewing them if necessary. Thoroughly grease the pivot bolts and ensure that the return springs hold both stands securely in the up positions when retracted.


**6** Lubricate the handlebar, ignition and stop lamp switches with WD40 or a similar water dispersant spray. This will keep the switches working properly and prolong their life, especially if the machine is used in adverse weather conditions.

## 12 Headlamp alignment




**1** An improperly adjusted headlamp may cause problems for oncoming traffic or provide poor, unsafe illumination on the road ahead. Before adjusting the headlamp be sure to consult with traffic laws and regulations. For UK owners, refer to MOT Test Checks in the Reference section of this manual. If required, the beam can be adjusted as follows.

**2** On ZX900 models, the horizontal adjustment is altered by rotating the spring-loaded screw situated in the right-hand side of the headlamp rim (when viewed from the front of the machine). To make vertical adjustment, it is first necessary to remove the small headlamp cover which is situated on the underside of the upper fairing. Once the cover




12.2a On ZX900 models headlamp horizontal adjustment is made with screw situated in rim . . .






**12.2b** ... and vertical adjustment by slackening bolt situated behind headlamp cover




**12.3** Headlamp beam adjuster locations - ZX1000 models

A Horizontal adjustment  
B Vertical adjustment



**12.4a** ZX1100 C/D models vertical ...



**12.4b** ... and horizontal adjusters are situated on the back of the headlamp unit

has been removed, slacken the headlamp retaining bolt situated at the bottom of the headlamp, and move the headlamp to the required position (see illustrations). When the headlamp is correctly aligned, tighten the bolt and refit the cover.

**3** Both headlamp beam adjusters on ZX1000 models are situated on the back of the headlamp unit and are adjusted from underneath. On ZX1000 B models these can be reached using the holes provided in the fairing, whereas on ZX1000 A models it is first necessary to remove the cover situated on the underside of the upper fairing to gain access

to the adjusters. The adjusters can be rotated using a crosshead screwdriver; the upper right-hand adjuster alters the horizontal aim, and the lower left-hand one alters the vertical aim (see illustration). On ZX1000A models refit the headlamp cover once the headlamp is correctly adjusted.

**4** The headlamp unit which is fitted to ZX1100 C/D models is similar to that used on the ZX1000 models, the only differences being that the upper (horizontal) adjuster is fitted with an adjusting knob and both adjusters are accessed from inside the fairing (see illustrations).

## Every 6000 miles (10 000 km)

### 13 Engine/transmission oil and filter change



**1** It is important that the engine/transmission oil is changed at this interval to ensure adequate lubrication of the engine and transmission components. If regular oil changes are overlooked the prolonged use of degraded and contaminated oil will lead to premature engine wear. The oil should be changed with the engine at its normal operating temperature, after a short run. This ensures that the oil is relatively thin and will therefore drain quicker and more completely, also any impurities will be held in suspension.




**Saving a little money on the difference in cost between a good oil and a cheap oil won't pay off if the engine is damaged.**

4.0 litres (7.1 Imp pint/4.2 US qt) capacity, beneath the engine unit and remove both drain plugs from the sump (see illustration). As the engine will be hot, take great care to avoid scalding your hands on the escaping oil or on the exhaust system. Remove the oil filler plug to assist draining. Once the oil has drained from the engine unit slacken the single central bolt which retains the oil filter cover, noting that approximately another 0.5

litre of oil will be released as soon as the bolt is loosened, then lower the cover away from the engine. Remove the element baffle, element, flat washer and spring from the filter cover and separate the cover and centre bolt. Clean all the filter components, except the element which should be discarded, and check both the sealing O-rings for signs of damage, renewing them if necessary.

**3** Refit the centre bolt to the filter cover and fit




**13.2** Engine oil drain plugs are situated in the sump (front plug shown)



**Check the old oil carefully. If the oil was drained into a clean pan, small pieces of metal or other material can be easily detected. If the oil is very metallic colored, then the engine is experiencing wear from break-in (new engine) or from insufficient lubrication. If there are flakes or chips of metal in the oil, then something is drastically wrong internally and the engine will have to be disassembled for inspection and repair. If there are pieces of fiber-like material in the oil, the clutch is experiencing excessive wear and should be checked.**

**2** Place the machine on its centre stand and remove the lower fairing section (see Chapter 6). Place a suitably-sized container, of at least





13.3a Renew its O-ring and refit centre bolt to filter cover




13.3b Refit the spring and flat washer ...



13.3c ... and carefully screw on the new element



13.3d Fit the baffle plate over the element and a new O-ring to the cover ...



13.3e ... and refit the filter assembly to the sump

## 14 Air filter element cleaning

**1** The air filter element on ZX900 models is situated behind the left-hand sidepanel. With the sidepanel removed, release the two screws which retain the filter housing end cover and lift it clear (see illustration). Pull out the plastic wedge which holds the element in place, and then withdraw the element from the housing (see illustrations).

**2** On ZX1000 and ZX1100 models it will first be necessary to remove the fuel tank, as described in Chapter 4. On ZX1000 A models, remove the four screws that secure the top of the filter housing and lift it away. The element can then be removed from the housing. On ZX1000 B models, slacken and remove the four Allen bolts from the top of the air filter housing and on ZX1100 C models remove the two screws which secure the rear section of the air filter housing to the rest of the assembly. Partially separate the air filter housing until the element can be withdrawn from the gap. On ZX1100 D models remove its seven screws and lift off the air filter housing cover, noting its sealing ring. Lift out the element and its support frames.


**3** Check that the element is not split, hardened or severely clogged, renewing it if necessary. To clean the element, soak it in a high flash-point solvent such as white spirit

crankcases with the specified amount and grade of oil. Refit the filler plug and start the engine, allowing it to idle for a few minutes to distribute the new oil through the lubrication system. Switch off the engine and wait a few minutes to allow the oil level to settle. Check that the oil level is between the marks on the sightglass set in the left-hand casing and top up if necessary (see 'Daily (pre-ride) checks' at the beginning of this Manual).


**5** Although not specified as a regular maintenance item, the two filter screens situated in the sump should be removed and cleaned of any deposits with reasonable frequency. Access can be gained to the filters by removing the sump as described in Chapter 2. Information on cleaning will be found in Chapter 4, Section 17.

the coil spring and flat washer over the centre bolt (see illustrations). Fit the new oil filter element by carefully screwing it onto the centre bolt to prevent damaging its sealing grommets; apply a smear of oil to the element seals to ease the operation (see illustration). Place the element baffle over the top of the element and refit the filter assembly in the engine unit, ensuring that the large sealing O-ring on the cover is correctly positioned (see illustration). Check the condition of the sealing washers on both the drain plugs, renewing them if damaged, then refit them in the sump (see illustration). Tighten both drain plugs and the oil filter centre bolt to their specified torque settings.

**4** Remove the filler plug from the top of the left-hand engine casing and fill the



14.1a On ZX900 models remove end cover from left-hand side of filter housing ...




14.1b ... pull out the plastic wedge ...




14.1c ... and withdraw the air filter element






**14.5a** On ZX1000 and ZX1100 C models the element is fitted with the gauze on the carburettor side



**14.5b** Install the air filter element with its grey foam side uppermost - ZX1100 D models



**14.5c** Place the support frame over the element - ZX1100 D models


(stoddard solvent); petrol (gasoline) is not recommended due to the fire risk. Squeeze it gently to remove any old oil and dirt, taking care not to break or deform the frame. Dry the element with compressed air or by shaking it and place the element to one side to allow any remaining solvent to evaporate.

**4** When it is completely dry, soak the element in a clean SE class SAE 30 motor oil and carefully squeeze out the excess oil. Wrap it in a clean rag and continue squeezing the element until it is as dry as possible and only slightly oily to the touch.


**5** On refitting, check that the element is correctly seated and is secured by the plastic wedge (ZX900 models only). Note that on ZX1000 and ZX1100 models, ensure the element is positioned so that the gauze which supports the foam is on the carburettor side of the element

(see illustration). On ZX1100 D models, install the element (grey foam side upwards, yellow side downwards) complete with support frames. Check that the air screen is correctly installed (protrusion facing the carburettor air intakes) and


that the seal is in position (see illustrations). On all models reassemble the air filter housing, ensuring that all disturbed sections or covers are correctly seated, then tighten the retaining screws securely (see illustrations).



**14.5d** Protrusion on air screen must face the carburettor intakes - ZX1100 D models



**14.5e** Tighten all housing screws securely - ZX1100 C models



**14.5f** Air filter - ZX1100 D models


- |                                      |                            |   |
|--------------------------------------|----------------------------|---|
| 1 Air intake ducts                   | 7 Air screen               | 13 Vacuum valve - California only         |
| 2 Connecting hoses to filter housing | 8 Housing                  | 14 Air suction vacuum switch valve        |
| 3 Housing cover                      | 9 Crankcase breather hose  | 15 Alternative connections for California |
| 4 Seal                               | 10 Oil reservoir           |   |
| 5 Element support frames             | 11 Carburettor air intakes |   |
| 6 Air filter element                 | 12 Air vent filter         |   |




**6** Remember it is essential that the filter element and housing sections or covers are correctly positioned and seat well to prevent unfiltered air from entering and damaging the engine. The carburettor is jetted to compensate for the presence of the air filter element, if the element is damaged, severely blocked or bypassed in any way or omitted, serious engine damage could result. Owners of US machines should also note that the air filter is subject to the anti-tampering legislation currently in force (see Chapter 4). For this reason the engine should never be run with the air filter element removed or disconnected.

**7** Note that this interval is the maximum for filter cleaning. If the machine is used in wet weather or very dirty or dusty conditions, the filter must be removed for cleaning more frequently.

**8** On ZX1100 C/D models it will also be necessary to clean the small vent filter, located underneath the left-hand inner fairing section. Remove the inner fairing section (see Chapter 6) and disconnect the vent filter from its hose on the right-hand side of the main air duct (see illustration). Before removing the filter, mark it in some way to ensure that it can be returned to its original position on refitting. Clean the filter by directing a jet of compressed air from the clean to the dirty side of the filter. Note that if the filter is damaged in any way it must be renewed. Refit the filter to the hose, using the mark made on



**14.8a** On ZX1100 C and D models do not forget to clean the vent filter . . .



**14.8b** . . . and drain the filter housing reservoir . . .

removal to align it correctly, and secure with the hose clips. Also check the transparent oil reservoir, situated on the left-hand side of the engine next to the alternator, for any sign of oil. If oil is present in the reservoir it must be drained off by removing the plug from the bottom of the drain hose and draining the oil into a suitable container (see illustrations). When all oil has drained from the reservoir, refit the plug to the drain hose.

## 15 Spark plugs renewal



**1** The spark plugs should be renewed at this interval regardless of their apparent condition as they will have passed peak efficiency. Check that the new plugs are of the correct type and heat range and are gapped correctly before fitting them.

## 16 Valve clearances check and adjustment



**1** The valve clearances must be checked and adjusted with the engine cold, preferably after the machine has been left overnight. Remove the fuel tank, pulser coil cover and the cylinder head cover using the information given in the appropriate Chapters.


**2** Using a spanner on the large hexagon nut on the left-hand end of the crankshaft, turn the crankshaft anti-clockwise until the 1.4 T mark on the ignition rotor aligns with the index mark on the crankcase and number 4 cylinder is at TDC on its compression stroke (ie inlet valve has just closed). The index mark on the crankcase is in the form of a straight line which is situated just above the right-hand pulser coil. With the engine in this position check the inlet valve clearances of numbers 2 and 4 cylinders and the exhaust valve clearances of cylinders 3 and 4. Using feeler gauges, measure the clearance between the valve and adjusting screw tip or follower (as applicable). Turn the crankshaft through one

complete turn (360°) so that number 1 cylinder is at TDC on its compression stroke, and check the inlet valve clearances on numbers 1 and 3 cylinders and the exhaust valve clearances on cylinders 1 and 2.


**3** All clearances must be within the specified limits given in the Specifications. If any are less than specified, action must be taken immediately to prevent damage to the valve and valve seat. If any are larger than specified the error must still be corrected but the problem is not quite as serious. If necessary adjust the clearances using the relevant procedure given below.

**4** On ZX900 and ZX1000 A models the valve clearances are adjusted via the screw and locknuts which are fitted to the cam followers. Slacken the locknut and turn the adjusting screw in or out until a feeler gauge of the appropriate size is a light sliding fit between the adjusting screw tip and valve. Hold the screw and tighten the locknut to the specified torque setting. Recheck the clearance after the locknut has been tightened and readjust if necessary. Repeat the above procedure for the second screw and locknut on the cam follower noting that it is essential that the clearance on both screws is identical.

**5** The method of adjustment is slightly more complicated on ZX1000 B and ZX1100 C/D models due to the fact that the clearances are altered by using shims of varying thicknesses. Measure the clearance between the valve and cam follower and make a note of this exact distance. Slide the cam follower to one side of the valve and carefully remove the shim from the top of the valve, using a magnet or pair of tweezers. The thickness of the shim should be printed on one side of it, if however the numbers are illegible the size of the shim can be determined by direct measurement using a micrometer or vernier caliper (see illustration). Refer to the relevant accompanying table (inlet or exhaust), follow the vertical column down until the measured clearance is found (given in millimetres), then follow the top column across until the existing shim thickness is found (see illustrations). Where the two columns intersect the size of the required shim is given.



**14.8c** . . . by removing the plug from the bottom of its drain hose



**16.5a** Shim thickness can be determined using a micrometer or vernier if numbers are illegible



		PRESENT SHIM																				
PART NUMBER (92025-)		1870	1871	1872	1873	1874	1875	1876	1877	1878	1879	1880	1881	1882	1883	1884	1885	1886	1887	1888	1889	1890
THICKNESS (mm)		2.00	2.05	2.10	2.15	2.20	2.25	2.30	2.35	2.40	2.45	2.50	2.55	2.60	2.65	2.70	2.75	2.80	2.85	2.90	2.95	3.00
0.00 - 0.03					2.00	2.05	2.10	2.15	2.20	2.25	2.30	2.35	2.40	2.45	2.50	2.55	2.60	2.65	2.70	2.75	2.80	2.85
0.04 - 0.08				2.00	2.05	2.10	2.15	2.20	2.25	2.30	2.35	2.40	2.45	2.50	2.55	2.60	2.65	2.70	2.75	2.80	2.85	2.90
0.09 - 0.12		2.00	2.05	2.10	2.15	2.20	2.25	2.30	2.35	2.40	2.45	2.50	2.55	2.60	2.65	2.70	2.75	2.80	2.85	2.90	2.95	
0.13 - 0.18	SPECIFIED CLEARANCE / NO CHANGE REQUIRED																					
0.19 - 0.23		2.05	2.10	2.15	2.20	2.25	2.30	2.35	2.40	2.45	2.50	2.55	2.60	2.65	2.70	2.75	2.80	2.85	2.90	2.95	3.00	
0.24 - 0.28		2.10	2.15	2.20	2.25	2.30	2.35	2.40	2.45	2.50	2.55	2.60	2.65	2.70	2.75	2.80	2.85	2.90	2.95	3.00		
0.29 - 0.33		2.15	2.20	2.25	2.30	2.35	2.40	2.45	2.50	2.55	2.60	2.65	2.70	2.75	2.80	2.85	2.90	2.95	3.00			
0.34 - 0.38		2.20	2.25	2.30	2.35	2.40	2.45	2.50	2.55	2.60	2.65	2.70	2.75	2.80	2.85	2.90	2.95	3.00				
0.39 - 0.43		2.25	2.30	2.35	2.40	2.45	2.50	2.55	2.60	2.65	2.70	2.75	2.80	2.85	2.90	2.95	3.00					
0.44 - 0.48		2.30	2.35	2.40	2.45	2.50	2.55	2.60	2.65	2.70	2.75	2.80	2.85	2.90	2.95	3.00						
0.49 - 0.53		2.35	2.40	2.45	2.50	2.55	2.60	2.65	2.70	2.75	2.80	2.85	2.90	2.95	3.00							
0.54 - 0.58		2.40	2.45	2.50	2.55	2.60	2.65	2.70	2.75	2.80	2.85	2.90	2.95	3.00								
0.59 - 0.63		2.45	2.50	2.55	2.60	2.65	2.70	2.75	2.80	2.85	2.90	2.95	3.00									
0.64 - 0.68		2.50	2.55	2.60	2.65	2.70	2.75	2.80	2.85	2.90	2.95	3.00										
0.69 - 0.73		2.55	2.60	2.65	2.70	2.75	2.80	2.85	2.90	2.95	3.00											
0.74 - 0.78		2.60	2.65	2.70	2.75	2.80	2.85	2.90	2.95	3.00												
0.79 - 0.83		2.65	2.70	2.75	2.80	2.85	2.90	2.95	3.00													
0.84 - 0.88		2.70	2.75	2.80	2.85	2.90	2.95	3.00														
0.89 - 0.93		2.75	2.80	2.85	2.90	2.95	3.00															
0.94 - 0.98		2.80	2.85	2.90	2.95	3.00																
0.99 - 1.03		2.85	2.90	2.95	3.00																	
1.04 - 1.08		2.90	2.95	3.00																		
1.09 - 1.13		2.95	3.00																			
1.14 - 1.18		3.00																				

VALVE CLEARANCE (mm)

INSTALL THE SHIM OF THIS THICKNESS (mm)

16.5b Inlet valve shim selection table

		PRESENT SHIM																					
PART NUMBER (92025-)		1870	1871	1872	1873	1874	1875	1876	1877	1878	1879	1880	1881	1882	1883	1884	1885	1886	1887	1888	1889	1890	
THICKNESS (mm)		2.00	2.05	2.10	2.15	2.20	2.25	2.30	2.35	2.40	2.45	2.50	2.55	2.60	2.65	2.70	2.75	2.80	2.85	2.90	2.95	3.00	
0.00 - 0.03						2.00	2.05	2.10	2.15	2.20	2.25	2.30	2.35	2.40	2.45	2.50	2.55	2.60	2.65	2.70	2.75	2.80	
0.04 - 0.08						2.00	2.05	2.10	2.15	2.20	2.25	2.30	2.35	2.40	2.45	2.50	2.55	2.60	2.65	2.70	2.75	2.80	2.85
0.09 - 0.13					2.00	2.05	2.10	2.15	2.20	2.25	2.30	2.35	2.40	2.45	2.50	2.55	2.60	2.65	2.70	2.75	2.80	2.85	2.90
0.14 - 0.17				2.00	2.05	2.10	2.15	2.20	2.25	2.30	2.35	2.40	2.45	2.50	2.55	2.60	2.65	2.70	2.75	2.80	2.85	2.90	2.95
0.18 - 0.23	SPECIFIED CLEARANCE / NO CHANGE REQUIRED																						
0.24 - 0.28		2.05	2.10	2.15	2.20	2.25	2.30	2.35	2.40	2.45	2.50	2.55	2.60	2.65	2.70	2.75	2.80	2.85	2.90	2.95	3.00		
0.29 - 0.33		2.10	2.15	2.20	2.25	2.30	2.35	2.40	2.45	2.50	2.55	2.60	2.65	2.70	2.75	2.80	2.85	2.90	2.95	3.00			
0.34 - 0.38		2.15	2.20	2.25	2.30	2.35	2.40	2.45	2.50	2.55	2.60	2.65	2.70	2.75	2.80	2.85	2.90	2.95	3.00				
0.39 - 0.43		2.20	2.25	2.30	2.35	2.40	2.45	2.50	2.55	2.60	2.65	2.70	2.75	2.80	2.85	2.90	2.95	3.00					
0.44 - 0.48		2.25	2.30	2.35	2.40	2.45	2.50	2.55	2.60	2.65	2.70	2.75	2.80	2.85	2.90	2.95	3.00						
0.49 - 0.53		2.30	2.35	2.40	2.45	2.50	2.55	2.60	2.65	2.70	2.75	2.80	2.85	2.90	2.95	3.00							
0.54 - 0.58		2.35	2.40	2.45	2.50	2.55	2.60	2.65	2.70	2.75	2.80	2.85	2.90	2.95	3.00								
0.59 - 0.63		2.40	2.45	2.50	2.55	2.60	2.65	2.70	2.75	2.80	2.85	2.90	2.95	3.00									
0.64 - 0.68		2.45	2.50	2.55	2.60	2.65	2.70	2.75	2.80	2.85	2.90	2.95	3.00										
0.69 - 0.73		2.50	2.55	2.60	2.65	2.70	2.75	2.80	2.85	2.90	2.95	3.00											
0.74 - 0.78		2.55	2.60	2.65	2.70	2.75	2.80	2.85	2.90	2.95	3.00												
0.79 - 0.83		2.60	2.65	2.70	2.75	2.80	2.85	2.90	2.95	3.00													
0.84 - 0.88		2.65	2.70	2.75	2.80	2.85	2.90	2.95	3.00														
0.89 - 0.93		2.70	2.75	2.80	2.85	2.90	2.95	3.00															
0.94 - 0.98		2.75	2.80	2.85	2.90	2.95	3.00																
0.99 - 1.03		2.80	2.85	2.90	2.95	3.00																	
1.04 - 1.08		2.85	2.90	2.95	3.00																		
1.09 - 1.13		2.90	2.95	3.00																			
1.14 - 1.18		2.95	3.00																				
1.19 - 1.23		3.00																					

VALVE CLEARANCE (mm)

INSTALL THE SHIM OF THIS THICKNESS (mm)



6 The shims can be purchased from an authorized Kawasaki dealer, but note that it may be possible to swap shims between the valves to reduce the cost. On no account use more than one shim on any valve, or grind the surface of a larger shim to make it smaller. Attempting to do either will almost certainly lead to extensive engine damage. Once the correct shim has been obtained, install it on the top of the valve (size marking facing downwards), ensuring that it is correctly seated in the valve spring retaining collar, then slide the cam follower back into position.

7 On all models recheck the valve clearances before refitting the cylinder head cover as described in Chapter 2.

8 Fortunately the valve clearances, once properly set, will not go out of adjustment for thousands of miles and the adjusting procedure will not be required very often. However they should still be checked at this interval to preserve engine performance and prevent the risk of engine damage. Always record all the information (original clearance and shim thickness, new clearance and shim thickness) so that an accurate picture of the valve gear and its rate of wear can be built up. This information will also greatly assist any future adjustments which are needed.

## 17 Fuel filter clean and renewal

**Note:** Petrol (gasoline) is extremely flammable, especially when in the form of vapour. Take all precautions to prevent the risk of fire and read the Safety first! section of this manual before starting work.

1 Prior to cleaning the fuel filters drain a small amount of fuel from the carburettor float chambers and check for contamination. Set the fuel tap to the PRI position and, dealing with one carburettor at a time, attach a short length of hose to the stub on the bottom of the float chamber and place the end in a clear glass container. Unscrew the drain screw on the float chamber by a few turns and allow a small amount of fuel to drain into the container. Tighten the drain screw. Note that if difficulty is experienced in gaining access to the drain screws on ZX1000 B and ZX1100 C models, a service tool is available under Part no. 57001-1269. If the drained fuel shows signs of water contamination or dirt, the fuel system components must be dismantled and thoroughly cleaned as described in Chapter 4.

2 On ZX900 and ZX1000 models remove the fuel tap, as described in Chapter 4, and remove the gauze filter(s) from the tap assembly. On ZX1100 C/D models the fuel tap filter is situated on the underside of the tank and is separate from the tap assembly. The filter is a screw fit into the tank and is joined to the tap by a short length of hose (see illustration).

3 These filters can be cleaned by washing

them in clean petrol (gasoline). If the filter is cracked or badly clogged it should be renewed. Check that the sealing O-ring is in good condition and then refit the filter or fuel tap assembly to the tank. Do not overtighten the filter or tap components as they are easily damaged.

4 The ZX1000 B and ZX1100 C/D models are fitted with a second fuel filter which filters the fuel before entering the fuel pump. It is not possible to clean the filter; it should be renewed at this interval as described in Chapter 4.

## 18 Fork oil change

1 The fork oil should be changed at regular intervals to prevent the inevitable reduction in fork performance which results as the oil deteriorates in service.

### ZX900 A1 to A6 and ZX1000 A models

2 Place the machine on its centre stand and release the fork air pressure by depressing the air valve(s). On ZX900 A2 to A6 models, unscrew the large top bolts from the top of each fork leg.

3 With the forks fully extended unscrew the top plug from one of the fork legs, noting that the plug may be expelled forcibly as the last threads are released. Lift out the fork spring. Remove the drain plug from the lower leg and allow the oil to drain into a suitable container; pump the fork legs up and down to assist draining. It is advisable to place a large piece of card against the wheel during the draining operation to prevent oil running onto the tyre. Once all the oil has drained clean the threads of the drain plug and its threaded hole. Apply a small amount of liquid gasket to the threads of the drain plug, to ensure an oil-tight seal, and tighten it securely.

4 Pour in the specified amount of oil and then gently pump the forks to expel any air which may be trapped. Remove the lower fairing section (see Chapter 6) and raise the front wheel clear of the ground by placing blocks or

a suitable stand beneath the crankcase so that the forks are fully extended. Using a dipstick (a length of welding rod or a steel rule is ideal) check the level of the oil below the top of the stanchion (see illustration). If necessary, add or subtract oil until the level is correct, then refit the fork spring and top plug and tighten the top plug to the specified torque setting. On ZX900 A2 to A6 models, refit the top bolt and tighten it to the specified torque setting.

5 Repeat the above procedure on the other fork leg, then set the air pressure as described in the Monthly interval. Remove the stand from beneath the crankcase and refit the lower fairing section.


### ZX900 A7-on and ZX1000 B models

6 On ZX1000 B models first remove the two screws which retain the top yoke cover and lift it clear of the machine. On both models, unscrew the handlebar casting mounting bolts and remove the bars from the top yoke. Support the handlebars to avoid placing any strain on the hydraulic hoses and to prevent the possible spillage of fluid from the master cylinder reservoirs. Remove the lower fairing section (see Chapter 6) and raise the front wheel clear of the ground by placing blocks or a suitable stand beneath the crankcase. With the forks fully extended, remove the fork top plugs, noting that they may be expelled forcibly as the last threads are released. Withdraw the fork spring from each leg. Place a large piece of card against the wheel to prevent oil running onto the tyre and remove the drain plugs from the lower legs, catching the oil in a suitable container. Pump the forks up and down to assist the draining of the oil. When all the oil has drained clean the drain plug and its threaded hole. Apply a liquid gasket to the threads of the drain plug, to ensure an oil tight seal, and tighten it securely.

7 Add the specified amount of oil to each fork leg (where given) and pump the forks gently to expel air which may be trapped. Measure the level of the fork oil from the top of the stanchion, using a steel ruler or a dipstick fabricated from a length of welding rod; note that the fork legs must be fully compressed



17.2 On ZX1100 C/D models fuel filter is separate from the fuel tap and is a screw fit in the tank



18.4 Front fork oil level check



when the measurement is taken. The easiest way to achieve this is to remove the stand from under the crankcase and allow the weight of the machine to compress them. If necessary, add or subtract oil until the level is correct. Reposition the stand beneath the crankcase and refit the fork spring and top plug to each leg; tighten the top plugs to the specified torque setting. Remount the handlebars onto the top yoke, tightening their mounting bolts to the specified torque setting, and on ZX1000 B models refit the top yoke cover.

### ZX1100 C/D models

**8** Due to the lack of a drain plug on the lower fork legs, it is necessary to remove the fork legs from the machine, as described in Chapter 6, and invert them to change the front fork oil. After refilling with the specified quantity of oil, check the oil level as described above; note that the forks must be fully compressed when the level check is made.

## 19 Cooling system check



**1** With reference to Chapter 3, check the cooling system for leaks or any damaged components. Pay particular attention to the hoses and check that all hose clips are correctly positioned and securely fastened.


## 20 Coolant filter cleaning



**1** On UK models, the carburettor warmer (coolant) hose filter (if fitted) should also be removed and cleaned at this service interval. The filter is located on the front right-hand side of the carburettors (see illustration). On ZX1000 B and ZX1100 C/D models it will be necessary to remove the right-hand lower fairing section to gain access to it (see Chapter 6).

**2** Mark the filter as an aid to reassembly and disconnect it from the coolant hoses. Swiftly plug the ends of the hoses with a suitably-sized clean screw or bolt to prevent the coolant from escaping and mop up any spilt coolant immediately. The filter can be cleaned by directing a jet of compressed air through it from the carburettor side of the filter to dislodge and remove any particles of foreign matter. If the filter is severely blocked or damaged in any way it must be renewed.

**3** Refit the filter to the coolant hoses, using the mark made on dismantling to return it to its original position, and secure it with the hose clips. Refit the lower fairing section (if removed) and top up the cooling system if necessary.



**20.1 Coolant filter (UK models) is located on the right-hand side of the carburettors - ZX900 shown**

## 21 Swinging arm and suspension linkage bearings lubrication




**1** To ensure the rear suspension functions correctly and that the bearings in the swinging arm and suspension linkage do not fail prematurely it is essential to lubricate all the swinging arm and rear suspension pivots regularly. On ZX1000 B and ZX1100 C/D models this task is simplified by the fitting of grease nipples at all the pivot points (see illustration). A grease gun can be used to force molybdenum disulphide grease into the bearings until grease is expelled from both ends of the bearing. On ZX1000 A models, a grease nipple is fitted to the relay arm pivot.

**2** All the pivot points on ZX900 models, and the remaining pivot points on ZX1000 A models are not equipped with grease nipples. Therefore the suspension linkage and swinging arm must be removed from the machine to lubricate the bearings. Refer to Chapter 6 for information on all operations involving the swinging arm and rear suspension linkage.

## 22 Fastener security check



**1** Work around the machine checking all nuts and bolts for tightness. Pay particular attention to the engine mountings, exhaust mountings, rear suspension and swinging arm bolts, top and bottom yoke pinch bolts, rear sprocket nuts, footrest bolts, front wheel spindle nut and all the brake caliper bolts. Where possible, use a torque wrench to check that all fasteners are tightened to their specified torque settings. Note that the cylinder head bolts must also be checked tightened at this interval - refer to Chapter 2.



**21.1 Where provided, lubricate swinging arm and suspension linkage via the grease nipples**

## 23 Wheels check



**1** Check the complete wheel for cracks and chipping, particularly at the spoke roots and the edge of the rim. As a general rule a damaged wheel must be renewed as cracks will cause stress points which may lead to sudden failure under heavy load. Small nicks may be radiused carefully with a fine file and emery paper (No 600 No 1000) to relieve the stress. If there is any doubt as to the condition of a wheel, advice should be sought from a reputable dealer or specialist repairer.

**2** Each wheel is covered with a coating of lacquer, to prevent corrosion. If damage occurs to the wheel and the lacquer finish is penetrated, the bared aluminium alloy will soon start to corrode. A whitish grey oxide will form over the damaged area, which in itself is a protective coating. This deposit however, should be removed carefully as soon as possible and a new protective coating of lacquer applied.

**3** Check the lateral runout at the rim by spinning the wheel and placing a fixed pointer close to the rim edge. If the maximum runout is greater than 0.5 mm (0.020 in) axially or 0.8 mm (0.032 in) radially, Kawasaki recommend that the wheel be renewed. This is, however, a counsel of perfection; a runout somewhat greater than this can probably be accommodated without noticeable effect on steering. No means is available for straightening a warped wheel without resorting to the expense of having the wheel skimmed on all faces. If warpage was caused by impact during an accident, the safest measure is to renew the wheel complete. Worn wheel bearings may cause rim runout. These should be renewed.

**4** Note that impact damage or serious corrosion on models fitted with tubeless tyres has wider implications in that it could lead to a loss of pressure from the tubeless tyres. If in any doubt as to the wheel's condition, seek professional advice.



## Every 12 000 miles (20 000 km)

### 24 Air filter element renewal



1 The air filter element should be renewed at this interval or every five cleanings, whichever comes first. Details of element removal can be found under the 6000 mile (10 000 km) service interval.

### 25 Brake and clutch fluid renewal



**Note:** brake fluid is an excellent paint stripper and will attack painted and plastic components. Wash away any spilt fluid immediately with copious quantities of water.

1 The hydraulic fluid must be renewed at this interval or every two years to preserve maximum brake/clutch efficiency by ensuring

the fluid has not been contaminated and deteriorated to an unsafe level.

2 Before starting work, obtain a new, sealed can of the recommended hydraulic fluid and carefully read the Section on bleeding in Chapter 7. Prepare the clear plastic tube and glass jar in the same way as for bleeding, then open the bleed nipple and apply the lever or pedal (as applicable) repeatedly. This will pump out the old fluid. **Note:** keep the master cylinder reservoir topped up at all times, otherwise air will enter the system and greatly lengthen the operation.



**Old brake fluid is invariably much darker in colour than new fluid, making it easier to see when old fluid has been expelled from the system.**

3 When the new fluid appears in the clear plastic tubing completely uncontaminated by traces of old brake fluid, close the bleed

nipple and remove the plastic tubing. Refit the bleed nipple cap. Top up the master cylinder reservoir as described in 'Daily (pre-ride) checks' at the beginning of this Manual, and wash off any spilt fluid immediately. Finally check that the clutch/braking system is operating correctly before taking the machine on the road.

### 26 Steering head bearings lubrication



1 The steering head bearings must be lubricated at this interval or every two years, whichever comes first.

2 Refer to the relevant Sections of Chapter 6 and dismantle the steering head. Clean all the components and examine them for wear renewing any worn items. Reassemble the steering head and lubricate the bearings with fresh grease.

## Every 24 000 miles (40 000 km)

### 27 Coolant renewal



1 The coolant must be renewed at this interval or every two years, whichever comes first.

2 To minimise the build-up of deposits in the cooling system and to ensure the maximum

protection against freezing, the cooling system should be checked for leakage and damage, drained completely, flushed out and filled with fresh coolant as described in Chapter 3.

## Every two years

### 28 Brake and clutch components overhaul



1 The master cylinders, brake calipers and clutch slave cylinder should be dismantled and checked. This is because their seals will deteriorate whether the machine is ridden regularly or hardly at all. The seals should be renewed regardless of their apparent

condition and the master cylinder, slave cylinder and caliper bores checked carefully for wear or damage. Refer to Chapter 7 for further information.

### 29 Anti-dive unit seals (ZX900 A1 to A6 and ZX1000 A models) renewal



1 The anti-dive units should be dismantled

and the seals, plungers and O-rings renewed, regardless of their apparent condition. Information on overhaul can be found in Chapter 6. Note that a test is also given for testing the units, should there be any doubt about their correct operation. At the same time as the seals are renewed, check the condition of the metal pipe; if corroded this should be renewed.

## Every four years

### 30 Hydraulic hoses and fuel lines renewal



1 The hydraulic hoses and fuel lines should be renewed regardless of their external appearance. After this period of time the synthetic material of the hoses is likely to have deteriorated significantly and for reasons of

safety they should be renewed. Refer to Chapter 3 for further information on the fuel lines and Chapter 7 for information on the brake hoses.



# Specifications

## Engine

Type .....	DOHC, 16 valve, 4-cylinder, liquid-cooled
Capacity:	
ZX900 models .....	908 cc (55 cu in)
ZX1000 models .....	997 cc (60 cu in)
ZX1100 C/D models .....	1052 cc (64 cu in)
Bore:	
ZX900 models .....	72.5 mm (2.85 in)
ZX1000 models .....	74.0 mm (2.91 in)
ZX1100 C/D models .....	76.0 mm (2.99 in)
Stroke:	
ZX900 models .....	55.0 mm (2.17 in)
ZX1000 and ZX1100 C/D models .....	58.0 mm (2.28 in)
Compression ratio:	
ZX1000 A models .....	10.2 : 1
All other models .....	11.0 : 1

<http://manuals.magnamaniac.com>



# Engine (continued)

Engine output - UK models:	Maximum power bhp @ rpm	Maximum torque kgf m (lbf ft) @ rpm
ZX900 models	115 @ 9500	8.7 (62.9) @ 8500
ZX1000 A models	125 @ 9500	10.1 (73.1) @ 8500
ZX1000 B models	125 @ 10000	Not available
ZX1100 C/D models	125 @ 9500	Not available
Engine output - US models:		
ZX900 models	110 @ 9500	8.7 (62.9) @ 8500
ZX1000 A models	125 @ 9500	10.1 (73.1) @ 8500
ZX1000 B models	137 @ 10000	10.5 (76.0) @ 9000
ZX1100 C/D models	147 @ 10500	9.0 (81.0) @ 8500
Cylinder identification	Left to right, 1-2-3-4	
Firing order	1-2-4-3	
Compression pressure at cranking speed with engine fully warmed up:		
ZX900 models	9.4 - 14.5 kg/cm <sup>2</sup> (134 - 206 psi)	
ZX1000 A models	8.4 - 13.0 kg/cm <sup>2</sup> (119 - 185 psi)	
ZX1000 B models	8.8 - 13.5 kg/cm <sup>2</sup> (125 - 192 psi)	
ZX1100 C/D models	9.0 - 13.8 kg/cm <sup>2</sup> (128 - 196 psi)	

**Note** - compression pressure must not vary excessively between any two cylinders

# Camshafts, followers and cam chain

Cam lobe height:	
ZX900 and ZX1000 A models	35.824 - 35.940 mm (1.410 - 1.414 in)
Service limit	35.710 mm (1.406 in)
ZX1000 B models	21.687 - 21.787 mm (0.854 - 0.858 in)
Service limit	21.590 mm (0.850 in)
ZX1100 C/D models:	
Inlet	36.872 - 36.972 mm (1.452 - 1.456 in)
Service limit	36.770 mm (1.448 in)
Exhaust	36.687 - 36.787 mm (1.444 - 1.448 in)
Service limit	36.590 mm (1.441 in)
Camshaft journal OD	24.900 - 24.922 mm (0.980 - 0.981 in)
Service limit	24.870 mm (0.979 in)
Camshaft bearing ID	25.000 - 25.021 mm (0.984 - 0.985 in)
Service limit	25.080 mm (0.987 in)
Camshaft journal/cylinder head bearing clearance	0.078 - 0.121 mm (0.003 - 0.005 in)
Service limit	0.210 mm (0.008 in)
Camshaft standard runout	Less than 0.02 mm (0.001 in)
Service limit	0.1 mm (0.004 in)
Cam follower ID:	
ZX900 and ZX1000 A models	12.500 - 12.518 mm (0.492 - 0.493 in)
Service limit	12.550 mm (0.494 in)
ZX1000 B and ZX1100 C/D models	12.000 - 12.018 mm (0.472 - 0.473 in)
Service limit	12.050 mm (0.474 in)
Cam follower shaft ID:	
ZX900 and ZX1000 A models	12.466 - 12.484 mm (0.490 - 0.491 in)
Service limit	12.440 mm (0.489 in)
ZX1000 B models	11.976 - 11.994 mm (0.471 - 0.472 in)
Service limit	11.950 mm (0.470 in)
ZX1100 C/D models	11.966 - 11.984 mm (0.470 - 0.471 in)
Service limit	11.940 mm (0.469 in)
Camchain standard length of 20 links	158.8 - 159.2 mm (6.252 - 6.268 in)
Service limit	161.5 mm (6.358 in)

# Cylinder head

Maximum warp	0.050 mm (0.002 in)
--------------	---------------------

# Cylinder block

Cylinder bore ID:	
ZX900 models	72.494 - 72.506 mm (2.854 - 2.855 in)
Service limit	72.600 mm (2.858 in)
ZX1000 models	73.994 - 74.006 mm (2.913 - 2.914 in)
Service limit	74.110 mm (2.918 in)
ZX1100 C/D models	75.994 - 76.006 mm (2.991 - 2.992 in)
Service limit	76.100 mm (2.996 in)
Piston/cylinder clearance:	
ZX900 and ZX1000 models	0.044 - 0.074 mm (0.002 - 0.003 in)
ZX1100 C/D models	0.056 - 0.088 mm (0.002 - 0.004 in)



## Valves guides and springs

### Inlet valve clearances:

ZX900 and ZX1000 A models	0.13 - 0.18 mm (0.005 - 0.007 in)
ZX1000 B and ZX1100 C/D models	0.13 - 0.19 mm (0.005 - 0.007 in)

### Exhaust valve clearances:

ZX900 and ZX1000 A models	0.18 - 0.23 mm (0.007 - 0.009 in)
ZX1000 B and ZX1100 C/D models	0.18 - 0.24 mm (0.007 - 0.009 in)

### Valve head thickness:

Inlet	0.50 mm (0.20 in)
Service limit	0.25 mm (0.10 in)
Exhaust:	
ZX900 and ZX1000 A models	1.00 mm (0.40 in)
Service limit	0.70 mm (0.28 in)
ZX1000 B and ZX1100 C/D models	0.80 mm (0.31 in)
Service limit	0.50 mm (0.20 in)
Valve stem maximum runout	0.05 mm (0.002 in)

### Inlet valve stem OD:

ZX900 and ZX1000 A models	5.475 - 5.490 mm (0.215 - 0.216 in)
Service limit	5.460 mm (0.214 in)
ZX1000 B and ZX1100 C/D models	4.975 - 4.990 mm (0.195 - 0.196 in)
Service limit	4.960 mm (0.194 in)

### Exhaust valve stem OD:

ZX900 and ZX1000 A models	5.455 - 5.470 mm (0.214 - 0.215 in)
Service limit	5.440 mm (0.213 in)
ZX1000 B and ZX1100 C/D models	4.955 - 4.970 mm (0.194 - 0.195 in)
Service limit	4.940 mm (0.193 in)

### Valve seat width

	0.5 - 1.0 mm (0.02 - 0.04 in)
--	-------------------------------

### Valve seat OD:

ZX900 and ZX1000 A models - inlet	28.3 - 28.5 mm (1.114 - 1.122 in)
ZX900 and ZX1000 A models - exhaust	24.0 - 24.2 mm (0.945 - 0.953 in)
ZX1000 B model - inlet	29.3 - 29.5 mm (1.154 - 1.161 in)
ZX1000 B model - exhaust	25.3 - 25.5 mm (0.996 - 1.004 in)
ZX1100 C/D model - inlet	30.8 - 31.0 mm (1.213 - 1.220 in)
ZX1100 C/D model - exhaust	26.3 - 26.5 mm (1.035 - 1.043 in)

### Valve guide ID:

ZX900 and ZX1000 A models	5.500 - 5.512 mm (0.216 - 0.217 in)
Service limit	5.580 mm (0.219 in)
ZX1000 B and ZX1100 C/D models	5.000 - 5.012 mm (0.197 - 0.198 in)
Service limit	5.080 mm (0.200 in)

### Inlet valve/guide clearance - valve installed, using dial gauge:

ZX900 and ZX1000 A models	0.02 - 0.08 mm (0.001 - 0.003 in)
Service limit	0.22 mm (0.008 in)
ZX1000 B and ZX1100 C/D models	0.02 - 0.07 mm (0.001 - 0.003 in)
Service limit	0.18 mm (0.007 in)

### Exhaust valve/guide clearance - valve installed, using dial gauge:

ZX900 and ZX1000 A models	0.07 - 0.14 mm (0.003 - 0.006 in)
Service limit	0.27 mm (0.011 in)
ZX1000 B and ZX1100 C/D models	0.06 - 0.11 mm (0.002 - 0.004 in)
Service limit	0.21 mm (0.008 in)

### Inner valve spring free length:

ZX900 and ZX1000 A models	37.2 mm (1.46 in)
Service limit	36.0 mm (1.42 in)
ZX1000 B and ZX1100 C/D models	35.5 mm (1.40 in)
Service limit	33.6 mm (1.32 in)

### Outer valve spring free length:

ZX900 and ZX1000 A models	40.4 mm (1.58 in)
Service limit	39.0 mm (1.54 in)
ZX1000 B and ZX1100 C/D models	40.5 mm (1.59 in)
Service limit	38.6 mm (1.52 in)

## Pistons

### Piston OD:

ZX900 models	72.435 - 72.450 mm (2.851 - 2.852 in)
Service limit	72.300 mm (2.846 in)
ZX1000 models	73.935 - 73.964 mm (2.911 - 2.912 in)
Service limit	73.790 mm (2.905 in)
ZX1100 C/D models	75.918 - 75.938 mm (2.988 - 2.989 in)
Service limit	75.770 mm (2.983 in)



## Pistons (continued)

### Top compression ring groove width:

ZX900 and ZX1000A models	1.02 - 1.04 mm (0.040 - 0.041 in)
Service limit	1.12 mm (0.044 in)
ZX1000 B models	0.82 - 0.84 mm (0.032 - 0.033 in)
Service limit	0.92 mm (0.036 in)
ZX1100 C/D models	0.84 - 0.86 mm (0.033 - 0.034 in)
Service limit	0.94 mm (0.037 in)

### Second compression ring groove width:

ZX900 and ZX1000 models	1.01 - 1.03 mm (0.039 - 0.040 in)
Service limit	1.12 mm (0.044 in)
ZX1100 C models	1.02 - 1.04 mm (0.040 - 0.041 in)
Service limit	1.12 mm (0.044 in)
ZX1100 D models	0.82 - 0.84 mm (0.032 - 0.033 in)
Service limit	0.92 mm (0.036 in)

### Oil scraper ring groove width

Service limit	2.51 - 2.53 mm (0.098 - 0.099 in)
---------------	-----------------------------------

### Top compression ring/groove clearance

Service limit	2.60 mm (0.102 in)
---------------	--------------------

### Second compression ring/groove clearance

All models except ZX1100 D	0.03 - 0.07 mm (0.001 - 0.003 in)
Service limit	0.17 mm (0.007 in)
ZX1100 D models	0.02 - 0.06 mm (0.001 - 0.002 in)
Service limit	0.16 mm (0.006 in)
ZX1100 D models	0.03 - 0.07 mm (0.001 - 0.003 in)
Service limit	0.17 mm (0.007 in)

## Piston rings

### Top compression ring thickness:

ZX900 and ZX1000 A models	0.97 - 0.99 mm (0.038 - 0.039 in)
Service limit	0.90 mm (0.035 in)
ZX1000 B and ZX1100 C/D models	0.77 - 0.79 mm (0.030 - 0.031 in)
Service limit	0.70 mm (0.027 in)

### Second compression ring thickness

All models except ZX1100 D	0.97 - 0.99 mm (0.038 - 0.039 in)
Service limit	0.90 mm (0.035 in)
ZX1100 D models	0.77 - 0.79 mm (0.030 - 0.031 in)
Service limit	0.70 mm (0.027 in)

### Top compression ring end gap - installed:

ZX900 and ZX1000 models	0.20 - 0.35 mm (0.007 - 0.013 in)
ZX1100 C/D models	0.20 - 0.32 mm (0.007 - 0.012 in)
Service limit - all models	0.70 mm (0.027 in)

### Second compression ring end gap - installed

Service limit	0.20 - 0.35 mm (0.007 - 0.013 in)
---------------	-----------------------------------

### Oil scraper ring end gap - installed:

ZX900 and ZX1000 models	0.70 mm (0.027 in)
Service limit	0.20 - 0.70 mm (0.007 - 0.027 in)
ZX1100 C/D models	1.00 mm (0.039 in)

## Connecting rod and bearings

### Connecting rod maximum distortion

Service limit	0.2/100 mm (0.008/3.94 in)
---------------	----------------------------

### Big-end bearing standard ID:

ZX900 and ZX1000 models	38.000 - 38.016 mm (1.4961 - 1.4967 in)
ZX1100 C/D models	39.000 - 39.016 mm (1.5354 - 1.5361 in)

### Size groups - ZX900 and ZX1000 models:

Connecting rod unmarked	38.000 - 38.008 mm (1.4961 - 1.4963 in)
Connecting rod marked 'O'	38.009 - 38.016 mm (1.4964 - 1.4967 in)

### Size groups - ZX1100 C/D models:

Connecting rod unmarked	39.000 - 39.008 mm (1.5354 - 1.5357 in)
Connecting rod marked 'O'	39.009 - 39.016 mm (1.5358 - 1.5361 in)

### Crankpin standard OD:

ZX900 and ZX1000 models	34.984 - 35.000 mm (1.3773 - 1.3779 in)
Service limit	34.970 mm (1.3767 in)
ZX1100 C/D models	35.984 - 36.000 mm (1.4167 - 1.4173 in)
Service limit	35.970 mm (1.4161 in)

### Size groups - ZX900 and ZX1000 models:

Crankshaft unmarked	34.984 - 34.992 mm (1.3773 - 1.3776 in)
Crankshaft marked 'O'	34.993 - 35.000 mm (1.3777 - 1.3780 in)

### Size groups - ZX1100 C/D models:

Crankshaft unmarked	35.984 - 35.992 mm (1.4167 - 1.4170 in)
Crankshaft marked 'O'	35.993 - 36.000 mm (1.4171 - 1.4173 in)







## Clutch

Type .....	Wet, multi-plate
Friction plates:	
Number:	
ZX900 models .....	8
ZX1000 and ZX1100 C/D models .....	9
Thickness:	
ZX900 and ZX1000 B models .....	2.9 - 3.1 mm (0.114 - 0.122 in)
Service limit .....	2.75 mm (0.108 in)
ZX1000 A models .....	2.9 - 3.1 mm (0.114 - 0.122 in)
Service limit .....	2.8 mm (0.110 in)
ZX1100 C/D models .....	2.7 - 3.0 mm (0.106 - 0.118 in)
Service limit .....	2.5 mm (0.098 in)
Plain plates:	
Number:	
ZX900 models .....	7
ZX1000 and ZX1100 C/D models .....	8
Friction and plain plate warpage .....	Less than 0.2 mm (0.008 in)
Service limit .....	0.3 mm (0.012 in)
Clutch springs:	
Number:	
ZX900 models .....	5
ZX1000 and ZX1100 C/D models .....	6
Free length:	
ZX900 models .....	33.0 - 34.2 mm (1.30 - 1.35 in)
Service limit .....	32.1 mm (1.26 in)
ZX1000 models .....	33.2 mm (1.31 in)
Service limit .....	32.1 mm (1.26 in)
ZX1100 C/D models .....	46.3 mm (1.82 in)
Service limit .....	42.7 mm (1.68 in)
Primary gear/clutch drum backlash .....	0.03 - 0.10 mm (0.0011 - 0.0039 in)
Service limit .....	0.14 mm (0.0055 in)

## Alternator/starter clutch

Drive chain - 20 link length .....	158.8 - 159.2 mm (6.25 - 6.27 in)
Service limit .....	161.5 mm (6.36 in)

## Final drive

Type .....	Chain and sprockets
Ratio:	
ZX900 models:	
UK models .....	2.882 : 1 (49/17 T)
US models .....	2.941 : 1 (50/17 T)
ZX1000 A models:	
UK models .....	2.666 : 1 (40/15 T)
US models .....	2.733 : 1 (41/15 T)
ZX1000 B and ZX1100 C/D models .....	2.647 : 1 (45/17 T)

## Torque settings

	kgf m	lbf ft
Cylinder head cover bolts .....	1.0	7.0
Top camchain guide bolts:		
ZX900 and ZX1000 A models .....	1.0	7.0
ZX1000 B and ZX1100 C/D models .....	Not available	
Cam follower shaft retaining bolts - ZX900 and ZX1000 A models only .....	1.0	7.0
Camshaft cap bolts .....	1.2	9.0
Camshaft sprocket retaining bolts .....	1.5	11.0
Cam follower locknuts .....	2.5	18.0
Cylinder head oil pipe union bolts - ZX900 and ZX1000 A models only .....	1.0	7.0
Main cylinder head oil pipe union bolts .....	2.5	18.0
Sump to crankcase metal oil pipe union bolts:		
ZX900 and ZX1100 C/D models .....	2.5	18.0
ZX1000 models .....	1.8	13.0



<b>Torque settings (continued)</b>	<b>kgf m</b>	<b>lbf ft</b>
<b>Cylinder head bolts:</b>		
ZX900 and ZX1000 A models:*		
New head bolt and washer:		
Flat-headed bolts	4.0	29.0
Taper-headed bolts	5.2	38.0
Old head bolt and washer:		
Flat-headed bolts	3.7	27.0
Taper-headed bolts	4.9	35.0
ZX1000 B and ZX1100 C/D models:		
Initial torque setting	2.0	14.5
Final torque setting:		
Flat-headed bolts	4.0	29.0
Taper-headed bolts	5.2	38.0
6 mm cylinder head/block retaining bolt	1.0	7.0
7 mm block/crankcase retaining bolts	1.5	11.0
Camchain tensioner mounting bolts	1.0	7.0
Camchain blade mounting bolt	2.0	14.5
<b>Clutch spring retaining bolts:</b>		
ZX900 and ZX1000 models	1.0	7.0
ZX1100 C/D model	1.1	8.0
Clutch centre nut	13.5	98.0
Ignition rotor retaining bolt	2.5	18.0
Alternator mounting bolts	2.5	18.0
Alternator/starter clutch drive sprocket bolt	2.5	18.0
Alternator/starter clutch shaft cush drive coupling nut	6.0	43.0
Alternator drive coupling/shaft retaining bolt	1.0	7.0
<b>Starter clutch bolts:</b>		
ZX900 and ZX1000 A models	3.5	25.0
ZX1000 B and ZX1100 C/D models	1.2	9.0
Engine sprocket nut	10.0	72.0
Gearchange mechanism cover bolts - ZX1100 C/D model	1.0	7.0
<b>Crankcase fastening bolts:</b>		
6 mm	1.5	11.0
7 mm - ZX1100 C/D and late ZX900 A7-on models only	1.8	13.0
8 mm	2.8	20.0
8 mm main bearing bolts - ZX900 and ZX1000 models:		
Initial setting	1.4	10.0
Final setting	2.8	20.0
9 mm main bearing bolts - ZX1100 C/D and late ZX900 A7-on models:		
Initial setting	1.0	7.0
Final setting	3.3	24.0
<b>Connecting rod bolts (see text):</b>		
ZX900 models	3.7	27.0
ZX1000 A models:		
With new nuts	3.0	22.0
With old nuts	2.7	19.5
ZX1000 B models:		
New connecting rod and new nuts	2.0	14.5
New connecting rod and old nuts	1.8	13.0
Old connecting rod and new nuts	2.6	18.8
Old connecting rod and old nuts	2.4	17.4
ZX1100 C/D models	1.5	11.0
Oil drain plugs in sump	3.0	22.0
Oil filter mounting bolt	2.0	14.5
<b>Engine mounting bolts:</b>		
ZX900 models	6.0	43.0
ZX1000 A models:		
Front mounting bolts	4.5	33.0
Rear mounting bolts	5.3	38.0
ZX1000 B, ZX1100 C/D models	4.5	33.0
<b>Frame cradle retaining bolts:</b>		
ZX1000 A models	5.3	38.0
ZX1000 B, ZX1100 C/D models	4.5	33.0
Rear mounting bolt collar Allen screws - ZX1100 D models	2.0	14.5

<http://manuals.magnamaniac.com>

\*On ZX900 and 1000 A models initial torque setting is approximately half of the final torque settings.



## 1 General description

The engine/gearbox unit is of water-cooled four cylinder in-line design, fitted transversely across the frame. The sixteen valves are operated by double overhead camshafts which are chain driven off the crankshaft. The engine/gearbox unit is constructed in aluminium alloy with the crankcase being divided horizontally.

The crankcase incorporates a wet sump, pressure fed lubrication system which incorporates a gear driven dual rotor oil pump, an oil filter and by-pass valve assembly, a relief valve and an oil pressure switch. Also contained in the crankcase is the balancer shaft and starter clutch. Power from the crankshaft is transmitted to the gearbox via the clutch, which is of the wet multi-plate type and is gear driven off the crankshaft. The starter motor and alternator assemblies are also linked to the crankshaft via a chain and tensioner mechanism on the right-hand end of the crankshaft. The water pump is mounted on the left-hand side of the crankcase and is driven off the oil pump shaft.

Final drive to the rear wheel is by chain and sprockets. The engine sprocket being externally mounted on the output shaft.

## 2 Operations with the engine/gearbox unit in the frame

The components and assemblies listed below can be removed without having to remove the engine unit from the frame. If, however a number of areas require attention at the same time, removal of the engine is recommended:

- (a) Clutch slave cylinder
- (b) Engine sprocket
- (c) Neutral switch
- (d) Gear selector mechanism external components
- (e) Water pump
- (f) Ignition system components
- (g) Starter motor
- (h) Alternator
- (i) Alternator/starter clutch drive components
- (j) Clutch assembly
- (k) Oil filter and bypass valve assembly
- (l) Sump, oil screens, oil pump and relief valve assembly
- (m) Cylinder head cover and camshafts
- (n) Camchain and tensioner
- (o) Cylinder head
- (p) Cylinder block and pistons

## 3 Operations with the engine/gearbox unit removed from the frame

It is necessary to remove the engine/gearbox unit from the frame and separate the crankcase halves to gain access to the following components:

- (a) Crankshaft assembly
- (b) Main and big-end bearings
- (c) Connecting rods
- (d) Gearbox shafts and pinions
- (e) Gear selector drum and forks
- (f) Balancer shaft
- (g) Starter clutch

Note that if only removal of the gearbox components is required, the engine/gearbox unit can be removed from the frame and inverted so that the lower crankcase half can be withdrawn. This will permit the examination of the gearbox components without disturbing the top end of the engine or the clutch. This also applies to the balancer shaft and starter clutch components.

## 4 Removing the engine/gearbox unit from the frame



**If the machine is dirty, wash it thoroughly before starting any major dismantling work. This will make work much easier and will rule out the possibility of caked-on lumps of dirt falling into some vital component.**

1 If possible work can be made easier by raising the machine to a suitable working height on a hydraulic ramp or a suitable platform.

2 Remove the fuel tank as described in Chapter 4, and the complete fairing as described in Chapter 6.

3 Place a suitably sized container beneath the engine/gearbox unit and drain the engine oil as described in Chapter 1. Remove the oil

filter assembly and discard the element, ensuring the baffle, spring and washer are retained. Disconnect the battery leads (negative lead first) and remove the battery from the machine. If the machine is to be left dismantled for some time, give the battery regular refresher charges as described in Chapter 8.

4 Drain the coolant and remove the radiator and cooling fan assembly, and the water pump as described in Chapter 3. Slacken and remove all the oil cooler hose union bolts which secure the hoses to the engine and the oil cooler mounting bolts, and remove the oil cooler and hose assembly from the machine (see illustrations). Make a note of the routes taken by the oil cooler hoses to use as a guide when refitting them to the machine.


5 Remove the carburettors from the machine as described in Chapter 4. Once the carburettors have been removed on ZX900 and ZX1000 A models slacken and remove the air filter housing mounting bolt(s) and manoeuvre it out of the frame. On ZX1100 C/D models remove the mounting bolts which retain the front section of the air filter housing (duct) noting the correct position of the shouldered spacer, situated behind the front mounting bolt. Disconnect the vent hose from the carburettors and lift the assembly clear of the machine. On US models disconnect and remove all the relevant clean air and emission control system components, referring to Chapter 4 for further information.

6 Remove the three bolts that secure the clutch slave cylinder to the engine sprocket casing and withdraw the cylinder from the casing. Push the piston as far back as possible by hand and then slowly bring the clutch operating lever back to the handlebars and hold it there with a stout elastic band. This will prevent the slave cylinder piston from being accidentally expelled. Tie the slave cylinder to the frame so that it does not hamper engine removal.

7 Marking its shaft so that it can be refitted in the same position, slacken and remove the gearchange linkage pinch bolt and pull the linkage off the gearchange shaft splines. Release the engine sprocket casing retaining bolts and remove the casing from the




4.4a Remove all union bolts which secure the oil cooler hoses to the engine unit.




4.4b ... release oil cooler mounting bolts and remove cooler and hoses as an assembly - ZX1100 C shown






4.8a ZX900 silencer mounting bolt ...



4.8b ... and clamp



4.10a Remove the lead from the starter motor terminal

machine, noting the two locating dowels fitted behind it. If these dowels are loose they should be removed and stored with the casing for safekeeping. The clutch pushrod should also be removed for safekeeping. Flatten the sprocket nut locking tab and slacken the sprocket nut whilst applying the rear brake hard to prevent it rotating. Pull the sprocket off the output shaft splines and disengage it from the chain, noting that it may be necessary to first slacken the drive chain to obtain the required amount of freeplay to enable this. Remove the sprocket and allow the chain to hang over the swinging arm.


8 On ZX900 models release the two bolts which secure the lower fairing mounting bracket to the bottom of the crankcase and remove the bracket from the machine. Mark the bracket in some way to use as a reference on refitting. Also remove all the mounting bolts from the lower front fairing mounting bracket. On ZX900 and ZX1000 A models, release the silencer mounting bolts and clamps and pull the left and right-hand silencers out of the exhaust pipes (see illustrations). Slacken the eight nuts which secure the exhaust pipes to the cylinder head and remove the exhaust pipe mounting clamps. Remove the two bolts that secure the exhaust pipe assembly to the frame and lower the exhaust pipe assembly and fairing bracket (ZX900 models) away from the machine.

9 On ZX1000 B and ZX1100 C/D models, release the eight nuts which secure the exhaust pipes to the cylinder head and remove

the exhaust mounting clamps. Slacken the clamp situated beneath the engine which secures the left and right-hand exhaust sections together. Remove the right-hand silencer mounting bolt and then on ZX1100 C/D models remove the right-hand silencer. Remove the left-hand silencer mounting bolt, lower the exhaust system to the ground and manoeuvre it clear of the machine. Note that on ZX1000 B models removal may prove easier if the left and right-hand sections of the exhaust are first separated.

10 On all models, disconnect the lead from the starter motor terminal and remove the earth strap from the top of the crankcase (see illustration). Also disconnect the electrical connections from the pulser coil(s), neutral switch, sidestand switch and the oil pressure and temperature switch (as applicable) and release all wiring from any cable ties or hooks which secure it to the frame. Pull the suppressor caps off the spark plugs and position them clear of the engine. On ZX900 models slacken the HT ignition coil retaining nuts and remove the coils from the machine having first made a note of the correct location of the low tension leads. On ZX1000 B and ZX1100 C/D models slacken the hose clips on each end of the coolant hose which runs over the cylinder head cover and remove it from the machine. On all ZX1000 and ZX1100 C/D models remove the air baffle plate from the front of the cylinder head cover (see illustration).

11 The engine/gearbox unit should now only be retained by its mounting bolts. Check




4.10b On ZX1000 B and ZX1100 C/D remove coolant hose which runs over cylinder head cover

carefully that all components which may hinder the removal of the unit have been removed and that all cables and leads are wedged or tied out of the way of the engine. Note at least two people will be required to remove the engine/gearbox from the frame safely.

12 Prior to removing the rear mounting bolts on ZX1100 D models, slacken the Allen screw on each supporting collar, inboard of the frame on the left-hand side. Access to the top Allen screw can be made from above (see illustration), whereas the lower Allen screw must be accessed from below and to the rear.


13 On ZX1000 and ZX1100 C/D models remove the two front engine mounting bolts and then remove the eight bolts that retain the frame cradle and lower the cradle away from the engine (see illustrations). On ZX900



4.12 Upper rear engine mounting bolt Allen screw location (arrow)




4.13a On ZX1000 and ZX1100 C/D remove the engine front and frame cradle mounting bolts ...



4.13b ... and lower the frame cradle away from the machine ...





4.13c . . . remove chrome caps to reveal engine rear mounting bolts

models remove the two upper engine mounting bolts which secure the cylinder head to the frame, noting that there may be a shim fitted between the frame and the cylinder head on the left-hand side. On all models, place some sort of support beneath the engine to take the weight of the engine then remove both the upper and lower rear mounting bolts. Take a firm hold of the engine and lift it off the support. Remove the support from below the engine and manoeuvre the engine out of the bottom of the frame.

## 5 Dismantling the engine/gearbox unit - preliminaries

1 Before any dismantling work is undertaken, the external surfaces of the unit should be thoroughly cleaned and degreased. This will prevent the contamination of the engine internals, and will also make working a lot easier and cleaner. A high flash-point solvent, such as paraffin (kerosene) can be used, or better still, a proprietary engine degreaser such as Gunk or Jizer. Use old paintbrushes and toothbrushes to work the solvent into the various recesses of the engine castings. Take care to exclude solvent or water from the electrical components and inlet and exhaust ports. The use of petrol (gasoline) as a cleaning medium should be avoided because of the fire risk.

2 When clean and dry, arrange the unit on the workbench, leaving a suitable clear area for working. Gather a selection of small containers and plastic bags so that parts can be grouped together in an easily identifiable manner. Some paper and a pen should be on hand to permit notes to be made and labels attached where necessary. A supply of clean rag is also required.

3 Before commencing work, read through the appropriate section so that some idea of the necessary procedure can be gained. When removing the various engine components it should be noted that great force is seldom required, unless specified. In many cases, a component's reluctance to be removed is indicative of an incorrect approach or removal method. If in any doubt, re-check with the

## 6 Cylinder head cover, camshafts and followers - removal



1 These components can be removed with the engine/gearbox unit in or out of the frame. In the former case it will be necessary first to remove the fuel tank and the lower and side fairing sections as described in the relevant Sections of Chapters 3 and 5. On ZX900 models, the HT ignition coils should also be removed; make a note of how their low tension leads are arranged prior to removing them. On ZX1000 A models remove the four bolts which retain the top section of the air filter housing and lift it clear of the machine. On ZX1100 C/D models remove the rubber plugs from the back of the air filter housing and slacken the eight bolts which secure the housing to the carburettors. Slacken the clip which secures the air filter housing to the front section of the duct and lift the filter housing away from the machine. On both ZX1000 B and ZX1100 C/D models drain at least 500 cc of coolant out of the cooling system, then remove the flexible coolant hose which runs over the cylinder head cover. On all US models disconnect the hoses from the air suction valves and carefully remove the reed valve assemblies from the cylinder head cover. On all models unplug the suppressor caps from the cylinder head and position them clear of the cover.

2 Slacken and remove the cylinder head cover retaining bolts and carefully lift the cover away from the engine. If possible remove all the dowels and store them with the cover for safekeeping. **Note - take care not to allow the cover locating dowels to drop into the engine.** If a dowel should drop into the engine do not turn the engine over until it has been retrieved. Failure to do so will lead to extensive engine damage. Carefully remove all the rubber gaskets from the top of the cylinder head.


3 If the camshafts are also to be removed, slacken the tensioner cap bolt and the two bolts which secure the camchain tensioner to the back left-hand side of the cylinder block. Remove the tensioner assembly from the engine. Remove the Allen bolts which retain

the top camchain guide and lift the guide away from the cylinder head.


4 Slacken each of the camshaft bolts by about one turn at a time. The camshafts are under pressure from the valve springs and will be pushed clear of the bearing surfaces in the cylinder head. Once the valve spring pressure has been relieved remove the bolts and place them with the bearing caps in a safe place. Also remove all the bearing cap dowels and store these with the caps. Note that on ZX1000 B and ZX1100 C/D models, if the engine is in the frame it may not be possible to remove the left-hand camshaft bearing cap due to there being insufficient clearance to lift the bolts out. If this is so and removal is necessary the cap can be removed with the cylinder head assembly as described in Section 9.

5 The camshafts can then be disengaged from the camchain and manoeuvred out of the cylinder head. The camshafts are marked on their shafts to avoid confusion (IN on the inlet shaft, EX on the exhaust shaft). **Do not remove the sprockets from the camshafts unless necessary.** On ZX1000 and ZX1100 C/D models each sprocket has two sets of holes, one for the inlet shaft and another for the exhaust. If the sprockets are ever removed make a note of which holes are used for each respective shaft, although as a rule the holes with a square indented area surrounding them are used for the inlet camshaft and those with a round surrounding area are used for the exhaust camshaft.

6 If necessary the cam followers can be removed as follows. Note that on ZX1000 B and ZX1100 C/D models, if the work is being carried out with the engine unit in the frame, it will first be necessary to remove the cylinder head if the inlet cam followers are to be removed. On ZX1000 B and ZX1100 C/D models remove the two union bolts from the oil delivery on the right-hand side of the cylinder head, remove it from the head, and withdraw the springs which are fitted behind it. On ZX900 and ZX1000 A models remove the two Allen headed bolts from the cylinder head. On all models the cam follower shafts can then be removed by screwing an 8 mm bolt of suitable length into the end of the shaft and pulling it out with the bolt (see illustration). Lift the followers and springs




6.6a Withdraw cam follower shaft using a suitable 8 mm bolt . . .



6.6b . . . and remove springs . . .





**6.6c ... and followers as they are freed from the end of the shaft**


clear of the cylinder head as they are freed from the end of the shaft (**see illustrations**). Make a note of how the followers and springs are arranged to use as a reference on reassembly (**see illustrations**).

## 7 Ignition rotor assembly - removal




1 The ignition rotor can be removed with the engine in or out of the frame. In the case of the former, the only preliminary dismantling required being that on ZX1000 and ZX1100 C/D models it will be necessary to remove the lower and left-hand side fairing sections as described in Chapter 6.

2 Remove the retaining bolts from the left-hand crankshaft end cover and lift the cover away from the engine, noting that if the engine is in the frame and the oil has not been drained a small amount of oil may escape. Trace the pulser coil wiring back to the block



**6.6d Camshafts and valves – ZX900 and ZX1000 A models**


- |   |                                      |                               |
|---|--------------------------------------|-------------------------------|
| 1 Exhaust camshaft                          | 11 O-ring                            | 21 Locknut – 16 off           |
| 2 Camchain upper guide                      | 12 Cap bolt                          | 22 Valve – 16 off             |
| 3 Inlet camshaft                            | 13 O-ring                            | 23 Seal – 16 off              |
| 4 Camchain                                  | 14 Exhaust cam follower shaft        | 24 Outer spring seat – 16 off |
| 5 Inlet camshaft sprocket                   | 15 O-ring – 2 off                    | 25 Outer spring – 16 off      |
| 6 Exhaust camshaft sprocket                 | 16 Allen bolt – 2 off                | 26 Inner spring seat – 16 off |
| 7 Camchain guide blade                      | 17 Inlet cam follower shaft          | 27 Inner spring – 16 off      |
| 8 Camchain tensioner blade                  | 18 Cam follower – 8 off              | 28 Retainer – 16 off          |
| 9 Metal chain guide                         | 19 Spring – 8 off                    | 29 Collet – 32 off            |
| 10 Camchain tensioner (ZX900 A7-on similar) | 20 Valve clearance adjuster – 16 off |                               |



**6.6e Camshafts and valves – ZX1000 B and ZX1100 C/D models**

- |                             |                               |
|-----------------------------|-------------------------------|
| 1 Exhaust camshaft          | 10 Camchain tensioner         |
| 2 Inlet camshaft            | 11 Spring                     |
| 3 Camchain                  | 12 O-ring                     |
| 4 Camchain upper guide      | 13 Cap bolt                   |
| 5 Exhaust camshaft sprocket | 14 Exhaust cam follower shaft |
| 6 Inlet camshaft sprocket   | 15 Spring – 2 off             |
| 7 Camchain guide blade      | 16 Inlet cam follower shaft   |
| 8 Camchain tensioner blade  | 17 Cam followers – 16 off     |
| 9 Gasket                    | 18 Spring – 6 off             |
|                             | 19 Spring – 4 off             |
|                             | 20 Valve – 16 off             |
|                             | 21 Seal – 16 off              |
|                             | 22 Outer spring seat – 16 off |
|                             | 23 Inner spring seat – 16 off |
|                             | 24 Outer spring – 16 off      |
|                             | 25 Inner spring – 16 off      |
|                             | 26 Retainer – 16 off          |
|                             | 27 Collet – 32 off            |
|                             | 28 Shim – 16 off              |





**7.2 If loose, remove pin (arrowed) from crankshaft end**

connector and disconnect it from the main wiring loom. Slacken the mounting bolts from the pulser coil(s) and remove the coil(s) from the engine. Slacken the Allen bolt which secures the ignition rotor to the crankshaft end, whilst holding the large hexagon nut with a ring spanner to prevent it from rotating. Remove the ignition rotor from the end of the crankshaft and check that the pin which is located in the end of the crankshaft is firmly fixed in position (see illustration). If not it should be removed and stored with the ignition rotor components for safekeeping.

## 8 Camchain and tensioner blade - removal



**1** These components can be removed with the engine in or out of the frame. Remove the cylinder head cover, camshafts and ignition rotor assembly as described in Sections 6 and 7 of this Chapter. Note if the front camchain guide is to be removed it will also be necessary to remove the cylinder head as described in Section 9.

**2** Slacken and remove the two bolts which retain the metal camchain guide (situated behind the ignition rotor) to the crankcase and remove it from the engine. Disengage the camchain from its sprocket and manoeuvre it over the end of the crankshaft. The chain can then be lifted out of the top of the cylinder head.


**3** To remove the tensioner blade, remove the bolt and flat washer from the bottom of the blade and manoeuvre the blade out of the top of the cylinder head. Note the sleeve which is fitted inside the tensioner blade pivot and the flat washer which is positioned between the blade and the crankcase.

## 9 Cylinder head, block and pistons - removal



**1** These components can be removed with the engine in or out of the frame (see illustrations). However, if the engine is in the

- 1 Cylinder head cover
  - 2 Bolt - 6 off
  - 3 Washer - 6 off
  - 4 O-ring - 6 off
  - 5 Air suction valve cover <sup>1</sup>
  - 6 Reed valve <sup>1</sup>
  - 7 Gasket <sup>1</sup>
  - 8 Seal - 4 off
  - 9 Cover seal
  - 10 Cylinder head
  - 11 Bolt - 20 off
  - 12 Camshaft cap - 10 off
  - 13 Dowel - 20 off
  - 14 Main oil pipe
  - 15 Inner oil pipe
  - 16 Tapered-headed bolt - 6 off
  - 17 Washer - 6 off
  - 18 Flat-headed bolt - 4 off
  - 19 Washer - 4 off
  - 20 Valve guide - 16 off
  - 21 O-ring - 16 off
  - 22 Plug - 2 off
  - 23 Head gasket
  - 24 Cylinder block
  - 25 Base gasket
  - 26 Bore liner - 4 off
  - 27 Dowel - 2 off
  - 28 Coolant drain plug - 2 off
  - 29 Sealing washer - 2 off
  - 30 Bolt - 2 off
  - 31 Bolt
  - 32 Dowel - 2 off
- <sup>1</sup> US models only



**9.1a Cylinder head and block - ZX900 and ZX1000 A models**

frame it will be necessary first to remove the radiator, oil cooler, carburettors and exhaust system as described in Section 4 of this Chapter, then carry out the work described in Section 6.


**2** Before proceeding any further on ZX1000 B and ZX1100 C/D models, it is recommended that all the shims are removed from the tops of the valves. Make a note of where each shim is positioned and store the shims separately so that each shim can be refitted in its original position. On reassembly this will make the task of adjusting the valve clearances easier. If not already done during the coolant draining process, remove any residual coolant from the cylinder block by removing the drain plugs which are situated on the front face of the block.

**3** On ZX900 and ZX1000 A models remove the two union bolts which retain the oil pipe to the inside of the cylinder head and lift the pipe

out of the engine. Mark the pipe in some way to ensure that it is positioned correctly on reassembly. Note also that the two union bolts are different and it is essential that they are refitted correctly. Kawasaki mark the head of each bolt with paint (white for the exhaust side bolt and black for the inlet side bolt), if these marks are no longer visible mark both bolts to avoid interchanging them on reassembly. Remove the three union bolts from the main oil pipe which is situated at the front of the engine and the bolt that secures the pipe to the cylinder block and remove the pipe from the engine. On ZX900 models if the engine is in the frame, remove both the cylinder head to frame mounting bolts noting the shim (where fitted) between the left-hand side of the cylinder head and the frame.

**4** On ZX1000 B and ZX1100 C/D models remove the union bolt from the bottom of the oil pipe which runs down the right-hand side





- 1 Bolt – 6 off
  - 2 Sealing ring – 6 off
  - 3 Cylinder head cover
  - 4 Cover seal
  - 5 Seal – 4 off
  - 6 Dowel – 4 off
  - 7 Air suction valve cover<sup>1</sup>
  - 8 Reed valve<sup>1</sup>
  - 9 Gasket<sup>1</sup>
  - 10 Tapered-headed bolt – 6 off
  - 11 Washer – 10 off
  - 12 Flat-headed bolt – 4 off
  - 13 Camshaft cap – 8 off
  - 14 Bolt – 18 off
  - 15 Dowel – 18 off
  - 16 Left-hand outer camshaft cap
  - 17 Bolt – 2 off
  - 18 Left-hand inner camshaft cap
  - 19 Dowel – 2 off
  - 20 Cylinder head
  - 21 Valve guides – 16 off
  - 22 Oil pipe
  - 23 Oil pipe union block
  - 24 Head gasket
  - 25 Cylinder block
  - 26 Dowel – 2 off
  - 27 Coolant drain plug – 2 off
  - 28 Sealing washer – 2 off
  - 29 Bore liner – 4 off
  - 30 Bolt
  - 31 Bolt – 2 off
- <sup>1</sup> US models only

9.1b Cylinder head and block – ZX1000 B and ZX1100 C models

the cylinder head to the block (see illustration). Working in the reverse of the tightening sequence shown (see illustration 42.7) slacken by about one turn at a time the ten cylinder head bolts until all the pressure is released, then remove all the bolts. Tap around the joint faces of the cylinder head with a soft faced mallet to free the head. Once the seal has been broken, lift the head clear whilst feeding the camchain through the tunnel. The front camchain guide can then be lifted out of the cylinder block.

6 Remove any residual road dirt from the base of the cylinder block then lift the block a couple of inches off the crankcase. Before the pistons emerge from the bottom of the bores, pack the crankcase mouth with clean rag to prevent any broken piston rings or other debris falling into the crankcase. Note that if the engine unit is in the frame, it will be necessary to disconnect the flexible coolant hose from the front of the cylinder block. The block can now be lifted off of the pistons and clear of the crankcase.

7 Remove the circlips from the pistons by inserting a small flat-bladed screwdriver into the groove in the piston boss and levering them out of position. Discard all circlips regardless of their apparent condition and use new ones during the rebuild.

8 Press each gudgeon pin out of position, noting that if the pins are a tight fit in the piston bosses it is advisable to warm up the pistons before attempting to remove them. Do not use excessive force to remove the gudgeons pins, if necessary, make up a drawbolt arrangement to press them from position. Using a spirit-based marker or scribe, mark each piston inside the skirt so that it is refitted in the appropriate bore on reassembly.

9 The piston rings can be removed by holding the piston in both hands and gently prising the ring ends apart until they can be lifted out of their grooves and onto the piston lands, one side at a time. The rings can then be slipped off the piston and put to one side for examination. Store the rings in the exact order that they were fitted as a guide to reassembly. If the rings are stuck in their grooves by excessive carbon deposits use three strips of thin metal to remove them as shown (see illustration). Be careful as the rings are brittle and will break easily if overstressed.


of the cylinder block (see illustration). Unscrew the flexible hose from its union on the head and remove the pipe.

5 On all models slacken the bolts which retain the ignition pickup cover and remove the cover


from the engine. Remove the two bolts which pass up through the crankcase and retain the cylinder block, one of which is situated behind the cover, and the single bolt from the front underside of the cam chain tunnel which secures



9.4 ZX1000 B and ZX1100 C/D models remove oil hose which runs down right-hand side of cylinder block




9.5 Do not forget to remove two bolts which pass up through the crankcase



9.9 Method of removing piston rings





**10.5** Hold alternator/starter clutch cush drive with service tool (or equivalent) and slacken nut

## 10 Alternator/starter clutch drive components - removal


**1** The alternator/starter clutch drive components can be removed with the engine unit in or out of the frame. If the work is to be carried out with the engine in the frame it will first be necessary to drain the oil as described in Chapter 1, and remove the lower and right-hand fairing sections as described in Chapter 6.

**2 Note** - if it is necessary to remove the alternator/starter clutch shaft cush drive, a holding tool will be required. Kawasaki produce a service tool, Part Number 57001-1189, for the job. Alternately a home made peg spanner could be fabricated.


**3** Slacken and remove all the retaining bolts from the right-hand crankcase cover and remove the cover from the machine. Be prepared to catch any residual oil which may be released as the cover is removed.

**4** Lock the alternator/starter clutch drive chain tensioner by pushing up the tensioner's locking plate. Slacken both its mounting bolts and lift the tensioner assembly clear of the engine. Release the bolt which retains the chain guide and lift the guide off its locating stud. Remove the sleeve from inside the chain guide and store it with the tensioner components for safekeeping.

**5** Using the service tool or the home-made alternative, hold the alternator/starter clutch shaft cush drive and slacken the cush drive assembly nut, followed by the bolt from the right-hand end



**11.5** Hold the clutch centre as shown whilst slackening centre nut



**11.2** Fabricated clutch holding tool

of the crankshaft (see illustration). Once loose, remove both the nut and bolt along with their flat washers. Simultaneously pull both the cush drive assembly and the crankshaft sprocket off their respective shafts and remove them along with the drive chain. Disengage the sprocket and cush drive from the chain, and dismantle the cush drive assembly.

## 11 Clutch - removal

**1** The clutch can be removed for inspection or overhaul with the engine unit in or out of the frame. In the former case it will be necessary to drain the engine oil as described in Chapter 1, and remove the lower and right-hand side fairing sections as described in Chapter 6.

**2 Note** - if it is necessary to remove the clutch centre nut, a holding tool will be required to prevent the clutch centre from rotating. Kawasaki produce a service tool, Part Number 57001-305 for ZX900 and ZX1000 A models, and 57001-1243 for ZX1000 B and ZX1100 C/D models, which is basically a self-locking wrench with blade-like jaws that are turned through 90° to engage with the splines in the clutch centre. In the absence of the correct tool a simple alternative, which is shown (see illustration), can be made. The tool was fabricated from 1/8 in steel strip and uses a nut and bolt as a pivot. The jaws should be filed or ground to suit the splines in the clutch centre and the handles should be about 2 - 3 feet in length to provide a secure grip.

**3** Remove the retaining screws from the right-hand crankcase cover and detach the cover from the engine. Be prepared to catch any residual oil which may be released as the cover is removed. Progressively slacken the clutch spring retaining bolts until spring pressure is released, and remove the clutch springs and their retaining bolts. Lift off the clutch pressure plate.

**4** On ZX1000 and ZX1100 C/D models withdraw the short mushroom headed pushrod assembly from the centre of the input shaft. Remove the cup from the end of the pushrod and lift off the thrust washer and bearing. On ZX900 models pull out the

pushrod from the centre of the input shaft and remove the shouldered spacer from the centre of the pressure plate. On all models remove all the clutch plain and friction plates.

**5** Using the Kawasaki service tool or home-made substitute, securely hold the clutch centre whilst slackening the centre nut with a socket and extension bar (see illustration). Once the nut has been slackened, remove it and the large plain or toothed washer beneath it. Pull off the clutch centre followed by the large plain thrust washer.

**6** Withdraw the clutch drum centre collar by screwing one of the crankcase cover bolts into the holes provided and pulling it out with the bolt. The clutch drum can then be manoeuvred out of the crankcase followed by the oil pump drive gear and the large and small thrust washers. On some early ZX900 and ZX1000 A models these thrust washers have been omitted and a single large chamfered washer used instead; if this is the case note which way round the washer is fitted. On ZX1100 C/D models remove the needle roller bearing from the centre of the clutch drum (see illustrations).


## 12 Sump and oil pump - removal

**1** The sump and oil pump can be removed with the engine unit installed in the frame or on the workbench. If the work is to be carried out in the frame, it will first be necessary to remove the lower and side fairing sections, drain the oil and remove the oil filter, oil cooler and hoses, radiator and exhaust system as described in Section 4.


**2** Slacken and remove both the union bolts from the metal oil pipe which links the sump to the crankcase and lift it clear of the engine. Remove the union bolt which secures the main cylinder head oil pipe or hose to the sump, if not already having done so. Disconnect the electrical leads from both the oil pressure and temperature switches (as necessary) and release the lead(s) from any cable ties or guides. Remove all the sump retaining bolts and lower it away from the engine unit. Make a note of the correct position of any oil hose or electrical guides that are fitted to the sump bolts to use as a reference when refitting the sump to the engine. Note the large dowel which locates the sump on the oil pump bracket, if this is loose remove it and store it with the sump.

**3** Once the sump has been removed, pull out the large oil screen from the bottom of the engine unit, followed by the black plastic pipe and the two metal oil pipes. To allow the oil pump and mounting bracket assembly to be removed from the engine it is first necessary to ensure that the projections on the shaft of the pump are vertical. If the clutch has also been removed this can be done by simply turning the oil pump drive gear, situated





### 11.6a Clutch – ZX900 and ZX1000 B models





behind the clutch. If not, it will be necessary to turn the crankshaft. This can be done by removing the cover from the left-hand end of the crankshaft and turning the ignition rotor with a large ring spanner.

4 Remove the three oil pump bracket mounting bolts and withdraw the bracket assembly from the engine noting the dowel, and the oil nozzle and O-ring that locate the bracket on the crankcase. Make a note of their correct positions and remove them if loose.

## 13 Alternator and starter motor - removal



1 These components can be removed with the engine unit either in or out of the frame. In the former case on ZX1000 and ZX1100 C/D models, it will first be necessary to remove the lower and left-hand side fairing sections as described in Chapter 6.

2 The alternator is situated on the left-hand side of the engine, behind the cylinder block. Trace the alternator wiring back to its block connector and disconnect it from the main wiring loom. Remove the three alternator mounting bolts and pull the alternator away from the engine. Once the alternator has been lifted clear, remove the rubber dampers from its cush drive assembly and store them with the alternator.

3 To remove the starter motor Kawasaki recommend that it is first necessary to remove the external gearchange mechanism cover. However on the machine shown in the photographs, it was found that there was just enough clearance to remove the starter motor without removing this cover.

4 Slacken and remove the nut which secures the starter motor lead and disconnect it from the motor. Release both the starter motor mounting bolts and manoeuvre the motor away from the engine.

## 14 Gearchange components - removal



1 The external gearchange mechanism components can be removed with the engine in or out of the frame. If the work is to be carried out with the unit in the frame it will first be necessary on ZX1000 and ZX1100 C/D models to remove the lower and left-hand side fairing sections as described in Chapter 6. On all models it is necessary to drain the oil and remove the water pump, clutch slave cylinder, gearchange linkage, engine sprocket casing and the sprocket itself. Refer to Section 4 for further information.

2 Slacken all the gearchange mechanism cover retaining bolts and remove the cover from the engine. Be prepared to catch any residual oil which may be released as the

cover is removed. Note the two dowels that locate the cover on the crankcase. If these dowels are loose, remove them and store them with the cover for safekeeping.

3 Disengage the gearchange shaft from the selector drum and pull the shaft out of the crankcase. Remove the nuts and shouldered washers which retain the neutral and gear position detent arms and remove the arms along with their return springs. Note that although the detent arms are identical the return springs are different and are not interchangeable. On ZX900 and ZX1000A models Kawasaki mark the neutral (upper) arm return spring with blue paint, and on ZX1000 B models the gear position (lower) arm spring is marked with white paint. On ZX1100 C/D models the gear position (lower) arm spring is yellow, and the neutral (upper) arm spring white. If these marks have worn off, it will be necessary to mark the springs in some way to ensure they are positioned correctly on refitting.

## 15 Separating the crankcase halves



1 The crankcase halves cannot be separated until the engine/gearbox unit has been removed from the frame as described in Section 4 of this Chapter, and all the preliminary dismantling has been carried out. If a full engine/gearbox strip is being performed, then all operations described in Sections 6 to 14 inclusive must be carried out first. If, however, it is wished only to examine the gearbox or starter clutch components, then the operations described in Sections 6, 7, 8, 9, 11 and 13 can be ignored. Note also that it is only necessary to remove the clutch if the gearbox input shaft is to be dismantled, otherwise it can be left in position.

2 The crankcase halves are secured by two 8 mm bolts and six 6 mm bolts fitted from the top side of the crankcase, and eleven 6 mm bolts and nine 8 mm bolts (which are situated around the main bearings) from the underside of the crankcase. Note on ZX1100 C/D models the nine main bearing bolts are 9 mm in diameter and one of the lower 6 mm bolts is replaced with a 7 mm item. With the unit upright, progressively slacken and remove first the 6 mm bolts, then the 8 mm bolts from the top side of the crankcase. Then invert the crankcase and repeat the process for the bolts on the underside of the crankcase. Slacken the main bearing bolts in the reverse order of their tightening sequence which is stamped on the lower crankcase half. Note that it is not necessary to remove the main bearing cap, situated behind the balancer shaft, to separate the crankcase halves. As each bolt is removed, store it in its relative position, along with any guides or washers, in a cardboard template of the crankcase halves so that it can be refitted in its original position on reassembly.

3 Leverage points are provided on the front left-hand side of the crankcase, inside the ignition rotor housing, and on the back right-hand side, inside the clutch housing. Insert a large flat-bladed screwdriver between these points and gently prise the crankcase halves apart. Alternately, a hammer and a block of wood can be used to jar the cases apart. Usually the joint will break fairly easily.



**If difficulty is encountered in breaking the seal on the crankcase halves, thoroughly check that all crankcase bolts and components have been removed before forcing the cases apart.**

4 Separate the crankcase halves with the unit inverted on the bench, lifting the lower half off the upper half. The crankshaft and gearbox shafts will remain in position in the upper half but take care not to dislodge or lose any main bearing inserts from the lower casing. Note the two crankcase half locating dowels that are located on each side of the crankshaft; if loose, remove them for safekeeping.

## 16 Upper crankcase components - removal




1 Once the crankcase halves have been separated, both the input and output gearbox shaft assemblies can be lifted out of the upper casing, noting that these have half ring retainers fitted to the ball journal bearing grooves, and locating pins for the needle roller bearing outer races on the opposite ends of each shaft. Remove the half ring retainers from the casing and, if loose, the locating pins.

2 To remove the crankshaft, slacken the two bolts which retain the single main bearing cap and lift it clear. Note the direction of the arrow on the top surface of the bearing cap and take care not to lose the bearing insert or the dowels. The crankshaft can then be lifted out of position, taking care not to dislodge any of the bearing inserts.

3 Hold the alternator cush drive coupling, slacken its retaining bolt, and remove the coupling from the engine. If difficulty is encountered in holding the coupling, temporarily refit the alternator/starter clutch cush drive assembly to the opposite end of the shaft and hold it with the service tool whilst removing the bolt. The shaft can then be withdrawn from the casing and the starter clutch removed. If the starter motor idler gear is also to be removed, slacken and remove the bolt and washer that hold the idler gear shaft in position, remove the shaft itself and lift out the idler gear. Note that on ZX1100 C/D models, the idler shaft retaining bolt also retains an oil spray pipe. This should also be removed from the casing.





**16.4 If necessary, breather cover can be removed for cleaning; use a new gasket on refitting**

4 On all models the breather cover on the top surface of the crankcase, retained by four bolts, need not be removed except for cleaning purposes. If removed, renew the gasket when refitting the cover to the casing (see illustration).

## 17 Lower crankcase components - removal

1 Remove the bolts which secure the selector drum retaining plate to the side of the casing and remove the plate. Withdraw the selector fork shaft from the lower crankcase and lift out the selector forks as they are freed from the end of the shaft. Make a note of how the three selector forks are positioned to use as a guide when reassembling the gear selector components. Once the selector shaft and forks are removed the selector drum can also be removed from the casing.

2 To remove the balancer shaft assembly, slacken and remove both the balancer shaft clamp pinch and mounting bolts and pull the clamp off its shaft. On ZX1000 B and ZX1100 C/D models, remove the balancer shaft guide pin retaining plate from inside the crankcase, and lift out the guide pin with a pair of sharp-nosed pliers. On all models tap or pull the balancer shaft out until the oil seal is displaced from the crankcase half. Remove the oil seal from the end of the shaft, followed by the thrust washer (ZX1000 B and ZX1100 C/D models only). Fully withdraw the balancer shaft, whilst holding the balancer weight, and remove both components from the casing.

## 18 Examination and renovation - general

1 Before any component is examined, it must be cleaned thoroughly. Being careful not to mark or damage the item in question, use a blunt-edged scraper (an old kitchen knife or a broken plastic ruler can be very useful) to remove any caked-on deposits of dirt or oil, followed by a good scrub with a soft wire

brush (a brass wire brush of the type sold for cleaning suede shoes is best, with an assortment of bottle-cleaning brushes for ports, coolant passages, etc). Take care not to remove any paint code marks from internal components.

2 Soak the component in a solvent to remove the bulk of the remaining dirt or oil. If one of the proprietary engine degreasers (such as Gunk or Jizer) is not available, a high flash-point solvent such as paraffin (kerosene) should be used. The use of petrol as a cleaning agent cannot be recommended because of the fire risk. With all of the above cleaning agents take great care to prevent any drops getting into the eyes and try to avoid prolonged skin contact. To finish off the cleaning procedure wash each component in hot soapy water (as hot as your hands can bear); this will remove a surprising amount of dirt on its own and the residual heat usually dries the component very effectively. Carefully scrape away any remaining traces of old gasket material from all joint faces.

3 If there is the slightest doubt about the lubrication system, for example if a fault appears to have been caused by a failure of the oil supply, all components should be dismantled so that the oilways can be checked and cleared of any possible obstructions. Always use clean, lint-free rag for cleaning and drying components to prevent the risk of small particles obstructing oilways.

4 Examine each part carefully to determine the extent of wear, checking with the tolerance figures listed in the Specifications section of this chapter. If there is any doubt about the condition of a particular component, play safe and renew it.



*As a general rule, time is the primary cost of an overhaul so it doesn't pay to install worn or substandard parts.*

5 Various instruments for measuring wear are required, including an internal and external micrometer or vernier gauge, and a set of standard feeler gauges. Additionally, although not absolutely necessary, a dial gauge and mounting bracket are invaluable for accurate measurement of endfloat, and play between components of very low diameter bores where a micrometer cannot reach. After some experience has been gained, the state of wear of many components can be determined visually, or by feel, and a decision on their suitability for re-use made without resorting to direct measurement.

6 The machine's manufacturer recommends the use of Plastigauge for measuring radial clearance between working surfaces such as shell bearings and their journals. Plastigauge consists of a fine strand of plastic material manufactured to an accurate diameter. A short length of Plastigauge is placed between the two surfaces, the clearance of which is to

be measured. The surfaces are assembled in their normal working positions and the securing nuts or bolts fastened to the correct torque setting; the surfaces are then separated. The amount of compression to which the gauge material is subjected and the resultant spreading indicates the clearance. This is measured directly, across the width of the Plastigauge, using a pre-marked indicator supplied with the Plastigauge kit. If Plastigauge is not available, both an internal and external micrometer will be required to check wear limits.

## 19 Engine cases and covers - examination and renovation

1 Small cracks or holes in aluminium castings may be repaired with an epoxy resin adhesive, such as Araldite, as a temporary measure. Permanent repairs can only be effected by argon-arc welding, and only a specialist in this process is in a position to advise on the economics or practicability of such a repair.

2 Damaged threads can be economically reclaimed by using a diamond section wire insert, of the helicoil type, which is easily fitted after drilling and re-tapping the affected thread. Most motorcycle dealers and small engineering firms offer a service of this kind.

3 Sheared studs or screws can usually be removed with screw extractors, which consist of tapered, left-hand thread screws of very hard steel. These are inserted into a pre-drilled hole in the stud, and usually succeed in dislodging the most stubborn stud or screw. If a problem arises which seems beyond your scope, it is worth consulting a professional engineering firm before condemning an otherwise sound casing. Many of these firms advertise regularly in the motorcycle press.

## 20 Bearings and oil seals - examination and renovation


1 Ball bearings should be washed thoroughly to remove all traces of oil then tested as follows. Hold the outer race firmly and attempt to move the inner race up and down, then from side to side. Examine bearing balls, tracks and cages looking for signs of pitting or other damage. Finally spin the bearing and check that it rotates smoothly and with no sign of notchiness. If any free play, roughness or other damage is found the bearing must be renewed.

2 Roller bearings are checked in much the same way, except that free play can only be checked in the up and down direction with the components temporarily assembled. Remember that if a roller bearing fails it may well mean having to replace, as well as the





**20.4a** Carefully lever out old oil seals using a flat-bladed screwdriver . . .



**20.4b** . . . and tap new seals into position with a suitable drift



**21.1** Examine cam lobes for signs of scoring

bearing, one or two other components which form its inner and outer races. If in any doubt about the condition of a roller bearing, renew it.

**3** Do not waste time checking oil seals. Discard all seals and O-rings disturbed during dismantling work and fit new ones on reassembly. Considering their habit of leaking once disturbed, and the amount of time and trouble necessary to replace them, they are relatively cheap if renewed as a matter of course whenever they are disturbed.

**4** Oil seals can be levered out of the casings using a large flat-bladed screwdriver (**see illustration**). Take care not to scratch or damage the casing whilst doing this. On refitting, use a hammer and suitably sized socket, which bears only on the hard outer race of the seal, to tap the seal into position (**see illustration**). Ensure the seal enters the casing squarely and is flush with the casing once in position. Smear the lips of the seal with grease to prevent the seal being damaged on reassembly.

## 21 Camshafts and camshaft drive mechanism - examination and renovation



**1** Examine the camshaft lobes for signs of wear or scoring (**see illustration**). Wear is normally evident in the form of visual flats worn on the peak of the lobes, and this may be checked by measuring each lobe at its widest point. If any lobe is worn by a significant amount the camshaft must be renewed. Scoring or similar damage can usually be attributed to a partial failure of the lubrication system, possibly due to the oil and filter not having been renewed at the specified intervals, causing unfiltered oil to be circulated by way of the bypass valve. Before fitting a new camshaft, examine the bearing surfaces of the cylinder head and the cam followers.

**2** If the cam lobes are scored it is likely that the surfaces of the cam followers are also damaged. If this is the case all the damaged followers must be renewed along with the camshaft. Also measure the inside diameter of

each follower and the external diameter of the followers shaft. If any component is found to have worn beyond the service limits given in the Specifications at the start of this Chapter, it must be renewed.

**3** If the camshaft bearing surfaces are scored or excessively worn, it is likely that renewal of both the cylinder head and camshafts will be necessary. This is because the camshafts run directly in the cylinder head casting, using the alloy as a bearing surface. Note that it is not possible to purchase the camshaft bearing caps alone, as they are machined together with the cylinder head and are thus matched to it. It may however be possible for an expert to effect a repair. There are a number of engineering firms who specialise in this repair, usually involving the fitting of bearing inserts (shells), or needle roller bearings to the cylinder head and bearing caps. Due to the cost of a new cylinder head it is recommended that one of these firms, who regularly advertise in the motorcycle press, is consulted before condemning an otherwise sound cylinder head.

**4** Measure the camshaft bearing journals, using a micrometer. If any journal has worn beyond the service limit, the camshaft(s) must be renewed. The clearance between the camshaft and its bearing cap can be checked using Plastigauge or by direct measurement. The clearance must not exceed the specified limit.

**5** Camshaft runout can be checked by supporting each end of the camshaft on V-blocks, and measuring any runout using a dial gauge. If the runout exceeds the service limit the camshaft must be renewed.

**6** The camchain should also be checked for wear, particularly if chain noise has been noted when the engine is running, this is usually an indication that the chain is due for renewal. Lay the chain on a flat surface and get an assistant to stretch it taut. Using a vernier caliper, measure a 20 link length of the chain, ie from the centre of one pin to the centre of the 21st pin along. Repeat this check on several different sections of the chain and note the readings obtained. If any section of the chain has worn beyond the service limit it must be renewed.

**7** The tensioner guide and blade should be examined for wear or damage, which will normally be fairly obvious, renewing it if necessary. The camchain tensioner can be checked for wear only by comparison with a new item. If any doubt exists as to the condition of the tensioner it should be renewed.

## 22 Cylinder head - examination and renovation



**1** Remove all traces of carbon from the cylinder head using a blunt-ended scraper (the rounded end of an old steel rule will do). Finish by polishing with metal polish to give a smooth shiny surface.

**2** Check the condition of the spark plug threads. If the threads are worn or cross-threaded they can be reclaimed by the fitting of a Helicoll insert. Most motorcycle dealers operate this service which is very simple, cheap and effective.

**3** Lay the cylinder head on a sheet of 1/4 inch plate glass to check for distortion. Aluminium alloy cylinder heads distort very easily, especially if the cylinder head bolts are tightened down unevenly. If the amount of distortion is only slight, it is permissible to rub the head down until it is flat again by wrapping a sheet of very fine emery cloth around the sheet of glass and rubbing with a rotary motion.

**4** If the cylinder head is badly distorted (as shown by frequent blowing of the cylinder head gasket), the head will have to be skimmed by a competent engineer who is experienced in this kind of work. This will of course raise the compression of the engine and if too much is removed, the performance of the engine will be adversely affected. In extreme cases the valves might even strike the pistons, causing serious engine damage. If there is a risk of this happening, the only solution is to renew the cylinder head.

**5** Refer to Sections 21 and 23 of this Chapter for information on the camshaft bearings and valves.



## 23 Valves, valve seats and valve guides - examination and renovation



operations. With this and the cost of the Kawasaki service tools needed for the job in mind, it is strongly recommended that the job be entrusted to an authorized Kawasaki dealer. However, for the more skilled and better equipped owner the procedure is as follows.

**6** Heat the cylinder head slowly and evenly, in an oven to prevent warpage, to approximately 120 - 150°C (248 - 302° F). Using a stepped drift, tap the guide(s) lightly out of the head, taking care not to burn yourself on the hot casting. New guides are fitted in a similar manner, being tapped down lightly until they are correctly seated. If a valve guide is loose in the cylinder head, it may be possible to have an oversize guide machined and fitted by a competent engineering works.

**7** After the guide has been fitted it must be reamed using a Kawasaki reamer (Part Number 57001-1079 on ZX900 and ZX1000 A models and 57001-1204 on ZX1000 B and ZX1100 C/D models). Make sure the reamer passes squarely through the valve guide, taking care not to gouge out too much material accidentally. The valve seat must now be recut as follows (see illustration). This process requires the use of five cutters, 32° and 45° inlet valve cutter, 32° and 45° exhaust valve cutter and 60° cutter for both, along with a pilot bar and T-handle. All of which can be purchased from any Kawasaki dealer.

**8** Fit the appropriate 45° cutter to the pilot bar, fit the T-handle and insert the pilot bar into the valve guide until the cutter makes contact with the valve seat. Using firm hand pressure, rotate the cutter through one or two full turns to clean the seat then withdraw the cutter and examine the seat. If the seat is continuous and free from pitting proceed to the next step, but if pitting is still evident, refit the cutter and repeat the procedure until all pitting has been removed. Be very careful to remove only the bare minimum of material necessary as valve seat inserts are not available. If the seat becomes sunken through overcutting, the complete cylinder head assembly must be renewed.


**9** Once the valve seating face is in good condition it is necessary to check the outside

diameter of the seating face, using a vernier caliper, to ensure it is within the specified limits. If the outside diameter is too small, repeat the above procedure with the 45° cutter until it is within the specified range. However, if the outside diameter is too large proceed as follows.


**10** Fit the appropriate 32° cutter to the pilot bar, fit the T-handle and insert the pilot bar into the valve guide until the cutter comes into contact with the valve seat. Noting that the 32° cutter removes material very quickly, press down lightly on the T-handle and rotate the cutter through one turn. Remove the cutter and recheck the valve seat diameter, repeat the above procedure until the outside diameter is within the specified range.

**11** With the seating face outside diameter correct, it is now necessary to check the width of the valve seat (45° portion). If the valve seat width is below the specified limit, cut the seat using the 45° cutter until the seat width is slightly too wide, then trim the seat back to within the specified range using the 32° cutter. If the seat is too wide, fit the 60° cutter to the pilot bar and trim the seat until it is within the specified range. Once both the outside diameter and the width of the valve seat are correct the valves should be ground in as follows.

**12** The valves should be ground in using oil-bound grinding paste to remove any light pitting or to finish off a newly cut seat. Note that it is not normally essential to resort to using the coarse grinding paste which is supplied in the dual-grade containers. Commence by smearing a trace of fine grinding compound (carborundum paste) on the valve seat and apply a suction tool to the head of the valve. Oil the valve stem and insert the valve into its guide so that the valve and valve seat make contact with each other. With a semi-rotary motion, grind in the valve head to the seat, using a backwards and forwards motion. Lift the valve occasionally to ensure the grinding paste is evenly distributed. Repeat the application until an



23.4 Valve stem to guide wear check



23.7 Valve seat recutting angles

- 1 Valve
- 2 Cylinder head
- 3 Seating area outside diameter
- 4 Seating area width

**1** Before removing the valves from the cylinder head, obtain a container and partition it off into 16 separate sections. Clearly label each section with the cylinder number and valve position and place the valve components in their respective sections as they are removed. This will prevent interchanging of valve components and ensure that they are refitted in their original positions. However, where possible, it is still recommended that work should be carried out on one valve assembly at a time.


**2** Compress the valve springs with a suitable valve spring compressor, and remove both valve collets. Carefully remove the valve spring compressor and lift the spring retainer collar off the valve. Lift off both the valve springs, noting that they are fitted with the closer-pitched coils at the bottom, and then slide the valve out of the cylinder head. The oil seal can then be carefully levered off the valve guide and both the spring seats removed.

**3** Inspect each valve for wear, overheating or burning and renew as a set if necessary. Normally, the exhaust valves will need attention or renewing more often than the inlet valves, as the latter run at relatively low temperatures. If any of the valve seats are badly pitted, do not attempt to cure this by grinding them, as this invariably causes the valve seats to become pocketed. It is permissible to have the valve(s) refaced by a motorcycle specialist or engineering firm. Measure the valve stem diameter, the valve head thickness (distance between the edge of the seating surface and the top of its head) and the valve stem runout. Renew the valve if any measurement obtained is outside the service limits given in the Specifications.

**4** Check the valve stems and their guides for wear either by direct measurement or as follows using the 'wobble' method. Insert the valve into its guide and set up a dial test indicator perpendicular to it as shown (see illustration). Rock the valve to and fro along the direction of the cam lobe, and then at right angles to it. Note the readings obtained. If either measurement is greater than the service limit and the valve stem diameter is known to be correct, the valve guide is worn and must be renewed. If a small bore gauge and micrometer are available, the two components can be measured at three or four points along their bearing surfaces, both in the direction of the cam lobe and at right angles to it. If any measurement obtained is beyond the service limit, one or both components must be renewed.

**5** Valve guide renewal is not easy and will require that the valve seats be re-cut after the guide has been fitted and reamed. It is also remarkably easy to damage the cylinder head unless great care is taken during these






**23.14a** Fit a new oil seal (arrowed) to the valve guide and refit both the outer ...



**23.14b** ... and inner spring seats



**23.14c** Liberally oil the valve stem and insert it into the guide

unbroken ring of light grey matt finish is obtained on both the valve and valve seat. This denotes the grinding operation is now complete. Before moving on to the next valve, ensure that all traces of grinding compound are removed from both the valve and its seat and that none has entered the valve guide. If this precaution is not observed, rapid wear will take place due to the highly abrasive nature of the grinding compound.

**13** Examine the spring retaining collars and collets, renewing any that are marked or damaged in any way. Measure the length of all the valve springs and renew any that are on or below the service limit given in the Specifications at the start of this Chapter. Although valve springs are available separately, it is considered good practice to renew them all as a set.

**14** Place both the spring seats over the guides and press a new seal over each valve guide upper end (see illustrations). Liberally oil the guide bore and the valve stem before inserting the valves into the guides (see illustration). Refit the valve springs, ensuring that the closer-pitched coils are at the bottom (next to the cylinder head), and fit the spring retaining collar (see illustration). Check that both springs are correctly seated, compress them, and refit the collets (see illustration). Remove the valve spring compressor and give the end of each valve a sharp tap with a hammer to ensure the collets are correctly seated.



**23.14d** Refit the valve springs, ensuring that their closer-pitched coils are at the bottom ...

## 24 Cylinder block - examination and renovation

**1** The usual indication of badly worn cylinder bores and pistons is excessive smoking from the exhausts. This usually takes the form of a blue haze tending to develop into a white haze as the wear becomes more pronounced.

**2** The other indication is piston slap, a form of metallic rattle which occurs when there is little load on the engine. If the top of the bore is examined carefully, it will be found that there is a ridge on the thrust side; the depth will vary according to the rate of wear which has taken place.

**3** Cylinder wear can be assessed by measuring the bore diameter at the following points: 10 mm and 60 mm from the top of the bore, and 20 mm from the base of the bore. Measure both along the gudgeon pin axis and at right angles to it so that a total of six measurements are taken. If any of the readings obtained exceed the service limit given in the Specifications, the cylinder block will have to be rebored and fitted with oversize pistons.

**4** Kawasaki supply pistons in only one oversize, + 0.5 mm (+ 0.020 in). If boring in excess of 0.5 mm becomes necessary, the cylinder liners must be renewed and new pistons fitted. Liner renewal is strictly a task

for experts and the job should be entrusted to an authorised Kawasaki dealer.


**5** If new rings are to be run in a used cylinder bore, the bore surface must first be prepared by honing, or glaze-busting. This process, which can also be used to remove marks caused by very light piston seizure, involves the use of a cylinder bore honing tool usually in conjunction with an electric drill to break down the glazed surface which forms on any bore during normal service. The prepared bore will have a very lightly roughened surface which will help the rings to bed in rapidly and fully. This is normally done as a matter of course after reboring. It also has the advantage of removing the lip from the top of the bore which could otherwise damage the new top piston ring. Most motorcycle dealers have glaze-busting equipment and will carry out the work for a small charge.

## 25 Pistons and piston rings - examination and renovation

**1** If the cylinders are rebored or new liners fitted, the existing pistons and rings can be disregarded as they will be replaced by new items. If, however, the bores have been cleaned and checked as described in the preceding Section and are to be re-used, clean and check the pistons and rings as follows.



**23.14e** ... followed by the spring retaining collar




**23.14f** Compress the valve springs and refit the collets






25.3 Measuring piston diameter



25.4 Checking piston ring to groove clearance



25.5 Measuring piston ring end gap

2 Remove all traces of carbon from the piston crowns using a blunt-ended scraper to avoid damaging the piston surface. Finish off by polishing the crowns of the pistons with metal polish to prevent carbon deposits adhering so rapidly in future. Never use emery cloth on the soft aluminium alloy of the piston.

3 Piston wear usually occurs at the skirt or lower end of the piston and takes the form of vertical streaks or score marks on the thrust side of the piston. Damage of this nature will necessitate renewal and is checked by measuring the outside diameter of the skirt at a point 5 mm (0.2 in) from the base of the skirt and at right angles to its gudgeon pin axis (see illustration). If any piston has worn to or beyond its service limit, it must be renewed.

4 After the engine has covered a high mileage, it is possible that the ring grooves may have become enlarged. To check this, refit the rings to the piston and measure the clearance between the ring and groove using feeler gauges (see illustration). If the gap exceeds the service limit, remove the rings from the piston and measure the thickness of the piston rings and the piston ring groove, renewing any component which exceeds its service limit.

5 To measure the piston ring end gap, insert the ring into its bore, using the crown of the bare piston to locate it approximately 10 mm from the bottom of the bore. Ensure it is square in the bore and measure the end gap of the ring using feeler gauges (see illustration). If the ring gap exceeds the

limits given, the rings should be renewed as a set.

6 It is also necessary to check the end gap when fitting new rings. If there is insufficient clearance, the rings will break up in the bore whilst the engine is running causing extensive engine damage. If necessary the end gap can be increased by carefully filing the ends of the rings with a fine file. Support the ring on the end as much as possible to avoid breakage and ensure the ring ends are kept square. Remove only a small amount at a time and keep rechecking the end gap in the bore.

## 26 Connecting rods and big-end bearings - examination and renovation


1 Examine the connecting rods for signs of cracking or distortion, renewing any rod which is not in perfect condition. Check the connecting rod big-end side clearance, using feeler gauges. If the clearance exceeds the specified limit it will be necessary to renew the con-rod or crankshaft as necessary. Examine the gudgeon pin and small-end bore of the con-rod for scoring or signs of wear, renewing both components as a pair if any sign of damage is present. Connecting rod distortion can only be properly assessed with a great deal of specialised equipment and should therefore only be checked by an expert, otherwise if any doubt remains about the condition of a rod it should be renewed.

2 If a connecting rod is renewed, it is essential that it is of the correct weight group to minimise vibration. The weight is indicated by a letter which is marked across each rod and its big-end cap (see illustration). This letter together with the crankpin diameter mark (see paragraph 6) should be quoted when purchasing new con-rod(s). Ideally all rods should be of the same weight although it is permissible for the rods of cylinders 1 and 2 to be of one weight group and those of cylinders 3 and 4 of another.


3 To examine the big-end bearing inserts and the crankshaft journals it is necessary to remove the connecting rods from the crankshaft. Mark the rods with a spirit-based marker to ensure that they are refitted to their appropriate crankpin on reassembly. Note that on ZX1000 and ZX1100 C/D models the connecting rod bolts are designed to stretch when tightened and therefore whenever the bolts and nuts are disturbed they should be renewed on reassembly. *Never re-use them as this could lead to the big-end caps becoming loose while the engine is running, resulting in extensive engine damage.* The bolts are an extremely tight fit in the connecting rod and great care will be required to avoid marking the rod when tapping out the old bolts. Ensure the heads of the new bolts are fitted in the same position as the old ones and that they do not rotate as their nuts are tightened. Wash the new nuts and bolts in a high flash-point solvent to remove the anti-rust solution which they are coated with at the factory. Dry the bolts immediately using a jet of compressed air.

4 Examine closely the big-end bearing inserts (shells). The bearing surface should be smooth and of even texture, with no signs of scoring or streaking on its surface (see illustration). If any insert is in less than perfect condition, all bearing inserts should be renewed as a set. In practice, it is advisable to renew the bearing inserts during a major overhaul as a precautionary measure. The inserts are relatively cheap and it is false economy to re-use worn components.

5 The crankshaft journals should be given a close visual examination, paying particular attention where damaged bearing inserts




26.2 Connecting rod weight is indicated by the letter stamped on each rod




26.4 Examine bearing inserts for signs of wear, renewing if necessary





26.6a Location of crankshaft size range marks

- Crankpin diameter mark – O mark or unmarked  
 □ Main bearing journal diameter mark – 1 mark or unmarked



26.6b Bearing insert (shell) colour code location

were discovered. If the journals are scored or pitted in any way, a new crankshaft will be required. Note that undersize inserts are not available, thus precluding the option of re-grinding the crankshaft.

6 To select new inserts, use the manufacturer's size code system. The standard crankpin outside diameter is divided into two size groups to allow for manufacturing tolerances. The size group of each crankpin can be determined by examining the crankshaft web which is immediately adjacent to it (see illustration). The crank web will be marked with either an O or no mark at all. **Note** - ignore 1 marks as these refer to main bearing journals. The connecting rods are marked in a similar fashion with the mark, if applicable, being situated next to the weight mark. If the equipment is available, these marks can be checked by direct measurement. The bearing

inserts can then be selected using the relevant table below (see illustration).

#### ZX900 and ZX1000 A models

Connecting rod mark	Crankshaft mark	Insert colour
○	Unmarked	Blue
○	○	Black
Unmarked	Unmarked	Black
Unmarked	○	Brown

#### ZX1000 B and ZX1100 C/D models

Connecting rod mark	Crankshaft mark	Insert colour
○	Unmarked	White
○	○	Blue
Unmarked	Unmarked	Blue
Unmarked	○	Black

7 If the existing inserts are to be re-used, use Plastigauge to check the clearance as described in Section 18. If the clearance measured is within the specified limits, the existing shells can be re-used. If the clearance

is excessive, even with new shells (of the correct size code) the crankpin is worn and expert advice should be obtained.

## 27 Crankshaft and main bearings - examination and renovation

1 The crankshaft should be thoroughly cleaned using a high flashpoint solvent. Be very careful to check that all the oilways are completely free from dirt and other foreign matter.


2 Examine the crankshaft closely. Any obvious signs of damage such as marked bearing surfaces or damaged threads will mean that it must be renewed (see illustration). There are however engineering firms, who advertise in the motorcycle press, who can undertake major crankshaft repairs. In view of the expense of a new component it is worth trying such firms provided they are competent.

3 Temporarily refit the crankshaft in either crankcase half and use feeler gauges to measure the clearance between the crankcase pillars and their respective crank webs. Alternatively, a dial gauge can be mounted parallel to the crankshaft with its tip touching one end. Push the crankshaft fully away from the gauge, zero the gauge, then push the crankshaft fully towards the gauge and note the reading obtained. If the crankshaft endfloat exceeds the specified service limit the crankcases must be renewed as a matched pair. Crankshaft runout is measured using a dial gauge with the crankshaft mounted on V-blocks at each outer main bearing journal. If crankshaft runout, measured at the centre main bearing journal, exceeds the service limit the crankshaft must be renewed.

4 Examine the camchain drive sprocket on the left-hand end of the crankshaft for signs of wear or damage. If necessary, the sprocket can be removed for renewal using a bearing puller tool.

5 Make a visual examination of the bearing crankshaft journals and inserts as described in paragraphs 4 and 5 of the preceding Section. New inserts can be selected as follows.

6 The standard crankshaft main bearing journal diameter is divided into two size groups to allow for manufacturing tolerances. The size group of each journal can be determined by examining its adjacent crank web. The crank web will be marked with either a 1 or no mark at all. Ignore O marks as these refer to big-end crankpin diameters. The upper crankcase is also marked along its front edge with either an O or no mark at all. Both marks can be checked by direct measurement if the necessary equipment is available. The bearing inserts can then be selected using the table below. Note - when ordering bearing inserts always state the journal number of the required insert (see



- 1 Crankshaft
- 2 Locating pin
- 3 Primary drive gear
- 4 Washer
- 5 Bolt
- 6 Main bearing shells - plain - 6 off
- 7 Main bearing shells - grooved - 4 off
- 8 Connecting rod - 4 off
- 9 Big-end bolt - 8 off
- 10 Nut - 8 off
- 11 Big-end bearing shells - 8 off



illustration), noting that numbers 2 and 4 inserts have an oil groove in them.

Crankcase mark	Crankshaft mark	Insert colour
0	1	Brown
Unmarked	Unmarked	Blue
0	Unmarked	Black
Unmarked	1	Black

7 If the existing inserts are to be re-used, use Plastigauge to check the clearance as described in Section 18, noting that it will be necessary to retighten all the crankcase bolts and tighten them in the correct order progressively up to their specified torque settings. If the clearance measured is within the specified limits, the existing inserts can be re-used. If the clearance is excessive, even with new inserts (of the correct size code), the main bearing journal is worn and expert advice should be obtained.

## 28 Alternator/starter clutch drive components - examination and renovation



1 The condition of the alternator/starter clutch drive chain can be assessed by measuring a section of the chain as follows. Lay the chain on a flat surface and get an assistant to stretch it taut. Using a vernier caliper, measure a 20 link length of the chain, ie from the centre of one pin to the centre of the 21st pin along. Repeat this check on several different sections of the chain and note the readings obtained. If any section of the chain measured has stretched beyond the service limit it must be renewed.


2 The tensioner blade and guide should be examined for wear or damage which will be fairly obvious, renewing it if necessary. The strength of the chain tensioner can only be tested in comparison with a new one. If any doubt exists as to the condition of the tensioner it should be renewed.

3 Wear of the shaft itself is unlikely unless a very high mileage has been covered. Check carefully its various threads and splines.


4 The two cush drives fitted on each end of the shaft consist of inner and outer parts with rubber segments to take up the transmission shocks. Any damage will be self-evident once they are dismantled and should normally be confined to the rubber segments. These will become compressed and rounded off, or may even start to break, but again only after a high mileage. Renew the rubbers as a set if in any doubt as to their condition (see illustration).

5 Renew the starter idler gear and driven gear if their teeth are chipped or worn, or if their centre bearing surfaces have worn, making them a sloppy fit on their respective shafts.


6 Remove the circlip and washer from the starter clutch assembly, separate the starter clutch and driven gear, and remove the needle roller bearing from the clutch. Examine the needle roller bearing for any sign of wear together with the bearing surfaces of the driven gear and clutch (see illustration). Also check



27.6 Main bearing inserts journal number locations



28.4 If worn, renew cush drive rubbers as a set




28.6a Alternator/starter clutch drive and balancer assembly

- |                                     |                                     |                                  |
|-------------------------------------|-------------------------------------|----------------------------------|
| 1 Nut                               | 16 Roller - 3 off <sup>1</sup>      | 32 Thrust washer - 3 off         |
| 2 Washer                            | 17 Bolt - 3 off <sup>1</sup>        | 33 Needle roller bearing - 2 off |
| 3 Cush drive outer section          | 18 Washer - 3 off <sup>1</sup>      | 34 Shouldered thrust washer      |
| 4 Cush drive rubber - 4 off         | 19 Starter clutch body <sup>2</sup> | 35 Cush drive rubber - 6 off     |
| 5 Cush drive inner section          | 20 Roller assembly <sup>2</sup>     | 36 Balancer weight               |
| 6 Drive chain                       | 21 Bolt - 6 off <sup>2</sup>        | 37 Thrust washer                 |
| 7 Alternator/starter clutch shaft   | 22 Starter clutch cover             | 38 Needle roller bearing         |
| 8 Needle roller bearing             | 23 Ball journal bearing             | 39 Shouldered thrust washer      |
| 9 Circlip                           | 24 Cush drive inner section         | 40 Balancer shaft                |
| 10 Washer - 2 off                   | 25 Cush drive rubber - 4 off        | 41 Spacer                        |
| 11 Needle roller bearing            | 26 Washer                           | 42 Oil seal                      |
| 12 Starter clutch driven gear       | 27 Bolt                             | 43 Adjusting lever               |
| 13 Starter clutch body <sup>1</sup> | 28 Bolt                             |                                  |
| 14 Plunger - 3 off <sup>1</sup>     | 29 Washer                           |                                  |
| 15 Spring - 3 off <sup>1</sup>      | 30 Alternator coupling              |                                  |
|                                     | 31 Balancer                         |                                  |

<sup>1</sup> ZX900 and early ZX1000 A models

<sup>2</sup> ZX1000 B, ZX1100 C/D and late ZX1000A models







28.6b Renew starter clutch rollers if they are marked in any way




28.7a Refit the needle roller bearing . . .



28.7b . . . followed by the driven gear . . .



28.7c . . . and washer . . .



28.7d . . . and secure them with the circlip

that the outer bearing surface of the driven gear is smooth and unmarked by contact with the clutch rollers. The rollers themselves should also be undamaged with no signs of wear such as pitting or flat spots, and should be able to move freely. On ZX900 and early ZX1000 A models, check that the plungers and springs are in good condition. If any component is found to be worn or damaged, it must be renewed (see illustration).

7 Liberally oil the needle roller bearing and fit it onto the starter clutch assembly (see illustration). Refit the driven gear, followed by the washer and secure them both with the circlip (see illustrations). Check that the driven gear will spin freely in one direction, but not the other.

## 29 Clutch - examination and renovation



1 After an extended period of service the clutch friction plates will wear and promote clutch slip. Measure the thickness of each friction plate using a vernier caliper noting the readings obtained (see illustration). If any plate has worn to or beyond the service limit given in the Specifications, the friction plates must be renewed as a set.


2 The plain plates should not show any signs of excess heating (blueing). Check the warpage of each plate using a flat surface and feeler gauges. If any plate exceeds the

maximum permissible amount of warpage, or shows signs of blueing, all plain plates must be renewed as a set.


3 Examine the clutch assembly for burrs or indentations on the edges of the protruding tangs of the friction plates and/or slots in the edges of the clutch outer drum with which they engage (see illustration). Similarly wear can occur between the inner tongues of the plain plates and the slots in the clutch centre (see illustration). Wear of this nature will cause clutch drag and slow disengagement during gear changes, since the plates will snag and free fully when the pressure plate is lifted. With care a small amount of wear can be corrected by dressing with a fine file, but if this is excessive the worn components must be renewed.

4 On ZX1100 C/D models, examine the needle roller bearing and the bearing surfaces of the clutch drum and collar for any signs of wear or damage, renewing any component as necessary.


5 Examine the pressure plate lifting bearing for wear. On ZX900 models ensure the ball journal bearing fitted in the pressure plate itself spins freely without any sign of notchiness and that there is no sign of freeplay between the inner and outer races. On all other models check the needle roller bearing, situated on the end of the mushroom-headed pushrod, and its relevant bearing surfaces for any signs of wear or



29.1 Measuring friction plate thickness




29.3a Examine the slots in the clutch drum . . .



29.3b . . . and centre for indentations or burrs and repair or renew as necessary





**29.6 Clutch centre damper mechanism is retained by a circlip**

damage. On all models, renew worn components as necessary.


6 On ZX1000 A and ZX1100 C/D models, the clutch centre is fitted with a damper mechanism which consists of twelve springs and a cam set up. If, after a high mileage, the clutch operation becomes harsh or excessive transmission slop has been noted, it is probably this which is at fault. Compress the damper plate, which has the pressure of the twelve damper springs on it, and remove the large circlip from the back of the clutch centre (see illustration). Slowly release the damper plate and remove the springs and damper cam follower. Examine the bearing surface of the damper cam and follower and renew any worn component. The springs can only be tested by comparison with new items and should be renewed as a set if in any doubt as to their condition. Fit the springs, cam follower and damper plate to the clutch centre, compress the damper plate and refit the circlip.

7 On all models check that the teeth of the crankshaft drive gear and the clutch outer drum are unworn. If a dial gauge (DTI) is available the gear backlash can be measured. If the backlash exceeds the service limit, both components must be renewed as a pair.

8 Measure the free length of each clutch spring (see illustration). If any one has settled to less than the service limit, the clutch springs must be renewed as a complete set.

9 The clutch pushrod should be rolled on a flat surface to check that it is not bent. If bent, it can be straightened but if its hardened ends are worn it must be renewed.

10 The clutch master cylinder is very similar to that which is used for the front brake and can be dismantled and overhauled as described in Section 10 of Chapter 7. The slave cylinder can also be overhauled using the information given in Section 9 of Chapter 7. Ensure the new seal is fitted the correct way around and seats fully in its groove in the piston. On reassembly fill the master cylinder reservoir with new hydraulic fluid and bleed the system as described in Section 13 of Chapter 7.



**29.8 Measuring clutch spring free length**

### 30 Gearbox components - examination and renovation


1 Give the gearbox components a close visual inspection for signs of wear or damage such as broken or chipped teeth, worn dogs, damaged or worn splines and bent selector forks. Renew any parts found to be worn; there is no satisfactory way in which they can be reclaimed (see illustration). The shaft assemblies can be dismantled and reassembled as described in the following section.

2 If a dial gauge is available the gear backlash can be checked to measure tooth wear, if any pair of gears is found to exceed the maximum permissible backlash both gears must be renewed as a pair.

3 The gearbox shafts are unlikely to sustain damage unless the engine has seized, placing an unusually high loading on the gearbox, or unless the machine has covered a very high mileage. Check the surfaces of the shaft, especially where a pinion turns on it, and renew the shaft if it has scored or has picked up. Examine the threads of the shafts and check them for trueness by setting them up in V-blocks and measuring any runout with a dial gauge. Damage of any kind can only be cured by renewal of the shaft concerned. Renew any bushes that show signs of wear.


4 The selector forks should be examined closely to ensure that they are not badly damaged or worn. Measure the width of both fork ends and the diameter of its guide pin (see illustration). If either fork end or the guide pin has worn to less than its service limit the selector fork(s) must be renewed. The selector fork shaft can be checked for trueness by rolling it along a flat surface. A bent shaft will cause difficulty in selecting gears and make the gearchange action heavy. The shaft must be renewed if it is bent.

5 Measure the width of the three grooves in the selector drum at several points along their length. If at any point the width of a groove exceeds the service limit the selector drum must be renewed. Check that the bearing fitted to the drum rotates freely and has no



#### 30.1 Gearchange mechanism

- |                                     |                                |
|-------------------------------------|--------------------------------|
| 1 Selector fork shaft               | 10 Neutral detent arm assembly |
| 2 Selector forks                    | 11 Drum retaining plate        |
| 3 Selector drum                     | 12 Selector claw               |
| 4 Camplate locating pin             | 13 Spring                      |
| 5 Bearing                           | 14 Gearchange shaft            |
| 6 Camplate                          | 15 Locating post               |
| 7 Change pins                       | 16 Return spring               |
| 8 Pin retaining plate               | 17 Circlip                     |
| 9 Gear position detent arm assembly | 18 Washer                      |



**30.4 Measure the width of guide pin (A) and fork ends (B), renewing selector fork if necessary**



sign of freeplay between its inner and outer race. To renew the bearing, slacken the screw from the end of the drum and lift off the pin retaining plate. Remove the pins from the camplate, noting exactly which hole the longer pin is fitted in, and lift the camplate away from the drum. If loose, also remove the camplate locating pin, fitted to the selector drum. The bearing can then be removed from the drum. Fit the new bearing and reassemble the selector drum components ensuring the camplate locating pin is in position, and the longest pin is refitted in its original place as noted on dismantling. Apply a few drops of thread-locking compound to the threads of the screw and tighten it securely.

6 Check the gearchange shaft for signs of wear or damage especially at the splined end of the shaft. If the shaft is damaged in any way, the only satisfactory method of repair is renewal. The gearchange shaft and claw arm return spring tension can be checked only by comparison with new items. If in any doubt as to their condition, the springs should be renewed.

### 31 Gearbox input and output shafts - dismantling and reassembly



#### Dismantling - general

1 The gearbox shafts should not be disturbed unless damage is obvious, such as chipped or worn teeth, unless or course careful examination of the whole assembly fails to pinpoint the source of the problem.

2 Should either of the ball journal bearings require renewal, a bearing puller will be required to remove the oil seal collar from the output shaft and to extract both of the bearings. Note the position of the locating groove in the outer race of the bearing prior to removing it and ensure that the new bearing is fitted with the groove in the same position. Pull the bearing and collar (as necessary) off the shaft and fit the new bearing using a hammer and tubular drift which bears only on the inner race of the bearing.



**When dismantling the transmission shafts, place the parts on a long rod or thread a wire through them to keep them in order and facing the proper direction. A large rubber band will keep them from being disturbed**

3 The input and output shaft should be kept separate, to avoid confusion during reassembly, and if possible dismantled individually to avoid the risk of interchanging components. Dismantling the shafts should pose no problem providing a good pair of circlip pliers is available. As each component is removed, place it in order on a clean

surface so that the reassembly sequence is self-evident and the risk of parts being fitted the wrong way around or in the wrong sequence is avoided. Note that the output shaft incorporates an ingenious neutral finder mechanism which consists of three steel balls running in radial drillings that are spaced 120° apart within the 5th gear pinion. Take care not to lose these balls as the 5th gear is slid off the shaft. Examine all thrust washers, renewing any which show signs of wear, and renew all circlips regardless of their apparent condition.

#### Reassembly - general

4 Having checked and renewed the gearbox components as required, reassemble each shaft (see illustration). The correct assembly sequence is detailed below. Oil the shafts and pinion bushes liberally during assembly. When fitting the circlips to the shafts take care not to expand them any larger than is necessary to slide them over the shaft. Also when fitting a circlip to a splined shaft ensure that the ends of the circlip are positioned in the middle of the splines. These two simple precautions ensure that the circlips are as secure as possible on the shaft. Ensure that the bearing surfaces of each component are liberally oiled before fitting.


5 If problems arise in identifying the various gear pinions which cannot be solved by reference to the accompanying photographs or figures, the number of teeth on each pinion can be used to identify them. Reference to the gearbox specifications at the start of this chapter will show the number of teeth for each gear. The output shaft pinions are listed first, followed by those on the input shaft. The problem would not arise, however, if the instructions given in paragraph 3 of this Section are followed carefully.

#### Input shaft


6 The input shaft is easily identified by its integral 1st gear pinion. Although not strictly necessary, on the project bike it was found to be easier to install the input shaft and clutch drum in the upper crankcase half as one assembly. However, if wished, the clutch drum can be installed later as described in Section 40. If the input shaft and clutch drum are to be fitted together follow the sequence below, whereas if the clutch drum is to be installed later ignore the information (and the accompanying photographs) given in paragraph 7 and proceed as described in paragraph 8 onwards.

7 Holding the left-hand (plain) end of the shaft fit the following clutch components over the


- 1 Input shaft
- 2 Ball journal bearing
- 3 Input shaft 5th gear
- 4 Splined thrust washer - 2 off
- 5 Circlip - 2 off
- 6 Input shaft 3rd/4th gear
- 7 Input shaft 6th gear
- 8 6th gear bush
- 9 Input shaft 2nd gear
- 10 Thrust washer
- 11 Needle roller bearing
- 12 Circlip
- 13 Bearing outer race
- 14 Spacer
- 15 Ball journal bearing
- 16 Thrust washer (where fitted)
- 17 Output shaft
- 18 Output shaft 2nd gear
- 19 Steel balls
- 20 Toothed washer
- 21 Circlip - 3 off
- 22 Output shaft 6th gear
- 23 Output shaft 4th gear
- 24 Toothed washer - 2 off
- 25 3rd/4th gear bush
- 26 Output shaft 3rd gear
- 27 Output shaft 5th gear
- 28 Output shaft 1st gear
- 29 Thrust washer
- 30 Needle roller bearing
- 31 Bearing outer race
- 32 Circlip








**31.7a** First fit the small thrust washer over the threaded end of the input shaft ...



**31.7b** ... followed by the large thrust washer ...



**31.7c** Fit the clutch drum centre collar with its flat surface facing the thrust washers ...


right-hand (threaded) end of the shaft. First fit the smaller thrust washer over the end of the shaft, followed by the larger thrust washer (see illustrations). On early ZX900 and ZX1000 A models where a single large chamfered thrust washer is used instead, ensure this is fitted with its chamfered edge facing the bearing. On all models install the clutch drum centre collar so that its flat face is against the thrust washer, then fit the oil pump drive gear (dogs facing right-hand end of the shaft) over the collar and turn the shaft around (see illustrations).

8 Holding the right-hand (threaded) end of the shaft fit the 5th gear pinion over the left-hand (plain) end of the shaft, ensuring that its dogs are facing left, followed by a splined thrust washer (see illustration). Slide both the gear and washer along the shaft and secure them in position with a circlip (see illustration). The double 3rd/4th gear pinion is fitted next with the smaller diameter 3rd gear towards the 5th gear pinion (see illustration). Fit the second circlip to the groove in the shaft and slide on another splined thrust washer (see illustrations).


9 Fit the splined 6th gear bush on to the shaft ensuring that the hole in the bush aligns with the oilway in the shaft (see illustration). Slide the 6th gear pinion onto the bush with its dogs facing the right-hand end of the shaft, followed by the 2nd gear pinion (see illustrations). Place the plain thrust washer




**31.7d** ... and the oil pump drive gear with its dogs facing away from the thrust washers




**31.8a** Turn the shaft around and slide on 5th gear pinion followed by splined thrust washer ...




**31.8b** ... and secure with circlip




**31.8c** Fit 3rd/4th gear with its smaller 3rd gear pinion facing 5th gear pinion ...



**31.8d** ... and fit the second circlip to the groove in the shaft ...




**31.8e** ... followed by splined thrust washer




**31.9a** Fit the splined 6th gear bush so that the hole in the bush aligns with the oilway in the shaft ...







31.9b ... then fit the 6th gear pinion ...




31.9c ... followed by the 2nd gear pinion ...



31.9d ... and the plain thrust washer



31.9e Fit the needle roller bearing to the end of the shaft and secure with circlip



31.9f Liberally oil the bearing and fit its outer race

over the shaft and fit the needle roller bearing (see illustration). Secure the needle roller bearing with a circlip and slide the bearing outer race over the end of the shaft (see illustration).


### Output shaft

10 The output shaft is easily identified due to it having no integral pinions. Holding the shaft by its left-hand (threaded) end slide the 2nd gear pinion along the shaft so that its deeper recessed surface is facing the right, followed by the toothed washer and secure them with a circlip (see illustrations). Ensure the circlip is fitted so that the teeth of the washer are not positioned between the ends of the circlip.


11 The 6th gear pinion is then fitted with its selector fork groove facing the right-hand end of the shaft and is retained by another circlip (see illustration). Slide a toothed washer along the shaft followed by the splined 3rd/4th gear pinion bush (see illustration). Ensure both the holes in the bush align with the oilways in the output shaft.

12 Slide the 4th gear pinion onto the bush, with its recessed surface facing the 6th gear pinion, followed by the 3rd gear pinion with its recessed surface facing away from the 4th gear pinion, and a toothed washer (see illustrations). Secure the 3rd gear pinion and washer with a circlip (see illustration).


13 Insert the three steel balls into the closed




31.10a Output shaft – fit the 2nd gear pinion as shown ...




31.10b ... followed by the toothed washer ...



31.10c ... and secure them with a circlip as described in text




31.11a Slide on the 6th gear pinion and fit the second circlip to the shaft




31.11b Fit a splined thrust washer and the splined 3rd/4th gear bush – ensure holes in bush align with oilways in shaft






31.12a Fit the 4th gear pinion as shown ...




31.12b ... followed by the 3rd gear pinion




31.12c Slide another splined thrust washer along the shaft ...

off drillings in the 5th gear pinion (see illustrations). Ensuring the balls remain in position, slide the 5th gear pinion on to the output shaft splines so that the steel balls in the pinion are aligned with the recesses in the shaft (see illustration).

14 Fit the 1st gear pinion with its deeply recessed surface facing the 5th gear pinion, followed by the plain thrust washer and the needle roller bearing (see illustration). Secure the needle roller bearing with the circlip and refit the outer bearing race (see illustrations).



31.12d ... and secure it with a circlip




31.13a Insert the three steel balls ...

## 32 Balancer shaft - examination and renovation


32

1 Dismantle the balancer shaft components, noting that the needle roller bearing and thrust washer fitted inside the balancer weight are a different size to the others. Check for wear as follows.


2 Examine the three needle roller bearings and thrust washers for signs of wear or damage, renewing them if necessary. Check the inside of the balancer gear/cush drive holder and the shaft itself for signs of scoring or flat spots. Such damage is only likely if the balancer shaft has been adjusted incorrectly or if a high mileage has been covered. Also check the balancer gear for wear or damage




31.13b ... into the closed-off drillings (arrowed) in 5th gear pinion




31.13c Refit the 5th gear pinion so that the balls in the pinion align with the recesses in the shaft



31.14a Slide on the 1st gear pinion followed by a plain thrust washer



31.14b Fit needle roller bearing and secure with circlip




31.14c Lubricate the bearing and fit the bearing outer race

<http://manuals.motoman.co.uk>






**32.4a** Use grease to hold the cush drive rubbers in position



**32.4b** On reassembly position punch marks (arrowed) as described in text



**32.5** Ensure shouldered washers are fitted with their shoulders facing the balancer assembly

such as chipped teeth. If damage of any kind is discovered the only satisfactory means of repair is to renew the damaged components.

**3** Examine the rubber segments of the cush drive for wear or deterioration. Any damage will be self evident and the rubbers must be renewed as a set. Renew the balancer shaft oil seal as a matter of course and reassemble the balancer as follows.

**4** With the balancer gear/cush drive housing stood vertically on its gear, fit the first thrust washer to the inside of the housing followed by a needle roller bearing and a second thrust washer. Apply a small amount of grease to the backs of the cush drive rubbers and position them in the housing (see illustration). Fit the balancer weight to the holder noting that the punch mark on the balancer weight must be positioned directly opposite the punch mark on the housing (see illustration). Ensure the rubbers remain in position as the weight is fitted.

**5** Place a thrust washer inside the balancer weight, followed by a needle roller bearing and then fit the large shouldered thrust washer over the end of the weight. Turn the shaft around and fit the thrust washer, needle roller bearing and shouldered thrust washer to the gear end of the assembly. Ensure that both shouldered thrust washers are fitted with their shoulders facing the balancer assembly (see illustration).

### 33 Engine reassembly - general


**1** Before reassembly of the engine/gearbox unit is commenced, the various component parts should be cleaned thoroughly and placed on a sheet of clean paper, close to the working area.

**2** Make sure all traces of old gaskets have been removed and that the mating surfaces are clean and undamaged. Great care should be taken when removing old gasket compound not to damage the mating surface. Most gasket compounds can be softened using a suitable solvent such as methylated spirits, acetone or cellulose thinner. The type

of solvent required will depend on the type of compound used. Gasket compound of the non-hardening type can be removed using a soft brass-wire brush of the type used for cleaning suede shoes. A considerable amount of scrubbing can take place without fear of harming the mating surfaces. Some difficulty may be encountered when attempting to remove gaskets of the self-vulcanising type, the use of which is becoming widespread, particularly as cylinder head and base gaskets. The gasket should be pared from the mating surface using a scalpel or a small chisel with a finely honed edge. Do not, however, resort to scraping with a sharp instrument unless necessary.

**3** Gather together all the necessary tools and have available an oil can filled with clean engine oil. Make sure that all new gaskets and oil seals are to hand, also all replacement parts required. Nothing is more frustrating than having to stop in the middle of a reassembly sequence because a vital gasket or replacement has been overlooked. As a general rule each moving engine component should be lubricated thoroughly as it is fitted into position.

**4** Make sure that the reassembly area is clean and that there is adequate working space. Refer to the torque and clearance settings wherever they are given. Many of the smaller bolts are easily sheared if overtightened. Always use the correct size screwdriver bit for the crosshead screws and never an ordinary screwdriver or punch. If the existing screws



**34.1a** Refit the selector drum to the casing




**34.1b** Position the left-hand selector fork and insert the selector fork shaft until it engages with the fork . . .


### 34 Lower crankcase components - refitting

**1** Insert the selector drum into the crankcase half and push it fully into position so that its bearing is flush with the casing (see illustration). Partially insert the selector fork shaft in the casing and, using the notes made on dismantling, locate the left-hand selector fork in its groove in the selector drum (see illustration). Push the selector fork shaft in until it engages with the fork then repeat the






**34.1c ... then repeat the process for the centre ...**



**34.1d ... and right-hand fork and push the selector fork shaft fully in**




**34.1e Apply thread locking compound to selector drum retaining plate bolts and refit the plate**


process on the centre and right-hand forks and push the shaft fully home (see illustrations). Refit the selector drum retaining plate and tighten its retaining bolts securely having first applied a few drops of thread-locking compound to their threads (see illustration).

**2** Fit the washer over the gearchange detent arm stud followed by its return spring (see illustrations). Ensure that the correct return spring is fitted, referring to Section 14 for further information. Locate the detent arm with the return spring and push it onto its stud. Refit the shouldered spacer, ensuring that the shoulder correctly engages with the detent arm, and tighten its retaining nut securely (see illustration). Check that the detent arm is free to move and repeat the above sequence for the neutral detent arm. Rotate the selector drum until it is in the neutral position, ie neutral (upper) detent arm engaged with its cutout in the selector drum.


**3** Hold the balancer weight assembly in position, ensuring that both the shouldered washers are in place, and insert the balancer shaft from the right-hand side of the casing. Push the balancer shaft fully into position and check that the weight spins freely on the shaft (see illustration). On ZX1000 B and ZX1100 C/D models, refit the balancer shaft guide pin and retaining plate (see illustration). Apply a few drops of thread-locking compound to its retaining bolt and tighten it securely (see illustration). Also refit the thrust washer over



**34.2a Fit plain washer over detent arm stud followed by return spring**




**34.2b Locate the detent arm with the return spring ...**




**34.2c ... refit the shouldered spacer as shown and tighten its retaining nut securely**




**34.3a Position the balancer weight assembly in the casing and refit the shaft**



**34.3b On ZX1000 B and ZX1100 C/D models insert the balancer shaft guide pin ...**




**34.3c ... and secure it with retaining plate and bolt; apply thread-locking compound to the bolt**




**34.3d Refit the thrust washer (ZX1000 B and ZX1100 C/D only) ...**






**34.3e** ... and fit a new balancer shaft oil seal



**34.4a** Position the balancer shaft as described in text ensuring that the punch mark (arrowed) is at the front



**34.4b** Install the balancer shaft clamp and tighten its mounting and pinch bolts securely

the end of the balancer shaft (**see illustration**). On all models apply a small amount of grease to the lips of the oil seal and press it into position so that it is flush with the casing (**see illustration**). If necessary the seal can be tapped in using a hammer and suitably sized socket which bears only on the hard outer edge of the seal.

**4** Position the shaft so that the line on the shaft is horizontal (with the punch mark at the front) and install its mounting clamp (**see illustrations**). Tighten both the clamp mounting and pinch bolts securely. Note that the balancer shaft will need adjusting when the engine is first started.

**5** Ensuring that each is in its correct position, refit the five main bearing inserts into the

casing and main bearing cap. Check that all the insert locating tangs are correctly seated in their recesses and lubricate all inserts with clean engine oil.

### 35 Upper crankcase components - refitting




**Note** - The manufacturer advises that the big-end bolts be renewed on installation due to them having stretched in service.


**1** Fit the big-end bearing inserts to the connecting rods and big-end caps, ensuring that the locating tang of each insert is fitted correctly into its recess. On ZX1000 and

ZX1100C models smear molybdenum-disulfide grease over the outer surface of the connecting rod insert. *Do not apply any grease to the inner surface of the connecting rod insert or to either surface of the big-end cap insert.* On ZX1000 B models measure the length of each big-end cap bolt and make a note of this (**see illustration**). On all models, lubricate the crankpins with clean engine oil, refit each rod to its original crankpin and fit the big-end cap (**see illustration**). Use the marks made on dismantling or the weight group letter to ensure that the caps are correctly aligned with their respective rods and that the rods are refitted the same way round as before.


**2** Fit the cap nuts and tighten them by hand only, then tighten the nuts evenly to their specified torque setting (**see illustration**). On ZX1000 and ZX1100 C/D models the nuts must then be tightened a further 120° more (**see illustration**). On ZX1000 models, once the nuts have been fully tightened it is necessary to check that the bolts have not stretched excessively. On ZX1000 A models this is checked by measuring the length of the bolt which protrudes above the top surface of the nut. If more than 0.8 mm (0.03 in) of the bolt is visible, the nut and bolt must be removed and renewed. On ZX1000 B models measure the length of each bolt after it has been tightened and compare this with the measurement taken earlier (**see illustration**).




**35.1a** On ZX1000 B models note the length of big-end cap bolts before installation




**35.1b** Lubricate the crankpins and refit each connecting rod to its original crankpin



**35.2a** Tighten big-end cap bolts to their specified torque setting ...




**35.2b** ... and on ZX1000 A and ZX1100 C/D models a further 120° more




**35.2c** On ZX1000 B models measure big-end cap bolt length after tightening to ensure they are not overstretched






**35.3a Fit the main bearing inserts to the casing . . .**



**35.3b . . . and refit the crankshaft assembly**



**35.3c Refit the main bearing cap – ensuring arrow cast in top surface points forwards**

If any bolt has stretched by more than 0.31 mm (0.012 in) where an old connecting rod is fitted, or by 0.37 mm (0.014 in) where a new rod is fitted, it must be removed and a new nut and bolt fitted. This procedure ensures the new nuts and bolts that are fitted are of the required standard and eliminates the possibility of fitting a faulty bolt which could fail in use with disastrous consequences. On all models check that the rods revolve smoothly and easily around their crankpins. Some stiffness is inevitable if new inserts have been fitted, but this must not be excessive.


**3** Ensuring that all are in their correct places, refit the five main bearing inserts in the crankcase half (**see illustration**). Check that the insert locating tang of each bearing is correctly located in its recess and lubricate all

bearing inserts with clean engine oil. Use an oil can to prime the oilways of both crankcase halves and the crankshaft and lower the crankshaft into position in the top half of the casing, ensuring that the connecting rods pass through the crankcase mouth (**see illustration**). Refit the main bearing cap, ensuring that the two locating dowels are in position and the arrow on the cap is facing forward, and evenly tighten its retaining bolts to the specified torque setting (**see illustration**). Check that the crankshaft revolves smoothly and easily.


**4** Position the starter clutch assembly in the crankcase (driven gear facing the right-hand side of the casing) and insert the shaft from the right-hand side of the crankcase half (**see illustration**). Locate the starter clutch on the

shafts splines and push the shaft fully into position. Refit the alternator cush drive coupling to the left-hand end of the shaft and tighten its retaining bolt to the specified torque setting (**see illustration**). Hold the starter clutch idler gear in position and insert its shaft into the casing (**see illustration**). Refit the oil spray tube (ZX1100 C/D models only) and tighten the idler gear shaft retaining bolt securely (**see illustration**).

**5** Refit the two half ring retainers and the locating pins to the casing (**see illustration**). If the clutch drum is being installed with the input shaft, fit the needle roller bearing (ZX1100 C/D models only) and clutch drum to the clutch centre collar making sure that the dogs on the oil pump drive gear engage with the slots in the back of the drum (**see illustration**). Fit the input




**35.4a Position the starter clutch in the crankcase and insert its shaft**




**35.4b Refit the alternator coupling and tighten its retaining bolt to the specified torque setting**




**35.4c Fit the starter clutch idler gear and insert its shaft**



**35.4d On ZX1100 C/D models the idler gear retaining bolt also retains an oil spray tube**




**35.5a Do not omit half ring retainers or locating pins**




**35.5b Fit large needle roller bearing (ZX1100 C/D only) and slide clutch drum onto the input shaft**







**36.5c** Ensure recesses in bearing races engage correctly with locating pins



**36.1a** Use ignition rotor to position crankshaft as described in text . . .



**36.1b** . . . and position balancer shaft so that its punch mark is aligned with centre of adjacent hole



**36.1c** Do not omit the two crankcase dowels from the upper casing

shaft assembly to the upper crankcase half ensuring that the locating peg on the left-hand side of the casing engages with the hole in the outer needle bearing race of the shaft, and the half ring retainer locates in the groove in the outer race of the ball journal bearing on the opposite end of the shaft (see illustration). Install the output shaft assembly again ensuring that both the locating peg and half ring retainer engage correctly with their respective hole or slot on the shaft assembly. Oil all gearbox components, position the gears in neutral and check that each shaft rotates smoothly and easily.

### 36 Joining the crankcase halves




**1** Check that all components are refitted and that they are revolving or sliding smoothly and easily. Use a rag soaked in high flash-point solvent to wipe over the gasket surfaces of both halves to remove all traces of oil. Ensure that the gear selector and gearbox components are in the neutral position and that the crankshaft is positioned with cylinders 1 and 4 at TDC. This can be achieved by temporarily fitting the ignition rotor to the left-hand end of the crankshaft and aligning the T 1.4 mark with the line cast on the casing (see illustration). Position the balancer weight so that the punch mark on its weighted portion is aligned with the centre of the adjacent oil passage hole in the casing

(see illustration). Refit the two dowel pins to the upper crankcase half (see illustration).


**2** Apply a thin film of jointing compound to both the upper and lower crankcase faces. Take great care to leave a narrow margin around any oilways and the main bearing inserts so that there is no risk of any surplus compound blocking an oilway. Note - on ZX1100 C/D models do not apply any compound to the small area of either casing which is between the input and output gearbox shafts on the left-hand side.

**3** Ensuring that the main bearing inserts are in position, and all the components are positioned as described in paragraph 1, carefully lower the lower crankcase half onto the upper half (see illustration). Ensure the selector forks engage with their respective slots in the gearbox and the balancer weight remains in position as the halves are joined (see illustration). Check that the lower crankcase half is correctly seated and that all components are free to rotate. Refit all the lower crankcase bolts, using the cardboard template to ensure each bolt is refitted in its correct position. Note - do not omit the washers fitted to the three centre main bearing bolts (numbers 1 to 3 on the casing). Tighten all bolts finger-tight.


**4** The tightening order for the nine main bearing bolts is indicated by the numbers cast in the casing next to each bolt. Working in this sequence, tighten the main bearing bolts first to their initial torque setting, and then to their final torque setting (see illustrations). Both



**36.3a** Apply jointing compound to the crankcase mating surfaces (see text) and join crankcase halves . . .



**36.3b** . . . whilst ensuring the selector forks engage correctly with slots in gear pinions



**36.4a** Tighten main bearing bolts to their specified torque setting . . .




**36.4b** . . . using the numbers stamped on the lower crankcase half






**37.3a Refit dowels to the crankcase and position a new gasket over them**



**37.3b Refit the gearchange casing**



**37.3c On ZX1100 C/D models apply threadlocking compound to four bolts arrowed**

torque settings are given in the specifications at the start of this Chapter. Then tighten the 7 mm bolt (ZX1100 C/D and late ZX900 A7-on models only), followed by all the 6 mm bolts, to their specified torque settings. Refit the upper crankcase bolts, again using the cardboard template to ensure each bolt is refitted in its original position. **Note** - on ZX1100 C/D and late ZX900 A 7-on models do not omit the washer from the front 8 mm bolt. First tighten the 8 mm bolts, then the 6 mm bolts, to their specified torque settings.

5 Check that the crankshaft rotates smoothly and easily, as should the gearbox shafts. It is impossible to select any gears other than 1st or neutral unless the output shaft can be spun fast enough to disengage the neutral finding mechanism. If there are any signs of undue stiffness or of any other problem, the fault must be rectified before work can proceed further. Plug the crankcase mouths with clean rag to prevent debris entering the crankcase until the cylinder block has been refitted.

### 37 Gearchange components - refitting




### 38 Alternator and starter motor - refitting



1 Clean the three alternator mounting points on both the crankcase and the alternator itself. This is most important as the mounting points are used to earth the alternator. Failure to earth the alternator properly will almost certainly lead to it being damaged.


2 Insert the cush drive rubbers into the coupling on the shaft and fit a new O-ring to the alternator (see illustration). Apply engine oil to the O-ring and cush drive rubbers to aid the refitting procedure. Refit the alternator to its drive coupling ensuring that the rubber segments of the cush drive remain in position and engage correctly with the alternator (see illustration). Apply a thread-locking compound to the alternator mounting bolts



**38.2a Refit cush drive rubbers to the alternator coupling**



**38.2b Refit alternator - apply threadlocking compound to its bolts and tighten to specified torque setting**




**38.3 Apply engine oil to starter motor O-ring and install starter motor, tightening its bolts securely**

1 The neutral and gear position detent arms are refitted as described in Section 34 of this Chapter.


2 Check that the locating post for the gearchange shaft return spring is secure. If it is loose remove the post, apply a threadlocking compound to its threads, refit it and tighten it securely. Ensure that the circlip and washer are fitted to the gearchange shaft and offer up the gearchange to the casing. As the shaft is fitted, ensure that the selector claw engages correctly with the end of the selector drum, and that the return spring engages correctly with its locating post. Check that the gearchange shaft moves easily and centralises quickly with the pressure of the return spring.

3 Refit the two dowels to the crankcase and place a new gasket over them (see illustration). Apply a small amount of grease to the lips of the output and gearchange shaft







39.1a Refit the dowel to the underside of the crankcase ...




39.1b ... and install the oil nozzle so that its small hole faces the oil pump bracket and fit a new O-ring



39.1c Ensure the slots in oil pump drive gear and water pump are vertical ...



39.1d ... install the oil pump and bracket assembly ...




39.1e ... and tighten its mounting bolts securely

### 39 Oil pump and sump - refitting


**1** If removed, refit the oil nozzle and dowel to the underside of the crankcase, noting that the small hole of the nozzle must be facing the oil pump bracket (see illustration). Fit a new O-ring over the oil nozzle (see illustration). Ensure that the slots in the oil pump drive gear and the water pump shaft (as necessary) and the projections on the oil pump shaft are all positioned vertically (see illustration). Install the oil pump and mounting bracket assembly ensuring that the slots on the oil pump shaft engage with the slots in the drive gear and water pump. Refit the three oil pump bracket mounting bolts and tighten them securely (see illustration).

**2** Fit new O-rings to both of the metal oil pipes and the oil screen (see illustration). Smear the O-rings with engine oil and refit the metal oil pipes to the bottom of the crankcase, followed by the black plastic pipe and the oil screen (see illustrations).


**3** Ensure the dowel is in position and fit the two new O-rings to the oil pump bracket, using a smear of grease to retain them (see illustration). Note that the flat surface of the smaller O-ring must face the bracket. On ZX900 A7-on and ZX1100 C/D models apply




39.2a Renew all O-rings on the metal oil pipes ...




39.2b ... and refit them to their original positions in the crankcase ...



39.2c ... along with the plastic pipe ...




39.2d ... and oil screen - ZX1100 C/D shown



39.3a Ensure that dowel is in position and fit two new O-rings to the oil pump bracket





**39.3b** Apply sealant to the shaded areas (1) of sump and crankcase on refitting


silicone sealant to both the crankcase and sump in the area shown (**see illustration**). On all models fit a new sump gasket, using a dab of grease to retain it. Place a new O-ring in the groove around the oil filter chamber and refit the sump to the engine unit (**see illustrations**).

4 Apply thread-locking compound to the threads of the four sump bolts that are fitted next to the triangular marks cast in the sump and refit all sump bolts, along with any oil hose or electrical guides, using the notes made on dismantling (**see illustration**). Tighten all sump bolts securely.

5 Refit the oil filter assembly, using a new filter element as described in Chapter 1 and tighten its retaining bolt to the specified



**39.3c** Fit a new O-ring around the oil filter chamber in the sump ...



**39.3d** ... fit a new gasket to the crankcase ...

torque setting. Also refit both drain plugs, renewing their sealing washers if necessary, and tighten them to the specified torque setting. Offer up the metal oil pipe which links the sump to the crankcase and position a new sealing washer on each side of its unions (**see illustration**). Refit the union bolts and tighten them to the specified torque setting.

## 40 Clutch - refitting




1 If not fitted previously (**see Section 31**), install the clutch drum as follows. First fit the small thrust washer to the input shaft,

followed by the large thrust washer (**see illustration**). On early ZX900 and ZX1000 A models where a large chamfered washer is used, ensure this is fitted with its chamfered face pointing inwards. On all models, fit the oil pump drive gear next, so that its dogs are facing outwards (**see illustration**). Offer up the clutch drum ensuring that it engages correctly with the oil pump dogs and refit its needle roller bearing (ZX1100 C/D models only) (**see illustration**). Hold the clutch drum in position and slide the clutch drum centre collar, with its flat surface facing inwards, along the input shaft and into the clutch drum (**see illustration**).


2 Refit the large plain thrust washer, slide the clutch centre into place followed by the large




**39.3e** ... and refit the sump




**39.4** Apply thread-locking compound to the four sump bolts fitted next to triangular marks on sump




**39.5** Fit a new sealing washer on each side of the metal oil pipe union



**40.1a** Fit the small and large thrust washers ...




**40.1b** ... and the oil pump drive gear




**40.1c** Locate the clutch drum on the oil pump drive gear dogs ...






40.1d ... refit the needle roller bearing (ZX1100 C/D models only) ...




40.1e ... and install the clutch drum centre collar




40.2a Fit the large plain washer ...




40.2b ... and refit the clutch centre




40.2c Fit the large washer and a new clutch centre nut and tighten it to the specified torque setting




40.3a Last clutch friction plate must be installed with its tang in the smaller slots in the clutch drum




40.3b Where clutch friction plates have diagonal grooves, install as shown



40.4a On ZX1000 and ZX1100 C/D models refit the pushrod ...



40.4b ... followed by the needle roller bearing, plain thrust washer ...




40.4c ... and cup

washer (see illustration). Fit a new clutch nut and tighten it to the specified torque setting whilst holding the clutch centre in the same manner as was used during dismantling (see illustrations).


3 If new clutch plates are to be fitted, apply a coating of oil to their surfaces to prevent seizure. Fit the clutch plates alternately, starting with a friction plate, noting that the last friction plate must be fitted with its tangs in the smaller slots of the clutch drum (see illustration). Note on models where the grooves in the friction plates are cut diagonally, as opposed to straight, across the friction material, they must be installed as shown (see illustration).

4 On ZX900 models insert the pushrod into the centre of the input shaft ensuring that its flat end is facing outwards. On ZX1000 and ZX1100 C/D models apply a small amount of molybdenum-disulfide grease to the inner end of the mushroom headed pushrod and insert it into the input shaft (see illustration). Refit the needle roller bearing to the pushrod followed by the thrust washer and cup (see illustrations). On all models ensure the pushrod is in the fully retracted position and fit the clutch pressure plate (see illustration). Refit the clutch springs and bolts, tightening them evenly and progressively to their specified torque setting (see illustrations). If necessary, refit the right-hand crankcase cover as described in Section 41.






40.4d Refit the pressure plate ...



40.4e ... and the clutch springs and bolts ...



40.4f ... and tighten them evenly and progressively to their specified torque setting


#### 41 Alternator/starter clutch drive components - refitting




1 Refit the cush drive rubbers to the outer section of the coupling and insert the inner coupling section whilst ensuring the rubbers remain in position (see illustration). Fit the cush drive assembly and the sprocket to the drive chain. Offer up the assembly to the engine unit and slide the cush drive and sprocket onto their splined shafts simultaneously (see illustration). Refit the retaining nut and washer to the cush drive shaft and the bolt and flat washer to the crankshaft (see illustrations). Tighten both to their specified torque settings whilst holding the cush drive coupling with the special tool.

2 Refit the chain guide over its locating stud and insert the collar and washer in the guide (see illustrations). Apply a thread-locking compound to the chain guide retaining bolt and tighten it securely (see illustration).

3 Compress the tensioner blade and lock up the tensioner by pushing up its locking plate. Stick the flat washer (where fitted) to the upper tensioner bolt hole on the crankcase using a smear of grease (see illustration). Apply a few drops of thread-locking compound to the tensioner mounting bolts and offer up the tensioner to the crankcase




41.1a Fit cush drive rubbers and reassemble the coupling



41.1b Fit the drive sprocket and coupling to the chain and install as an assembly




41.1c Refit the nut and washer which retains the coupling ...




41.1d ... and the bolt and washer which retain the sprocket and tighten both to their specified torque settings



41.2a Fit the chain guide over its locating stud ...




41.2b ... refit its collar ...




41.2c ... washer and bolt - apply thread-locking compound to the bolt and tighten it securely






41.3a Use grease to stick the washer to the crankcase




41.3b Lock up the chain tensioner, apply thread-locking compound to its bolts and tighten securely...



41.3c ... then release the tensioner locking plate



41.4a On ZX1000 B and ZX1100 C/D apply silicone sealant as described in text before fitting new gasket



41.4b Apply thread-locking compound to the four front casing bolts

(see illustration). Refit the mounting bolts, ensuring the top bolt passes through the washer (where fitted), and tighten them securely. Release the tensioner blade by pulling down on the locking plate (see illustration).

4 Ensure the mating surfaces of the clutch cover and crankcase are clean and dry. On ZX1000 B and ZX1100 C/D models apply a smear of silicone sealant to the crankcase side of the clutch gasket surface to cover the area which is approximately 3.5 mm each side of the crankcase mating points (see illustration). On all models fit a new gasket, using a smear

of grease to hold it in place if necessary, and offer up the right-hand crankcase cover. Apply thread-locking compound to the four front cover retaining bolts (see illustration) and refit all the cover bolts along with any relevant hose guides. Tighten all the crankcase cover retaining bolts securely.


## 42 Pistons, cylinder block and head - refitting



1 Refit the rings to the pistons using the method employed on dismantling and position them as follows. The oil expander ring is fitted first and positioned so that its ends butt together at the back of the piston. The side rails are then fitted on each side of the oil expander ring. Position the side rails so that the end of one rail is approximately 30 - 40° from the front


of the piston on one side, and the end gap of the other rail is 30 - 40° from the front of the piston on the opposite side (see illustration). The second compression ring will have one surface marked 2N, this must be fitted with the 2N mark facing upwards and with its end gap at the back of the piston (see illustration). On ZX1000 and ZX1100 C/D models the top compression ring will have an N mark on its upper surface and must be fitted accordingly. On ZX900 models the top ring is not marked and when new can be fitted either way. However, if an old ring is being re-used it must be refitted the original way up, this being revealed by the wear marks. On all models position the top compression ring so that its end gap is at the front of the piston.

2 Check that each piston has one new circlip fitted to it and insert the gudgeon pin from the opposite side. If it is a tight fit, the piston should be warmed as described in Section 9. If the original pistons are being refitted, use the marks made on dismantling to ensure that each piston is refitted to its original bore. Lubricate the gudgeon pins, piston bosses and connecting rod small-ends and lower each piston in turn over its respective rod. Push the gudgeon pin through both piston bosses and the connecting rod small-end. If necessary the pins can be tapped carefully into position, using a hammer and suitable drift, whilst supporting the piston and connecting rod. Secure each gudgeon pin with a second new circlip, ensuring that it is correctly seated in its groove (see illustrations). Refit the two dowels to the crankcase mouth and stick the base gasket to the bottom of the block using a




42.1a Piston ring gap positions

- 1 Top compression ring
- 2 Second compression ring
- 3 Oil expander ring side rails
- 4 Oil expander ring



42.1b Compression rings are identified by the mark on their top surface



42.2a Ensure pistons are fitted with the arrow pointing forwards






42.2b Insert the gudgeon pin into the piston ...



42.2c ... and secure it with a new circlip



42.3 Cylinder block refitting can be made easier by supporting the pistons as shown

smear of grease. Remove any rag used to plug the crankcase mouths.


3 Lubricate the pistons and the surface of the cylinder bores with clean engine oil. It is advisable to enlist the help of an assistant to refit the block. It also helps to support the base of each piston and to position all pistons at the same height. In the absence of the correct Kawasaki service tool, this can be achieved using two long wooden dowels or metal bars (*see illustration*). Take great care to avoid damaging the crankcase gasket surface in the process.

4 The cylinder bores have a generous lead-in for the pistons at the bottom, although on a multi-cylinder engine such as this it would be an advantage to use the special Kawasaki piston ring compressors. In the absence of these it is possible to lead the pistons into the bores gently, working across from one side to the other, guiding in one ring at a time whilst gently tapping on the cylinder block. Great care has to be taken not to put too much pressure on the piston rings as they are easily broken. The above process takes time and patience and must not be rushed. Once all the piston rings have entered the bore remove the piston supports and fit the base gasket over both the dowel pins. Push the cylinder block down until it seats firmly on the base gasket and refit the two block retaining bolts to the underside of the block. Tighten the bolts finger-tight only at this stage. Check that the crankshaft can be rotated smoothly whilst holding the block down and keeping the camchain (if fitted at this stage) taut.

5 Refit the camchain guide to the front of the block ensuring that its lugs are correctly located in the slots in the block (*see illustration*). Refit the two dowels to the cylinder block and place a new cylinder head gasket over them (*see illustration*). **Note** - if the work is being carried out with the engine unit in the frame, on ZX900 models it will be necessary to fit the four cylinder head bolts and washers (numbers 3 to 6 in the tightening sequence) to the cylinder head before fitting the head on the barrels. The same applies on ZX1000 B and ZX1100 C/D models to the left-hand camshaft cap, which along with its dowels and bolts, must also be fitted to the cylinder head prior to installation. The above measures are necessary due to the fact that once the cylinder head is installed there is insufficient clearance between the cylinder head and the frame to insert the bolts.



42.5a Refit camchain guide to the block ...



42.5b ... fit a new head gasket ...



42.6a ... and lower the cylinder head assembly onto the block




42.6b Flat-headed cylinder head bolts are fitted to the four outer holes ...




42.6c ... and tapered-headed bolts are fitted to the six inner holes







42.7a Cylinder head bolt tightening sequence



42.10 On ZX1000 B and ZX1100 C/D models refit the shims to the valves using the notes made on dismantling



43.1a Stick the tensioner rear washer to the crankcase with a smear of grease ...




43.1c Insert the tensioner blade collar ...


7 Using the tightening sequence, tighten the cylinder head bolts to their initial specified torque setting, and then to their final specified torque setting (see illustration). Once all the cylinder head bolts have been tightened, tighten the three cylinder head/block retaining bolts to their specified torque settings.

8 On ZX1000 B and ZX1100 C/D models refit the flexible oil pipe which runs down the right-hand side of the cylinder block to its union on the cylinder head. Fit a new sealing washer to the union bolt and position a new collar behind the bottom union of the pipe. Refit the union bolt and tighten it to its specified torque setting.


9 On ZX900 and ZX1000 A models offer up the main oil pipe to the front of the engine unit and fit its retaining bolt finger-tight only.



43.1b ... and lower the tensioner blade into position from top of cylinder head



43.1d ... and refit the retaining bolt having first applied a thread-locking compound




42.7b Tighten cylinder head bolts to the specified torque setting as described in text

Position a new sealing washer on each side of its three unions and refit the union bolts. Tighten all the union bolts to the specified torque setting and then tighten the oil pipe retaining bolt securely. Using the notes made on dismantling, refit the oil pipe to the inside of the cylinder head. Refit its union bolts, ensuring that they are correctly positioned, and tighten them to the specified torque settings. If the engine unit is in the frame refit the two cylinder head to frame mounting bolts, not forgetting the shim (where fitted) which is fitted between the left-hand side of the cylinder head and the frame, and tighten them to the specified torque setting.

10 Finally, on all models tighten the drain plugs at the front of the block to their specified torque setting, and on ZX1000 B and ZX1100 C/D models refit the shims to their respective valves using the notes made on dismantling for identification (see illustration).

### 43 Camchain and tensioner blade - refitting


1 Stick the camchain tensioner blade rear washer to the crankcase using a smear of grease (see illustration). Insert the tensioner blade into the top of the cylinder head, lowering it down the camchain tunnel and into position, and refit the sleeve to the tensioner blade bolt hole (see illustration). Refit the flat




43.2a Lower the camchain down through the cylinder head ...

43.2a






**43.2b** ... fit it to the crankshaft sprocket and refit the chain guide



**44.1a** Apply thread-locking compound to the pulser coil mounting bolts and install them finger-tight




**44.1b** Fit the ignition rotor to the crankshaft and refit the hexagonal nut and retaining bolt

washer to the tensioner blade retaining bolt and apply a few drops of thread-locking compound to the threads of the bolt (see illustration). Refit the bolt to the bottom of the tensioner blade, ensuring that it passes through the washer positioned between the blade and the casing, and tighten it to the specified torque setting.

**2** Feed the camchain down through the camchain tunnel and over the end of the crankshaft (see illustration). Engage the chain on its drive sprocket, refit the metal camchain guide, and tighten its two retaining bolts securely (see illustration).

#### 44 Ignition rotor components - refitting

**1** Offer up the pulser coil(s) and refit their mounting bolts finger-tight only, having first applied a few drops of thread-locking compound to their threads (see illustration). Refit the locating pin (if removed) in the end of the crankshaft and fit the ignition rotor. Ensure the rotor is fitted with its marked surface facing outwards. Refit the rotor retaining bolt along with the large hexagon nut ensuring that the peg in the back of the nut locates with the cutout in the ignition rotor (see illustration). Tighten the ignition rotor retaining bolt to the specified torque setting whilst holding the large hexagon nut to prevent the crankshaft from rotating (see illustration).



**44.1a** On ZX1000 B and ZX1100 C/D models do not omit the shaft retaining springs ...


**2** Working as described in Chapter 5, set up the pulser coil/ignition rotor clearance and tighten the pulser coil mounting bolts securely.

#### 45 Camshafts refitting and setting the valve timing

**1** If removed, refit the cam followers as follows. Lubricate the cam follower shaft and followers with clean engine oil and fit new O-rings to the cam follower shaft retaining bolts. Partially insert the cam follower shaft and using the notes made on dismantling, position the left-hand spring and follower in the cylinder head. Push the cam follower shaft in until it locates with the spring and follower and repeat this procedure until all the followers and springs are correctly refitted and the shaft is fully home. If necessary repeat the above procedure for the opposite shaft. On ZX1000 B and ZX1100 C/D models insert the shaft retaining springs into the cylinder head and stick a new sealing washer to the oil union points using a smear of grease. Offer up the oil pipe union, refit its union bolts and tighten them to the specified torque setting (see illustrations). On ZX900 and ZX1000 A models refit the Allen bolts which secure the cam follower shafts in position and tighten them to the specified torque setting.




**45.1b** ... and use a new sealing washer when refitting oil pipe union



**44.1c** Tighten the rotor retaining bolt to the specified torque setting


**2** If removed, refit the camshaft sprockets to the camshafts, using the notes made on dismantling for guidance (see Section 6, paragraph 5 of this Chapter). Apply a few drops of thread-locking compound to the threads of the sprocket mounting bolts and tighten them to the specified torque setting. Hold the camchain taut and rotate the crankshaft until the T 1.4 mark on the ignition rotor aligns with the line cast in the crankcase casing (see illustration).

**3** To ensure correct valve timing it is essential that the exhaust camshaft is correctly fitted. With the crankshaft positioned as described above and the front of the camchain held taut, engage the exhaust camshaft sprocket with the camchain and refit the exhaust camshaft to the cylinder head so that the EX mark next to the scribed line on the camshaft sprocket is




**45.2** Hold the camchain taut and rotate the crankshaft to the T 1.4 position







**45.3a** Hold the front of the camchain taut and refit the exhaust camshaft ...



**45.3b** ... so that the EX mark is level with the cylinder head surface (ZX1000 B and ZX1100 C/D shown)



**45.4a** Count back the required number of pins and refit the inlet camshaft (ZX1000 B and ZX1100 C/D shown) ...



**45.4b** ... so that the IN mark is level with the cylinder head surface (ZX1000 B and ZX1100 C/D shown)

level with the front surface of the cylinder head (see illustrations).

**4** The positioning of the inlet camshaft is determined by counting the number of camchain linkpins between the aforementioned EX mark on the exhaust camshaft sprocket, and the IN mark next to the scribed line on the inlet camshaft sprocket (see illustrations). On ZX900 and ZX1000 A models the IN mark should be between the 35th and 36th pin after the EX mark, and on ZX1000 B and ZX1100 C/D models it should


be between the 30th and 31st pins. Count back the required number of pins from the EX mark and mark the correct position of the IN mark on the camchain with a spirit-based marker. Engage the inlet camshaft sprocket with the camchain, ensuring that the IN mark next to the scribed line is aligned with the mark on the camchain, and refit the camshaft to the cylinder head. The IN and EX marks next to the scribed lines should be in alignment with the cylinder head surface in this position. Note also the position of the sprocket securing bolts as an indication of correct alignment; these should be as shown (see illustration). Where two sets of bolt holes are drilled in the sprocket, the bolts on the exhaust camshaft will be in the holes with the circular surround, and those on the inlet camshaft will be in the holes with the square surround.

**5** Lubricate the camshaft and bearing caps with clean engine oil and refit all the bearing cap dowels to the cylinder head (see illustration). Install the bearing caps in their original positions, using the numbers cast on the top surface of each cap, and ensuring the arrow (also cast on the top surface of each cap) is pointing towards the front of the engine unit (see illustration). Refit the camshaft cap retaining bolts and, working in sequence, tighten them evenly and progressively to their specified torque setting (see illustration).

**6** With both camshafts secured, recheck the valve timing. With the front and top runs of the chain taut, and the crankshaft in the T 1.4 position, check that the scribed lines next to the EX mark on the exhaust camshaft and the IN mark on the inlet camshaft are parallel with the top surface of the cylinder head. If this is not the case there is no need to worry unless the difference is in the order of one or more camchain links, in which case repeat the above procedure to check.

**7** Once the camshafts are correctly positioned refit the top camchain guide to the cylinder head (see illustration). On ZX1000 B and ZX1100 C/D models apply a thread-locking compound to the threads of its retaining bolts and tighten them securely, whilst on ZX900 and ZX1000 A models refit the bolts and tighten them to the specified torque setting. Install the camchain tensioner as follows.

**8** On ZX900 A1 to A6 and ZX1000 A models remove the cap bolt. Fit new O-rings to both the cap bolt and tensioner body. Insert a screwdriver into the back of the tensioner body and turn the screwdriver in a clockwise direction whilst pushing the pushrod back into the tensioner body until the end of the pushrod is approximately 10 mm from the inner surface of the tensioner body. Keeping the screwdriver in position, refit the tensioner assembly to the engine unit, ensuring the arrow cast on the tensioner body is pointing



**45.4c** Valve timing marks

1 Exhaust camshaft 2 Inlet camshaft




**45.5a** Refit camshaft cap dowels to the cylinder head



**45.5b** ... and install the bearing caps using the arrows and numbers cast into the top surface






45.5c Camshaft cap bolt tightening sequence

upwards (see illustration). Push the tensioner hard against the cylinder block, remove the screwdriver, and refit its mounting bolts finger-tight only. **Note** - at no point should the tensioner body be allowed to come away from


the cylinder block. If pressure is released on the tensioner and it is pushed away from the block, the tensioner must be removed and the whole installation procedure repeated. Once the tensioner is correctly installed, tighten its mounting bolts to the specified torque setting, refit the cap bolt and tighten it securely.

**9** On ZX900 A7-on, ZX1000 B and ZX1100 C/D models remove the cap bolt from the tensioner body and withdraw the spring. Release the tensioner locking mechanism by pulling the pushrod stopper back towards the tensioner body, and pushing the tensioner pushrod back until it is fully retracted in the tensioner body. Using a new gasket, refit the tensioner to the cylinder block ensuring that the arrow cast on it is facing upwards; tighten its mounting bolts to the specified torque setting (see illustrations). Install the tensioner spring, refit the cap bolt and tighten it securely.


**10** On all models rotate the crankshaft a few times, using a ring spanner on the large




45.9a Fully retract the tensioner pushrod and refit the tensioner using a new gasket




45.9b Tighten tensioner mounting bolts to the specified torque setting and refit the cap bolt and spring



45.10 Apply silicone sealant to the four semi-circular cutouts in the cylinder head




45.7 Refit the top camchain guide as described in text



45.8 Ensure tensioner is fitted so that the arrow on the tensioner body points upwards

hexagon ignition rotor nut, to settle all the disturbed components. Check the valve clearances as described in Chapter 1 and adjust if necessary. Lubricate all bearing surfaces with clean engine oil and wipe both the cylinder head and cover gasket surfaces with a rag moistened in a high flash-point solvent. Examine all the cylinder head cover rubber gaskets for signs of damage, renewing them if necessary. Apply silicone sealant to the surfaces of the four semicircular cutouts in the cylinder head (see illustration).

**11** On ZX900 and ZX1000 A models refit the dowels to the cylinder head cover and refit all the gaskets to the cover. Apply a liquid gasket compound to the gaskets to help hold them in place, and take great care to ensure that the dowels do not drop out of the cover as it is refitted to the cylinder head (see illustration).



45.11a On ZX1000 B and ZX1100 C/D models refit cylinder head cover gaskets to the cylinder head





**45.11b** Do not omit cylinder head cover dowels



**45.11c** Refit the cylinder head cover . . .



**45.11d** . . . and tighten its retaining bolts evenly and progressively to the specified torque setting


On ZX1000 B and ZX1100 C/D models refit the dowels to the cylinder head and fit the gaskets to the head. On all models refit the cylinder head cover to the engine unit (**see illustration**). Fit the six cover retaining bolts and oil seals and tighten them evenly and progressively to their specified torque setting (**see illustration**).

**12** On all US models refit the air suction (reed) valve assemblies and covers to the cylinder head, using new gaskets, and tighten their retaining screws securely.

## 46 Refitting the engine/gearbox unit to the frame



**1** The assistance of at least one, preferably two, people will be required to lift the engine



**46.4** Use grease to hold new exhaust gaskets in position

back into the frame. Remove all traces of corrosion from the engine mounting bolts and apply a smear of grease to their shanks to ease the task of refitting them.

**2** Position the unit beneath the frame then lift it up and manoeuvre it in to position. Secure it by inserting both the upper and lower rear mounting bolts. On ZX1000 and ZX1100 C/D models refit the frame cradle, tighten its retaining bolts to the specified torque setting, then refit the two front engine mounting bolts. On ZX900 models fit the two upper engine mounting bolts not forgetting to refit the shim (where fitted) between the cylinder head and the left-hand frame mounting. When refitting the two rear engine mounting bolts on ZX1100 D models, install the collar on the left-hand side, with its flanged head facing the right-hand side. Clamp the spacer with the Allen screw, noting the torque setting given in the Specifications.

On all models tighten all engine mounting bolts to their specified torque settings.

**3** Connect the starter motor lead earth strap to the top of the crankcase, and remake the electrical connections to the pulser coil(s), neutral switch, sidestand switch and the oil pressure and temperature switches (as applicable). Refit any cable ties that were removed and refit the wiring to any relevant guide hooks or clamps. On ZX900 models, refit the ignition HT coils and reconnect the low tension leads correctly, using the marks made on dismantling. On ZX1000 and ZX1100 C/D models refit the air baffle plate in front of


the cylinder head cover. On all models refit the suppressor caps to the spark plugs using the numbers on the HT leads to ensure that they are fitted correctly.

**4** Place new exhaust gaskets in the ports, using a dab of grease to stick them in place (**see illustration**). Refit the exhaust system as follows, noting that on ZX900 models the exhaust pipes and front fairing bracket must be refitted together.

**5** On ZX1000 B models join the left and right sections of the exhaust system (if separated), then on all models offer up the exhaust pipes to the cylinder head (**see illustration**). Push the pipes into the ports and hold them there while an assistant lifts up the rear of the exhaust system and inserts the rear exhaust or silencer mounting bolt(s) (as applicable) (**see illustration**). Tighten the bolt(s) finger-tight only at this stage. Refit the exhaust mounting clamps and the eight mounting nuts (**see illustration**). Tighten the front exhaust mounting nuts evenly and securely and then tighten the rear exhaust or silencer mounting bolt(s). On ZX900 and ZX1000 A models refit both the left and right-hand silencers and tighten their mounting bolts and clamps securely. On ZX1100 C/D models refit the right-hand silencer, positioning the exhaust clamp as shown (**see illustration**), and then tighten both the mounting bolts and clamp securely. On ZX1000 B models tighten the exhaust clamp which secures the left and right-hand sections of the exhaust system together. On ZX900 models refit the lower fairing bracket,



**46.5a** Refit the exhaust pipes to the ports . . .




**46.5b** . . . and fit the exhaust system rear mounting bolt




**46.5c** Refit the exhaust pipe front clamps and nuts and tighten as described in text






**46.5d** On ZX1100 C/D models the exhaust clamp must be positioned as shown, approximately 45° to the rear



**46.6** Tighten the drive sprocket nut to the specified torque setting and secure it with the locking tab



**46.7a** Insert the clutch pushrod as described in text

using the marks made on dismantling for guidance, and tighten both the lower and front fairing bracket mounting bolts securely.

**6** On all models, engage the sprocket on the drive chain and refit it to the splines on the output shaft. Inspect the tab washer, if it is weakened due to repeated bending of its tab renew it (see the note below concerning the ZX1100 C/D model). Refit the sprocket retaining nut and tighten it to the specified torque setting whilst applying the rear brake hard to prevent the sprocket from rotating (transmission in gear and rear wheel touching the ground). Using slip-joint pliers flatten a section of the tab washer against one of the flats of the nut (**see illustration**). Adjust the drive chain tension as described in Routine Maintenance. **Note** - A modified tab washer was introduced for all ZX1100 C/D models in late 1993. It can be identified by its shaped periphery and convex cross-section; refer to a Kawasaki dealer for details. Kawasaki advise that when fitting the new washer, the nut also be renewed, and that a light coating of oil is applied to the shaft threads and both sides of the washer. A section of the washer should be flattened fully against one of the nut flats to form a 90° angle.


**7** Lubricate the clutch pushrod and insert it into the engine ensuring that its rounded end is facing outwards (**see illustration**). Fit the two sprocket casing locating dowels in the crankcase (if removed) and refit the casing itself (**see illustrations**). Fit a new insulating gasket to the slave cylinder, push its piston in



**46.7b** Refit the dowels to the crankcase . . .

as far as possible with hand pressure and install the slave cylinder in the sprocket casing. Refit the three retaining bolts and tighten these and the sprocket casing mounting bolts securely. Ensure that the clutch hydraulic hose and metal pipe are secured by the clamps provided. Operate the clutch lever to bring the piston into contact with the pushrod; if there is evidence of air in the system it must be bled as described in Chapter 7, Section 13. Using the marks made on dismantling, refit the gearchange linkage on to its shaft and tighten its pinch bolt securely (**see illustration**).

**8** On ZX900 and ZX1000 A models, install the air filter housing and fit its mounting bolt(s) finger-tight only. On all models refit the carburettors as described in Chapter 4. Once refitted, check the throttle and choke cable



**46.7c** . . . and refit the sprocket casing to the engine unit

freeplay as described in Chapter 1 and adjust if necessary. On US models refit all clean air and emission control system components, referring to Chapter 4 for further information. On all ZX1100 C/D models fit the front section of the air filter housing not forgetting to connect the vent hose to the carburettors and to fit the shouldered spacer behind the front housing mounting bolt (**see illustration**). On all models tighten all disturbed components securely.

**9** Refit the radiator and cooling fan assembly, and the water pump. Fill the cooling system as described in Chapter 3. Offer up the oil cooler assembly and tighten its mounting bolts securely. Route the oil hoses correctly, using the notes made on dismantling, and position a new sealing washer on both sides of each hose union (**see illustration**). Refit the



**46.7d** Using the marks made on dismantling refit the gearchange linkage to the shaft tightening its bolt securely




**46.8** On ZX1100 C/D models do not omit shouldered spacer from behind front air filter housing mounting bolt



**46.9** Fit a new sealing washer on each side of all oil cooler hose unions





47.4 Adjusting the balancer shaft

union bolts and tighten them to their specified torque settings.

**10** Reconnect the battery, remembering to connect the negative terminal last. Refit the fuel tank as described in Chapter 4. Working as described in Chapter 1, fit a new oil filter element and add the required amount of oil to the engine. Be prepared to top up the oil once the engine has been run as the level will drop as soon as the oil begins to circulate. Do not refit the fairing until the engine has been run and the balancer shaft adjusted as described in the following Section.

## 47 Starting and running the rebuilt engine



**1** Attempt to start the engine using the usual procedure adopted for a cold engine. Do not be disillusioned if there is no sign of life initially, especially on ZX1000 B and ZX1100 C/D models where due to the nature of the fuel system it can take anything up to 30 seconds of turning the engine over just to refill the carburettors with fuel. A certain amount of perseverance may prove necessary to coax the engine into activity even if new parts have not been fitted. Should the engine persist in not starting, check that the spark plugs have not become fouled by the oil used during reassembly. Failing this go through the fault diagnosis section and work out what the fault is methodically.

**2** When the engine does start, keep it running as slowly as possible to allow the oil to circulate. The oil pressure warning light should go out almost immediately the engine has started, although in certain instances a very short delay can occur whilst the oilways fill and the pressure builds up. If the light does not go out the engine should be stopped before damage can occur, and the cause determined. Open the choke as soon as the engine will run without it. During the initial running, a certain amount of smoke may be in evidence due to the oil used in the reassembly sequence being burnt away. The resulting smoke should gradually subside.

**3** Check the engine for blowing gaskets and oil leaks. Before using the machine on the road, check that all the gears select properly, and that the controls function correctly.

**4** Before the engine warms the balancer shaft must be adjusted. Start the engine and allow it to idle. Slacken the balancer shaft pinch bolt and using a flat-bladed screwdriver turn the balancer shaft anti-clockwise until the balancer gear starts to make a noise (see illustration). Then turn the shaft back slowly in a clockwise direction until the noise stops. Tighten the pinch bolt securely whilst holding the balancer shaft in position.

**5** Warm the engine up to normal operating temperature and thoroughly check for any oil or coolant leaks. If no leaks are present check both the oil and coolant levels as described in 'Daily (pre-rise) checks' at the beginning of this Manual and top up as necessary. Do not forget to check these both before and after the machine has been for a run. Refit the fairing as described in Chapter 6 and make a final check that all disturbed components have been securely tightened before taking the machine on the road.

## 48 Taking the rebuilt machine on the road

**1** Any rebuilt machine will need time to settle down, even if parts have been refitted in their original order. For this reason it is highly advisable to treat the machine gently for the first few miles to ensure oil has circulated throughout the lubrication system and that new parts fitted have begun to bed down.

**2** Even greater care is necessary if the engine has been rebored or if a new crankshaft has been fitted. In the case of a rebore, the engine will have to be run in again, as if the machine were new. This means greater use of the gearbox and a restraining hand on the throttle until at least 500 miles have been covered. There is no point in keeping to any set speed limit; the main requirement is to keep a light loading on the engine and to gradually work up performance until the 500 mile mark is reached. These recommendations can be lessened to an extent when only a new crankshaft is fitted. Experience is the best guide since it is easy to tell when an engine is running freely.

**3** If at any time a lubrication failure is suspected, stop the engine immediately and investigate the cause. If an engine is run without oil, even for a short period, irreparable engine damage is inevitable.

**4** When the engine has cooled down completely after the initial run, recheck the various settings, especially the valve clearances. During the run most of the engine components will have settled into their normal

working locations. Check the various oil levels, particularly that of the engine as it may have dropped slightly now that the various passages and recesses have filled.

## 49 Engine - compression test



**1** A good indication of the engine's condition can be gained by carrying out a compression test. A compression gauge will be required, together with a suitable adaptor. Note that a gauge, adaptor and sealing gasket can be obtained for this purpose from Kawasaki dealers.

**2** Check the valve clearances as described in Chapter 1.

**3** Run the engine until it reaches normal operating temperature, then stop it and remove all four spark plugs. Refit the plugs in the plug caps and arrange the plug electrodes so that their metal bodies are earthed (grounded) to the cylinder head; this will prevent damage to the ignition system as the engine is spun over. On ZX900 models, it will be necessary to remove the ignition HT coils; reconnect the earth (ground) wire to the rearmost of the coil mountings on the frame, using a suitable nut and bolt. Install the compression gauge in one of the spark plug holes and as a precaution against the risk of fire, plug the other three holes with a small wad of rag.

**4** Open the throttle fully and spin the engine over on the starter motor until the highest gauge reading is recorded. After one or two revolutions the pressure should build up to a maximum figure and then stabilise. Take a note of the reading and then repeat the test on the three remaining cylinders.

**5** The correct pressures are given in the Specifications. If the results fall within this range and all are relatively equal, the engine is in good condition. If there is a marked discrepancy between the readings, or if the readings are lower than specified, examination of the top end components should be made.

**6** Low compression pressure may be due to worn cylinder bores, pistons or rings, failure of the cylinder head gasket, worn valve seals, or poor valve seating. To distinguish between cylinder/piston wear and valve leakage, pour a small quantity of oil into the bore to temporarily seal the piston rings, then carry out the above compression tests. If the readings show a noticeable increase this confirms that the cylinder bore, piston or rings are worn. If, however, no change is indicated, the cylinder head gasket or valves should be examined.

**7** Readings in excess of those specified indicate excessive carbon build-up in the combustion chamber and on the piston crown.



# Specifications

## Coolant

Mixture type .....	Distilled water, and corrosion-inhibited ethylene-glycol antifreeze suitable for use in aluminium engines
Standard recommended mixture ratio down to -35°C (-31 °F) .....	50% antifreeze/50% distilled water
Total capacity of system:	
ZX900 models .....	2.9 lit (5.1 Imp pt, 3.0 US qt)
ZX1000 models .....	3.1 lit (5.5 Imp pt, 3.2 US qt)
ZX1100 C/D models .....	2.5 lit (4.4 Imp pt, 2.6 US qt)

## Thermostat

Valve opening temperature:	
ZX1000 B UK models .....	69 - 73°C (156 - 163°F)
All other models .....	80 - 84°C (176 - 183°F)
Valve lift @ 95°C (203°F) .....	More than 8 mm (0.31 in)

## Radiator

Cap valve opening pressure:	
ZX900 and ZX1000 A models .....	0.75 - 1.05 kg/cm <sup>2</sup> (11 - 15 psi)
ZX1000 B and ZX1100 C/D models .....	0.95 - 1.25 kg/cm <sup>2</sup> (14 - 18 psi)


## Torque settings

	kgf m	lbf ft
Coolant drain plug:		
ZX1100 D models .....	1.0	7.0
Other models .....	0.8	6.0
Cooling fan switch unit:		
ZX900 and ZX1000 A models .....	0.75	5.5
ZX1000 B and ZX1100 C/D models .....	1.8	13.0
Temperature sender unit:		
ZX900 and ZX1000 A models .....	0.8	6.0
ZX1000 B and ZX1100 C/D models .....	1.5	11.0
Thermostat housing bleed valve .....	0.8	6.0
Water pump mounting bolts:		
ZX1100 C/D models .....	1.0	7.0
Other models .....	Not available	










1.1b Cooling system components – ZX1000 A models

- |                           |                                |                                |                                      |  |
|---------------------------|--------------------------------|--------------------------------|--------------------------------------|--|
| 1 Radiator                | 10 Fan                         | 16 Thermostat                  | 23 Water pump to cylinder metal pipe | 30 Lower hose  |
| 2 Bolt – 2 off            | 11 Bolt – 3 off                | 17 Thermostat cover            | 24 Drain plug                        | 31 Carburettor warmer pipe check valve assembly <sup>1</sup> |
| 3 Spacer – 2 off          | 12 Nut – 3 off                 | 18 Bleed valve                 | 25 Sealing washer                    | 32 Rear coolant pipe   |
| 4 Mounting rubber – 4 off | 13 Radiator to thermostat hose | 19 Upper hose                  | 26 Water pump                        | 33 Carburettor warmer pipe filter assembly <sup>1</sup>      |
| 5 Fan switch              | 14 Thermostat housing          | 20 Radiator cap assembly       | 27 Water pump cover                  | 34 Expansion tank  |
| 6 Radiator guard          | 15 Temperature sensor switch   | 21 Front coolant pipe          | 28 Bleed bolt                        |  |
| 7 Bolt – 4 off            |                                | 22 Water pump to cylinder hose | 29 Sealing washer                    |  |
| 8 Nut – 4 off             |                                |                                |                                      |  |
| 9 Mounting rubber – 2 off |                                |                                |                                      |  |

<sup>1</sup> UK models only






1.1c Cooling system components - ZX1100 C models (ZX1000 B similar)

- |                           |                                      |  |                                 |   |
|---------------------------|--------------------------------------|--|---------------------------------|---|
| 1 Radiator                | 10 Nut - 3 off                       | 16 Water pump cover  | 23 Expansion tank               | 29 Radiator cap   |
| 2 Bolt - 2 off            | 11 Front coolant pipe                | 17 Water pump  | 24 Thermostat housing           | 30 Radiator to thermostat hose                          |
| 3 Spacer - 2 off          | 12 Water pump to cylinder hose       | 18 Bleed bolt  | 25 Temperature sensor switch    | 31 Upper hose   |
| 4 Mounting rubber - 3 off | 13 Water pump to cylinder metal pipe | 19 Sealing washer  | 26 Bleed valve                  | 32 Upper metal pipe                                     |
| 5 Radiator guard          | 14 Drain plug                        | 20 Lower metal pipe  | 27 Thermostat                   | 33 Carburettor warmer pipe filter assembly <sup>1</sup> |
| 6 Screw - 4 off           | 15 Sealing washer                    | 21 Carburettor warmer pipe check valve assembly <sup>1</sup> | 28 Thermostat cover/filler neck |   |
| 7 Fan switch              |                                      | 22 Lower hose  |                                 |   |
| 8 Fan                     |                                      |  |                                 |   |
| 9 Bolt - 3 off            |                                      |  |                                 |   |

<sup>1</sup> UK models only

**Note:** carburettor warmer pipe assembly differed slightly on UK ZX1000 B model. The filter assembly (item 33) was taken off the thermostat housing (item 24), and the check valve shown in item 21 was omitted.






1.1d Cooling system components - ZX1100 D models

- |                           |                       |                                      |   |  |
|---------------------------|-----------------------|--------------------------------------|---|--|
| 1 Radiator                | 10 Fan                | 19 Insulators                        | 27 Water pump to cylinder hose                            | 33 Bleed valve                                       |
| 2 Bolt - 2 off            | 11 Bolt - 3 off       | 20 Water pump                        | 28 Carburettor warmer pipe check valve assembly - UK only | 34 Temperature sensor switch                         |
| 3 Spacer - 2 off          | 12 Front coolant pipe | 21 Air bleed bolt                    | 29 Expansion tank   | 35 Upper hose  |
| 4 Mounting rubber - 2 off | 13 Lower hose         | 22 O-ring                            | 30 Pressure cap neck                                      | 36 Upper metal pipe                                  |
| 5 Radiator guard          | 14 Lower metal pipe   | 23 Water pump cover                  | 31 Thermostat   | 37 Carburettor warmer pipe filter assembly - UK only |
| 6 Screw - 4 off           | 15 Drain plug         | 24 Drain plug                        | 32 Thermostat housing                                     |  |
| 7 Nut - 7 off             | 16 Sealing washer     | 25 Sealing washer                    |   |  |
| 8 Mounting rubber         | 17 Bolt               | 26 Water pump to cylinder metal pipe |   |  |
| 9 Fan switch              | 18 O-rings            |                                      |   |  |






2.3 Location of cooling system drain plug

2 Cooling system - draining

**Note:** to avoid the risk of personal injury such as scalding, the cooling system should only be drained when the engine and cooling system are cold. Coolant will attack painted surfaces; wash away any spilt coolant immediately with fresh water.

- 1 Place the machine on its centre stand on a level surface. To gain access to the radiator cap on ZX900 models, remove the seat, sidepanels and the fuel tank mounting bolts. Move the fuel tank backwards, noting that it is not necessary to disconnect or remove it. On ZX1000 A models remove the inner fairing section, as described in Chapter 6. On ZX1000 B and ZX1100 C/D models, remove the two bolts which retain the small cover to the right-hand inner fairing section and lift the cover away from the machine.
- 2 If the engine is cold remove the cap by turning it in an anti-clockwise direction. If the engine is still warm place a thick rag over the cap and turn it slightly until all the pressure in the system has been allowed to escape. A rag must be used to prevent escaping steam from scalding the hands. If the cap is removed suddenly, the drop in pressure could allow the coolant to boil violently and be expelled from the filler neck, scalding the skin and damaging paintwork. Where time and circumstances permit it is therefore strongly recommended that a hot engine is allowed to cool before the cap is removed.
- 3 Remove the lower fairing section as described in Chapter 6 and place a suitably sized container underneath the drain plug, located at the bottom of the left-hand engine coolant pipe (see illustration). If the coolant is to be re-used, ensure that it is drained into a clean non-metallic container. Unscrew the drain plug and allow the coolant to drain fully into the container. Once drained, refit the drain plug and tighten it to the specified torque setting. If damaged, the drain plug sealing washer must be renewed.
- 4 Complete draining of the system will require that the cylinder block drain plugs be



2.5 Coolant expansion tank mountings (arrows) - ZX1100 D

- removed to allow the escape of residual coolant from the engine castings. These drain plugs are situated on the front edge of the block, although note that access to them may be rather limited. Have ready a suitable container to catch the escaping coolant as the plugs are unscrewed. If damaged, renew the drain plug sealing washers and tighten the plugs securely.
- 5 If necessary the expansion tank can also be drained. On ZX900 and ZX1000 A models this can be achieved by simply removing the tank mounting bolts and tipping its contents out. On ZX1000 B and ZX1100 C disconnect the pipe from the union at the base of the tank and allow the contents to drain into a suitable container. On ZX1000 B models to do this it is necessary to remove the right-hand middle fairing section, as described in Chapter 6. On ZX1100 D models the seat and tail section must be removed to gain access to the expansion tank. To drain the expansion tank, remove its two mounting bolts and invert the tank to expel the coolant (see illustration).
  - 6 The manufacturer recommends that the coolant is changed at regular intervals (see Chapter 1).

3 Cooling system - flushing

- 1 After extended service the cooling system will slowly lose efficiency, due to the build-up of scale, deposits from the water and other foreign matter which will adhere to the internal surfaces of the radiator and coolant passages. This condition will worsen if distilled water has not been used at all times. Removal of the deposits can be carried out easily using a suitable flushing agent in the following manner.
- 2 Drain the system as described in the previous Section. Refit the drain plug and refill the system with clean water and the specified amount of flushing agent. Any proprietary flushing agent can be used in either liquid or dry form, providing it is recommended for use in aluminium engines. *Never use a compound suitable for iron engines as it will react violently with the aluminium alloy.* The

manufacturer of the flushing agent will give instructions on the quantity of flushing agent to be used.

- 3 Run the engine for ten minutes at normal operating and then drain the system. Repeat the procedure twice and then again using only clean cold water. Finally refill the system as described in the following Section.

4 Cooling system - filling

- Note:** to avoid the risk of personal injury such as scalding, the cooling system should only be drained when the engine and cooling system are cold. Coolant will attack painted surfaces; wash away any spilt coolant immediately with fresh water.
- 1 Before filling the system first check that the drain plugs have been fitted and tightened to the specified torque setting (where given). Check that all coolant pipes and hoses are correctly fitted and held securely by their hose clips.
  - 2 The recommended mixture of coolant given in the Specifications will give protection against the coolant freezing in temperatures of down to -35°C (-31 °F). To give adequate protection against wind chill factors and other variables, the coolant should always be prepared for temperatures 5°C (9°F) lower than the lowest anticipated temperature.
  - 3 Use only good quality antifreeze of the type specified, never use an alcohol based antifreeze. In view of the small quantities used, always use distilled water and never tap water. Against its extra cost can be set the fact that it will keep the system cleaner and save the time and effort spent flushing the system that would otherwise be necessary with tap water. However, tap water that is known to be soft, or rainwater caught in a non-metallic container and filtered before use, may be used in an emergency. Never use hard tap water as the risk of scale building up is too great.
  - 4 So that a reserve is left for subsequent topping up, prepare approximately 3.5 litres (6.2 Imp pint/3.7 US qt) of coolant in a clean non-metallic container. At the standard recommended mixture strength this will mean mixing equal quantities of both antifreeze and distilled water, although adjustments can be made if lower temperatures are expected.
  - 5 Add the coolant via the radiator filler neck, pouring it in slowly to reduce the amount of air which will be trapped in the system. When the level is up to the base of the filler neck, slacken the bleed bolt situated at the top of the water pump housing (see illustration 7.2b) until coolant starts to trickle slowly out of the bolt hole. Once the coolant starts to flow from the hole tighten the bolt securely, and mop up any spilt coolant. This procedure bleeds the water pump of air. Top up the radiator if necessary, to the base of the filler



neck. A further bleed bolt is situated on the thermostat housing, in the form of a bleed valve. Slacken the bleed valve and allow coolant to flow from the valve whilst adding coolant via the filler neck. When the flow of coolant is free of air bubbles, tighten the bleed valve to the specified torque setting. Check that the coolant level is topped up to the base of the filler neck and refit the radiator cap. Fill the expansion tank to its upper level line and refit the expansion tank cap.

**6** Start the engine and allow it to idle until it reaches normal operating temperature and the cooling fan comes on. Stop the engine at this point and allow it to cool. When the engine is cool check the level in the expansion tank as described in 'Daily (pre-ride) checks' at the beginning of this Manual and top up if necessary.

**7** When the machine has been ridden for the first time after refilling, allow the engine to cool down and check the level at the radiator filler cap to ensure that no further pockets of air have been expelled, topping up if necessary. All subsequent checks of the level at the recommended maintenance intervals should be checked at the expansion tank, as described in 'Daily (pre-ride) checks' at the beginning of this Manual.


## 5 Radiator - removal, cleaning, examination and refitting



**1** Remove the fairing as described in Chapter 6. On ZX1000 B and ZX1100 C/D models it is also necessary to remove the fuel tank as described in Chapter 4. **Note:** on all models the cooling fan and switch are connected directly to the battery, enabling the fan to operate with the ignition switched off. For this reason ensure that the engine is cold before attempting to remove the radiator and disconnect the battery negative lead. Failure to do so could lead to injury from the fan blades should the fan come on unexpectedly.

**2** Drain the coolant as described in Section 2 of this Chapter.

**3** Slacken the hose clamps on both the lower and upper radiator hoses and disconnect the




**5.3a** Slacken the clamps and remove both the upper . . .

hoses from the radiator (see illustrations). On ZX900 models remove the mounting bolts from the lower fairing mounting bracket and push the bracket downwards to disengage it from the peg on the bottom of the radiator. On ZX1000-A models remove the mounting bolts from both the oil cooler and its mounting bracket, and push the oil cooler mounting bracket clear of the radiator. Tie the oil cooler to the frame to avoid placing any strain on its hoses. On ZX1000 and ZX1100 C/D models disconnect both the horns and remove them along with their mounting brackets. Each horn bracket is retained by a single mounting bolt.

**4** On all models, remove the radiator mounting bolts and disconnect the cooling fan and switch electrical connectors (see illustrations). On ZX900 and ZX1000 A models note that it will not be possible to disconnect these until the radiator is partially removed. The radiator can then be carefully manoeuvred out of position. If necessary the radiator and cooling fan can be separated by removing the three bolts which secure the fan to the back of the radiator.

**5** Remove any obstructions from the radiator matrix using compressed air from behind. To prevent the radiator vanes from being damaged keep the air jet perpendicular to the radiator and at least 20 inches away from the radiator core. The conglomeration of moths, flies and road dust which usually builds up in the radiator matrix restricts the air flow and severely reduces the efficiency of the cooling system.

**6** The interior of the radiator is easily cleaned



**5.3b** . . . and lower radiator hoses

whilst the radiator is in position on the machine, using the flushing procedure described in Section 3. Additional flushing can be carried out by placing a hose in the radiator filler, neck and allowing water to flow through for about ten minutes. Under no circumstances should the hose be connected to the filler neck mechanically as a sudden blockage in the radiator outlet would subject the radiator to the full pressure of the mains supply (about 50 psi). The radiator should never be pressurised to more than 15 psi.

**7** Bent fins can be straightened, if care is exercised, by using a flat-bladed screwdriver. Badly damaged fins cannot be repaired. As a rule a new radiator should be fitted if bent fins obstruct more than 20% of the air flow.


**8** If the radiator is found to be leaking, repairs are usually impractical and a new component will have to be fitted. Very small leaks may sometimes be stopped by the addition of a special sealing agent in the coolant. If an agent of this type is used follow the manufacturer's instructions very carefully. Soldering, using soft solder, may be effective for caulking large leaks but this is a specialist repair which is best left to the experts.

**9** Inspect the radiator mounting rubbers for perishing or compaction. Renew the rubbers if there is any doubt as to their condition. The radiator could be damaged by vibration if the isolating effect of the rubbers is lost.

**10** The radiator is refitted by a reversal of the removal sequence. Remount the cooling fan on the radiator and tighten its mounting bolts



**5.4a** Remove the radiator mounting bolts . . .



**5.4b** . . . and disconnect the cooling fan switch . . .



**5.4c** . . . and cooling fan wiring - ZX1100 C shown



securely. On ZX1000 A models do not forget to refit the cooling fan switch earth lead to one of the fan bolts. Refit the radiator to the machine and connect both the cooling fan and switch leads. Refit the radiator mounting bolts and tighten them securely. On ZX900 models do not forget to refit the cooling fan switch earth lead to the top left-hand radiator mounting bolt.

**11** On ZX900 models reposition the fairing bracket, ensuring that it locates correctly with the peg on the bottom of the radiator, and refit its mounting bolts. On ZX1000 A models refit the oil cooler and bracket ensuring that the bracket locates correctly with the pegs on the bottom of the radiator and those on the oil cooler. On ZX1000 B and ZX1100 C/D models refit the radiator cover. On ZX1000 and ZX1100 C/D models refit the horns and connect their electrical leads. On all models tighten all disturbed nuts and bolts securely.

**12** Refit the coolant hoses to the radiator and secure them with the hose clips. Fill the cooling system as described in Section 4 and refit the fairing.


## 6 Radiator cap - testing



**1** If the valve or valve spring in the radiator cap is faulty the pressure in the cooling system will be reduced, causing the coolant to boil over.

**2** The only satisfactory way of testing the radiator cap is to pressure test it. This requires special equipment not normally found in the home workshop. The cap should therefore be taken to an authorized Kawasaki dealer who will have the necessary equipment available to test it. The only other means of testing the cap is by substitution.

**3** If the correct equipment is available, wet the sealing surfaces of the cap and fit it to the pressure tester. Apply a pressure of 11 - 15 psi (0.79 - 1.1 kg/cm<sup>2</sup>) on ZX900 and ZX1000 A models and 14 - 18 psi (1 - 1.25 kg/cm<sup>2</sup>) on ZX1000 B and ZX1100 C/D models, usually by means of a hand-operated plunger. *Never exceed the upper limit of the specified*



**6.2 Radiator cap can be tested if necessary equipment is available**

*pressures when testing the cap.* The pressure must be held for a period of 6 seconds, during which time it should remain within the specified limits with no measurable loss. If the cap is found to be faulty it must be renewed.

**4** In addition to pressure testing the cap the same equipment can be used to pressurise the cooling system and check for leakage of coolant. Remove the radiator cap, check that the coolant level is topped up, and connect the equipment to the filler neck. Apply a pressure of no more than 15 psi (1.1 kg/cm<sup>2</sup>) on ZX900 and ZX1000 A models, and 18 psi (1.25 kg/cm<sup>2</sup>) on ZX1000 B and ZX1100 C/D models, by means of the hand-operated plunger. Any leaks should soon become apparent. Most leaks will however be readily apparent due to the tell-tale traces of antifreeze left on the components in the immediate area of the leak.

## 7 Coolant hoses and pipes - removal, refitting and checking for leaks



**1** The cooling system can be regarded as a semi-sealed system, the only normal coolant loss being minute amounts through evaporation in the expansion tank. If, however, significant coolant loss is experienced, the source of the leak should be promptly investigated before engine damage results.

**2** The radiator is connected to the engine by various flexible hoses and metal (see illustrations). The hoses should be

periodically inspected and renewed if any sign of cracking or perishing is discovered. The most likely problem area is around the clips which secure each hose to its unions. Another area which should be regularly checked is the unions between the metal coolant pipes and the engine. All these unions are sealed by O-rings which will in time perish and allow coolant to leak. On UK models do not forget to include the carburettor warmer hoses when checking the cooling system for leaks.


**3** Before removing any of the hoses or coolant pipes drain the coolant as described in Section 2. To disconnect the hoses, use a screwdriver to slacken the clamps then slide them back along the hose and clear of the union spigot, noting that it may be necessary to remove the radiator mounting bolts, or alternately the coolant pipe retaining bolts, to allow the hose to be removed. The hoses can be worked off with relative ease when new or slightly warm, using a twisting action. Do not, however, attempt to disconnect any part of the system whilst it is still hot due to the risk of personal injury. Note that the radiator unions and the metal coolant pipes are fragile. *Do not use excessive force when attempting to remove the hoses.* If a hose proves stubborn, try to release it by rotating it on its union before working it off. If all else fails, cut the hose with a sharp knife then slit it at each union so that it can be peeled off in two pieces. Whilst this is expensive it is preferable to buying a new radiator.

**4** Serious leakage will be self-evident, though slight leakage can be difficult to spot. It is likely that the leak will only be apparent when the machine is running and the system is under pressure, and even then the rate of escape may be such that the hot coolant evaporates as soon as it reaches the atmosphere, although traces of antifreeze should reveal the source of the leak. If not it will be necessary to use the test equipment described in the previous Section of this Chapter to pressurise the system when cold and trace the leak. This operation is best entrusted to an authorized Kawasaki dealer who will have access to the necessary equipment.

**5** Other possible sources of leakage are the



**7.2a** Cooling system hoses are secured with clamps ...



**7.2b** ... whilst pipes are retained by bolts (note bleed bolt - A) ...



**7.2c** ... and sealed with O-rings



O-rings on the water pump casing and thermostat housing and the water pump's mechanical seal. The latter can easily be checked by examining the drainage hole on the bottom of the water pump housing as described in Section 9.

6 In very rare cases the leak may be due to a broken head gasket, in which case the coolant will be drawn into the engine and expelled as vapour in the exhaust gases. If this proves to be the case it will be necessary to remove the cylinder head for further investigation.

7 When refitting the hoses, first slide the clips onto the hose and then work the hose onto its spigots. *Do not use a lubricant of any kind, if necessary the hose can be softened up by soaking it in boiling water before refitting, although care is obviously necessary to prevent scalding the hands in the process.* When the hose is refitted rotate it on its spigots to settle it and check that the two components it joins are securely fastened so that the hose is correctly positioned before sliding its clips into place and tightening them securely. Note that on some hoses there is a small white dot or arrow which must be aligned with the mark, usually in the form of a line cast into the surface of the pipe, on the relevant union.

## 8 Thermostat - removal and testing

1 The thermostat remains in the closed position when the engine is cold, restricting the flow of the coolant, and opens only when the engine reaches its normal operating temperature. This enables the engine to warm up quickly when it is cold. If the thermostat malfunctions it will probably remain closed even when the engine has reached its normal operating temperature. The flow of the coolant will be impeded and will not be able to pass through the radiator and consequently the engine temperature will rise abnormally, causing the coolant to boil over. Alternately the thermostat could remain open which would mean the engine would take an

abnormally long time to warm up from cold. If the performance of the thermostat is suspect, it should be removed from the machine and tested as follows.

2 Drain the coolant as described in Section 2 of this Chapter.

### ZX900 models

3 The thermostat is situated between the cylinder head and the carburettors (see illustration). Remove the fuel tank as described in Chapter 4, noting that on US models it is also necessary to remove the air suction valves and hoses. Remove the cylinder head cover as described in Chapter 2.

4 Slacken the hose clips on each end of the upper radiator hose which connects the thermostat and radiator, and remove the hose. Slacken the choke cable adjuster locknut and rotate the adjuster to obtain the maximum amount of free play possible. Disconnect the cable from the carburettors and remove the choke cable mounting clamp screw. Disconnect the wires from the fan switch and temperature sensor on the thermostat body. Remove the mounting bolt from the underside of the thermostat housing and withdraw the thermostat.

### ZX1000 and ZX1100 C models

5 The thermostat is located just beneath the radiator pressure cap assembly. To gain access to the thermostat housing it is first necessary to remove the fairing as described in Chapter 6.

6 Disconnect the wire from the temperature sender unit and disconnect the expansion tank hose from the filler neck. Slacken the hose clip which secures the short radiator hose to the bottom of the thermostat housing and remove the two Allen-headed housing mounting bolts. Free the thermostat housing from the coolant hose and manoeuvre it out of the frame.

### ZX1100 D models

7 The thermostat/pressure cap assembly is mounted on a bracket attached to the front right-hand side of the frame, just to the rear of the air intake duct. Remove the fairing for access.

8 If only the thermostat is being removed, there is no need to disconnect any of the hoses or electrical connections, although be prepared for a small amount of coolant loss. Remove the four screws and separate the thermostat housing from the pressure cap neck (see illustration). Lift the thermostat out of its housing.

9 To remove the housing completely, disconnect the electrical connector to the temperature sensor switch, the earth wire, and the main coolant hose. Similarly, if the pressure cap neck requires removal, disconnect the reservoir tank hose and main coolant hose, followed by the bolts retaining it to its bracket.


### All models

10 Slacken the two screws which retain the thermostat housing cover, lift off the cover and remove the thermostat. Examine it visually before carrying out tests. If it remains open at room temperature it should be discarded. If however it appears to be serviceable it should be tested as follows.


11 Suspend the thermostat by a piece of wire in a glass heat-proof vessel of cold water. Place a thermometer in the water so that its bulb is close to the thermostat (see illustration). Heat the water up, noting the temperature at which the thermostat begins to open and approximately how much lift the valve has when it is fully open. Compare the results obtained with those given in the Specifications. If the results obtained differ from those specified, the thermostat must be renewed.

12 If the thermostat is faulty it can be removed and the machine used without it as an emergency measure. Take care when starting the machine from cold as the warm-up will take much longer than usual, and ensure that a new unit is fitted as soon as possible.


13 The thermostat is refitted by a reversal of the removal procedure, noting that on ZX1000 B and ZX1100 C/D models where the thermostat is mounted vertically, ensure that



8.3 Thermostat housing - ZX900 models (note fan switch A, temperature sensor B, bleed valve C)




8.8 Thermostat/pressure cap assembly - thermostat housing outer screws (A)



8.11 Thermostat operation test

Ensure thermostat (1) is completely submerged and that it and the thermometer (2) do not touch sides or bottom of container.







**8.13a** On ZX1000 B and ZX1100 C/D models ensure thermostat bypass hole (arrowed) is positioned at the top




**8.13b** Fit a new O-ring to thermostat housing cover ...



**8.13c** ... tighten its retaining screws securely



**8.13d** Fit a new O-ring to the back of the housing ...



**8.13e** ... before securing to frame with long Allen-headed bolts

the small bypass hole in the thermostat is positioned at the top. Renew both the O-rings on the thermostat housing cover regardless of their apparent condition (see illustrations). Fill the cooling system as described in Section 4 of this Chapter and refit all disturbed components.

## 9 Water pump - removal, examination and refitting



**1** To prevent the leakage of water or oil from the cooling system to the lubrication system and vice versa, two seals are fitted on the pump shaft. On ZX1000 B and ZX1100 C/D models there is also a drainage hole situated on the underside of the pump body (see illustration). If either seal fails this hole should allow the coolant or oil to escape and prevent the oil and coolant mixing.

**2** On all models, the seal on the water pump side is of the mechanical type which bears on the rear face of the impeller. The second seal, mounted behind the mechanical seal, is of the normal 'feathered' lip type. However, neither seal is available as a separate item and should

either one fail the only solution is to renew the complete pump assembly as follows.


**3** Drain the coolant as described in Section 2 of this Chapter.

**4** On ZX1000 and ZX1100 C/D models remove the left-hand side fairing section. Marking its shaft so that it can be refitted in the same position, slacken and remove the gearchange linkage pinch bolt and pull the linkage off the gearchange shaft splines. Release the retaining bolts from the clutch slave cylinder and remove it from the engine sprocket casing. Push the piston as far back as possible by hand and then slowly bring the clutch operating lever back to the handlebars and hold it there with a stout elastic band. This will prevent the slave cylinder piston from being expelled. Slacken and remove the sprocket casing retaining bolts and remove the casing from the engine. Withdraw the clutch pushrod and store it with the casing for safekeeping. **Note:** There is no need to remove the gearchange linkage, clutch slave cylinder and engine sprocket cover on ZX1100 D models.

**5** On ZX900 and ZX1000 A models, slacken the hose clip which secures the flexible coolant hose to the water pump cover, and work the hose off its union. On ZX1000 B and


ZX1100 C/D models, remove the bolt which retains the metal pipe to the pump cover and pull the pipe clear. On all models release the bolt which retains the inner metal coolant pipe and disengage it from the pump housing. Before removing the water pump, place a suitable container beneath the engine to catch any oil which may be released when the pump is removed, then release the pump mounting bolts, withdraw the pump assembly from the machine and lift off the pump cover.

**6** The pump assembly is a sealed unit and



**9.1** Examine drainage hole for signs of coolant leakage






**9.6a On refitting, renew the water pump cover O-ring . . .**

cannot be repaired. If either seal fails or the impeller is damaged or corroded it must be renewed. Renew all O-rings as a matter of course (**see illustrations**).

7 The water pump is fitted by a reversal of the removal procedure. When fitting the pump to



**9.6b . . . and housing O-ring and ensure that slot in the pump shaft engages with the oil pump shaft projection**

the engine unit ensure the slot on the impeller shaft aligns with the projection on the oil pump shaft and that the two components engage correctly. Tighten the pump mounting screws securely to the specified torque (setting where given) and refit the coolant

pipes and hoses (as applicable) to the pump. Fill the cooling system as described in Section 4 of this Chapter and top up the oil level as necessary. Refit the clutch pushrod, ensuring that its rounded end is facing outwards, and refit the sprocket casing and clutch slave cylinder. Refit the gearchange shaft, using the marks made on dismantling and tighten the engine casing, slave cylinder and gearchange pinch bolts securely. Finally refit the lower fairing section and thoroughly check for leaks before taking the machine on the road.

## **10 Cooling system electrical components - general**

The cooling system electrical components can be removed and refitted, and if necessary tested, as described in the relevant Sections of Chapter 8.



# Specifications

## Fuel tank capacity

ZX900 models:

	Litre	Imp gal	US gal
Overall .....	22.0	4.85	5.8
Reserve .....	4.4	0.97	1.2

ZX1000 A models:

Overall .....	21.0	4.63	5.5
Reserve .....	3.0	0.66	0.8

ZX1000 B models:

Overall .....	22.0	4.85	5.8
Reserve .....	4.0	0.88	1.1

ZX1100 C models - overall .....

21.0	4.63	5.5
------	------	-----

ZX1100 D models:

Overall .....	24.0	5.28	6.34
Reserve .....	6.5	1.43	1.72

**Fuel grade** .....

Unleaded or leaded, minimum octane rating 91 (Research method/RON)

## Carburettors

Make .....

**ZX900**

Keihin

Type .....

CVK34

Main jet:

UK models .....

132 (100 - A7-on)

US models .....

135

Main air jet .....

100

Jet needle:

UK models .....

N27B

US models .....

N27A

<http://manuals.magnamaniac.com>



## Carburettors (continued)

**ZX900**

Pilot jet:	
UK models	35
US models	35
Pilot air jet	160
Starter jet:	
UK models	42
US 49-state models	42
California models	38
Pilot screw - turns out:	
UK models	2 1/2 (1 1/2 - A7-on)
US models	Preset
Fuel level - below mark	0.5 mm (0.02 in)
Float height	17 mm (0.67 in)
Idle speed - rpm	950 - 1050

## Carburettors

**ZX1000 A**

Make	Keihin
Type	CVK36
Main jet:	
UK models	132
US 49-state models	132 (130*)
California models	138 (135*)
Main air jet	100
Jet needle:	
Cylinders 1 and 4	N36D
Cylinders 2 and 3	N36E
Pilot jet:	
UK models	35
US models	35 (32*)
Pilot air jet	140
Starter jet:	
UK models	50
US 49-state models	50
California models	45
Pilot screw - turns out:	
UK models	1 3/4
US models	Preset
Fuel level - below mark	2.0 mm (0.08 in)
Float height	17 mm (0.67 in)
Idle speed - rpm:	
UK and US 49-state models	950 - 1050
California models	1150 - 1250

## Carburettors

**ZX1000 B**

Make	Keihin
Type	CVKD36
Main jet:	
UK models	130
US models	130 (128*)
Main air jet	100
Jet needle:	
UK models	N54D
US models	N14C
Pilot jet:	
UK models	38
US models	38 (35*)
Pilot air jet	130
Starter jet:	
UK models	55
US 49-state models	52
California models	52
Pilot screw - turns out:	
UK models	2
US models	Preset
Fuel level - below mark	5.0 mm (0.20 in)
Float height	13 mm (0.51 in)
Idle speed - rpm	950 - 1050



**Carburettors**

Make .....	<b>ZX1100 C</b> Keihin
Type .....	CVKD40
Main jet:	
UK models .....	155 - C1, 140 - C2-on
US models .....	155 (152*) - C1, 140 (152 *) - C2-on
Main air jet .....	70
Jet needle .....	N60U
Pilot jet:	
UK models .....	38
US models .....	38 (35*)
Pilot air jet .....	130
Starter jet .....	55
Pilot screw - turns out:	
UK models .....	2
US models .....	Preset
Fuel level - below mark .....	4.5 mm $\pm$ 1 mm (0.18 $\pm$ 0.04 in)
Float height .....	13 mm $\pm$ 2 mm (0.51 $\pm$ 0.08 in)
Idle speed - rpm .....	950 - 1050

**Carburettors**

Make .....	<b>ZX1100 D</b> Keihin
Type .....	CVKD40
Main jet:	
Cylinders 1 and 4 .....	160 (158*)
Cylinders 2 and 3 .....	158 (155*)
Main air jet .....	70
Jet needle .....	N96X
Pilot jet .....	38 (35*)
Pilot air jet:	
UK models .....	130
US models .....	120
Starter jet .....	58
Pilot screw - turns out:	
UK models .....	2
US models .....	Preset
Fuel level - below mark .....	4.5 $\pm$ 1 mm (0.177 $\pm$ 0.040 in)
Float height .....	13 $\pm$ 2 mm (0.512 $\pm$ 0.080 in)
Idle speed:	
UK and US 49-state models .....	950 - 1050 rpm
California models .....	1150 - 1250 rpm

*Note - specifications denoted by the asterisk (\*) apply when the machine is used above 4000 ft (1216 m).*

<b>Cylinder identification</b> .....	Left to right, 1-2-3-4
--------------------------------------	------------------------

**Lubrication system**

Recommended oil grade .....	SAE 10W/40, 10W/50, 20W/40 or 20W/50 SE or SF class
Capacity:	
Oil change only:	
ZX1100 C/D models .....	3.2 lit (5.7 Imp pt/3.4 US qt)
All other models .....	2.7 lit (4.8 Imp pt/2.9 US qt)
Oil and filter change:	
ZX1100 C/D models .....	3.5 lit (6.2 Imp pt/3.7 US qt)
All other models .....	3.0 lit (5.3 Imp pt/3.2 US qt)
After engine rebuild:	
ZX1000 B models .....	4.0 lit (7.1 Imp pt/4.3 US qt)
All other models .....	Not available
Oil pressure - oil temperature 90°C (194°F):	
ZX900 and ZX1000 A models .....	2.7 - 3.3 kg/cm <sup>2</sup> (38 - 47 psi) @ 4000 rpm
ZX1000 B and ZX1100 C/D models .....	2.0 - 3.0 kg/cm <sup>2</sup> (29 - 43 psi) @ 4000 rpm
Relief valve opening pressure .....	4.4 - 6.0 kg/cm <sup>2</sup> (63 - 85 psi)



## Torque settings

	kgf m	lbf ft
Oil pump mounting bolts	1.2	8.5
Oil filter retaining bolt	2.0	14.5
Oil drain plug(s)	3.0	22.0
Oil pressure switch	1.5	11.0
Oil temperature switch - ZX900 only	0.8	5.8
Oil pressure passage blanking plug	1.8	13.0
Oil cooler hose to matrix union bolts	2.5	18.0
Oil cooler hose to sump union bolts (14 mm)	3.5	25.0
Oil cooler hose to sump union bolt (8 mm) - ZX1100 C/D only	1.5	11.0

## 1 General description

The fuel system comprises a tank from which fuel is fed to the carburettor float chambers. The ZX900 and ZX1000 A models use an automatic vacuum-operated tap to control the flow of the fuel, whereas ZX1000 B and ZX1100 C/D models are fitted with an electrically-operated fuel pump and fuel filter, together with a simplified fuel tap.

All models are fitted with four Keihin carburettors which are of the constant vacuum type. For cold starting a mixture-richening circuit is brought into operation via the handlebar mounted choke lever and cable.

Engine lubrication is of the wet sump type, the oil being contained in a sump at the bottom of the crankcase. The gearbox is also lubricated from the same source, the whole engine unit being pressure fed by a mechanical oil pump, driven off the clutch. Oil temperature is controlled by an oil cooler which is mounted on the frame front downtubes.

## 2 Precautions to be observed when working on the fuel system



**Warning: petrol (gasoline) is extremely flammable, particularly when in the form of vapour. Precautions must be taken, as described below, to prevent the risk of fire or explosion when working on any part of the fuel system. Note that petrol (gasoline) vapour is heavier than air and will collect in poorly ventilated corners of buildings. Avoid getting petrol (gasoline) in the eyes or mouth and try to avoid skin contact. In case of accidents flush the affected area immediately with copious quantities of water and seek prompt medical advice.**

1 Always perform service procedures in a well-ventilated area to prevent a build-up of fumes.

2 Never work in a building containing a gas appliance with a pilot light, or any other form of naked flame. Ensure that there are no naked light bulbs or any sources of flame or sparks nearby.

3 Do not smoke (or allow anyone else to smoke) while in the vicinity of petrol (gasoline) or of components containing petrol. Remember the possible presence of petrol (gasoline) vapour from these sources and move well clear before smoking.

4 Check all electrical equipment belonging to the house, garage or workshop where work is being undertaken (see the Safety first! section of this manual). Remember that certain electrical appliances such as drills, cutters, etc create sparks in the normal course of operation and must not be used near petrol (gasoline) or any component containing it. Again, remember the possible presence of petrol (gasoline) fumes before using electrical equipment.

5 Always mop up any spilt fuel and safely dispose of the shop towel or rag used.

6 Any stored fuel, or fuel that has been drained off during servicing work, must be kept in sealed containers that are suitable for holding petrol (gasoline), and clearly marked as such; the containers themselves should be kept in a safe place. Note that this last point applies equally to the fuel tank, if it is removed from the machine; also remember to keep its cap closed at all times.

7 Read the Safety first! section of this manual carefully before starting work.

8 Owners of machines used in the US, particularly California, should note that their machines must comply at all times with Federal or State legislation governing the permissible levels of noise and of pollutants such as unburnt hydrocarbons, carbon monoxide, etc that can be emitted by those machines. All vehicles offered for sale must comply with legislation in force at the date of manufacture and must not subsequently be altered in any way which will affect their emission of noise or of pollutants. In practice, this means that adjustments may not be made to any part of the fuel, ignition or exhaust systems by anyone who is not authorised or mechanically qualified to do so, or who does

not have the tools, equipment and data necessary to carry out the task properly. Also if any part of these systems is to be renewed it must be replaced only by the genuine Kawasaki components or by components which are approved under the relevant legislation, and the machine must never be used with any part of these systems removed, modified or damaged.

## 3 Fuel tank - removal, renovation and refitting




### All models except ZX1100 D

1 To remove the fuel tank it is first necessary to remove the seat and sidepanels. On ZX1100 C models it will also be necessary to remove both the left and right-hand inner fairing sections.


2 Remove all fuel tank mounting bolts and turn the fuel tap to the OFF position (see illustrations). Note that on ZX900 and ZX1000 A models the tap should be positioned in the ON position. On all California models, disconnect the fuel return and breather pipes from the fuel tank and block the end of the fuel return pipe with a suitable plug; this will prevent any fuel from entering the charcoal canister.

3 Lift the fuel tank and disconnect all the pipes and the fuel level sender unit block




3.2a ZX1100 C fuel tank rear mounting bolts can be reached through access holes in frame





3.2c Fuel tank - ZX1000 A models


- |                                 |                           |                   |
|---------------------------------|---------------------------|-------------------|
| 1 Filler cap                    | 10 Fuel level sender unit | 19 Return spring  |
| 2 Front mounting rubber - 2 off | 11 Seal                   | 20 Diaphragm      |
| 3 Trim                          | 12 Bolt - 4 off           | 21 O-ring         |
| 4 Bolt - 2 off                  | 13 Fuel tap               | 22 Seal           |
| 5 Spacer - 2 off                | 14 O-ring                 | 23 O-ring         |
| 6 Damping rubber - 2 off        | 15 Bolt - 2 off           | 24 Tap lever      |
| 7 Damping block                 | 16 Washer - 2 off         | 25 Wave washer    |
| 8 Rear mounting bracket         | 17 Washer - 2 off         | 26 Retainer plate |
| 9 Bolt - 4 off                  | 18 Diaphragm cover        | 27 Screw - 2 off  |



3.2b Fuel tank - ZX900 models


- |                                 |                          |                   |
|---------------------------------|--------------------------|-------------------|
| 1 Filler cap                    | 8 Seal                   | 18 Return spring  |
| 2 Front mounting rubber - 2 off | 9 Fuel level sender unit | 19 Diaphragm      |
| 3 Bolt - 2 off                  | 10 Lower cover           | 20 O-ring         |
| 4 Spacer - 2 off                | 11 Bolt - 4 off          | 21 Seal           |
| 5 Upper damping rubber - 2 off  | 12 Fuel tap              | 22 O-ring         |
| 6 Lower damping rubber - 2 off  | 13 O-ring                | 23 Tap lever      |
| 7 Rear mounting rubber          | 14 Bolt - 2 off          | 24 Wave washer    |
|                                 | 15 Washer - 2 off        | 25 Retainer plate |
|                                 | 16 Screw - 4 off         | 26 Screw - 2 off  |
|                                 | 17 Diaphragm cover       |                   |





3.2e Fuel tank - ZX1100 C models

- |                                 |                                  |                    |
|---------------------------------|----------------------------------|--------------------|
| 1 Filler cap                    | 9 Rear mounting bracket          | 18 Screw - 2 off   |
| 2 Bolt - 2 off                  | 10 Bolt - 2 off                  | 19 Seal            |
| 3 Spacer - 2 off                | 11 Spacer - 2 off                | 20 O-ring          |
| 4 Upper mounting rubber - 2 off | 12 Upper mounting rubber - 2 off | 21 Tap lever       |
| 5 Lower mounting rubber - 2 off | 13 Lower mounting rubber - 2 off | 22 Wave washer     |
| 6 Trim                          | 14 Fuel level sender unit        | 23 Retainer plate  |
| 7 Rear mounting rubber - 2 off  | 15 Screw - 2 off                 | 24 Screw - 2 off   |
| 8 Bolt - 2 off                  | 16 Washer - 2 off                | 25 Connecting pipe |
|                                 | 17 Fuel tap                      | 26 Fuel filter     |
|                                 |                                  | 27 O-ring          |




3.2d Fuel tank - ZX1000 B models

- |                                 |                               |                   |
|---------------------------------|-------------------------------|-------------------|
| 1 Filler cap                    | 8 Bolt - 4 off                | 15 Bolt - 2 off   |
| 2 Front mounting brackets       | 9 Rear damping rubber - 2 off | 16 Washer - 2 off |
| 3 Front mounting rubber - 2 off | 10 Rear mounting bracket      | 17 Seal           |
| 4 Bolt - 4 off                  | 11 Bolt - 2 off               | 18 O-ring         |
| 5 Fuel level sender unit        | 12 Spacer - 2 off             | 19 Tap lever      |
| 6 Seal                          | 13 Bolt - 4 off               | 20 Wave washer    |
| 7 Lower cover                   | 14 Fuel tap                   | 21 Retainer plate |
|                                 |                               | 22 Screw - 2 off  |






**3.3a On ZX1100 C models do not disconnect the lower fuel tap hose**



**3.3b Disconnect fuel level sender unit wiring at block connector**



**3.12 Detach the hose link and unscrew each filter for cleaning**

connector. On ZX1100 C models do not remove the lower pipe from the fuel tap (see illustrations). All pipes are disconnected by squeezing together the ears of their retaining clips and sliding the clips down the pipe, which can then be worked off its stub with the aid of a small screwdriver. Once the relevant pipes and wiring connectors have been disconnected the tank can be lifted away from the machine.

4 Fuel tank repairs are a task for the expert only. Any welding or brazing must be preceded by careful flushing out, once the fuel tank has been stripped of all its ancillary components. A resin-based tank sealing compound is a much more satisfactory and easier way of curing leaks. Accident damage repairs will inevitably involve re-painting the tank. Matching of modern paint finishes, especially metallic ones, is a very difficult task. It is therefore recommended that the tank be removed and taken to a motorcycle dealer or similar expert for professional attention.

5 Repeated contamination of the fuel tap filter and carburettor by water or rust and paint flakes indicate that the tank should be removed for flushing with clean fuel and internal inspection. Rust problems can be cured by using a resin tank sealant.

6 The fuel tank is refitted by a reversal of the removal procedure. Examine the rubber mounting dampers which are positioned underneath the tank for signs of deterioration and damage and renew if necessary. Smear a small amount of lubricant on the rubbers to allow the tank to slide easily into position. Connect the pipes, noting that on California models the blue marked (breather) pipe is fitted to the right-hand tank stub and the red marked (fuel return) pipe is fitted to the centre stub, except on ZX900 models where it is fitted to the left-hand stub.

7 Secure all the pipes with their retaining clips and reconnect the fuel level sender wiring connector. Turn the fuel tap to the ON position (PRI position on ZX900 and ZX1000 A models) and check for any fuel leaks. Refit the mounting bolts, tightening them securely, followed by the sidepanels, seat and inner fairing sections (where applicable).

## ZX1100 D models

8 Remove the seat.

9 With the tap in the OFF position, squeeze the clamp ears together and pull the fuel supply hose off the lower union on the tap; leave the other hoses connected. On California models, label and then disconnect the emission control hoses from the rear of the tank.

10 Remove the two mounting bolts at the rear and two at the front, and lift the tank sufficiently to disconnect the level gauge wiring and pull free the fuel breather pipe (where fitted).

11 Refer to the information in paragraph 4 concerning fuel tank repair and contamination problems.

12 There are two fuel filters inside the tank, which can be reached once the ON and RES hose links are detached from the tank underside (see illustration). Remove the filters and flush them through with clean fuel whilst observing the necessary fire precautions.

13 Refit the tank in a reverse of the removal sequence, making sure that all hoses are routed correctly. The emission control hose connections are given in illustration 13.1e. Check that there is no sign of fuel leakage before riding the machine.

## 4 Fuel tap - removal, examination and refitting

## ZX900 and ZX1000 A models

1 The fuel tap is of the vacuum type and is automatic in operation. The tap lever has three positions marked ON, RES (reserve) and PRI (prime). In the first two of these settings, fuel flow is controlled by a diaphragm and plunger held closed by a light coil spring. When the engine is started, the low pressure in the intake tract opens the plunger allowing fuel to flow through the tap to the carburettors. When the tap is set to the Pri position, the diaphragm and plunger are bypassed.

2 In the event of a fault, the most likely culprits are the vacuum pipe or diaphragm. If

a leak develops in either of these the tap will not operate in anything other than the Pri position. Check the vacuum pipe for obvious splits or cracks, and renew if necessary. If the diaphragm itself is suspect set the tap lever to ON or RES and disconnect the fuel and vacuum pipes at the carburettor. Suck gently on the vacuum pipe. If fuel does not flow, remove the tap for inspection as follows:


3 Remove the fuel tank as described in Section 3. If the tank is full or nearly full, drain it into a clean container suitable for holding petrol (gasoline), taking great care to prevent the risk of fire. Place the tank on its side on some soft cloth, arranging it so that the tap is near the top. Slacken and remove the two tap mounting bolts and lift the tap away, taking care not to damage the O-ring which seals it.

4 From the front of the tap remove the two small cross-head screws which secure the tap lever assembly. Withdraw the retainer plate, wave washer, tap lever, O-ring and the tap seal. Examine the tap seal and tap lever O-ring, especially if there has been evidence of leakage. Check that the tap seal has not become damaged and caused a blockage of the outlet hole. Fit a new O-ring and tap seal if required, and reassemble the tap lever assembly by reversing the above sequence.

5 Working from the rear of the tap, remove the four countersunk screws which retain the diaphragm cover, noting the direction in which the vacuum stub faces, and lift it away taking care not to damage the rather delicate diaphragm. Remove the small return spring. Very carefully dislodge the diaphragm assembly and remove it from the tap body. The diaphragm assembly contains a plastic diaphragm plate sandwiched between two thin diaphragm membranes. Carried through the centre of the assembly is the fuel plunger which supports a sealing O-ring.

6 Examine the diaphragm closely for signs of splitting or other damage. Carefully remove any dust or grit which may have found its way into the assembly. Check the condition of the O-ring on the end of the plunger. If wear or damage of the above components is discovered, it will be necessary to renew the diaphragm assembly complete. Note that one side of the diaphragm plate has a groove in it,





**4.11 Disconnect the ON and RES hose links from the rear of the tap**

and this must face towards the O-ring on the plunger. When fitting the diaphragm assembly and cover, check that the diaphragm lies absolutely flat, with no creases or folds. Fit the cover with the vacuum stub facing in the correct direction (this varies according to the model). Tighten the securing screws evenly and securely.

### **ZX1000 B and ZX1100 C models**

**7** The fuel tap is much simpler in design to that which is described above. Fuel should flow when the tap is in the ON or RES (ZX1000 B only) positions and not in the OFF position. During normal operation the tap can be left in the ON position, only needing to be turned OFF when the fuel tank is to be removed, as the flow of the fuel is controlled by an electrically operated pump.

**8** To remove the fuel tap, remove the fuel tank as described in Section 3 and drain the fuel into a clean metal container. Place the tank on its side on some soft cloth so that the fuel tap is positioned at the top. Slacken and remove the two screws that retain the tap assembly and lift the tap away, taking care not to damage the sealing O-ring.

**9** The fuel tap can then be overhauled as described in paragraph 4 of this Section.

### **ZX1100 D models**

**10** Remove the fuel tank as described above.

**11** Move the lever to the RES position and drain the fuel into a suitable container. Remove the two bolts retaining the tap to the

tank and disconnect the short ON and RES hoses from the tap to the tank underside (see illustration).

**12** To dismantle the tap, remove the central screw and remove the operating lever - note the spring and steel ball which will drop free. Remove the disc, O-ring and seal from the tap body.

**13** Clean the tap body thoroughly and renew the seal if leakage has been noted or signs of deterioration are apparent. Renew the large O-ring. Ensure that the steel ball is correctly located in its detent when refitting the operating lever.

### **All models**

**14** Examine the fuel tap sealing O-ring for sign of damage or deterioration and renew it if necessary. Refit the tap to the fuel tank and tighten its retaining screws securely. Refit the fuel tank to the machine as described in Section 3 and thoroughly check the tap assembly for fuel leaks before taking the machine on the road.

### **5 Fuel system pipes - general**

**1** Thin-walled synthetic rubber tubing is used for many purposes, whether in the fuel system, emission control system or as drain or breather pipes. All pipes are of the push-on type, being secured by small wire clips. Normally it is necessary to renew pipes only if they become hard or split; it is unlikely that the clips will need frequent renewal as the main seal between hose and union is effected by the interference fit.

**2** Check carefully at periodic intervals that the pipes are correctly fitted, undamaged, and secured to the frame by any clamps or ties provided. Check that they are correctly routed and that no drain or breather pipes are long enough to interfere with the final drive chain and gearbox sprocket or with the rear brake or suspension. If the pipes split, it is normally at the end, on or close to the union. In such cases the damaged length can be cut off and the pipe refitted.

**3** If any pipe has to be renewed, use only the genuine Kawasaki replacement parts, particularly on emission control systems. Where pipes are moulded to a particular shape or where they are of an unusual size, this will be necessary anyway. The only exception to this is that it is permissible to use proprietary synthetic rubber or neoprene tubing for vacuum, breather and drain pipes and, in an emergency, for fuel pipes. Never use natural rubber tubing or clear plastic petrol pipe; neither of these is suitable for such use.


### **6 Fuel pump and filter (ZX1000 B and ZX1100 C/D models) - removal and refitting**

**1** Remove the fuel tank and the carburettors as described in Sections 3 and 7 of this Chapter. The fuel pump and filter are located on the frame cross member, situated just below the carburettors.


**2** Disconnect the fuel pipes from the inlet side of the filter and the outlet side of the pump. Separate the fuel pump wiring block connector and remove the pump and filter assembly from the machine (see illustrations). Before separating the pump and filter, mark the pump inlet stub (filter side of the pump) to avoid connecting the fuel hoses wrongly on refitting.

**3** If necessary, the fuel pump can be tested as described in Chapter 8.

**4** The pump is refitted by a reversal of the removal procedure. Fit the fuel filter to the pump inlet stub, using the mark made on removal to align it correctly. Ensure that the arrow on the filter body is pointing towards the fuel pump (see illustration). Refit the pump and filter assembly to the machine and connect the relevant fuel pipes and the fuel pump block connector. Check that all fuel pipes are correctly routed and securely held by their retaining clips. Refit the carburettors and fuel tank as described in Sections 7 and 3 of this Chapter, and thoroughly check for any fuel leaks before taking the machine on the road.



**6.2a Disconnect the fuel pump wiring at block connector . . .**




**6.2b . . . and remove the fuel pump and filter assembly**



**6.4 Ensure arrow (highlighted) on filter body is pointing towards the pump**






**7.7a** On ZX1100 C models remove rubber plugs from air filter housing and slacken the mounting bolts



**7.7b** Disconnect air filter housing from the breather cover . . .



**7.7c** . . . and lift the housing clear

## 7 Carburetors - removal and refitting



1 Remove the fuel tank as described in Section 3 of this Chapter. Disconnect the carburettor warmer (coolant) pipes from both the left and right-hand side of the carburetors (where fitted) and block the ends of the pipes with a suitably-sized plug, such as a wooden bung or clean screw or bolt, to prevent excess coolant escaping. Mop up any spilt coolant and follow the procedure given under the relevant sub-heading. On California models note that it will also be necessary to disconnect the relevant emission control pipes from the carburetors before removal.

### ZX900 models

2 Slacken fully all the inlet stub clamp screws and roll the spring clips on the air filter hoses towards the housing. Slacken both the throttle and choke cable adjuster locknuts and fully screw in the adjusters so that the maximum freeplay possible is obtained on both cables. Remove the two air filter housing mounting bolts and position the air filter housing as far rearwards as possible.

3 Pull the carburettor assembly to the rear to clear it from the inlet rubbers and twist it carefully to disengage the air filter hoses. Manoeuvre the carburetors out to the right-

hand side of the machine until both the throttle and choke cables can be disconnected and the carburetors freed from the machine.

4 The above procedure describes the bare essentials of what is a very awkward and difficult procedure. When removing the carburetors, great care and patience must be exercised at all times to ensure they are not damaged in any way.

### ZX1000 and ZX1100 models

5 Remove the air filter element as described in Chapter 1.

6 On ZX1000 models roll the spring clips on the air filter hoses towards the filter housing and remove the casing from the machine. Note that on ZX1000 A models it will be necessary to remove the fuel tank mounting bracket to allow the air filter casing to be removed from the machine.


7 On ZX1100 C models the rear section of the air filter housing is mounted onto the carburetors by eight bolts, seven of which are covered by plugs. To remove the filter housing, prise out the rubber blanking plugs and remove all the housing mounting bolts (see illustrations). The housing can then be lifted off the carburetors (see illustration). To remove the air filter housing on ZX1100 D models, first remove the eight bolts from around the carburettor intakes, noting that access to one of them is made by removing

the plug in the rear of the filter housing (see illustration). You will notice that the housing is only held to the carburetors by four of these bolts, the other four just retain the plate between the carburettor bank and housing. Push the air intake ducts out of the front of the housing and pull the large diameter crankcase breather hose out of the housing at the rear. Raise the housing slightly, and pull off the small diameter breather pipes at the front, the oil reservoir pipe at the rear, and the air suction valve hose at the centre. Lift the air filter housing free, and remove the plate from the carburetors.


8 On all models, slacken the inlet stub clamp screws and the throttle and choke cable adjuster locknuts. Screw the adjusters in fully to obtain the maximum freeplay possible on both cables. On ZX1000 B and ZX1100 C/D models also disconnect the fuel line, which joins the carburetors to the fuel pump, from the underside of the carburetors (see illustration). Pull the carburetors to the rear to disengage them from the inlet rubbers and disconnect the throttle and choke cables. If it proves difficult to disconnect the throttle cables from the carburetors the task can be made easier by first removing the two screws from the right-hand handlebar switch and disconnecting the cables from the twistgrip (see illustration). Once the cables have been disconnected the carburetors can then be lifted away from the machine.



**7.7d** One of the air filter housing bolts must be accessed from side of housing



**7.8a** On ZX1000 B and ZX1100 C/D models disconnect the fuel pipe from underside of carburetors



**7.8b** If necessary, disconnect throttle cables from twistgrip



## All models

**9** The carburettors are refitted by a reversal of the removal procedure. A small amount of light grease may be smeared over the insides of the inlet stubs and air filter hoses to ease the task (see illustration). Position the carburettors and connect both the throttle and choke cables. Carefully manoeuvre the carburettors into position and insert them into the inlet stubs. Ensure the carburettors are pushed fully home at both ends and tighten the inlet stub clamps securely. Adjust the throttle and choke cable freeplay as described in Chapter 1.

**10** Install the air filter housing (if removed) and refit the hoses to the carburettors. Ensure the pipes are correctly located on the carburettors and secure them with the spring clips. On ZX900 and ZX1100 C/D models refit the housing mounting bolts and tighten them securely. On ZX1100 C/D models do not forget to refit the rubber plugs which fit into the air filter housing.

**11** On ZX1000 and ZX1100 C/D models refit the air filter element as described in Chapter 1.

**12** Reconnect the carburettor warmer (coolant) pipes, mopping up any spilt coolant. Check the level of coolant in the expansion tank as described in 'Daily (pre-ride) checks' at the beginning of this Manual and top up if necessary. Reconnect the emission control pipes on California models. Refit the fuel tank as described in Section 3 of this Chapter. Check that the throttle cables operate freely and that there are no fuel leaks before taking the machine on the road.


**13** On ZX1000B and ZX1100 C/D models do not be alarmed if the engine fails to start immediately. Due to the nature of the fuel supply system (fuel pump only operates when the starter button is pressed) it may take anything up to 30 seconds to refill the carburettors with fuel and the engine to start.

**Caution:** Do not operate the starter motor continuously for more than 5 seconds at a time, and wait 15 seconds before operating the starter again, otherwise the starter motor may overheat and be damaged as a result.

## 8 Carburettors - dismantling, examination and reassembly

**1** Remove the carburettors from the machine as described in Section 7. Never remove the carburettors from their mounting brackets unless absolutely necessary; each carburettor can be dismantled sufficiently for all normal cleaning or adjustment procedures whilst in position on the brackets (see illustrations). If necessary, however, the carburettors can be separated as described in Section 9. Note that it is necessary to separate the carburettors to dismantle the choke mechanism.


**2** Working on one carburettor at a time to



**7.9** Ensure inlet stub clamps are correctly positioned before fitting carburettors




**7.10** On ZX1100 C/D models do not omit O-rings from the carburettors



- 1 Screw - 4 off
- 2 Spring washer - 4 off
- 3 Washer - 4 off
- 4 Carburettor top cover
- 5 Spring
- 6 Needle retainer
- 7 Jet needle
- 8 Diaphragm/piston assembly
- 9 Needle jet
- 10 Needle jet holder
- 11 Main jet
- 12 Pilot jet
- 13 Floats
- 14 Pivot pin
- 15 Needle valve
- 16 Clip
- 17 O-ring
- 18 Float chamber
- 19 Drain screw
- 20 O-ring
- 21 Screw - 4 off
- 22 Spring washer - 4 off
- 23 Blanking plug - US only
- 24 Pilot screw
- 25 Spring
- 26 Washer
- 27 O-ring
- 28 Choke plunger
- 29 Spring
- 30 Nut
- 31 Cap




- 1 Screw - 4 off
- 2 Carburettor top cover
- 3 Spring
- 4 Needle retainer
- 5 Jet needle
- 6 Diaphragm/piston assembly
- 7 Air jet
- 8 Needle jet
- 9 Main jet
- 10 Pilot jet
- 11 Filter
- 12 O-ring
- 13 Needle valve seat
- 14 Screw
- 15 Needle valve
- 16 Clip
- 17 Floats
- 18 Pivot pin
- 19 Screw
- 20 O-ring
- 21 Float chamber
- 22 Drain screw
- 23 Shield
- 24 Screw - 4 off
- 25 Blanking plug - US only
- 26 Pilot screw
- 27 Spring
- 28 Washer
- 29 O-ring
- 30 Plunger
- 31 Spring
- 32 Nut
- 33 Cap



8.1b Carburettor - ZX1000 B and ZX1100 C/D models

avoid the accidental interchange of components, slacken and remove the four screws which retain the top cover. Lift off the cover and remove the spring from inside the piston (see illustration). Carefully peel the diaphragm away from its sealing groove in the carburettor and withdraw the diaphragm and piston assembly; do not use a sharp instrument to displace the diaphragm as it is easily damaged (see illustration). Remove the needle retaining clip from inside the piston and separate the needle and piston (see illustrations). On ZX1000 B and ZX1100 C/D models take care not to lose the small air jet situated in the top surface of the carburettor body (see illustration). If possible it should




8.2d ... and tip out the jet needle



8.2a Remove four screws and lift off top cover. Withdraw return spring ...



8.2b ... followed by piston assembly




8.2c Remove needle retaining clip ...




8.2e On ZX1000 B and ZX1100 C/D models note air jet set in diaphragm or carburettor casting







**8.3a** Remove float bowl to gain access to jets



**8.3b** On ZX1000 B and ZX1100 C/D models remove float pin retaining screw . . .



**8.3c** . . . and lift out the float and needle assembly



**8.3d** Needle valve seat is also retained by a screw



**8.3e** Clean needle valve seat filter and renew the O-ring

unscrewed using a small flat-bladed screwdriver (see illustration).

**5** The pilot air (mixture) screw is situated in the bottom of the carburettor body. On all US models the pilot screw drilling will be sealed with a blanking plug which must be removed to allow the pilot screw to be withdrawn. The plug should be deformed, using a punch or scriber, then levered out of position. On all models screw the pilot screw in until it seats lightly, counting the number of turns necessary to do so, then remove the screw along with its flat washer and O-ring. The screw should be renewed if bent or damaged.

**6** The choke assembly can be removed, providing the carburettors have been separated (see Section 9), by unscrewing the nut which retains it in the carburettor body. If the plunger does not operate smoothly and easily or is damaged, it must be renewed. The return spring should also be renewed if at all suspect.

**7** Carefully check the carburettor body, float chamber and carburettor top for damage such as cracks, splits or distorted sealing faces. Whilst it may be possible to repair small defects it will usually be necessary to renew the damaged component.


**8** Check that the diaphragm is not split, perished or damaged. Holding it up to a strong light will usually reveal even the smallest hole. The diaphragm must be renewed even if only slight damage is found; it is not repairable. Check that the needle is

be removed for safekeeping but do not risk damaging the valve on removal if it is stuck in the carburettor body.


**3** Remove the four screws which retain the float chamber to the bottom of the carburettor and lift off the chamber to gain access to the various jets (see illustration). On ZX900 and ZX1000 A models press out the float pivot pin and remove the float and needle valve assembly. On ZX1000 B and ZX1100 C/D models the float pivot pin is retained by a crosshead screw which must be removed before the float and needle valve assembly can be removed (see illustration). On these models the needle valve seat can also be removed (see illustration). Slacken and remove the valve seat retaining screw and pull out the seat, followed by the O-ring and fuel

filter which is situated behind it. Clean the fuel filter in some fresh fuel and examine it for any cracks, renewing it if necessary (see illustration). On all models separate the needle valve and float.


**4** The main jet is a screw fit into the bottom of the needle jet and can be removed with a flat-bladed screwdriver (see illustration). The needle jet is also a screw fit into the carburettor body and can be unscrewed using a suitably sized spanner (see illustration). On ZX900 and ZX1000 A models the needle jet comprises two components, a holder and the needle jet itself. The holder can be removed as described above and the needle jet can be pushed out of position from the top of the carburettor with a wooden dowel. The pilot jet is located next to the main jet and can be



**8.4a** Main jet is a screw fit into the needle jet . . .




**8.4b** . . . and needle jet is a screw fit into the carburettor body




**8.4c** Pilot jet is situated beside main jet





**8.11a Renew O-rings on carburettor warmer hose fittings (where fitted) . . .**



**8.11b . . . and secure them with their retaining plates**

straight by rolling it on a flat surface such as a sheet of glass. If it is bent it must be renewed as a set along with the needle jet and holder (as applicable).

9 Check that the floats are in good order and are not punctured. If either float is punctured it will produce the wrong fuel level in the float chamber, leading to an over-rich mixture and flooding. If the floats are damaged they must be renewed as a satisfactory repair is not possible.

10 The needle valve and seat will wear after lengthy service and should be closely examined, with a magnifying glass if necessary. Wear usually takes the form of a groove or ridge, which will cause the needle to seat imperfectly. Test the spring-loaded tip on the bottom of the needle valve by pushing it into the body of the needle. The tip should return quickly and easily with the spring pressure. If the needle valve or seat are damaged both should be renewed as a set. On ZX900 and ZX1000 A models the needle valve seat is an integral part of the carburettor body and is not available separately.

11 The carburettors are reassembled by a reversal of the removal procedure, renewing all sealing O-rings as a matter of course (**see illustrations**). Use only close-fitting spanners and screwdrivers to tighten the jets and tighten each one by just enough to secure it. Avoid overtightening as the jets are easily sheared. On ZX1000 B and ZX1100 C/D models do not omit the filter which is fitted behind the needle valve seat. Insert the piston

into the carburettor body and lightly push it down, ensuring the needle is correctly aligned with the needle jet, then press the diaphragm outer edge into its groove. On ZX1000 B and ZX1100 C/D models ensure the small tongue is correctly seated around the small air valve situated in the top of the carburettor body. On all models check the diaphragm is not creased, and the piston moves smoothly up and down the bore before refitting the spring and top cover.

## 9 Carburettors - separation

1 Remove the carburettors as described in Section 7 of this Chapter. Mark each carburettor body with its respective cylinder



number to ensure they are positioned correctly on reassembly.

2 Disengage the choke bracket return spring and release the three screws which secure the bracket to the carburettors. Remove the bracket together with the six plastic washers which are fitted on each side of the bracket. On ZX900 and ZX1000A models remove the sixteen screws which secure the carburettors to the mounting brackets and lift the brackets away from the carburettors. On ZX1000 B and ZX1100 C/D models release the eight screws from the bottom mounting bracket, then slacken and remove the long 5 mm nut and bolt which holds all the carburettor bodies together.

3 On all models, very carefully disengage each carburettor from its neighbour, freeing the fuel, vent and warmer pipes (as applicable) and noting exactly how the throttle linkages engage with each other. Catch the two coil springs that will be released from each throttle linkage when the carburettors are separated. Note that it may be necessary to slacken the throttle linkage screws to gain sufficient space to disengage the linkages.

4 On reassembly line up the carburettors on a flat surface ensuring that the throttle linkages are correctly engaged and the larger coil springs are positioned in between each carburettor (**see illustrations**). Very carefully push the carburettors together ensuring that all the fuel, vent and warmer pipes are correctly aligned. On ZX900 and ZX1000 A models position both mounting brackets and fit all the mounting screws finger-tight only.


- 1 Choke bracket
- 2 Screw - 6 off
- 3 Plastic washer - 6 off
- 4 Return spring
- 5 Front mounting bracket
- 6 Screw - 8 off
- 7 Spring washer - 8 off
- 8 Rear mounting bracket
- 9 Screw - 8 off
- 10 Spring washer - 8 off
- 11 Throttle linkage spring - 2 off
- 12 Throttle cable bracket
- 13 Screw
- 14 Spring washer
- 15 Choke cable plate
- 16 Screw
- 17 Spring washer
- 18 Synchronising screw - 3 off
- 19 Spring - 3 off
- 20 Spring - 3 off
- 21 Pipe unions
- 22 Pipe unions
- 23 Idle speed knob - ZX900 shown
- 24 Washer
- 25 Spring




**9.4a Ensure all connecting pipes, springs and linkages are aligned before joining carburettor bodies**

**9.4b Carburettor linkage - ZX900 and ZX1000 A models**






9.4c linkage - ZX1000 B and ZX1100 C models




9.4d On ZX1000 B and ZX1100 C/D models refit the long 5 mm bolt . . .

On ZX1000 B and ZX1100 C/D models refit the long 5 mm bolt which passes through the carburettor bodies, followed by the mounting bracket and screws, again tighten them only finger-tight at this stage (see illustrations).

5 On all models, use a sheet of glass or a straightedge to ensure the carburettors are correctly aligned both horizontally and vertically, then tighten all mounting screws and bolts securely. Position a plastic washer on each side of the choke bracket and tighten the three retaining screws securely (see illustration). Refit the choke bracket return spring and check that the choke mechanism operates smoothly and returns quickly (see illustration). Finally refit the throttle linkage springs and check that the throttle operates smoothly and closes quickly.



9.4e . . . then the bottom mounting bracket and screws



9.5a Position a plastic washer each side of the choke bracket mounting points . . .


## 10 Carburettors - checking the settings

1 The various jet sizes are predetermined by the manufacturer and should not require modification. Check with the Specifications at the beginning of this Chapter if there is any doubt about the types fitted. If a change appears necessary it can often be attributed to a developing engine fault unconnected with the carburettors. Although carburettors wear in service, this process occurs slowly over an extended length of time and hence wear of the carburettors is unlikely to cause sudden or extreme malfunction. If a fault does occur, check first other main systems, in which a fault may give similar symptoms, before proceeding with carburettor examination or modification.

2 Where non-standard items, such as exhaust systems, air filters or camshafts have been fitted to a machine, some alterations to carburation may be required. Arriving at the correct settings often requires trial and error, a method which demands skill born of previous experience. In many cases the manufacturer of the non-standard equipment will be able to advise on correct carburation changes.


3 As a rough guide, up to 1/8 throttle is controlled by the pilot jet, 1/8 to 1/4 by the throttle valve cutaway, 1/4 to 3/4 throttle by the needle position and from 3/4 to full by the size of the main jet. These are only approximate divisions, which are by no means clear cut. There is a certain amount of overlap between the various stages. The above remarks apply only in part to constant depression carburettors which utilise a butterfly valve in place of the throttle valve. The first and fourth stages are controlled in a similar manner. The second stage is controlled by the by-pass valve which is uncovered as soon as the throttle valve (piston) is opened. During the third stage the fuel passing through the main jet is metered by the needle jet working in conjunction with the piston needle (jet needle).

4 If alterations to the carburation must be




9.5b . . . and refit throttle linkage springs





**10.5 Fuel level measurement - ZX1000 B and ZX1100 C/D models**

- 1 Level tube
- 2 Carburettor casting mark
- 3 O mark on level tube
- 4 Fuel level



**10.7 Float height measurement**

- 1 Gasket surface
- 2 Float needle valve
- 3 Float

### Float height measurement

7 Remove the float chambers and hold the carburettor assembly vertical with the air filter side upwards, then slowly invert it until each float is just resting on its needle, yet not compressing it. (see illustration). Measure the distance between the bottom gasket surface of the carburettor body and the bottom of each float. If there is any discrepancy it can be corrected by bending the bridge piece carefully. Note the float heights of all carburettors to be adjusted, then remove the float and bend as necessary the tang which bears on the float needle. Bending the tang up increases the float height and lowers the fuel level, therefore bending it down decreases the float height and raises the fuel level. Be very careful when bending the tang; only the smallest movement is necessary to effect a major change in float height.

8 When adjustment is complete, reassemble the carburettors and recheck the fuel level. Make the adjustments again, if necessary, but note that if serious difficulties are encountered, the float assembly, float needle and seat must be removed and checked very carefully for wear. Refit the carburettors to the machine when all carburettor fuel levels are at the correct setting, or at least within tolerances.

### Pilot screw adjustment

9 Where these are given as 'Preset' in the Specifications, the pilot screw settings should be regarded as fixed and should not be altered except by an experienced and qualified mechanic using the necessary diagnostic equipment. This is beyond the scope of most private owners. It is recommended that the same attitude be applied to all other models, the factory setting is usually best for all normal use and while badly adjusted pilot screws will have a serious effect on engine performance, setting them accurately is by no means easy for the inexperienced. The object is to find the setting at which the engine runs fastest and smoothest when warmed up to normal operating temperature.

## 11 Carburettors - adjustment and exhaust emissions - general

1 In some countries legal provision is made for describing and controlling the types and levels of toxic emissions from motor vehicles.

2 In the US exhaust emission legislation is administered by the Environmental Protection Agency (EPA) which has introduced stringent regulations relating to motor vehicles. The Federal law entitled The Clean Air Act, specifically prohibits the removal (other than temporary) or modification of any component incorporated by the vehicle manufacturer to comply with the requirements of the law. The law extends the prohibition to any tampering which includes the addition of components, use of unsuitable replacement parts or maladjustment of components which allows the exhaust emissions to exceed the prescribed levels. Violations of the provisions of this law may result in penalties of up to \$10 000 for each violation. It is strongly recommended that appropriate requirements are determined and understood prior to making any change to or adjustments of components in the fuel, ignition, crankcase breather or exhaust systems.

3 To help ensure compliance with the emission standards some manufacturers have fitted to the relevant systems fixed or preset adjustment screws as anti-tamper devices. In most cases this is restricted to plastic or metal limiter caps fitted to the carburettor pilot adjustment screws, which allow normal adjustment only within narrow limits. Occasionally the pilot screw may be recessed and sealed behind a small metal blanking plug, or locked in position with a thread-locking compound, which prevents normal adjustment.

4 It should be understood that none of the various methods of discouraging tampering actually prevents adjustment, nor in itself, is adjustment an infringement of the current regulations. Maladjustment, however, which results in the emission levels exceeding those laid down, is a violation. It follows that no adjustments should be made unless the owner feels confident that he can make those adjustments in such a way that the resulting emissions comply with the limits. For all practical purposes a gas analyzer will be required to monitor the exhaust gases during adjustment, together with EPA data of the permissible Hydrocarbon and CO levels. Obviously, the home mechanic is unlikely to have access to this type of equipment or the expertise required for its use, and therefore, it will be necessary to place the machine in the hands of a competent motorcycle dealer who has the equipment and skill to check the exhaust gas content.


made, always err on the side of a slightly rich mixture. A weak mixture will cause the engine to overheat which may cause engine seizure. Reference to Chapter 1 will show how, after some experience has been gained, the condition of the spark plug electrodes can be interpreted as a reliable guide to mixture strength.

### Fuel level measurement

5 If the mixture is persistently too weak or too rich the fuel level should be checked. Position the machine on its centre stand on a level surface and attach the Kawasaki service tool, Part No 57001-1017. This is a clear plastic tube graduated in millimetres; an alternative is to use a length of clear plastic tubing and an accurate ruler. Connect one end of the tube to the float chamber drain outlet (use the drain tube if the Kawasaki tool is being used) and place the tube upper end against the carburettor body as shown (see illustration). Mark the tube at a point several millimetres above the bottom edge of the carburettor body (use the O mark on the service tool), then unscrew the float chamber drain plug by one or two full turns and switch on the fuel supply. Wait for the fuel level to stabilise then very slowly bring the tube down the carburettor body until the mark is level with its bottom edge. On ZX1000 B and ZX1100 C/D models, as the carburettors are mounted at an angle, the mark on the tube should be aligned with the mark situated just above the float chamber on the right-hand side of the carburettor body. On all models, do not lower the tube beyond the specified mark and raise it again or the level will be inaccurate. Measure the distance between the mark and the top of the fuel level in the tube or gauge. This distance is the fuel level.

6 The fuel level should be noted and the process repeated on the remaining carburettors. If any level is outside the tolerances given in the Specifications the carburettors must be removed from the machine and the setting altered by adjusting the float height as follows:





12.2 Vacuum take off points - ZX900 models

## 12 Carburettors - synchronisation




1 Carburettor synchronisation must be checked at the interval specified in Chapter 1, and whenever the carburettors have been disturbed or if the engine is running roughly. Always check the valve clearances before starting work. A set of accurate vacuum gauges is essential for the synchronisation, and if these are not available the job should be entrusted to an authorized Kawasaki dealer. On no account attempt to adjust synchronisation by 'feel'. It will almost certainly make things worse.

2 Remove the fuel tank and arrange a temporary fuel supply, either by using a small temporary tank or by using extra long fuel pipes to the now remote fuel tank on a nearby workbench. **Note:** if the vacuum pipe is bypassed (where applicable) it is important to plug its open end before attempting the check. Connect the vacuum gauge hoses to the four vacuum take-off points, having first disconnected the relevant hoses(s) and cap(s); the vacuum take-off points are to be found on the top or bottom of the intake stubs, or on the top of each carburettor body, where it enters the intake stub (see illustration). Start the engine and allow it to warm up to normal operating temperature. If the gauges are fitted with damping adjustment, set this so that needle flutter is just eliminated but so that they can still respond to small changes in pressure.

3 Running the engine at idle speed, check that all needles produce the same reading. A tolerance of up to 2 cm Hg between cylinders is permissible but it is better to have all cylinders adjusted to the same reading; this is by no means as difficult as it would appear, requiring only a little care and patience. Note that it does not matter what the reading is; only that it is the same for all cylinders. Stop the engine and allow it to cool down if it overheats.

4 The carburettors are adjusted by the three screws which are situated in between the carburettors in the throttle linkage (see



### 12.4 Synchronisation screw locations

- 1 Vacuum gauge take-off points
- 2 Adjusting screw for cylinders 3 and 4
- 3 Adjusting screw for left and right-hand pairs
- 4 Adjusting screw for cylinders 1 and 2


illustration). First check that the two left-hand carburettors are the same, then check that the two right-hand carburettors are equal. Adjust them if necessary, using the outer adjusting screws, then balance both pairs against each other using the centre screw. Do not press down on the screw whilst adjusting it, otherwise a false reading will be obtained. When all the carburettors are synchronised, open and close the throttle quickly to settle the linkage, and recheck the gauge readings, readjusting if necessary.

5 When the carburettors are correctly synchronised, stop the engine, disconnect the gauges and refit all disturbed components.

## 13 Evaporative Emission Control System - description and examination - California models

1 To comply with legislation in force in California and applying to all machines sold from 1984 onwards, these machines are fitted with equipment which prevents the escape into the atmosphere of any vapours produced by evaporation in any part of the fuel system. The equipment consists of a modified fuel tank, a canister of activated charcoal and a separator/pump unit, in addition to the connecting pipes and fittings (see illustrations).


2 Whilst the engine is stopped, vapour emitted by the evaporation of fuel in the tank passes through a blue-marked vent pipe to the top of the separator, where some of it condenses and passes through the separator into the pump unit, but the majority passes into the canister. Vapour emitted from the carburettor float chambers passes through a yellow marked pipe directly to the canister. From there it can only escape to the atmosphere by passing through the activated charcoal which traps the vapour completely. This works equally well in reverse when the engine is running, air passing via the air filter and the green-marked purge pipe to the canister and backwards through the system into the fuel tank and carburettors to compensate for the fuel consumed.



- 1 Fuel tank
- 2 Carburettor
- 3 Air filter casing
- 4 Separator unit
- 5 Canister
- 6 Blue-marked vent pipe
- 7 Red-marked fuel return pipe
- 8 Green-marked purge pipe
- 9 Blue-marked vent pipe
- 10 Yellow-marked vent pipe
- 11 White-marked vacuum pipe


13.1a Evaporative Emission Control System - ZX900 California models





**13.1c Evaporative Emission Control System - ZX1000 B California models**


- |                         |                               |
|-------------------------|-------------------------------|
| 1 Fuel tank             | 7 Red-marked fuel return pipe |
| 2 Carburettor           | 8 Green-marked purge pipe     |
| 3 Air filter casing     | 9 Blue-marked vent pipe       |
| 4 Separator             | 10 Yellow-marked vent pipe    |
| 5 Canister              | 11 White-marked vacuum pipe   |
| 6 Blue-marked vent pipe |                               |



**13.1b Evaporative Emission Control System - ZX1000 A California models**


- |                               |                            |
|-------------------------------|----------------------------|
| 1 Fuel tank                   | 7 Green-marked purge pipe  |
| 2 Red-marked fuel return pipe | 8 White-marked vacuum pipe |
| 3 Blue-marked vent pipe       | 9 Canister                 |
| 4 Separator                   | 10 Air filter casing       |
| 5 Blue-marked vent pipe       | 11 Carburettor             |
| 6 Yellow-marked vent pipe     |                            |





13.1e Evaporative Emission Control System - ZX1100 D California models

- |                     |                      |
|---------------------|----------------------|
| 1 Fuel tank         | 8 Vacuum valve       |
| 2 Blue-marked hose  | 9 Yellow-marked hose |
| 3 Red-marked hose   | 10 Canister          |
| 4 Separator         | 11 Catch reservoir   |
| 5 Blue-marked hose  | 12 Plug              |
| 6 White-marked hose | 13 Green-marked hose |
| 7 Inlet stub        |                      |



13.1d Evaporative Emission Control System - ZX1100 C California models

- |                                |                           |
|--------------------------------|---------------------------|
| 1 Fuel tank                    | 7 Canister                |
| 2 Red-marked fuel return pipe  | 8 Yellow-marked vent pipe |
| 3 Blue-marked fuel return pipe | 9 Green-marked vent pipe  |
| 4 Separator                    | 10 Air filter casing      |
| 5 White-marked vacuum pipe     | 11 Vacuum valve           |
| 6 Blue-marked vent pipe        | 12 Carburettor            |



3 As soon as the engine is started, the system is purged using the partial vacuum created at various points as the engine is running. All vapour remaining in the canister is drawn via the green-marked pipe into the air filter casing where it passes into the engine in the usual way. At the same time a simple pump, operated by the vacuum transmitted from number 3 carburettor inlet tract by the white-marked pipe, returns all liquid fuel in the separator to the fuel tank; both these purging operations being completed within moments of starting the engine. Since the pump runs automatically whenever the engine is running, it maintains the system at a pressure below that in the air filter casing, allowing air to enter the system so that the fuel system components can 'breathe' as described above.

### Fuel tank

4 This is fitted with a sealed cap in addition to the vent and fuel return pipes, and requires no maintenance other than to ensure that the cap seal, gasket and mounting screw O-rings are in good condition at all times. Renew the seals immediately if there is any doubt about their condition. On a general note, always plug the left-hand (fuel return) pipe union whenever the tank is removed with fuel still inside it, to prevent the loss of fuel, and never fill the tank to above the bottom of the filler neck. If fuel rises under expansion into the filler neck, it may enter the system via the vent hose and flood it, which would produce hard starting and indifferent engine performance due to an over-rich mixture. Use compressed air to clear the cap vent and tank pipes if they are blocked.

### Liquid/vapour separator and pump unit

5 Test the unit by removing the blue-marked vent pipe from its top, and then add about 20 cc of gasoline via the hose fitting. Disconnect the fuel return pipe from the tank union and place the pipe open end in a container, level with the tank top. Start the engine and allow it to idle; all the gasoline should be ejected into the container almost immediately. If not, the unit must be renewed. Keep it upright at all times to prevent surplus fuel from escaping.

### Charcoal canister

6 This should last the life of the machine in normal use and will not require attention of any sort other than to check its mountings and connections, but it should be noted that if fuel, solvent, water or any other liquid is allowed into the canister, its absorbing ability will be reduced to the point where it must be renewed. Check closely, therefore, for cracks or other damage.

### Pipes

7 These should be examined and renewed if necessary as described in Section 5. Use only genuine Kawasaki replacement parts and

ensure that the pipes are connected following the instructions given in the accompanying illustration whenever they are disturbed.

8 Check that the pipes are not pinched or trapped, or unusual symptoms may arise. If the engine performs erratically at high speeds or if it stops with apparent signs of fuel starvation, or if the tank sides bulge out because of excessive internal pressure, check the blue-marked vent pipe. If the engine is difficult to start and hesitates due to an over-rich mixture (ie produces clouds of black smoke), this is due to the canister being flooded because liquid fuel cannot return to the tank; check the red-marked fuel return pipe and the white-marked vacuum pipe, but note that similar symptoms may be caused by the presence of excess fuel vapour due to a blocked or pinched green-marked purge pipe. If the engine is difficult to start and hesitates due to a weak mixture, or stops with apparent signs of fuel starvation, check the yellow-marked vent pipe.

### General

9 The system is subject to the anti-tampering legislation currently in force in the US which means that the machine must never be used with any part of the system disconnected, missing, rendered inoperative or altered in any way. Use only genuine Kawasaki parts if renewal of any component is necessary.

### 14 Air filter - general

1 The air filter element can be removed and cleaned as described in Chapter 1. Never run the machine with the air filter disconnected or the element removed. Apart from the risk of increased engine wear due to unfiltered air being allowed to enter, the carburettors are jetted to compensate for the presence of the filter and a dangerously weak mixture will result if the filter is omitted which could lead to engine damage.

2 US owners should note that the air filter is subject to the anti-tampering legislation currently in force, which means the machine must never be run with the filter element removed or rendered inoperative, or with the assembly altered in any way. Furthermore, only genuine Kawasaki replacement parts may be used if the renewal of any component is necessary.

### 15 Exhaust system - general

1 All models except ZX1100 C/D models are fitted with an exhaust system consisting of two exhaust pipe/silencer assemblies that are joined by a connector pipe underneath the engine. The ZX1100 C/D models are fitted

with a 4 into 1 exhaust system which branches out into two silencers that are joined underneath the engine.

2 The exhaust system can be removed as described in Section 4 of Chapter 2 and refitted as described in Section 46 of Chapter 2. Apply liberal amounts of penetrating fluid to the mounting bolts and allow time for it to work before trying to remove them. Renew all gaskets whenever the exhaust system is removed. No maintenance is required except to ensure all the mounting bolts and nuts are secure.

3 Corrosion from inside and out is the most serious problem. Take care to keep the system as clean as possible and to protect it using a non-abrasive wax polish or by applying a light film of WD40.

4 Owners of US machines should note that if any part of the system is to be renewed only genuine Kawasaki parts should be used to ensure that the machine complies with all noise and pollution regulations in force. Under US federal law it is an offence to replace any part of the exhaust system with a component that is not EPA-approved, or to modify the system in any way if the modification results in an increase in noise levels.

### 16 Clean air system - US and ZX1100 D models

1 Some models incorporate an air injection system designed to enhance the burning of hydrocarbons in the exhaust gases, thus reducing toxic emissions. The system employs a modified cylinder head and cover, in which air is drawn in through a reed valve arrangement into the exhaust pipes.

2 The clean air system is automatic in operation and should not normally require attention. The most likely fault is that unfiltered air may be drawn into the system through a damaged air filter element or leaking hose, making the tickover unstable and reducing engine power. Backfiring or other unusual noises may be apparent.

### Air suction valve (reed valve)

3 The reed valves may be removed for examination after releasing their covers from the cylinder head cover. Check each valve for signs of deterioration, specifically examining the reeds for signs of delamination, cracking or scoring. Wash off any contaminants with a suitable solvent, and guard against scraping or scoring the sealing faces. The reeds and stopper plates may be removed if necessary, noting that Loctite or a similar thread-locking compound must be applied to the screw threads prior to reassembly.

### Vacuum switch valve

4 Regular inspection of the vacuum switch valve is unnecessary, and should be avoided unless a fault has been indicated. A vacuum





gauge and a syringe-type vacuum pump are required to check that the valve opens and closes at the specified pressures. Since few owners will have access to this type of equipment, it is suggested that the check is made by an authorized Kawasaki dealer, or by the temporary substitution of a sound valve. Note that Kawasaki state that a faulty valve must be renewed and that adjustment is not permitted, despite the adjuster screw and locknut fitted to the valve.


## Pipes

**5** Damaged or perished pipes are probably the most likely cause of trouble in the system, and are fortunately the cheapest problem to remedy. Remember that air leaks will cause erratic running, and if located between the vacuum switch valve and reed valves, will allow unfiltered air to enter the reed valves.

## General

**6** The removal and refitting of the system components is described in Sections 4 and 46 of Chapter 2, and that of the air suction valves in Sections 6 and 45 of the same Chapter. The system is subject to the anti-tampering legislation currently in force in the US which means that the machine must never be used with any part of the system disconnected, missing, rendered inoperative or altered in any way. Use only genuine Kawasaki replacement parts if renewal of any component is necessary.

- 1 Drive gear
- 2 Screw - 2 off
- 3 Gear holder
- 4 Washer
- 5 Circlip
- 6 Screw - 6 off
- 7 End cover
- 8 Dowel - 2 off
- 9 Thicker rotor set
- 10 Pump body
- 11 Pump shaft
- 12 Pin - 2 off
- 13 Thrust washer
- 14 Thinner rotor set
- 15 End cover
- 16 Pump bracket
- 17 Pressure relief valve
- 18 O-ring - 3 off
- 19 Dowel - 3 off
- 20 Seal - 3 off
- 21 Dowel
- 22 O-ring
- 23 Oil feed quill



17.2 Oil pump


## 17 Oil pump - examination and renovation

- 1** The oil pump and bracket assembly is removed as described in Section 12 of Chapter 2.
- 2** Remove the three bolts that secure the oil pump to the bracket and separate the pump and bracket, taking care not to lose the dowels which are fitted between the two components (see illustration). Slacken and remove the three screws from one end of the pump, lift off the cover, remove both the inner and outer pump rotors and withdraw the pin from the oil pump shaft. Turn the pump around and repeat the above procedure on the opposite end of the pump and withdraw the oil pump shaft.
- 3** Wash all the pump components and the oil


screen in a high flash-point solvent and allow them to dry. Examine the pump casing and internal components for any signs of wear or scoring (see illustration). Damage will occur if metal particles find their way into the pump. Renewal of the affected parts is the only remedy, bearing in mind that either set of rotors (inner and outer) should be renewed as a matching pair. The oil screen must be renewed if split or damaged and all sealing O-rings must be renewed as a matter of course.

**4** Reassemble the oil pump by reversing the dismantling procedure. Ensure that all pump components are absolutely clean and lubricate all the internal parts with clean engine oil. Do not omit the plain thrust washer from behind the inner set of rotors. Refit the end covers, ensuring the cover locating dowels are in position, and securely tighten all the screws (see illustrations).

17.3 Examine pump rotors for signs of scoring



17.4a Refit pin to the oil pump shaft . <http://manuals.magnamaniac.com>




17.4b ... and install both the inner and outer pump rotors




17.4c Ensure dowel is in position before refitting end cover





**17.5a Renew all O-rings and refit pump to the bracket**



**17.5b Apply thread-locking compound to oil pump mounting bolts and tighten to the specified torque setting**

5 Check that the oil pump shaft rotates smoothly and refit the locating dowels and O-rings to the bracket (**see illustration**). Note that the two O-rings which are fitted to the outlet side of the pump must be installed with their flat sides facing the bracket. Refit the pump assembly to the bracket and tighten its mounting bolts to the specified torque setting, having first applied a few drops of thread-locking compound to their threads (**see illustration**). Do not use an excess amount of thread-locking compound as this could block the oil passages. Refit the oil screen.

6 Before refitting the pump and bracket assembly to the engine it is recommended that the pressure relief valve should be examined as described in Section 19 of this Chapter, and the second oil screen which is located in the sump should be removed and cleaned as follows. Slacken and remove the three screws which secure the sump oil screen retaining plate and lift the screen out of the sump. Wash the screen in a high flashpoint solvent and examine it for damage, renewing it if necessary. Refit the screen to the sump and tighten its retaining screws securely.

7 Refit the oil pump and bracket assembly as described in Section 39 of Chapter 2.

## 18 Lubrication system - checking the oil pressure



1 The efficiency of the lubrication system is dependent on the oil pump delivering oil at the correct pressure. This can be checked by fitting an oil pressure gauge to the right-hand oil passage plug, which is located immediately below the ignition pick-up housing. Note that the correct threaded adaptor must be obtained or fabricated for this purpose. The best course of action is to obtain the correct Kawasaki pressure gauge and adaptor, Part Nos 57001-164 and 57001-1188 respectively.

2 Start by checking the pressure with the engine cold. Remove the end plug and fit the adaptor and gauge into position. Start the engine and note the pressure reading at


various engine speeds. If the system is working normally, the reading should comply with that given in the Specifications. If it exceeds the higher figure by a significant amount it is likely that the relief valve is stuck closed. Conversely, an abnormally low reading indicates that either the valve is stuck open or the engine is very badly worn. This test should now be repeated after the engine has been warmed up. Take the pressure reading at 4000 rpm. If the oil pressure is significantly below the figure given in the Specifications, and no obvious oil leakage is apparent, the oil pump should be removed for examination. On no account should the machine be used with low oil pressure, as plain bearing engines in particular rely on oil pressure as much as volume for effective lubrication.

3 It is likely that the normal oil pressure will be slightly above the specified pressure, but if it proves to be abnormally high, it is likely to be due to the oil pressure relief valve being jammed or damaged. This component is fitted to the inside of the sump. Refer to Section 19 for details.

## 19 Oil pressure relief valve - removal and testing



1 The pressure relief valve is located on the oil pump mounting bracket. To remove the relief valve, remove the oil pump assembly as



**19.2 Check that relief valve ball is free to move smoothly**

described in Section 12 of Chapter 2, and then unscrew the valve from the mounting bracket. Kawasaki caution against dismantling the valve, because it is felt that such action would cause inaccuracy in the assembly. It can, however, be tested as follows:

2 Using a wooden dowel or plastic rod, push the ball off its seat against spring pressure, noting that the ball should move smoothly and with no rough spots (**see illustration**). If any hesitation is felt, wash the valve in a high flash-point solvent and blow it dry with compressed air. Check the valve again. If no improvement is noted, renew the relief valve assembly. Note that this test is by no means conclusive, if any doubt remains about the condition of the valve it should be renewed.

3 On reassembly, apply thread-locking compound to the threads of the relief valve and tighten it securely (**see illustration**). Refit the oil pump and bracket assembly as described in Section 39 of Chapter 2.

## 20 Oil filter bypass valve - examination and renovation



1 The filter bypass valve is situated in the centre bolt of the oil filter assembly and is therefore removed and refitted with the oil filter as described in Chapter 1. Note that if the engine oil and filter are renewed at the specified intervals, it is unlikely that the bypass valve will ever come into operation or give trouble of any sort.

2 Its function is to ensure that the engine always receives a supply of oil (even if it is unfiltered) if the filter itself is too clogged to pass oil in sufficient quantities. In this event, the oil is diverted underneath it and into the centre bolt via the bottom pair of holes which are kept open by the presence of the coil spring and flat washer. The bypass valve ball is forced off its seat when subjected to this extra pressure so that the oil can pass on into the engine.

3 It will be evident that diagnosis of a bypass valve fault is very difficult, but as the valve is so simple and so rarely used it is not likely to give trouble. It should be washed in a high flash-point solvent whenever it is removed,



**19.3 On refitting apply thread-locking compound to its threads**



and care should be taken when refitting the filter to ensure that the valve can operate correctly if the need arises. If dismantling is necessary, place a wad of rag over the centre bolt open end, press out the retaining pin and tip out the spring and ball. All components should be examined for signs of wear, which should be evident, except for the spring which can only be compared with a new component, and renewed if necessary. Check that dirt is not present in the centre bolt, then refit the ball and spring. Compress the spring while inserting the retaining pin.

## 21 Oil pressure and oil temperature switches - removal and refitting



### Oil pressure switch


**1** The oil pressure switch is located on the left-hand side of the sump, opposite the oil filter housing (see illustration). To remove the switch, drain the engine oil as described in Chapter 1 and disconnect its electrical lead. The switch can then be unscrewed from the sump.

**2** If the oil warning lamp lights and the oil pressure is known to be correct, the switch should be tested as described in Chapter 8.

**3** On refitting, wipe the threads of the switch and the surrounding area of the sump clean. Apply a silicone sealant to the threads of the switch and then tighten it to the specified torque setting.

### Oil temperature switch - ZX900 models only

**4** The oil temperature switch is located on the front right-hand corner of the sump. To remove, drain the oil as described in Chapter 1 and disconnect its electrical lead. Unscrew the switch from the sump.



21.1 Oil pressure switch location

**5** On refitting, apply a thread-locking compound to the threads of the switch and tighten to the specified torque setting.

## 22 Oil cooler - removal, examination and refitting




**1** An oil cooler is fitted to limit the oil temperature during hard riding. The oil cooler matrix is positioned across the frame front downtubes to gain the best possible benefit from the airflow.

**2** To remove the oil cooler matrix it will first be necessary to remove the lower and side fairing sections as described in Chapter 6. Drain the engine oil as described in Chapter 1.

**3** Disconnect the oil hose union bolts from the oil cooler and remove the sealing washers. Release all the matrix mounting bolts and lift it clear of the machine. If necessary the hoses can also be removed by releasing the union bolts which secure them to the sump and freeing any clamps or ties which secure them to the frame.

**4** To maintain peak efficiency the matrix should be kept clear of any debris, preferably



22.5 Ensure oil cooler hoses are positioned correctly on refitting

by using an air jet directed from behind the matrix to blow out the air channels. Avoid using sharp instruments to dislodge any foreign matter as this could easily damage the vanes. Should the matrix become damaged and leakage occur, renewal of the component will probably be the only satisfactory solution as repair is unlikely to be successful. Hoses should be checked for cracks and splits or signs of leakage, renewing them if necessary. Renew all sealing washers as a matter of course.

**5** The oil cooler assembly is refitted by reversing the removal process. Examine the rubber dampers that are fitted to the matrix mounting bolts and renew any that are worn or perished. Install the matrix and tighten its mounting bolts securely. Refit the hoses ensuring that a new sealing washer is positioned on each side of the unions, and tighten the union bolts to their specified torque settings (see illustration). Do not forget to refit any clamps or ties that secure the hoses to the frame.

**6** Refill the engine with the correct amount of oil as described in Chapter 1, and thoroughly check for oil leaks before taking the machine on the road.



# Specifications

## Ignition timing

ZX900 and ZX1000 A models .....	10° BTDC @ 1000 rpm - 35° BTDC @ 3500 rpm
ZX1000 B models .....	10° BTDC @ 1000 rpm - 35° BTDC @ 7500 rpm
ZX1100 C/D models:	
UK models .....	10° BTDC @ 1000 rpm - 40° BTDC @ 6000 rpm
US 49-state models .....	7.5° BTDC @ 1000 rpm - 40° BTDC @ 6000 rpm
US California models .....	7.5° BTDC @ 1200 rpm - 40° BTDC @ 6000 rpm

## Pulser coil

### Resistance:

ZX900 models .....	390 - 590 ohms
ZX1000 models .....	400 - 490 ohms
ZX1100 C/D models .....	380 - 570 ohms

### Air gap:

ZX900 and ZX1000 A models .....	0.5 - 0.9 mm (0.020 - 0.036 in)
ZX1000 B and ZX1100 C/D models .....	0.7 mm (0.028 in)

## Ignition HT coil

### Primary windings resistance:

ZX900 and ZX1000 A models .....	1.8 - 2.8 ohms
ZX1000 B models .....	2.6 - 3.2 ohms
ZX1100 C/D models .....	2.3 - 3.5 ohms

### Secondary windings resistance:

ZX900 and ZX1000 A models .....	10 - 16 k ohms
ZX1000 B models .....	13 - 17 k ohms
ZX1100 C/D models .....	12 - 18 k ohms

### Minimum sparking distance:

ZX900 and ZX1000 A models .....	7 mm (0.28 in)
ZX1000 B and ZX1100 C/D models .....	6 mm (0.24 in)
Cylinder identification .....	Left to right 1-2-3-4



**Firing order** ..... 1-2-4-3

## Spark plugs

Recommended grade:

ZX900 and ZX1000 A models:

UK models

US models

ZX1000 B and ZX1100 C/D models:

UK models

US models

Electrode gap:

ZX900 and ZX1000 A models

ZX1000 B and ZX1100 C/D models

NGK

DR8ES

D8EA

CR9E

C9E

0.6 - 0.7 mm (0.024 - 0.028 in)

0.7 - 0.8 mm (0.028 - 0.032 in)

Nippon-denso

X27ESR-U

X24ES-U

U27ESR-N

U27ES-N

## Torque settings

	kgf m	lbf ft
Spark plugs	1.4	10
Ignition rotor retaining bolt	2.5	18

## 1 General description

Due to the lack of mechanical parts in the magnetically-triggered electronic ignition system it is totally maintenance free. The system comprises a rotor, pulser coil(s), IC ignitor unit and two ignition HT coils. The raised trigger on the rotor, fitted to the left-hand end of the crankshaft, magnetically operates the pulser coil(s) as the crankshaft rotates. The pulser coil(s) send a signal to the ignitor unit which in turn supplies the ignition HT coils with the power necessary to produce the spark at the plugs. Each coil supplies two spark plugs. Cylinders 1 and 4 operate off one coil and cylinders 2 and 3 off the other. For any given cylinder, the plug is fired twice for every engine cycle, but one of the sparks occurs during the exhaust stroke and therefore performs no useful function. This arrangement is commonly known as a 'spare spark' or 'wasted spark' system.

## 2 Precautions to be observed when working on the ignition system

**Warning: the very high output of the ignition system means that it can be very dangerous or even fatal to touch live components**

**or terminals of any part of the ignition system while it is still in operation. Therefore take great care to avoid personal contact with any part of the system while the engine is running, or even when the engine is stopped but the ignition is switched on.**

1 When working on any part of the ignition system, always cut off the power supply either by switching off the ignition key or by disconnecting the battery (negative terminal first). If test procedures require the system to

be in operation, take great care to prevent personal contact with any part of the system.

2 Do not attempt to run the engine with the battery disconnected or with its connections made to the wrong terminals; this will destroy the ignition trigger assembly and may damage the alternator and other electrical components.

3 Never disconnect or attempt to disconnect the ignition HT leads at the coils or spark plugs while the engine is running; apart from the personal risk described above, the coils and control unit would almost certainly be damaged.

4 Never use a meter or megger with a large capacity battery to test the IC ignitor unit as this will almost certainly damage the ignitor unit. It is recommended that only the Kawasaki tester (Part No 57001-983) is used to ensure the readings obtained are correct.

5 If the resistance of any other part of the system is to be tested, ensure that the power supply is cut off (see above) and that the wires leading to the pulser coils or ignitor unit are disconnected. This is to prevent the risk not only of personal injury but also of damage, either to the tester or to any of the system's components.

6 Note: owners of machines used in the US, particularly in California, should note the possible legal implications of attempting to service any part of the ignition system before undertaking such work. Refer to Chapter 4, Section 11.

## 3 Ignition system - fault finding

1 As no means of adjustment is available, any failure of the system can be traced to failure of a system component or a simple wiring fault. Of the two possibilities, the latter is by far the most likely. In the event of failure, check the system in a logical fashion, as described below (see illustrations).

2 Remove the spark plugs from No 3 and No 4 cylinders, giving them a quick visual check noting any obvious signs of flooding or oiling. Fit the plugs into their plug caps and rest them on the cylinder head so that the metal body of each plug is in good contact with the cylinder head metal. The electrode ends of the plugs should be positioned so that sparking can be checked as the engine is spun over using the starter motor.


3 **Note:** the energy levels in electronic systems can be very high. On no account should the ignition be switched on whilst the plugs or plug caps are being held. Shocks from the HT circuit can be most unpleasant. Secondly, it is vital that the plugs are soundly earthed when the system is checked for sparking. The IC ignitor unit can be seriously damaged if the HT circuit becomes isolated.

4 Check that the kill switch is in the RUN position, turn the ignition switch to ON and turn the engine over on the starter motor. If the system is in good condition a regular, fat blue spark should be evident at the plug electrodes. If the spark appears thin or yellowish, or is non-existent, further investigation will be necessary. Before proceeding further, turn the ignition off and remove the key as a safety measure.

5 Ignition faults can be divided into two categories, namely those where the ignition system has failed completely, and those which are due to a partial failure. The likely faults are listed below, starting with the most probable source of failure. Work through the list systematically, referring to the subsequent sections for full details of the necessary checks and tests.


- Loose, corroded or damaged wiring connections, broken or shorted wiring between any of the component parts of the ignition system
- Faulty ignition switch, side stand switch or engine kill switch
- Faulty ignition HT coil(s)
- Faulty pulser coil(s)
- Faulty IC ignitor unit





3.1a Ignition system circuit diagram - ZX900 and ZX1000 A models


- |                      |                   |                           |                |          |
|----------------------|-------------------|---------------------------|----------------|----------|
| 1 Ignitor unit       | 5 Ignition switch | 9 Side stand switch       | BL Blue        | R Red    |
| 2 Ignition HT coils  | 6 30 A fuse       | 10 Starter lockout switch | BR Brown       | W White  |
| 3 Pulser coils       | 7 Diodes          | 11 Neutral switch         | G Green        | V Yellow |
| 4 Engine kill switch | 8 Battery         | BK Black                  | LG Light green |          |



3.1b Ignition system circuit diagram - ZX1000 B and ZX1100 C/D models

- |                      |                   |                           |                |          |
|----------------------|-------------------|---------------------------|----------------|----------|
| 1 Ignitor unit       | 5 Ignition switch | 9 Side stand switch       | BK Black       | R Red    |
| 2 Pulser coil        | 6 Starter relay   | 10 Starter lockout switch | G Green        | W White  |
| 3 Ignition HT coils  | 7 30 A fuse       | 11 Neutral switch         | LG Light green | Y Yellow |
| 4 Engine kill switch | 8 Battery         | 12 Diodes                 |                |          |





**5.3 Engine kill switch is located in the right-hand handlebar switch**

## 4 Ignition system - checking the wiring



1 The wiring should be checked visually, noting any signs of corrosion around the various terminals and connectors. If the fault has developed in wet conditions it follows that water may have entered any of the connectors or switches, causing a short circuit. A temporary cure can be effected by spraying the relevant area with one of the proprietary dewatering aerosols such as WD40 or similar. A more permanent solution is to dismantle the switch or connector and coat the exposed parts with silicone grease to prevent the ingress of water. The exposed backs of connectors can be sealed off using a silicone rubber sealant.

2 Light corrosion can normally be cured by scraping or sanding the affected area, though in serious cases it may prove necessary to renew the switch or connector affected. Check the wiring for chafing or breakage, particularly where it passes close to part of the frame or its fittings. As a temporary measure damaged insulation can be repaired with PVC tape, but the wire concerned should be renewed at the earliest opportunity.

3 Using the appropriate wiring diagram at the end of this manual, check each wire for breakage or short circuits using a multimeter set on the resistance scale or a dry battery and bulb, wired as shown in illustration in 2.1 in Chapter 8. In each case, there should be continuity between the ends of each wire.

## 5 Ignition, engine kill and side stand switches - testing



1 The ignition system is controlled by the ignition or main switch, mounted on the top yoke. The switch has several terminals, of which two are involved in controlling the ignition system. These are the ignition terminal (yellow lead) and the power supply from the battery (white lead). The two terminals are connected when the switch is in the ON position and the connection should be



**5.5 Sidestand switch is mounted on frame, below footrest**

broken when the switch is in the OFF position. 2 If the operation of the switch is suspect, reference should be made to the wiring diagrams at the end of the manual. The switch connections are shown in diagrammatic form and indicate which are connected in the various switch positions. Trace the wiring back from the switch, disconnect it from the main wiring loom, and check the operation of the switch using a multimeter set to the resistance scale.

3 The engine kill switch is incorporated in the right-hand handlebar switch and can be tested in a similar manner (see illustration). Trace the wiring back from the switch to its block connector and disconnect it from the main wiring loom. Using the multimeter, continuity should be present between the yellow/red and red terminals when the switch is in the RUN position and an open circuit when the switch is in the OFF position.

4 If either switch is found to be faulty it must be renewed. While each is a sealed unit and can only be repaired by renewal, note that there is nothing to be lost by attempting a repair. Depending on the owner's skill, worn contacts may be reclaimed by building them up with solder or in some cases, simply by cleaning them with WD40 or a similar water dispersant spray.

5 The side stand switch is also linked into the ignition system and is designed to kill the ignition if the clutch is engaged with the transmission in gear whilst the side stand is down (see illustration). Trace the wiring back from the switch, disconnect it and carry out

the following test on the switch side of the wiring.

6 On ZX900 and ZX1000 A models when the side stand is up there should be continuity between the brown and black/yellow terminals, and when the stand is down there should be continuity between the black/yellow and green/white terminals. If not, the switch is at fault and must be renewed.

7 On ZX1000 B and ZX1100 C/D models there should be continuity between the two switch terminals when the stand is down and an open circuit when the stand is up. If not, the switch is faulty and must be renewed.

## 6 Ignition HT coils - testing




1 The ignition coils are situated underneath the fuel tank where they are mounted on the frame (see illustrations), except on ZX1000 A models where they are mounted on the bottom of the fairing bracket. By far the most accurate method of testing the ignition coils is to use the Kawasaki spark gap tester, but some idea of the condition of the coil can be gained by measuring the resistances of its primary and secondary windings as follows. These tests can be performed with the coils fitted to the machine.

2 To check the condition of the primary windings, disconnect the low tension leads from the terminals on the ignition coil and, using a multimeter set to the ohms x 1 scale, measure the resistance between the two terminals. To check the secondary winding, unscrew the suppressor caps from the HT leads and set the meter to the K ohms x 1 scale. Connect a meter probe to each HT lead, ensuring a good contact is made, and note the reading obtained. Compare both the primary and secondary resistance readings to those given in the Specifications. If either of the results obtained are not within the specified limits the coil should be taken to an authorized Kawasaki dealer for confirmation of your findings by testing the coils on a spark gap tester. If either coil is proved faulty it should be renewed; a satisfactory repair will not be possible.




**6.1a HT coil location - ZX1000 B and ZX1100 C/D models**



**6.1b HT coil location - ZX900 models**





**7.5 Pulser coil air gap measurement - ZX900 and ZX1000 A models shown**


- 1 Ignition trigger
- 2 Pulser coil for cyl 1 and 4
- 3 Pulser coil for cyl 2 and 3
- 4 Air gap

## 7 Pulser coils - testing

1 The pulser coil(s) are located on the left-hand side of the crankshaft. Note that a small amount of oil will be expelled as the pickup cover is removed, so place a container beneath the cover in which to drain the oil and then remove the cover. On ZX1000 and ZX1100 C/D models it will be necessary to remove the side fairing section, as described in Chapter 6. Trace the pulser coil wiring back to its block connector and disconnect it from the main loom; make the following test on the engine side of the wiring.

2 Using a multimeter set to the ohms x 100 scale, measure the resistance between the black and yellow wire terminals and compare the reading obtained with that given in the Specifications. On ZX900 and ZX1000 A models, carry out the same test using the black/white and blue wire terminals. If the actual reading is significantly different to that specified, the unit(s) are faulty and should be renewed. Note that on ZX900 and ZX1000 A models the pulser coils are not available separately and can only be purchased as a set.

3 If very little resistance is measured,



**7.7 Apply thread-locking compound to the top two pulser coil cover bolts (arrowed)**

indicating a short circuit, or if a very high resistance is measured, indicating an open circuit, note that this may be due to the wires being trapped or damaged at some point along their length. Such faults may be traced and easily repaired in the home workshop.

4 The pulser coil(s) can be removed from the machine once their mounting bolts have been removed. On refitting apply thread-locking compound to the threads of the mounting bolts and set up the pulser coil air gap as follows:

5 Using a large ring spanner on the engine turning hexagon, rotate the crankshaft anticlockwise until the raised trigger on the rotor is in line with the pulser coil and tighten the pulser coil mounting bolts fingertight only. Using feeler gauges adjust the gap between the pulser coil and ignition trigger until the correct air gap (see Specifications) is obtained (see illustration). Tighten the pulser coil mounting bolts securely. On ZX900 and ZX1000 A models repeat the above sequence for the second coil noting that it is important that the air gap on both coils is identical.

6 On ZX1100 C/D models ensure the tube situated between the pulser coil and rubber grommet is positioned at the coil end of the wiring and apply a small amount of silicone sealant around the crankcase mating surfaces to ensure the cover seals correctly.

7 On all models refit the cover, using a new gasket, and tighten its retaining bolts securely (see illustration). Note that the top two cover


retaining bolts, situated directly under the cylinder barrel, should have a thread-locking compound applied to their threads prior to installation. Remove the oil filler plug from the top of the left-hand engine casing and top up the oil level as described in 'Daily (pre-ride) checks' at the beginning of this Manual. On ZX1000 and ZX1100 C/D models refit the fairing section as described in Chapter 6.

## 8 IC ignitor unit - testing


1 The location of the IC ignitor unit varies depending on the model. On ZX900 models it is situated below the rear of the fuel tank, which must be removed to gain access to the unit. On ZX1000 A models the unit is mounted on the right-hand side of the rear mudguard and it will be necessary to remove the tail section of the bodywork to gain access to it. On ZX1000 B models the ignitor is situated behind the left-hand sidepanel, where it is mounted next to the battery. On ZX1100 C models the unit can be found behind the right-hand sidepanel. On ZX1100 D models the ignitor is mounted to the rear mudguard by two bolts.

2 To test the unit it is best to remove it from the machine. Kawasaki recommend that only their multimeter, Part no. 57001-983, should be used to test the ignitor unit as any other meter could produce different readings. However, it should be possible to gain an indication of the unit's condition with another type of meter, and then to have your findings confirmed by a Kawasaki dealer if a fault is indicated. *Do not use a meter with a large battery capacity as this will almost certainly damage the unit.* If in any doubt the unit should be taken to an authorized Kawasaki dealer for testing.


3 Make various tests between the wires from the ignitor block connector as shown (see illustrations). If the results obtained do not closely resemble those in the table the ignitor unit must be renewed.



**8.1a IC ignitor unit location - ZX900 models**




**8.1b IC ignitor unit location - ZX1100 C models**



**8.1c IC ignitor for ZX1100 D models is retained by two bolts (A). Disconnect at connector (B) for testing**






Value (k $\Omega$ )	
$\infty$	Infinity
A	2 – 6
B	5 – 11
C	9 – 20
D	15 – 28
E	25 – 55

Tester (-) Lead Connection	Tester (+) Lead Connection									
	Terminal Number	1	2	3	4	5	7	8	9	10
	1		A	D	B	B	A	A	B	A
	2	A		D	B	B	A	A	B	A
	3	D	D		E	E	D	D	B	D
	4	$\infty$	$\infty$	$\infty$		$\infty$	$\infty$	$\infty$	$\infty$	$\infty$
	5	$\infty$	$\infty$	$\infty$	$\infty$		$\infty$	$\infty$	$\infty$	$\infty$
	7	A	A	D	B	B		A	B	A
	8	A	A	D	B	B	A		B	A
	9	B	B	B	C	C	B	B		A
	10	A	A	C	A	A	A	A	A	

8.3a Ignitor unit test table - ZX900 models



Value (k $\Omega$ )	
0	Zero
A	0.3 – 4.2
B	6.6 – 21.4
C	25 – 75
D	125 – 375
$\infty$	Infinity


		Tester Positive (+) Lead Connection									
Terminal No.		1	2	3	4	5	6	7	8	9	10
Tester Negative (-) Lead Connection	1		D	D	D	D	D	D	D	D	$\infty$
	2	D		D	D	D	D	D	D	D	$\infty$
	3	C	C		B	B	B	B	B	B	$\infty$
	4	$\infty$	$\infty$	$\infty$		$\infty$	$\infty$	$\infty$	$\infty$	$\infty$	$\infty$
	5	$\infty$	$\infty$	$\infty$	$\infty$		$\infty$	$\infty$	$\infty$	$\infty$	$\infty$
	6	C	C	B	A	A		A	0	0	$\infty$
	7	C	C	B	A	A	A		A	A	$\infty$
	8	C	C	B	A	A	0	A		0	$\infty$
	9	C	C	B	A	A	0	A	0		$\infty$
	10	$\infty$	$\infty$	$\infty$	$\infty$	$\infty$	$\infty$	$\infty$	$\infty$	$\infty$	

8.3b Ignitor unit test table - ZX1000 A models

Tester (-) Lead Connection	Tester (+) Lead Connection								(x 1 k $\Omega$ )
	R	BK/Y	Y	BK/W	G	BK	G/BK	BK/R	
R	–	2.4 ~ 9.8	4.3 ~ 17	2.4 ~ 10	6.1 ~ 24	6.1 ~ 24	5.9 ~ 24	16 ~ 66	
BK/Y	$\infty$	–	1.4 ~ 5.8	0	2 ~ 8	2 ~ 8	2.6 ~ 10	9.2 ~ 37	
Y	$\infty$	1.4 ~ 5.8	–	1.4 ~ 5.8	4 ~ 16	4 ~ 16	4 ~ 17	11 ~ 44	
BK/W	$\infty$	0	1.4 ~ 5.8	–	2 ~ 8	2 ~ 8	2.6 ~ 10	9.1 ~ 37	
G	$\infty$	$\infty$	$\infty$	$\infty$	–	$\infty$	$\infty$	$\infty$	
BK	$\infty$	$\infty$	$\infty$	$\infty$	$\infty$	–	$\infty$	$\infty$	
G/BK	$\infty$	2.7 ~ 11	4.2 ~ 17	2.7 ~ 11	5.8 ~ 23	5.8 ~ 23	–	13 ~ 52	
BK/R	$\infty$	13 ~ 54	16 ~ 62	13 ~ 54	25 ~ 100	25 ~ 100	18 ~ 70	–	

8.3c Ignitor unit test table - ZX1100 C models





(kΩ)

Tester (-) Lead Connection	Terminal No.	Tester (+) Lead Connection					
		1	2	3	4	5	6
	1	∞	∞	∞	∞	∞	∞
	2	30 – 70	∞	30 – 70	30 – 70	40 – 100	18 – 30
	3	13 – 45	15 – 70	∞	13 – 45	8.5 – 13	5 – 9.5
	4	∞	∞	∞	∞	∞	∞
	5	35 – 150	40 – 150	8.5 – 13	35 – 150	∞	18 – 35
	6	2 – 3.8	2.6 – 5	4 – 6.5	2 – 3.8	12 – 24	∞

(kΩ)

Tester (-) Lead Connection	Terminal Number	Tester (+) Lead Connection			
		7	8	9	10
	7	∞	∞	∞	∞
	8	∞	∞	∞	35 – 70
	9	∞	∞	∞	∞
	10	∞	28 – 60	∞	∞

8.3d Ignitor unit test table - ZX1000 B models

## 9 HT leads and suppressor caps - examination

1 Erratic running faults and problems with the engine suddenly cutting out in wet weather can often be attributed to leakage from the high tension leads and suppressor caps. If this fault is present, it will often be possible to see tiny sparks around the leads at night. One cause of this problem is the accumulation of mud and road grime around the leads, and the first thing to check is that the leads and caps are all clean. It is possible to cure the problem by cleaning the components and sealing them with an aerosol ignition sealer, which will leave an insulating coating on all components.

2 Water dispersant sprays are also highly recommended where the system has become swamped with water. Both these products are easily obtainable at most garages and accessory shops. Occasionally, a suppressor cap or lead may break down internally. If this is suspected, the components should be renewed.

3 Where the HT leads are permanently attached to the ignition coils it is recommended that the renewal of the lead is entrusted to an auto-electrician who will have the expertise to solder on a new lead without damaging the coil windings.

## 10 Spark plugs - general

Information relating to spark plug cleaning, adjusting and renewal will be found in Chapter 1, and a colour condition guide at the end of this manual, which can be used to determine mixture strength and running conditions.

Unit: kΩ

Lead	Terminal	Tester (+) Lead Connection								
		R	BK/Y	Y	BK/W	BK	G	G/BK	R/W	BK/R
(-)*	R	–	2.8 ~ 12	4.9 ~ 20	2.8 ~ 12	6.7 ~ 28	6.7 ~ 28	8.5 ~ 34	3.1 ~ 13	8.1 ~ 33
	BK/Y	40 ~ 170	–	1.4 ~ 5.7	0	1.7 ~ 7.2	1.7 ~ 7.2	3.9 ~ 16	0.2 ~ 0.8	2.2 ~ 9.0
	Y	42 ~ 170	1.4 ~ 5.7	–	1.4 ~ 5.7	3.7 ~ 15	3.7 ~ 15	5.2 ~ 21	1.6 ~ 6.4	4.3 ~ 18
	BK/W	40 ~ 170	0	1.4 ~ 5.7	–	1.7 ~ 7.2	1.7 ~ 7.2	3.9 ~ 16	0.2 ~ 0.8	2.2 ~ 9.0
	BK	∞	∞	∞	∞	–	∞	∞	∞	∞
	G	∞	∞	∞	∞	∞	–	∞	∞	∞
	G/BK	46 ~ 190	4.2 ~ 17	5.6 ~ 23	4.2 ~ 17	7.5 ~ 30	7.5 ~ 30	–	8.1 ~ 33	4.4 ~ 18
	R/W	42 ~ 170	0.2 ~ 0.8	1.5 ~ 6.3	0.2 ~ 0.8	2.0 ~ 8.2	2.0 ~ 8.2	4.0 ~ 17	–	2.5 ~ 10
	BK/R	70 ~ 280	30 ~ 120	30 ~ 130	30 ~ 120	42 ~ 170	42 ~ 170	34 ~ 140	30 ~ 120	–

(-)\*: Tester (-) Lead Connection

<http://manuals.magnamania.com>

8.3e IC Ignitor unit test table - ZX1100 D models



# Specifications

## Front forks

### Wheel travel:

ZX900 models	140 mm (5.51 in)
ZX1000 models	135 mm (5.31 in)
ZX1100 C models	125 mm (4.92 in)
ZX1100 D models	120 mm (4.72 in)

### Air pressure ZX900 A1 to A6 and ZX1000 A models:

Standard	0.5 kg/cm <sup>2</sup> (7.1 psi)
Usable range	0.4 - 0.6 kg/cm <sup>2</sup> (5.7 - 8.6 psi)

### Fork spring free length:

	<b>Standard</b>	<b>Service limit</b>
ZX900 A1 to A6 models	522 mm (20.6 in)	511 mm (20.1 in)
ZX900 A7-on models	430.5 mm (16.9 in)	421 mm (16.6 in)
ZX1000 A models	504.5 mm (19.9 in)	494 mm (19.4 in)
ZX1000 B models	488 mm (19.2 in)	478 mm (18.8 in)
ZX1100 C models	438 mm (17.2 in)	429 mm (16.9 in)
ZX1100 D models	295 mm (11.6 in)	289 mm (11.4 in)

### Fork oil capacity per leg - after reassembly:

	<b>cc</b>	<b>Imp fl oz</b>	<b>US fl oz</b>
ZX900 A1 to A6 models	318 ± 4	11.2 ± 0.14	10.7 ± 0.13
ZX900 A7-on models	496 ± 4	17.5 ± 0.14	16.8 ± 0.13
ZX1000 A models	348 ± 4	12.2 ± 0.14	11.7 ± 0.13
ZX1000 B models	418 ± 4	14.7 ± 0.14	14.1 ± 0.13
ZX1100 C models	458 ± 4	16.1 ± 0.14	15.5 ± 0.13
ZX1100 D models	465 ± 4	16.4 ± 0.14	15.7 ± 0.13

### Fork oil capacity (approx) per leg - at oil change:

ZX900 A1 to A6 models	270	9.5	9.1
ZX900 A7-on models	420	14.8	14.2
ZX1000 A models	295	10.4	10.0
ZX1000 B models	360	12.7	12.2
ZX1100 C models	390	13.7	13.2
ZX1100 D models	410	14.4	13.9



**Front forks (continued)**

Fork oil level:\*

ZX900 A1 to A6 models	357 ± 2 mm (14.1 ± 0.08 in) fork fully extended
ZX900 A7-on models	110 ± 2 mm (4.3 ± 0.08 in) fork fully compressed
ZX1000 A models	348 ± 4 mm (13.7 ± 0.16 in) fork fully extended
ZX1000 B models	130 ± 2 mm (5.1 ± 0.08 in) fork fully compressed
ZX1100 C models	149 ± 2 mm (5.9 ± 0.08 in) fork fully compressed
ZX1100 D models	133 ± 2 mm (5.2 ± 0.08 in) fork fully compressed

\*Oil level is measured from the top of the stanchion with fork spring removed.

Recommended fork oil:

ZX900 A1 to A6 and ZX1000 A models	SAE 10W fork oil
ZX900 A7-on, ZX1000 B and ZX1100 C/D models	SAE 10W/20 fork oil

**Rear suspension**

Wheel travel:

ZX900 models	115 mm (4.53 in)
ZX1000 A models	130 mm (5.12 in)
ZX1000 B and ZX1100 C models	120 mm (4.72 in)
ZX1100 D models	112 mm (4.41 in)

Air pressure:

	Standard	Usable range
ZX900 models	0.5 kg/cm <sup>2</sup> (7 psi)	0.5 - 1.5 kg/cm <sup>2</sup> (7 - 21 psi)
ZX1000 A models	0.5 kg/cm <sup>2</sup> (7 psi)	0 - 1.5 kg/cm <sup>2</sup> (0 - 21 psi)
ZX1000 B models	Atmospheric pressure	0.1 kg/cm <sup>2</sup> (0 - 14 psi)
ZX1100 C models	10 kg/cm <sup>2</sup> (142 psi)	Non adjustable
ZX1100 D models	Not applicable	

**Torque settings**

Handlebar to top yoke mounting bolts:

	kgf m	lbf ft
ZX900 A7-on models	1.9	13.5
All other models	2.0	14.5

Top yoke retaining nut

	4.0	29.0
--	-----	------

Yoke pinch bolts:

ZX900 and ZX1000 A models - top and bottom	2.1	15.0
ZX1000 B models - top and bottom	2.9	21.0

ZX1100 C/D models:

Top	2.9	21.0
Bottom	2.1	15.0

Front fork top bolts

	2.3	16.5
--	-----	------

Front fork damper rod retaining bolt:

ZX900 A1 to A6 models	3.0	22.0
ZX1000 models	4.0	29.0

ZX900 A7-on and ZX1100 C/D models	6.2	45.0
-----------------------------------	-----	------

Swinging arm pivot shaft nut(s)

	9.0	65.0
--	-----	------

Suspension unit and linkage pivot bolts:

All suspension unit and linkage bolts except ZX900 upper suspension unit mounting bolt	6.0	43.0
--	-----	------

ZX900 upper suspension unit mounting bolt:		
--	--	--

ZX900 A2-on models	3.0	22.0
ZX900 A1 model	4.0	29.0

**1 General description**

All models are fitted with forks of the conventional coil-spring hydraulically damped telescopic type. Those fitted to the ZX900 A1 to A6 and ZX1000 A models are air assisted and feature an adjustable anti-dive unit. The ZX1100 C/D forks feature an 8 position preload and a 4 position damping adjuster.

Frame design varies from model to model. The ZX900 models employ a diamond type

frame, constructed of tubular steel and using the engine unit as a stressed member. The frame on ZX1000 A models is of a full cradle design and is constructed of square-section steel. Both the ZX1000 B and ZX1100 C/D models use a full cradle type frame constructed totally in an aluminium alloy and braced to increase rigidity.


All models employ Kawasaki's Uni-trak rear suspension system where a square-section aluminium swinging arm acts on a single suspension unit via a linkage. The rear suspension unit has a 4 position damping adjuster and all units except that fitted to ZX1100 C/D models are air assisted.

**2 Front forks - removal**


1 Place the machine on its centre stand and remove the fuel tank and complete fairing. Place some blocks underneath the crankcases and remove the front wheel as described in Section 2 of Chapter 7.

2 Slacken the top yoke cover retaining screws (where fitted) and remove the cover. Remove the Allen bolts which secure the handlebar castings to the top yoke and lift






**2.2a Mudguard retaining bolts are on the inside of the mudguard**



**2.2b On ZX1100 C models mudguard is split for easy removal**



**2.2c ZX1100 D mudguard rear section lower screw . . .**

them clear. On ZX1100 D models there is no requirement to remove the handlebar castings from the top yoke unless you intend dismantling the forks, in which case it is good practice to slacken off the top bolts whilst firmly held in the yokes. Support the handlebars to avoid placing any strain on the hydraulic hoses and also to prevent the possible leakage of fluid from the master cylinders. On ZX900 A1 to A6 and ZX1000 A models remove the two Allen bolts which secure each anti-dive plunger assembly to the top of its valve and also remove the junction box retaining bolts. On all models remove the mudguard retaining bolts and lift it clear of the machine (**see illustrations**). To remove the front mudguard on ZX1100 D models, first remove the single screw on each side, followed by the two screws at the join of the front and rear sections at the top (**see illustrations**). Unscrew the speedometer cable knurled nut at the wheel end and pull the cable through the guide on the mudguard. Free both brake hydraulic hoses from their guide clips, then manoeuvre the mudguard rear section free. To remove the front section, remove the two bolts from each fork lower leg and the single screw on each outer face (**see illustration**). Make sure that the brake hoses and speedometer cable are correctly located after refitting the mudguard.

**3** Remove the valve cap(s) and depress the valve core(s) (where fitted) to release the air pressure from the forks. Remove the fork top bolts on ZX900 A2 to A6 models. Note if the

forks are to be dismantled slacken the top plugs before removing them from the yokes. On ZX900 A1 to A5 and early ZX1000 A1 models it will also be necessary to slacken the clamps which retain the air pressure balance union in position.

**4** The fork legs can then be removed by twisting each stanchion whilst pulling the leg downwards. If the stanchions are stuck in the yokes, apply penetrating fluid, allow time for it to work, and try again. In extreme cases it is permissible to fully remove the pinch bolts and lever the yoke clamps apart by wedging a screwdriver blade between them, but great care must be taken when doing this or the clamps may be broken, necessitating the renewal of the yoke.

**5** When both legs are removed the air pressure balance union (where fitted) can be removed. If the fork legs are not to be dismantled, tape over the air holes in the stanchions to prevent the oil from escaping.

### 3 Front forks - dismantling and reassembly

**1** Remove the fork legs from the machine as described in the previous Section. Dismantle each leg separately to avoid interchanging parts (**see illustrations overleaf**).

**2** Remove the top bolt, followed by the spacer and spring seat (as applicable) and withdraw the fork spring; take a note of

whether the closer pitched coils are at the top or bottom of the spring as a guide to reassembly. Invert the fork assembly over a suitable container and pour out the fork oil. Note that on ZX900 A1 to A6 and ZX1000 A models care must be taken to tip the fork up slowly as the TCV (Travel Control valve) valve will also fall out. Catch the valve as it emerges to prevent it being damaged. If the valve does not come out, gently tap the side of the lower leg until it is released from the stanchion end.


**3** Carefully lever out the dust seal from the top of the lower leg and prise out the fork oil seal retaining circlip and washer (where fitted). Using a vice equipped with soft jaws, firmly clamp the lower leg by the brake caliper mounting lugs so that it is horizontal.

**4** Remove the wheel spindle pinch bolt(s) and unscrew the Allen bolt situated at the bottom of the fork leg to release the damper rod assembly. If one is lucky this will unscrew easily. If, however, the bolt turns without unscrewing it will be necessary to hold the damper rod whilst it is slackened. The Kawasaki service tool for holding the damper rod consists of an adaptor which is fitted to a long T-handle and passed down through the stanchion to engage with the damper rod head. A suitable alternative can be made by grinding a coarse taper on a wooden rod of sufficient length; the tapered end can then be passed down the stanchion to engage in the damper rod head. With an assistant holding the protruding end of the wooden rod with a self-locking wrench and applying pressure to the damper rod head, the Allen bolt can be removed. The stanchion and lower leg can now be separated by pulling the two components apart.

**5** Push the stanchion fully into the lower leg and pull it out as sharply as possible. Repeat the operation several times, using the slide-hammer action of the bottom bush against the top bush to dislodge the oil seal, until the stanchion is freed from the lower leg. Invert the stanchion and tip out the damper rod and rebound spring. The oil seal, washer and top bush can then be slid off the stanchion. Removal of the lower bush should only be attempted if renewal is required; it can be removed by inserting a screwdriver into the




**2.2d . . . and top screws (only one shown)**



**2.2e Front mudguard front section inner (A) and outer mountings (B) on fork leg**






### 3.1a Front forks and steering yokes - ZX900 A1 to A6 and ZX1000 A models

- |  |  |                        |                                      |
|--|--|------------------------|--------------------------------------|
| 1 Top yoke   | 12 Seal  | 21 Fork spring         | 33 Oil seal                          |
| 2 Pinch bolt - 2 off <sup>1</sup>                          | 13 Washer  | 22 Stanchion           | 34 Washer                            |
| 3 Nut - 2 off  | 14 Plunger   | 23 TCV                 | 35 Top bush                          |
| 4 Air balance pipe early ZX1000<br>A1 and all ZX900 models | 15 Plunger housing                                   | 24 Damper rod          | 36 Lower leg                         |
| 5 Bottom yoke/steering stem                                | 16 Bleed valve                                       | 25 Piston ring         | 37 Allen bolt and sealing washer     |
| 6 Pinch bolt - 4 off <sup>1</sup>                          | 17 Top plug assembly - ZX1000<br>models              | 26 Rebound spring      | 38 Drain screw and sealing<br>washer |
| 7 Right-hand fork leg                                      | 18 Top plug assembly- ZX900 A1<br>model              | 27 Wave washer - 2 off | 39 Bottom bush                       |
| 8 Anti-dive unit   | 19 Top plug/bolt assembly -<br>ZX900 A2 to A6 models | 28 Washer              |                                      |
| 9 Separator  | 20 Spring seat - ZX1000 models                       | 29 Damper rod seat     |                                      |
| 10 Plug  |  | 30 Dust seal           |                                      |
| 11 Seal  |  | 31 Oil clip            |                                      |
|  |  | 32 Washer              |                                      |

<sup>1</sup> Pinch bolts pass through yokes  
from the rear on ZX900  
models





### 3.1b Front forks and steering yokes - ZX900 A7-on, ZX1000 B and ZX1100 C/D models


- |  |                             |                    |  |
|--|-----------------------------|--------------------|--|
| 1 Top plug <sup>2</sup> 1                    | 8 Pinch bolt - 4 off        | 16 Piston ring     | 24 Lower leg                                   |
| 2 O-ring                                     | 9 Nut - 4 off               | 17 Rebound spring  | 25 Allen bolt and sealing washer               |
| 3 Top yoke <sup>2</sup>                      | 10 Spacer <sup>2</sup>      | 18 Damper rod seat | 26 Drain screw and sealing washer <sup>2</sup> |
| 4 Pinch bolt - 2 off                         | 11 Spring seat <sup>2</sup> | 19 Dust seal       |  |
| 5 Top plug/damping adjuster rod <sup>3</sup> | 12 Fork spring              | 20 Circlip         |  |
| 6 Top yoke <sup>3</sup> 1                    | 13 Stanchion                | 21 Oil seal        |  |
| 7 Bottom yoke/steering stem                  | 14 Bottom bush              | 22 Washer          |  |
|  | 15 Damper rod               | 23 Top bush        |  |

<sup>1</sup> ZX900 A7-on models


<sup>2</sup> ZX1000 B models

<sup>3</sup> ZX1100 C/D models





**3.5** If necessary, the bottom bush can be removed using a flat-bladed screwdriver



**3.7** Refit the rebound spring to the damper rod and insert the rod fully into the stanchion

vertical split and levering the two ends apart by just enough to allow the bush to be slid off the bottom of the stanchion (see illustration). Invert the lower leg and tip out the damper rod seat. Note that on ZX900 A1 to A6 and ZX1000 A models there will also be three washers to remove from the lower leg.

**6** When all components have been cleaned and examined or renewed as described in the following section, they should be reassembled in the reverse of the removal sequence.

**7** Refit the rebound spring to the damper rod and insert into the upper end of the stanchion, pushing it down using either the fork spring or wooden rod until it projects fully from the

lower end of the stanchion (see illustration). On ZX900 A1 to A6 and ZX1000 A models refit the three washers over the damper rod end. The flat washer should have a wave washer positioned on each side of it. On all models refit the damper rod seat to the end of the rod and carefully refit the bottom bush (if removed) to the lower end of the stanchion, ensuring that it is correctly positioned in its locating groove.

**8** Smear the bottom bush and stanchion with oil and insert the assembly into the lower leg. Press the stanchion fully into the lower leg to centralise the damper rod seat (see illustration). Check the condition of the


sealing washer on the Allen bolt and renew if necessary. Apply a few drops of thread-locking compound to the threads of the Allen bolt and install in the stanchion (see illustration). Hold the damper rod using the method employed when dismantling, and tighten the bolt to the specified torque setting. Refit the spindle pinch bolt(s).

**9** Lubricate the top bush and slide it down over the stanchion, fit the large plain washer on top of it and press the bush into position noting that the slit of the bush must be positioned on either the left or right-hand side of the stanchion. On no account should the slit be placed facing the front or rear of the stanchion. If necessary the bush can be tapped into position using a hammer and drift, such as a socket spanner, placed on top of the washer. Smear the oil seal lip with fork oil and slide it down the stanchion (see illustration). Press the seal squarely into the lower leg as far as possible by hand only and refit the second plain washer (where fitted). The seal can be tapped fully into place using a length of tubing, which bears only on the seal's hard outer edge; check first that there are no burrs or sharp raised edges which could damage the seal. As soon as the circlip groove is exposed withdraw the tube and refit the seal retaining circlip, ensuring that it is correctly seated (see illustration). Pack a small amount of grease above the oil seal and refit the dust seal (see illustration).


**10** Fill each leg with the specified amount of fork oil and slowly pump the stanchion up and down to distribute the oil. When the level has settled measure the oil level as described in Chapter 1, correcting it if necessary. When the oil level is correct, refit the TCV valve (where fitted), ensuring that the two nuts are at the top. Fit the fork spring, ensuring that it is installed with its closer-pitched coils as noted on dismantling. Install the spring seat, spacer and top plug (as applicable). On ZX1100 C models refit the spring, seat and top plug as an assembly, ensuring that the spring seat is located on the stepped portion of the top plug and that the damping adjuster rod correctly engages with the hole in the damper rod



**3.8a** Fit the damper rod seat to end of rod lubricate guide bush and insert stanchion assembly into lower leg



**3.8b** Apply thread-locking compound to damper rod Allen bolt and tighten to specified torque setting



**3.9a** Slide a new seal down the stanchion and press it into position as described in text




**3.9b** Secure the seal with the circlip



**3.9c** ... and refit the dust seal





**3.10a** On ZX1100 C models fit the fork spring, spring seat and top plug as an assembly . . .



**3.10b** . . . and ensure the damping adjuster rod engages correctly with damper rod



**3.10c** On ZX1100 D models install plain washer on top of fork spring . . .



**3.10d** . . . followed by spacer and special washer . . .



**3.10e** . . . then install top bolt

#### 4 Front forks - examination and renovation



**1** Wash all fork components thoroughly to remove all traces of old oil. Check particularly carefully that all dirt has been removed from the bottom of the fork lower leg and from the passageways in the damping mechanism. On ZX900 A1 to A6 models and ZX1000 A models, it is advisable to remove the anti-dive valve unit so that one can be certain of cleaning it thoroughly and drying it completely. Refer to Section 6.

**2** Discard the fork oil seal; this should be renewed whenever it is disturbed. Similarly check the dust seals for splits, cracks or other damage, and check all sealing O-rings and washers. Renew any component that is found to be worn or damaged. On models so equipped, do not forget the seals around the air valves and, where applicable, in the air union. Also check the piston ring around the head of the damper rod. This ring must fit closely and seal tightly in its bore if the damping mechanism is to function efficiently.

**3** On ZX900 A1 to A6 and ZX1000 models check the TCV (Travel Control Valve), especially if damping problems have been experienced. The valve assembly should not be dismantled and no replacement parts are available; if found to be faulty, it must be renewed. If a fault is suspected first inspect the piston ring of the damper rod before turning attention to the TCV, then go on to check that the oil holes of the TCV are clear. If no damage is found the TCV must be renewed. Note that the valve depends on an accurate fork oil level for correct operation.

**4** Apart from the above, the only other

components likely to wear are the bearing surfaces of the stanchion and lower leg. Insert the stanchion into the lower leg, complete with bushes, and feel for free play between the two at all points, from full compression to full extension. No specifications are given, therefore if free play appears to be excessive, the worn components should be renewed. Excessive wear is normally revealed by score marks on one or both surfaces; if such signs are found the component concerned must be renewed. Take the components to an authorized Kawasaki dealer for an expert opinion if in doubt. Note that both the top and bottom bushes are available separately.

**5** The stanchions can be checked for straightness by rolling them on a flat surface such as a sheet of plate glass; any bending or distortion should immediately be evident. It is usually possible to straighten slightly bent stanchions provided that the work is undertaken only by an expert; any local motorcycle dealer should be able to recommend such a person. However if the stanchion is bent so much that the tubing has creased or even split, it must be renewed; straightening, even if possible, would induce severe stresses resulting in a fatigue failure at a later date.

**6** Check that the stanchions' upper surfaces are clean and free from chips, dents or corrosion which might weaken the tubing or cause oil seal failure. Use fine emery paper to

polish off any corrosion; but chips or dents, if minor, can be filled with Araldite or similar and rubbed down to restore the original shape when the filling compound has set. UK owners should note that such damage will cause the machine to fail its MOT test certificate. If in doubt about the stanchion's strength, renew it in the interests of safety.

**7** The fork springs will take a permanent set after considerable usage and will require renewal if the fork action becomes spongy. The service limit for the total spring free length is given in the Specifications.

**8** Make a careful check of all other fork leg components, checking for cracks in castings, damaged threads, defective air valves, and any other signs of wear or damage, renewing any faulty components.

#### 5 Front forks - refitting



**1** Apply a small amount of grease to the stanchion upper end and the air union sealing O-rings (where fitted). Insert the stanchion into the bottom yoke and slide the air union and its retaining clamp (where fitted) into position. Slide the stanchion through the top yoke, whilst holding the air union against the bottom yoke, and lightly tighten the top and bottom pinch bolts.






5.3a Position the fork legs in the yokes as described in text . . .



5.3b . . . then tighten all yoke pinch bolts to the specified torque setting



5.3c Refit the handlebars and tighten their mounting bolts to the specified torque setting

### ZX900 A1 to A6 and ZX1000 A models

2 Slide the handlebars over the fork stanchions and refit their mounting bolts. Position each stanchion so that its top edge is level with that of the handlebar casting and tighten both the top and bottom yoke pinch bolts and the handlebar retaining bolts to their specified torque settings. Ensure that the air union (where fitted) is positioned hard against the top surface of the bottom yoke and tighten its retaining clamps securely. Refit the anti-dive plunger assembly (where fitted), tightening the mounting bolts to the specified torque settings, and remount the junction box on each fork leg.

### ZX900 A7-on, ZX1000 B and ZX1100 C/D models

3 On ZX900 A7-on and ZX1000 B models, position the stanchion so that its top edge protrudes 15 mm (0.60 in) above the surface of the top yoke (see illustration). On ZX1100 C models the stanchion should be 11.5 mm (0.45 in) above the top yoke (see illustration). On ZX1100 D models the top surface of the top bolt hex should be level with the top surface of the handlebar clamp. Once the stanchion is correctly positioned, tighten both the top and bottom yoke pinch bolts to their specified torque settings (see illustration). Refit the handlebar castings and tighten their mounting bolts to the specified torque setting (see illustration).

### All models

4 Refit the mudguard and tighten its retaining bolts to the specified torque setting. If the fork legs were dismantled, also tighten their top plugs to their specified torque setting. On ZX900 A2 to A6 models, refit the fork top bolts and tighten them to the specified torque setting. Refit the wheel as described in Section 3 of Chapter 7, followed by the fairing and fuel tank. Charge the forks with the specified amount of air (as applicable) and refit the valve caps. Thoroughly check the operation of the front forks and brake before taking the machine on the road.

### 6 Anti-dive valve assembly (ZX900 A1 to A6 and ZX1000 A models) - testing and renewal

1 The valve assembly is mounted on the front of each fork lower leg being retained by four Allen screws. The oil passages are each sealed by O-rings. Note that no replacement parts are available with which the assembly can be reconditioned. If it becomes worn out or is damaged in an accident, each assembly can only be renewed as a single unit. Note that actual wear is unlikely; the unit is most likely to fail due to dirt jamming a valve.

2 Note that the anti-dive is hydraulically activated; refer to the relevant Sections of Chapter 7 for information on the plunger assembly and hydraulic system. To test the valve assembly, remove the fork legs from the machine as described in Section 2, then remove the fork top plug and the fork spring and tape over the air union hole (models with air balance pipe) drilled in the stanchion. Clamp the fork leg vertically in a vice, ensuring that the vice has soft alloy or wooden jaw covers that bear only on the wheel spindle lug, then set the anti-dive to the softest (Number 1) setting, ie fully anti-clockwise.

3 Ensuring that no oil is spilled, pump the stanchion gently and smoothly up and down through its full travel, feeling the amount of damping present on both compression and rebound strokes when the anti-dive is not operating. Insert a rod such as an Allen key into the hole in the top of the valve assembly and press firmly downwards; do not apply heavy pressure as it is not necessary; this may damage the valves. The hydraulic plunger should extend by only 2 mm. Repeat the pumping action and compare the difference when the rod is released with when it is depressed, then repeat the test with the anti-dive on each of the stronger settings.

4 The amount of effort required to compress the fork should increase noticeably as soon as the rod is depressed and should return to normal as soon as the rod is released. As the

setting is increased to its stiffest position the effort required to compress the fork should increase in proportion, yet should still return to normal when the rod is released. If compression damping is heavy when no pressure is applied to the rod, or if it does not return to normal when the rod is released, also if there is no difference in damping with pressure applied to the rod, the anti-dive unit is faulty and must be renewed. As a safety measure the manufacturer recommends that the assembly should not be dismantled with a view to repair and does not supply replacement parts as a result.

### 7 Steering head - removal

1 Remove the seat and fuel tank as described in Chapter 4. Remove the front forks as described in Section 2. On ZX900 models it may also be necessary to remove the fairing mounting bracket.

2 Remove the two bolts which secure the front brake union joint to the bottom yoke and position the brake hose clear of the steering head assembly. Tie the hoses and calipers to the frame to avoid placing any strain on them. On ZX900 A7-on and ZX1100 C/D models, prise out the large circular cap to gain access to the nut which secures the top yoke to the steering stem. On all other models it will be necessary to release the two screws which retain the top yoke cover and remove the cover to gain access to the nut.

3 Slacken and remove the nut and washer and lift the top yoke assembly off the steering stem. Position the yoke behind the steering head and secure it to the frame to avoid straining the hydraulic hoses or electrical leads. Remove the lock washer and slacken the steering head bearing adjusting nut with a suitable C-spanner whilst supporting the bottom yoke. Lift off the dust seal and O-ring and lower the bottom yoke and steering stem assembly out of the headstock. The top bearing inner race can then be removed.



## 8 Steering head bearings - examination and renovation



1 The inner races are easily checked after all traces of old grease have been removed by washing in a suitable solvent. Turn each race slowly, checking for marks or discoloration of the roller faces (see illustration).


2 Clean the outer races and examine the bearing surface for wear or damage. If any wear is discovered, Kawasaki recommend that both bearings, including their outer races, should be renewed.

3 If renewal is necessary, removal of the old bearing outer races and installation of the new outer races may be accomplished using the correct Kawasaki service tools. If these tools are not available proceed as follows:

4 The outer races are a fairly tight fit in the headstock. Most universal slide-hammer type bearing extractors will work here, and these can often be hired from tool shops. Alternatively, a long drift can be passed through one race and used to drive out the opposite item. Tap firmly and evenly around the race to ensure that it drives out squarely. It may prove advantageous to curve the end of the drift slightly to improve access. Note that with this method there is a real risk of damage unless care is taken. If the race refuses to move, stop; leave the job until a proper extractor can be obtained.

5 The lower inner race can be levered off the steering stem, using screwdrivers on opposite sides to work it free. To fit the new item, find a length of tubing slightly larger in its internal diameter than the steering stem. This will suffice as a tubular drift. Grease the bearing thoroughly and wipe a trace of grease around the steering stem. Drive the bearing home evenly and fully.

6 The new outer races can be installed using a home-made version of the drawbolt arrangement (see illustration).



8.1 Steering head bearings - typical

- |                 |                            |
|-----------------|----------------------------|
| 1 Nut           | 6 O-ring                   |
| 2 Washer        | 7 Top bearing              |
| 3 Lock washer   | 8 Bottom bearing           |
| 4 Adjusting nut | 9 Dust seal - where fitted |
| 5 Dust seal     |                            |


in the handle at the correct distance. A spring balance capable of reading above 22.2 kg (48.94 lb) will also be required.

3 Fit the C-spanner and apply 4.0 kgf m (29 lbf ft) to the adjuster nut. This is achieved by hooking the spring balance to the hole in the C-spanner and pulling on it until a reading of 22.2 kg (48.94 lb) is shown. Check that the steering head assembly turns smoothly with no evidence of play or tightness.

4 Slacken the nut slightly until pressure is just released, then turn it slowly clockwise until pressure is just evident. Take great care not to apply excessive pressure because this will cause premature failure of the bearings. The object is to set the adjuster so that the bearings are under a very light loading, just enough to remove any free play. Once set correctly refit the lock washer, ensuring that its tangs engage correctly with the slots of the nut. Refit the top yoke, washer and nut, securing the nut only finger-tight at this stage. Tighten the nut to the recommended torque setting after the forks have been refitted in the yokes as described in Section 5. Continue reassembly in the reverse of the dismantling sequence, noting that all fasteners should be tightened to the specified torque settings on completion.

5 Referring to the relevant section of Chapter 1, check that the steering head bearings are correctly adjusted as soon as the forks, handlebars and front wheel are refitted.

6 Continue assembly by reversing the dismantling sequence. Check that all electrical cables and control cables are routed so that they do not impede steering movement. When setting the wiring connectors, if disconnected, check that the



8.6 Drawbolt tools for refitting bearing outer races

- 1 Drawbolt 2 Thick washer 3 Guide

wiring colour codes match up. When assembly has been completed check the operation of the front brake, throttle and clutch and adjust the headlamp alignment and rear view mirror setting.

## 10 Frame - examination and renovation



1 The frame is unlikely to require attention unless accident damage has occurred. In some cases, renewal of the frame is the only satisfactory remedy if it is badly out of alignment. Only a few frame specialists have the jigs and mandrels necessary for resetting the frame to the required standard of accuracy, and even then there is no easy means of assessing to what extent the frame may have been overstressed.

2 After the machine has covered a considerable mileage, it is advisable to examine the frame closely for signs of cracking or splitting at the welded joints. Rust corrosion can also cause weakness at these joints. Minor damage can be repaired by welding or brazing, depending on the extent and nature of the damage.

3 Remember that a frame which is out of alignment will cause handling problems and may even promote 'speed wobbles'. If misalignment is suspected, as a result of an accident, it will be necessary to strip the machine completely so that the frame can be checked, and if necessary, renewed.

## 9 Steering head - refitting



1 On refitting coat both bearings and the steering stem with grease. Offer up the bottom yoke and stem to the frame and fit the top bearing followed by the O-ring and dust seal, and refit the slotted adjuster nut finger-tight. It is important to bed the bearings in on assembly, before final adjustment - proceed as follows:


2 To preload the bearings, a C-spanner, preferably the correct Kawasaki item (Part No 57001-1100), will be required. If using any other spanner, note that it will be necessary to make some provision for a spring balance to be attached to a point 180 mm (7.1 in) from the centre of the steering stem. To this end extend the spanner as required and drill a hole

## 11 Rear suspension unit - removal



1 Place the machine on its centre stand, then remove the seat and sidepanels. Place a suitably sized block underneath the rear wheel to prevent the wheel dropping when the suspension unit bolts are removed.






**11.2a ZX900 models - remove expansion tank mounting bolts (arrowed) and drain its contents**



**11.2b Remove the air valve mounting nut**



**11.2c Slacken the damping adjuster locknut and unscrew the adjuster from the unit**

## ZX900 models

**2** Firstly, disconnect the battery as a safety precaution (negative terminal first). Remove the two bolts which secure the coolant expansion tank to the frame, remove the filler cap and drain its contents into a suitable container (see illustration). Have ready a wooden bung or clean screw of suitable diameter with which to plug the tank pipe when disconnected, then swiftly pull the pipe off the tank union and plug its open end. Wipe up any spilt coolant immediately. Free the starter relay mounting bracket from the left-hand side of the frame. Release the rear suspension unit air valve from the frame by removing its mounting nut (see illustration). Slacken the rear damping adjuster rod locknut situated at the top of the suspension unit, unscrew the damping adjuster rod and remove it along with the adjuster knob (see illustration).

**3** Slacken the suspension unit upper mounting bolt and nut but do not remove it at this stage. Slacken and remove the lower suspension unit mounting bolt and the tie-rod lower mounting bolt, allowing the relay bracket to pivot downwards (see illustration). Now remove the suspension unit upper bolt and lower the suspension unit out of the swinging arm and away from the machine (see illustrations).

## ZX1000 A models

**4** Remove the four bolts which secure the fuel

tank mounting bracket to the frame and remove the fuel tank along with its mounting bracket. Disconnect the battery (negative lead first) and remove it from the machine. Remove the air filter element as described in Chapter 1 and displace the four spring clips which retain the air filter hoses on the carburettors. The air filter housing can then be lifted out of the frame. Release both silencer mounting clamps and bolts and detach the silencers from the main exhaust pipes.

**5** Slacken both the starter and fan relay mounting bolts and remove them from the battery bracket. Free the suspension unit air valve from the frame by releasing its mounting nut. Release the bolt which secures the rear damping adjuster mounting bracket to the battery bracket, then slacken the battery bracket retaining bolts and remove it from the machine.

**6** Remove the upper suspension unit mounting bolt and unscrew the damping adjuster cable from the unit. Remove the cable and adjuster assembly, taking care not to displace the pinion gear from the suspension unit. Remove the lower suspension unit mounting bolt and lower the unit out of the frame.

## ZX1000 B models


**7** Disconnect the battery (negative lead first) and remove it from the machine. Remove all the mounting screws from the tail section of the bodywork, noting that two are located

inside the small compartment on the left-hand side of the tail section, and disconnect the turn signal and rear lamp wiring block connectors. Pull the tail section to the rear and remove it from the machine. Slacken the four bolts which secure the rear section of the rear mudguard to the frame and remove it. Release the IC ignitor mounting bolts, disconnect it from the wiring harness, and remove it from the machine. Remove the rear brake reservoir and starter relay mounting bolts. Tie the brake reservoir to the frame to avoid placing any strain on its connecting hose or the possible spillage of brake fluid. Disconnect the junction box block connectors and remove the box. Release the rear mudguard mounting bolt and remove it from the machine.


**8** Remove the rear suspension unit air valve mounting nut and the damping adjuster mounting bolts. Disconnect the adjuster from the cable and remove it from the machine. Slacken and remove the suspension unit upper and lower mounting bolts and the lower tie-rod bolt, then withdraw the unit from the frame.

## ZX1100 C/D models


**9** Remove the fuel tank as described in Chapter 4 and release the fuel tank mounting bracket retaining bolts and lift it clear of the frame. Remove all the electrical components which are mounted on the rear mudguard, releasing their wiring and the rear suspension



**11.3a Remove tie-rod to relay arm bolt (A) and suspension unit lower (B) ...**




**11.3b ... and upper mounting bolts**



**11.3c ... then lower the unit out of the frame**





**11.10 On ZX1100 C/D models do not attempt to separate the suspension unit and oil reservoir**

unit reservoir hose from any clamps or guides. Withdraw the mudguard rear section after removing its four mounting bolts, followed by the front (main) section which has a single mounting bolt.

**10** To gain access to the rear suspension unit upper mounting bolt it will be necessary to remove the mudguard mounting bracket, retained by two bolts. Free the rear suspension unit oil reservoir from the frame by removing its mounting bolt. *On no account attempt to separate the reservoir from the suspension unit. If the hose connections are loosened pressure will be lost and the complete assembly will have to be renewed.* Remove the upper and lower suspension unit mounting bolts and the tie-rod to relay arm bolt, and manoeuvre the suspension unit and reservoir out from below the swinging arm (see illustration).

## 12 Rear suspension unit - examination and renovation




**1** The most likely defect in the unit is poor damping, a failing which is ultimately inevitable. Typical symptoms are bouncing on undulating roads and wheel patter on broken surfaces. If handling problems do occur the unit should be renewed promptly.

**2** The suspension unit is of a sealed construction and is not repairable in any way; if defective, it must be renewed. The only serviceable items are the bearings or mounting bushes which can be examined as follows.

### ZX1000 A models

**3** Needle roller bearings are fitted at the mounting points. Lever out the oil seals from both sides of the unit and remove all traces of old grease and road dirt. Examine the pivot bolts for signs of wear or corrosion and the needle roller bearings for wear or discoloration. If either bearing is damaged in any way both must be renewed together. The old bearings can be drifted out of place and the new items fitted using a drawbolt



**12.4 Drawbolt tool for installing bearings or bushes in rear suspension components**

1 Drawbolt

2 Bearing or bush

3 Housing

4 Nut

5 Thick washers

arrangement as shown in the accompanying illustration. Renew the oil seals as a matter of course. On installation pack the bearings and lubricate the pivot bolt with molybdenum disulphide grease.

### All other models

**4** A single rubber bush is fitted at the upper mounting point. If there is excessive movement in the bush when the mounting bolt is inserted, it should be renewed. The bush can be removed and fitted using a drawbolt arrangement as shown (see illustration).

## 13 Rear suspension unit - refitting



**1** Lubricate the suspension unit and tie-rod mounting bolts with molybdenum disulphide grease prior to assembly and proceed as described below.

### ZX900 models

**2** Offer up the suspension unit and refit its upper mounting bolt. Fit the lower suspension unit and tie-rod mounting bolts and tighten both suspension unit and tie-rod mounting bolts to their specified torque settings. Refit the damping adjuster rod assembly, tightening its locknut securely, and secure the suspension unit air valve with its retaining nut. Remount the relay bracket on the left-hand side of the frame and install the coolant expansion tank. Swiftly unplug the expansion tank pipe and reconnect to the tank stub. Top up the expansion tank with the specified coolant as described in Chapter 1. Reconnect the battery.

### ZX1000 A models

**3** Before installing the suspension unit remove the dust cover from the top of the unit and set the damping adjuster gear to the number 1 position. This should be marked with a red painted line on the side of the gear and should be positioned in the centre of the cutaway. Refit the small pinion gear so that the square hole at its centre is as shown (see illustration). Also,

set the remote damping adjuster to the number 1 position.

**4** Offer up the suspension unit and refit both mounting bolts. Reconnect the damping adjuster cable and tighten the suspension unit mounting bolts to the specified torque setting. Refit the battery bracket and mount the damping adjuster and the suspension unit air valve on the frame. Refit the starter and fan relay to the battery bracket and tighten all the above mentioned mounting bolts and nuts securely.


**5** Install the air filter housing and refit the element as described in Chapter 1. Ensure that the air filter hoses are correctly fitted to the carburettors and secure them with the spring clips. Refit the battery and fuel tank, together with its mounting bracket.

### ZX1000 B models

**6** Before refitting the suspension unit it will be necessary to set up the damping adjuster gear as described in paragraph 3, noting that there is no small pinion to be fitted to the unit.


**7** Position the unit in the frame and fit both the suspension unit mounting bolts. Reconnect the damping adjuster cable and tighten the suspension unit mounting bolts to the specified torque setting. Refit the suspension unit air valve to the frame and tighten its retaining nut securely.

**8** Refit the rear mudguard to the machine, tighten all its mounting bolts securely, and refit the rear brake reservoir and starter relay



**13.3 Rear suspension unit pinion gear position - ZX1000 A models**







**13.9a** On ZX1100 C/D models offer up the suspension unit and refit its upper mounting bolt



**13.9b** Refit the tie-rod to relay arm bolt . . .




**13.9c** . . . and the lower suspension unit bolt; tighten all to their specified torque settings



**13.9d** Refit the oil reservoir to the frame, tightening its mounting bolt securely



**13.10a** Install the mudguard mounting bracket . . .



**13.10b** . . . followed by the mudguard front and rear sections

retaining bolts. Connect the IC ignitor and junction box to the main loom and remount them on the machine. Refit the tail section, tightening all its mounting screws securely, and connect the rear lamp and turn signal block connectors. Refit the battery.

### ZX1100 C/D models

**9** Install the rear suspension unit with the oil reservoir hose union bolt facing the rear and refit both its mounting bolts (*see illustration*). Refit the tie-rod to relay arm pivot bolt (*see illustrations*). Tighten the suspension unit and relay arm pivot bolts to the specified torque setting and refit the oil reservoir mounting bolt.

**10** Refit the mudguard mounting bracket and install the mudguard sections. Tighten the mudguard retaining bolts and refit all the electrical components which were removed. Ensure that the electrical wires and the reservoir hose are correctly routed and retained by the clamps. Refit the fuel tank mounting bracket and fuel tank.

### All models

**11** Set the required suspension unit damping setting and air pressure and refit the seat and sidepanels. Thoroughly check the operation of the rear suspension before taking the machine on the road.


## 14 Swinging arm - removal

### ZX900 models


- 1 Remove the rear wheel as described in Chapter 7 and the rear suspension unit as described in Section 11.
- 2 Release both silencer mounting clamps and bolts and remove them from the exhaust pipes. Remove the Allen-headed outer

swinging arm pivot nuts and the rear brake caliper mounting bolts. Disconnect the rear brake stop lamp switch wires and release the brake fluid reservoir retaining bolt. Slacken all the Allen bolts which secure the right-hand footrest bracket to the frame and release the rear brake hose from clamps. The footrest and complete rear brake assembly can then be manoeuvred out of the frame (*see illustration*). Take care to keep the brake fluid reservoir upright to prevent the spillage of fluid.

- 3 Remove all the left-hand footrest bracket




**14.2a** On ZX900 models disconnect the stoptamp switch wires . . .



**14.2b** . . . and remove right-hand footrest together with rear brake assembly



- 1 Swinging arm
- 2 Outer nut - 2 off
- 3 Pivot shaft
- 4 Inner sleeve - 2 off
- 5 Dust seal - 2 off
- 6 Needle roller bearing - 4 off
- 7 Dust seal - 2 off
- 8 Inner nut
- 9 Chain buffer
- 10 Guard
- 11 Circlip - 2 off
- 12 Washer - 2 off
- 13 Tie-rod to swinging arm shaft
- 14 Dust seal - 4 off
- 15 Needle roller bearing - 2 off
- 16 Left-hand tie-rod
- 17 Nut
- 18 Inner sleeve
- 19 Dust seal - 2 off
- 20 Needle roller bearing
- 21 Right-hand tie-rod
- 22 Tie-rod to relay arm bolt
- 23 Relay arm
- 24 Suspension unit to relay arm bolt
- 25 Inner sleeve
- 26 Dust seal - 2 off
- 27 Needle roller bearing
- 28 Nut
- 29 Relay arm to frame bolt
- 30 Dust seal - 2 off
- 31 Needle roller bearing
- 32 Inner sleeve
- 33 Nut




14.2c Swinging arm and suspension linkage - ZX900 models

retaining bolts and partially withdraw the bracket (see illustrations). Remove the circlip and washer which retain the gearchange pedal to the bracket and lift the bracket clear (see illustration). Slacken the left-hand pivot shaft nut and withdraw the pivot shaft from the right-hand side whilst supporting the swinging arm (see illustration). If necessary, due to a build-up of corrosion, the shaft can be tapped out using a hammer and a suitable drift. The swinging arm and tie-rod assembly can then be manoeuvred out of the frame. Remove a circlip from either end of the shaft which secures the tie-rods to the swinging arm and withdraw the shaft to separate the tie-




14.3a Note bracket which front two left-hand footrest brackets screw into




14.3b Free the gearchange pedal from the left-hand footrest bracket and remove the bracket





14.3c Support the swinging arm and withdraw the pivot shaft



14.3d Tie-rod pivot shaft is retained by circlips



14.5 Swinging arm and suspension linkage - ZX1000 A models

rods from the swinging arm (see illustration).

### ZX1000 A models

4 Remove the rear wheel as described in Section 4 of Chapter 7.

5 Release both silencer mounting clamps and bolts and remove them from the exhaust pipes. Slacken all the left-hand footrest bracket retaining bolts and lift the bracket clear. Remove the swinging arm pivot shaft nuts, the lower suspension unit pivot bolt and the tie-rod to swinging arm mounting bolt and withdraw them all from the right-hand side whilst supporting the swinging arm (see illustration). If necessary, due to a build-up of corrosion, the shaft can be tapped from position using a hammer and drift. The swinging arm can then be lowered out of the frame.

### ZX1000 B and ZX1100 C/D models

6 Remove the rear wheel as described in Section 4 of Chapter 7.

7 Remove the rear brake master cylinder mounting bolt and disconnect the stop lamp switch wiring from the main loom. Slacken the right-hand footrest mounting bolts and remove it from the machine, along with the rear brake reservoir and caliper assembly. Remove the chainguard and brake hose guide retaining screws from the swinging arm and lift the chainguard clear. Remove the torque arm to frame mounting bolt and lower the arm away from the machine.

8 Slacken and remove the suspension unit lower pivot bolt and the tie-rod to relay arm mounting bolt. Remove the swinging arm pivot shaft nut and withdraw the shaft whilst supporting the swinging arm (see illustration). If necessary, due to a build-up of corrosion, the pivot shaft can be tapped out of position using a hammer and drift. The swinging arm can then be manoeuvred out of the frame and the tie-rods separated from it if necessary.


### 15 Suspension linkage - removal

### ZX900 models


1 Remove the swinging arm as described in Section 14 of this Chapter.

2 To remove the relay arm it is necessary to retract the centre stand. A suitable support must therefore be placed under the crankcases and the machine safely and securely mounted on the support before retracting the stand. Once the machine is safely positioned, retract the stand and remove the relay arm to frame pivot bolt. The relay arm can then be removed from the machine.





14.8 Swinging arm and suspension linkage - ZX1000 B and ZX1100 C models



15.10 Suspension linkage - ZX1100 D model

**ZX1000 A models**

3 To remove the suspension linkage components it is necessary to remove the fuel tank and mounting bracket, air filter and battery bracket as described in paragraphs 4 and 5 of Section 11. Place a suitably sized block underneath the rear wheel to prevent the wheel dropping when the suspension linkage bolts are removed.

4 Remove the upper suspension unit mounting bolt and the tie-rod to relay arm pivot bolt. Slacken and remove the relay arm to frame pivot bolt and withdraw the pivot sleeve from the left-hand side of the frame. The relay arm can then be manoeuvred out of the frame. The tie-rod can then be removed after releasing the bolt which secures it to the swinging arm.

**ZX1000 B and ZX1100 C models**

5 Place a suitably sized block underneath the rear wheel to prevent the wheel dropping when the suspension bolts are removed.

6 Release both silencer mounting clamps and bolts and remove them from the exhaust pipes. Remove the bolt which secures the rear brake torque arm to the caliper mounting bracket and swing the torque arm clear of the suspension linkage.

7 Slacken and remove the two tie-rod upper mounting bolts and the tie-rod lower mounting bolt, then remove the tie-rods. Release the suspension unit lower mounting bolt and the relay arm to frame pivot bolt. The relay arm can then be manoeuvred out of the frame.

**ZX1100 D models**

8 Place a suitably-sized block of wood under the rear wheel to prevent the wheel dropping when the suspension bolts are removed. Detach the torque arm from the brake caliper and swing it downwards out of the way.


9 The tie-rods can be released after removing the through-bolts at their upper and lower ends. The right-hand exhaust pipe silencer prevents access to the tie-rod-to-swinging arm bolt, and will thus require removal first.

10 To release the relay arm, first detach the right-hand exhaust pipe silencer for access. Remove the suspension unit lower mounting bolt, the tie-rod lower end through-bolt (if not already done), and the relay arm-to-frame through-bolt (see illustration).


**16 Swinging arm and suspension linkage - examination and renovation**

1 Press or tap the inner sleeves out of position, noting that on ZX1000 B and ZX1100 C/D models the swinging arm pivot sleeve must be withdrawn from the left-hand side, and carefully lever out the dust seals. Clean off all the old grease and road dirt so that the components can be checked for wear. Do not





16.2a Examine pivot inner sleeves ...



16.2b ... and needle roller bearings for wear or damage



17.2 Ensure relay arm is fitted with arrow pointing forwards (ZX900)

remove the needle roller bearings unless renewal is necessary.

2 Examine the pivot sleeves for wear or corrosion and the needle roller bearings for signs of damage or discoloration (**see illustrations**). If either component is damaged in any way both the bearing(s) and sleeve should be renewed as a set. The needle roller bearings can be drifted out of position and the new ones fitted using a drawbolt arrangement as shown in the accompanying illustration. The pivot shaft should also be examined for wear or damage. Check for trueness by rolling the shaft across a flat surface, renewing it if bent. The dust seals should be renewed regardless of their apparent condition.

3 On ZX1000 B and ZX1100 C/D models the outer right-hand needle roller bearing is of the ball journal type and is retained by a circlip. This can be checked for wear by spinning the inner race of the bearing. If there is any sign of roughness the bearing should be renewed. It can be drifted out once the circlip has been removed and the bearing tapped into position using a suitably sized socket, which bears only on the outer race of the bearing. Refit the circlip ensuring that it is correctly seated in its groove.

4 Press the dust seals into place and pack the bearings with molybdenum disulphide grease. Grease the inner sleeves and insert them in the bearings.

## 17 Suspension linkage - refitting



1 Lubricate all suspension unit and linkage mounting bolts with molybdenum disulphide grease, having first checked them for wear as described in the previous section.

### ZX900 models

2 Offer up the relay arm, ensuring that the arrow cast on one side of the arm is pointing forwards, and refit the relay arm to frame mounting bolt (**see illustration**). Tighten the bolt to the specified torque setting and manoeuvre the machine off its temporary stand and place it on the centre stand. Refit

the swinging arm as described in Section 18 of this Chapter.

### ZX1000 A models

3 Refit the tie-rod to the swinging arm and tighten its mounting bolt to the specified torque setting. Offer up the relay arm, ensuring that the arrow cast on one side of the arm is pointing forwards. Refit the pivot sleeve from the left-hand side of the frame having first applied molybdenum disulphide grease to its outer surface. Fit the suspension unit upper bolt, the relay arm to frame pivot bolt and the tie-rod to relay arm pivot bolt, tightening them all to the specified torque setting. Refit the battery bracket, air filter assembly and fuel tank with mounting bracket as described in paragraphs 4 and 5 of Section 13.

### ZX1000 B and ZX1100 C/D models

4 Offer up the relay arm and install the relay arm to frame pivot bolt and the lower suspension unit mounting bolt, tightening both to the specified torque settings. Position the tie-rods and refit both of their upper mounting bolts, followed by the lower mounting bolt; tighten them to the specified torque setting. Refit the rear brake torque arm to caliper bracket retaining bolt, tightening it to its specified torque setting, and refit the silencers.

### All models

5 Thoroughly check the operation of the rear suspension before taking the machine on the road.

## 18 Swinging arm - refitting



1 Lubricate the pivot bolts of all the disconnected suspension linkage components and also the swinging arm pivot shaft with molybdenum disulphide grease.

### ZX900 models

2 Refit the tie rods to the swinging arm and tighten the mounting bolt to the specified

torque setting. Offer up the swinging arm assembly and fit the pivot shaft from the right-hand side. Refit the pivot shaft nut and tighten it to the specified torque setting.


3 Remount the gearchange linkage on the left-hand footrest bracket, securing it with the circlip, and fit the bracket to the machine. Install the right-hand footrest bracket and rear brake assembly and tighten the bracket retaining bolts securely. Refit the brake reservoir mounting bolt and connect the rear brake stop lamp switch wires. Fit the outer swinging arm pivot shaft nuts and tighten them to the specified torque setting. Refit the exhaust silencers.

### ZX1000 A models

4 Offer up the swinging arm and refit the pivot shaft from the right-hand side. Refit the suspension unit lower mounting bolt and the swinging arm to tie-rod mounting bolt from the right-hand side. Tighten all the above bolts to their specified torque settings. Refit the left-hand footrest bracket, securely tightening its retaining bolts, and refit the silencers.


### ZX1000 B and ZX1100 C/D models

5 Position the swinging arm and refit its pivot shaft, followed by the suspension unit lower bolt and the tie-rod to relay arm bolt, tightening them all to the specified torque setting (**see illustration**). Refit the rear brake



18.5a Offer up the swinging arm, refit the pivot shaft and tighten it to the specified torque setting





**18.5b Refit the rear brake torque arm, tightening its retaining bolt to the specified torque ...**

torque arm, tightening its mounting bolts to the specified torque setting, and secure the brake hose guides and chainguard to the swinging arm (see illustration). **Note:** Make sure that the brake hose is held well clear of the brake disc by the clamps on the swinging arm. Fit the right-hand footrest bracket and rear brake assembly to the machine and tighten the reservoir and footrest bracket mounting bolts securely. Reconnect the stop lamp switch wiring.

## All models


6 Refit the rear wheel as described in Section 5 of Chapter 7 and thoroughly check the operation of the rear suspension and brake before taking the machine on the road.

## 19 Footrests, stands and controls - examination and renovation

1 At regular intervals all footrests, the stand, the brake pedal and the gearchange lever should be checked and lubricated at the intervals specified in Chapter 1. Check that all mounting nuts and bolts are securely fastened, using the torque settings where these are given. Check that any securing split pins are correctly fitted.

2 Check that the bearing surfaces at all pivot points are well greased and unworn, renewing any component that is excessively worn. If lubrication is required, dismantle the assembly to ensure that grease can be packed fully into the bearing surface. Return springs, where fitted, must be in good condition with no traces of fatigue and must be securely mounted.

3 If accident damage is to be repaired, check that the damaged component is not cracked or broken. Such damage may be repaired by welding, but note that welding of aluminium components should only be entrusted to an expert in this field. Note, however, that such a repair will destroy the finish of the component, and renewal may therefore be the most satisfactory course of action. If a steel component is merely bent it can be straightened after the affected area has been



**18.5c .. and fit the chainguard to the swinging arm**

heated to a dull cherry red colour, using a blowlamp or welding torch. Again the finish will be destroyed, but the surface can be refinished at relatively low cost.

## 20 Speedometer and tachometer heads - removal, examination and refitting

1 The instrument assembly is secured to the fairing mounting bracket by two bolts. On ZX900 and ZX1000 A models these bolts are readily accessible, although on ZX1100 C/D models it will first be necessary to remove the upper fairing, and on ZX1000 B models the upper fairing inner sections and screen.

2 Remove the instrument panel mounting bolts and partially withdraw the assembly. Unscrew the speedometer drive cable retaining ring from the underside of the panel and separate the instrument panel wiring from the main loom. The assembly can then be lifted clear of the machine.

3 Slacken all the screws which retain the bottom cover and remove it from the assembly. Release the two nuts which secure the instruments to the mounting bracket and separate the two components (see illustration). The top cover can be removed once its retaining screws have been withdrawn.

4 Each instrument head is mounted onto the housing by two small crosshead screws.



**20.3 Instrument are retained to mounting bracket by two nuts**

Before removing the speedometer on ZX900 and ZX1000 models it is first necessary to remove the upper speedometer drive gearbox. This is also retained by two small crosshead screws. On all models disconnect the tachometer wiring before attempting to remove the instrument head (see illustration). **5** Note that these instruments are delicate and should be handled carefully at all times. Do not drop them or hold them upside down as this will damage the heads. Also do not allow them to come into contact with any dirt, grease, oil or water.

6 The speedometer and tachometer heads are sealed units and cannot be dismantled any further. Apart from defects in the drive or drive cable (speedometer) or relevant wiring (tachometer) an instrument is difficult to repair and must be renewed. Alternatively, it may be possible to have the instrument repaired by a suitable specialist or to obtain a second-hand item from a breaker.

7 The electronic tachometer can be tested as described in Chapter 8.


8 Remember that a speedometer in correct working order is a statutory requirement in the UK. Apart from this legal necessity, reference to the odometer readings is the most satisfactory means of keeping track with the maintenance schedules.

9 The instrument heads are refitted by a reversal of the removal procedure, taking care not to overtighten the instrument panel screws. Examine the damping rubbers fitted to the mounting bracket, renewing them if necessary.

## 21 Speedometer and tachometer drives - examination and renovation


### Speedometer

1 On ZX900 and ZX1000 models the speedometer has two drive gearboxes, the main one being mounted on the left-hand side of the front wheel and the other just under the instrument. The ZX1100 C/D models use only the wheel mounted gearbox. The gearbox in the instrument assembly (where fitted) serves



**20.4 Disconnect the tachometer wiring connectors (arrowed) before attempting to remove it from the panel**





22.1 Unscrew knurled retaining ring to remove speedometer cable (ZX1100 shown)

only to transmit the drive through 90° and is maintenance free; if a fault develops in this component, it should be renewed. The main wheel-mounted gearbox should be lubricated with a high melting-point grease whenever the wheel is removed, and if failure occurs it can be overhauled as follows:

**2** Remove the front wheel as described in Section 2 of Chapter 7 and remove the gearbox assembly from the wheel. The speedometer drive plate is retained in the hub by a circlip. Lever out the oil seal and tip out the larger drive gear. If it proves necessary to renew the small drive pinion or bush, the roll pin must be removed from the housing as follows.

**3** Pass a 1 mm drill up through the centre of the pin and drill through the gearbox housing. Using

the 1 mm hole as a pilot hole, drill a 3.0 - 3.5 mm hole in the underside of the gearbox housing. The roll pin can then be tapped out of place with a drift. The bush, pinion and thrust washers can then be removed from the housing. On reassembly always fit a new roll pin and stake it in place to prevent it dropping out.

### Tachometer

**4** The tachometer is electrically operated and is controlled by the ignition system. Should the tachometer malfunction the instrument head and relevant wiring should be examined as described in Chapter 8.

### 22 Speedometer drive cable - examination and maintenance


**1** The cable is secured at each end by knurled rings which should be slackened and tightened with a pair of pliers (see illustration). If the cable is thought to be at fault, remove it from the machine, and spin the inner cable at one end. If the other end of the cable fails to turn, the cable is broken and should be renewed.

**2** If the operation of the speedometer has become jerky and excessive force is needed to turn the cable manually as described above, the cable should be renewed. Lubrication is difficult with this type of cable, but an aerosol chain lubricant or a silicone-based lubricant can often be introduced using the aerosol's thin extension nozzle. Do not apply excess lubricant to the upper end of the cable otherwise there is a risk of it working up into the instrument head. On refitting ensure the cable is correctly routed, secured by any ties or guides and is not trapped or kinked anywhere.


### 23 Fairing - removal and refitting

#### ZX900 models

**1** Slacken and remove the eight screws which secure the lower fairing to the middle fairing and the screws which retain the lower fairing inner covers (see illustrations). Release both




23.1a Fairing - ZX900 models




23.1b ZX900 - note the nuts fitted to the two lower fairing mounting bolts






**23.2a** Middle fairing section is retained by two bolts on each side ...



**23.2b** ... and two bolts at the front



**23.2c** Radiator cowlings are retained by two screws

the lower fairing mounting bolts and nuts and lower the fairing away from the machine.

**2** Remove the six middle fairing mounting bolts, all of which are situated below the radiator, and carefully lower the middle fairing away from the machine noting the tangs that locate with the upper fairing (see illustrations). If necessary, the cowlings fitted to each side of the radiator can then be removed once their retaining screws have been released.

**3** Slacken and remove the top yoke cover retaining screws and lift the cover clear. Release the knurled ring which retains the upper end of the speedometer cable and free the cable from the instrument panel. Remove the two bolts which mount the instrument assembly to the fairing bracket and pull the

assembly upwards. Cover the fuel tank with a clean thick cloth and rest the instruments on the fuel tank (see illustration). Ensure the instruments are left in an upright position to prevent them being damaged in any way.

**4** Release the screws which retain each of the upper fairing inner covers and manoeuvre them out of the fairing, taking care not to scratch the windscreen (see illustration). Remove the rear view mirror mounting screws and remove both mirrors from the fairing. Slacken and remove the two headlamp cover retaining bolts situated on the underside of the upper fairing and lower the cover away from the machine (see illustration). Disconnect the turn signal and headlamp wiring connectors and remove the fairing mounting bolts (see illustrations). The upper

fairing can then be manoeuvred clear of its mounting bracket.

**5** If the fairing mounting bracket is also to be removed it will first be necessary to remove the fuel tank as described in Chapter 4. Disconnect all the wiring connectors situated on the left-hand side of the bracket and remove all the bracket mounting bolts. Lift the bracket away from the machine taking care not to damage the radiator.

**6** On refitting tighten all the fairing mounting bracket bolts securely (if removed) and connect the relevant wiring. Install the upper fairing and refit the mounting bolts and rear view mirrors. Do not omit the rubber dampers which are fitted behind both the rear view mirrors and on all the mounting bolt holes, or the collars which are fitted to the mounting




**23.3** Cover the fuel tank with a clean rag and rest the instrument panel on the tank




**23.4a** Slacken the upper inner fairing retaining screws and carefully remove the inner fairing sections



**23.4b** Remove the rear view mirror mounting screws ...



**23.4c** ... and disconnect the turn signal wiring connectors




**23.4d** Remove the upper fairing mounting screws ...




**23.4e** ... and bolts to permit its removal





23.7a On refitting do not omit rubber dampers which are fitted to the tangs on the middle fairing section . . .



23.7b . . . or the spacers that are fitted to its mounting bolts

bolts. Refit the inner covers, again taking care not to scratch the windscreen, and tighten their retaining screws securely. Remount the instrument assembly on the fairing bracket and reconnect the speedometer cable to its drive gearbox, ensuring that the speedometer cable is correctly routed and the left-hand instrument assembly retaining bolt is positioned in the left-hand hole in the fairing bracket. Connect the turn signal and headlamp wiring connectors and refit the headlamp cover.


7 Before installing the middle fairing ensure the rubber dampers are fitted correctly to the tangs at the top of the section and the bolt holes at the bottom, and refit the radiator cowlings (if removed). Fit the middle fairing, ensuring that the tangs locate correctly in the upper fairing, and tighten its mounting bolts securely (**see illustration**). Position the lower fairing and install the bottom mounting bolts finger-tight only. Refit the inner covers to the lower fairing and again tighten their retaining screws finger-tight only. Finally fit the screws that join the lower fairing to the middle fairing and tighten all the lower fairing screws securely.

### ZX1000 A models

8 Slacken and remove all screws which secure the lower fairing to the front and side fairings followed by the two main mounting screws and lower the fairing away from the machine (**see illustration**). Prise out the caps which cover the front turn signal retaining screws and release the screws. Remove the turn signals from the fairing and disconnect their wiring connectors. Remove all the screws which secure each side fairing section to the upper and front fairings followed by the main mounting screw, and lift each one clear of the machine. Release the screws which secure the front fairing to the upper fairing and the front fairing mounting screws and remove the front fairing section.


9 Release the upper fairing inner cover retaining screws and manoeuvre them out of the fairing, taking care not to damage the windscreen. Disconnect the headlamp bulb wiring connector. Prise out the caps which cover the rear view mirror mounting screws, slacken the screws and remove both mirrors. Release the two upper fairing mounting bolts and remove it from the machine.

10 On refitting, do not omit the rubber dampers which are fitted to all the mounting bolt holes and behind the rear view mirrors, or the collars fitted to all the mounting bolts. Install the upper fairing and refit the rear view mirrors and both mounting bolts. Before tightening the mounting bolts ensure the turn signal wiring connectors are positioned in the cutaways on the lower edge of the fairing. Connect the headlamp wiring and refit the inner covers, taking care not to scratch the windscreen, and tighten its retaining screws securely. Align the upper edge of the front fairing with the flange on the lower edge of the



- 1 Upper fairing
- 2 Windscreen
- 3 Rear view mirrors
- 4 Upper fairing inner covers
- 5 Upper fairing mounting bracket
- 6 Headlamp inspection cover
- 7 Oil cooler bracket
- 8 Centre fairing
- 9 Centre fairing bracket
- 10 Coolant expansion tank inspection cover
- 11 Left-hand side fairing
- 12 Right-hand side fairing
- 13 Lower fairing
- 14 Side fairing inner covers





23.12 Fairing - ZX1000 B models

- |                             |                              |
|-----------------------------|------------------------------|
| 1 Upper fairing             | 7 Front inner cover          |
| 2 Windscreen                | 8 Left-hand side fairing     |
| 3 Rear view mirrors         | 9 Right-hand side fairing    |
| 4 Upper fairing bracket     | 10 Side fairing inner covers |
| 5 Upper fairing inner cover | 11 Lower fairing             |
| 6 Reservoir access cover    |                              |


upper fairing and fit all its mounting bolts finger-tight. Once all the bolts are in place and the fairing is correctly positioned tighten the bolts securely.

**11** Ensure the rubber dampers are in position on the inside of each side fairing section and fit the side fairings to the machine. Locate the tabs on the front edge of the side fairings with the slots in the front section of the fairing and refit all the mounting bolts. Ensure the dampers are in position on the lower fairing inner covers and install the lower fairing. Align the lower fairing with the flanges on the front and side sections and fit all the mounting screws. Once all the screws are in place and the lower fairing is correctly positioned, tighten all the screws securely.

### ZX1000 B models

**12** Slacken and remove the six screws which secure the lower fairing to the side fairings and the two main mounting bolts (**see illustration**). The lower fairing can then be lowered away from the machine. Remove all the screws which retain the side fairings and lift both side fairings clear.

**13** Release the windscreen from the fairing by slackening its mounting screws. Remove all the upper fairing front inner cover retaining screws and lift the cover away from the instrument assembly. Slacken the nuts which retain the rear view mirrors and remove them from the machine. Disconnect the turn signal and headlamp wiring block connector and



23.15 Fairing - ZX1100 C models

- |                              |                                  |
|------------------------------|----------------------------------|
| 1 Windscreen                 | 7 Upper fairing mounting bracket |
| 2 Upper fairing              | 8 Left-hand side fairing         |
| 3 Rear view mirrors          | 9 Side fairing inner covers      |
| 4 Front inner cover          | 10 Right-hand side fairing       |
| 5 Reservoir access cover     | 11 Inner cover bracket           |
| 6 Upper fairing inner covers |                                  |

remove the upper fairing from the machine. If necessary, the inner fairing covers can be removed by releasing the relevant screws.


**14** The fairing is fitted by a reversal of the removal sequence. Do not omit the rubber dampers and collars that are fitted to the side and lower fairing mounting bolts and avoid overtightening the windscreen mounting screws.

### ZX1100 C models


**15** Slacken and remove all the screws which retain the lower fairing side sections to the upper fairing and the frame and lift them clear of the machine (**see illustration**).

**16** Remove the seven screws that secure the windscreen to the fairing and remove the






**23.17a ZX1100 C** - on refitting do not omit insulating rubbers from lower fairing sections



**23.17b** Offer up the upper fairing section ...



**23.17c** ... and refit the rear view mirrors

screen. Release all the screws which retain the upper fairing front inner cover and lift it away from the instrument assembly. Then remove both the left and right-hand side inner covers, each one being retained by two screws. Disconnect the turn signal and headlamp wiring block connector. Release the nuts which retain the rear view mirrors and remove them both. The upper fairing can then be removed from the machine.

**17** The fairing is fitted by a reversal of the removal procedure. Do not omit the rubber dampers and collars from the lower fairing mounting bolts (where fitted) and avoid overtightening the windscreen mounting screws. Also ensure that the insulating

rubbers that are fitted to the inside of the lower fairing sections are correctly fitted (see illustrations).

### ZX1100 D models

#### Side sections


**18** While it may be possible to remove the fairing side sections as a complete assembly, the following procedure is advised to avoid the likelihood of damage. This involves removing each panel separately, and may well be preferable if work is only required on one side of the machine.

**19** Start by removing the four screws from the front edge of one of the side sections

(three are accessed from inside the panel, and the fourth, or lower screw, from the outside face) (see illustrations).

**20** Remove the four screws along the main fairing bottom edge on each side, and the single Allen screw at the top and bottom rear corners on each side (see illustrations). Also remove the screw securing the panel to the strut on the underside at the rear. The side section is now free.

**21** Having removed one side section, you can either perform the same procedure on the other side section which will allow the delicate inner panels to be freed separately, or just the steps in paragraph 20, which will retain the inner panel with the side section. If you



**23.17d** Refit the front inner cover ...




**23.17e** ... and screen; tighten screen retaining screws securely




**23.17f** Refit both right and left side inner fairing sections



**23.17g** Offer up the lower fairing sections ...




**23.17h** ... fit all its retaining screws ...




**23.17i** ... and bolts tightening them securely






23.19a Fairing - ZX1100 D models



23.19b Remove the three screws on the fairing side section front inner edge . . .



23.19c . . . and the single screw at the lower corner


choose the latter, however, be very careful not to break the inner panel as it is withdrawn .

**22** Refit the fairing side sections in a reversal of the removal procedure, but install the main fasteners only finger-tight during installation. When you are satisfied with the final fit of the panels secure all fasteners.


#### Screen and inner panels

**23** Remove the six screws which retain the windscreen to the fairing and lift the screen free. The two outer screws have nuts on the inside of the fairing.

**24** Having removed the screen, detach the instrument panel cover by removing its four retaining screws (see illustration). Manoeuvre the panel off the instruments.



23.20a Remove the four screws (A) along the main fairing bottom edge, the single Allen screw (B) . . .



23.20b . . . followed by the single Allen screw (C) and strut mounting screw (D)



23.24 Instrument panel cover is retained by two screws (arrows) on each side





**23.28a** Pull the hose off the air vent filter . . .



**23.28b** . . . and slacken the screw on each air intake duct clamp



**23.29** Main fairing is retained to its mounting bracket at the mirror mountings

**25** The fairing inner panel is held by the four instrument panel cover screws described above, two bolts on the fuel tank front mounting and the single Allen screw at the top corner of each fairing side section. With care, the inner panel can be manoeuvred over the fuel tank, although if in doubt about doing this safely, remove the tank first.

**26** When refitting the inner panel, make sure that its front ends rest on the two cushioned support brackets and that the inner panel and instrument panel cover mesh properly together before tightening the screws. Note that apart from the two outer screws, the main screen retaining screws thread into nuts held in the instrument panel cover; check that all threads are visible and correctly aligned before fitting the screen and do not overtighten them.

### Main section

**27** Remove the side sections, screen and

inner panels as described above. The main fairing is removed complete with the headlamp, turn signals and air ducts. Weaving the instruments attached to the mounting bracket.

**28** Working from inside the fairing, pull the hose off the air vent filter and free it from its clip on the right-hand air intake duct (**see illustration**). Slacken the clamps of both air intake ducts (**see illustration**).

**29** Remove the two nuts on each mirror mounting to release the mirrors and main fairing from the mounting frame (**see illustration**). Ease the fairing forwards until the 6-pin wiring connector (coloured black) can be disconnected, then remove the fairing fully.

### All sections

**30** Refit all components in the reverse of the removal procedure, paying particular attention to the correct location of any spacers and damper strips.

### 24 Seat mechanism (ZX1100 D models)

**1** The seat latch is operated by a short cable from the seat lock. To gain access to the cable, first remove the seat and trace the cable's route.

**2** To remove the cable, first remove the latch mechanism bolts and invert the latch to allow the cable end to be disconnected. Turning

attention to the seat lock, remove the two bolts from its mounting bracket and manoeuvre the bracket so that access can be gained to the cable connection on its reverse side. Release the outer cable from its stay and free the cable trunnion from the lock lever.


### 25 Tail unit (ZX1100 D models) - removal and refitting

**1** Remove the seat.  
**2** Remove its two bolts and detach the grab rail. Remove the two screws directly under the grab rail (**see illustration**).  
**3** Working on one panel at a time, release the screw from the front portion, then flip up the luggage hooks and release the screws retaining them (**see illustration**).  
**4** There is a further screw at the joint of the two panels, just under the tail lamp. Once removed, unhook the two sidepanels at the rear joint and gently pry them off the mounting stub on the frame. The rear turn signals are detached with the panel, but reach behind and twist out the bulbholder as the panel is withdrawn. The fillet between both sections at the top can be lifted free.

**5** Refit in the reverse of the removal procedure, noting that the rear joint hook should be engaged before the retaining screws are secured. Take care not to overtighten the screws and ensure that all grommets and damping rubbers are correctly located (**see illustrations**).




**25.2** Grab rail is retained by two bolts



**25.3** Flip up luggage hooks to reveal their retaining screws



**25.5a** Ensure that panel stub engages grommet on refitting



**25.5b** Tab must engage properly where two panels meet under tail lamp (arrow)



# Specifications

## Wheels

Type .....	Cast alloy
Rim maximum runout:	
Radial .....	0.8 mm (0.032 in)
Axial .....	0.5 mm (0.020 in)

## Brakes

Minimum disc thickness:	
Front:	
ZX900 A7-on models .....	4.0 mm (0.16 in)
All other models .....	4.5 mm (0.18 in)
Rear:	
ZX900 A1 to A6 models .....	6.0 mm (0.24 in)
All other models .....	5.0 mm (0.20 in)
Disc maximum warpage .....	0.3 mm (0.0118 in)
Recommended brake fluid .....	DOT 4 specification

## Tyres

Type .....	Tubeless	
Size:	<b>Front</b>	<b>Rear</b>
ZX900 A1 to A6 models .....	120/80V16-V250	130/80V18-V250
ZX900 A7-on models .....	120/70V17-V250	150/70V18-V250
ZX1000 A models .....	120/80V16-V270	150/80V16-V270
ZX1000 B models .....	120/70VR17-V280	160/60VR18-V280
ZX1100 C models .....	120/70VR17-V290	170/60VR17-V290
ZX1100 D models .....	120/70ZR17	185/55ZR17



**Tyre pressures****UK ZX900 A1 to A6 models:**

Up to 97.5 kg (215 lb) load, below 130 mph (210 kmh) .....	2.25 kg/cm <sup>2</sup> (32 psi)	2.50 kg/cm <sup>2</sup> (36 psi)
97.5 - 181 kg (215 - 399 lb) load, below 130 mph (210 kmh) .....	2.50 kg/cm <sup>2</sup> (36 psi)	2.50 kg/cm <sup>2</sup> (36 psi)
Above 130 mph (210 kmh) .....	2.50 kg/cm <sup>2</sup> (36 psi)	2.90 kg/cm <sup>2</sup> (41 psi)
UK ZX900 A7-on models .....	2.50 kg/cm <sup>2</sup> (36 psi)	2.90 kg/cm <sup>2</sup> (41 psi)

**US ZX900 A1 to A3 models:**

Up to 97.5 kg (215 lb) load .....	2.25 kg/cm <sup>2</sup> (32 psi)	2.50 kg/cm <sup>2</sup> (36 psi)
97.5 - 180 kg (215 - 397 lb) load .....	2.50 kg/cm <sup>2</sup> (36 psi)	2.50 kg/cm <sup>2</sup> (36 psi)

**UK ZX1000 A models:**

Below 130 mph (210 kmh) .....	2.50 kg/cm <sup>2</sup> (36 psi)	2.50 kg/cm <sup>2</sup> (36 psi)
Above 130 mph (210 kmh) .....	2.50 kg/cm <sup>2</sup> (36 psi)	2.90 kg/cm <sup>2</sup> (41 psi)

**UK ZX1000 B models:**

Up to 97.5 kg (215 lb) load, below 130 mph (210 kmh) .....	2.50 kg/cm <sup>2</sup> (36 psi)	2.50 kg/cm <sup>2</sup> (36 psi)
97.5 - 181 kg (215 - 399 lb) load, below 130 mph (210 kmh) .....	2.50 kg/cm <sup>2</sup> (36 psi)	2.90 kg/cm <sup>2</sup> (41 psi)
Above 130 mph (210 kmh) .....	2.50 kg/cm <sup>2</sup> (36 psi)	2.90 kg/cm <sup>2</sup> (41 psi)

**US ZX1000 A and ZX1000 B models**

.....	2.50 kg/cm <sup>2</sup> (36 psi)	2.90 kg/cm <sup>2</sup> (41 psi)
-------	----------------------------------	----------------------------------

**ZX1100 C/D models**

.....	2.90 kg/cm <sup>2</sup> (41 psi)	2.90 kg/cm <sup>2</sup> (41 psi)
-------	----------------------------------	----------------------------------

**Torque settings****kgf m****lbf ft****Wheel spindles:**

ZX900 models - front and rear .....	9.0	65.0
-------------------------------------	-----	------

**ZX1000 A models:**

Front .....	6.5	47.0
Rear .....	9.0	65.0

**ZX1000 B models:**

Front .....	9.0	65.0
Rear .....	11.0	80.0

**ZX1100 C models - front and rear**

.....	11.0	80.0
-------	------	------

**ZX1100 D models:**

Front .....	15.0	110.0
Rear .....	11.0	80.0

**Front spindle pinch bolts:**

ZX900 and ZX1000 A models .....	2.1	15.0
All other models .....	2.0	14.5

**Rear wheel chain adjuster pinch bolts**

.....	4.0	29.0
-------	-----	------

**Rear sprocket retaining nuts:**

ZX900 A1 to A6 models:		
Before Frame No. ZX900A-016130 .....	7.0	51.0
After Frame No. ZX900A-016131 .....	8.8	64.0
ZX1000 A models .....	11.0	80.0
ZX900 A7-on, ZX1000 B and ZX1100 C/D models .....	7.5	54.0

**Brake disc bolts:**

ZX900, ZX1000 A and ZX1100 C models .....	2.3	17.0
---	-----	------

**ZX1000 B models:**

Front disc .....	3.5	25.0
Rear disc .....	2.3	17.0

**ZX1100 D models:**

Front disc .....	2.3	17.0
Rear disc .....	2.5	18.0

**Brake caliper mounting bolts:**

ZX900 A1 to A6 and ZX1000 A models .....	3.4	24.0
ZX900 A7-on, ZX1000 B and ZX1100 C models .....	3.5	25.0

**Front brake caliper joining bolts - ZX900 A7-on and ZX1100 C models**

.....	2.1	15.0
-------	-----	------

**Brake caliper - ZX1100 D models:**

Front:		
Mounting bolts .....	3.5	25.0
Joining bolts .....	2.1	15.0

Rear:		
Mounting bolts .....	2.5	15.0
Joining bolts .....	Not available	

**Front master cylinder clamp bolts:**

ZX900 A1 to A6 and ZX1000 A models .....	0.9	6.5
ZX900 A7-on, ZX1000 B and ZX1100 C/D models .....	1.1	8.0

**Brake hose union bolts**

.....	2.5	18.0
-------	-----	------

**Torque arm nuts/bolts**

.....	2.5	18.0
-------	-----	------

**Metal brake pipe gland nuts anti-dive models only**

.....	1.5	11.0
-------	-----	------

**Anti-dive plunger housing bolts**


.....	0.45	3.3
-------	------	-----

**Bleed nipples**

.....	0.8	5.8
-------	-----	-----



- 1 Wheel spindle
- 2 Right-hand spacer
- 3 Oil seal
- 4 Circlip
- 5 Bearing - 2 off
- 6 Central spacer
- 7 Speedometer drive ring
- 8 Circlip
- 9 Oil seal
- 10 Speedometer drive gear
- 11 Drive gear housing
- 12 Nut
- 13 Pin
- 14 Washer - 2 off
- 15 Speedometer driven gear
- 16 Bush



2.4 Front wheel - typical

## 1 General description

All models use cast alloy wheels which are designed to run with tubeless tyres. Although the wheels vary in size and style, all are very similar in construction. Both front and rear brakes are hydraulically operated discs, a twin disc set up at the front and a single at the rear.

On ZX900 A1 to A6 models and ZX1000 A models, the front braking system is also used to actuate the anti-dive units fitted to the front forks. These are hydraulically operated from a junction box situated on each lower fork leg.

## 2 Front wheel - removal

1 Place the machine on its centre stand, leaving adequate space around the wheel area. Slacken the knurled ring which retains the speedometer cable to its drive gearbox and pull the cable clear of the wheel.

2 On all models except the ZX900 A1 to A6, remove the brake caliper mounting bolts and lift both calipers clear of the discs. Place a wooden wedge between the brake pads to prevent their expulsion if the brake lever is accidentally operated, and tie both calipers to

the frame to avoid straining the hydraulic hoses.

3 On ZX900 A1 to A6 models it is necessary to remove only one of the calipers. Remove the caliper mounting bolts and wait until the wheel has been lowered out of the forks as described below before removing the caliper.

4 On all models, release the wheel spindle pinch bolt(s) situated on the right-hand lower fork leg and slacken the wheel spindle from the right-hand side (see illustration).

5 Remove the lower fairing, as described in Chapter 6, and place some blocks or a suitable stand underneath the engine so that the front wheel is raised clear of the ground. Support the wheel and withdraw the spindle from the right-hand side. The wheel can then be lowered to the ground and removed from the machine. On ZX900 A1 to A6 models slide the caliper off the disc, placing a wedge between the pads and tying the caliper to the machine as described above.

6 Note that the wheel should not be placed on its side with the weight resting on one of the brake discs as this could distort the disc. Place a wooden block beneath the wheel rim or rest the wheel against a wall.

7 Refer to Chapter 1 for details of wheel examination.

## 3 Front wheel - refitting

1 On reassembly, grease the speedometer gearbox and the lips of the oil seal fitted to the right-hand side of the hub. Refit the speedometer gearbox to the left-hand side of the wheel, ensuring that the tangs on its drive plate engage correctly with the slots in the hub (see illustration). Insert the spacer into the right-hand side of the hub (see illustration). Check that the spindle is straight and free from corrosion and smear a small amount of high melting-point grease along its shank.


2 Remove the wooden wedge from the brake caliper and refit it to the relevant disc on the wheel (ZX900 A1 to A6 models only). Offer up the wheel and insert the spindle from the right-hand side (see illustration). Position the



3.1a Refit speedometer gearbox ensuring that it is correctly located ...




3.1b ... and refit spacer to right-hand side of the wheel




3.2a Manoeuvre the wheel into position and refit the spindle






**3.2b** Ensure lugs on speedometer gearbox are correctly positioned ...



**3.2c** ... then tighten the wheel spindle ...



**3.2d** ... and pinch bolts to their specified torque settings

speedometer gearbox so that the projection on the gearbox is in contact with the lug on the lower fork leg and then tighten the wheel spindle and pinch bolts to their specified torque settings (see illustrations).

**3** On all other models except the ZX900 A1 to A6, remove the wooden wedges from the brake calipers and refit the calipers to the discs. On all models, refit the caliper mounting

bolts, tightening them to the specified torque setting, and refit the speedometer cable.

**4** Remove the blocks or stand from underneath the engine and refit the lower fairing section. Push the machine off the centre stand and apply the front brake, pumping the lever until normal operation of the brake returns. Thoroughly check the operation of the front brake and forks before taking the machine on the road.

## 4 Rear wheel - removal


**1** Place the machine on its centre stand on level ground. On ZX900 and ZX1000 A models, release the right-hand silencer mounting clamp and bolt and remove the silencer from the exhaust pipe. On all models remove the rear caliper mounting bolts and remove the caliper from the disc. Place a wooden wedge between the brake pads to prevent their expulsion if the brake pedal is accidentally operated, and support the caliper in such a way as to avoid placing any strain on the brake hose.

**2** ZX900 models release the locknut on the caliper bracket fixing bolt and then remove both the fixing bolt and the caliper bracket collar retaining bolt. Remove the caliper bracket collar from the swinging arm lug and store it with the bolts for safekeeping. On all other models, slacken and remove the caliper bracket to torque arm retaining bolt (see illustration).

**3** Slacken both chain adjuster pinch bolts situated in the ends of the swinging arm, and rotate one of the adjusters to obtain the maximum drive chain free play possible. Using a small flat-bladed screwdriver, prise out the right-hand wheel spindle retaining circlip and remove the spindle nut and washer. Remove the left-hand spindle circlip and withdraw the wheel spindle whilst supporting the wheel. The spindle can be tapped out of position if necessary using a hammer and a suitable drift. Remove the caliper mounting bracket from the right-hand side of the wheel and lower the wheel to the ground. Disengage the drive chain from its sprocket and loop the chain over the swinging arm end. Remove the wheel from the machine.


**4** Note that the wheel should not be placed on its side with the weight resting on the brake disc as this could distort the disc.

**5** Refer to Chapter 1 for details of wheel examination.




- 1 Circlip - 2 off
- 2 Nut
- 3 Washer
- 4 Right-hand spacer
- 5 Oil seal
- 6 Circlip
- 7 Wheel bearing - 2 off
- 8 Central spacer
- 9 Cush drive rubbers
- 10 Cush drive hub spacer
- 11 Cush drive hub/sprocket carrier
- 12 Bearing
- 13 Circlip
- 14 Oil seal
- 15 Left-hand spacer
- 16 Wheel spindle






5.1a Do not omit the right-hand ...



5.1b ... and left-hand wheel spacers



5.2a Engage the final drive chain on the sprocket ...

## 5 Rear wheel - refitting



1 Apply a small amount of grease to the lips of the rear wheel oil seals and refit the spacers (see illustrations). Check that the wheel spindle is straight and free from corrosion and smear a small amount of high melting-point grease along its shank to assist refitting.

2 Loop the final drive chain over the sprocket, offer up the wheel and partially insert the spindle from the left-hand side (see illustrations). Slide the caliper mounting bracket into position and push the spindle fully in (see illustration). Refit the left-hand spindle retaining circlip, ensuring that it is correctly seated in the groove provided, and fit the spindle nut and washer. Tighten it by hand only at this stage.

3 On ZX900 models refit the caliper collar, collar retaining bolt and caliper bracket fixing bolt. Do not tighten either bolt at this stage, until the wheel alignment and chain tension have been set. On all other models refit the caliper bracket to torque arm bolt, tightening it fingertight only.

4 Remove the wooden wedge from between the brake pads, install the caliper on the disc and refit its mounting bolts, tightening them to the specified torque setting.

5 Adjust the wheel alignment and chain tension as described in Chapter 1. Tighten the wheel spindle, chain adjuster pinch bolts and

the caliper bracket to torque arm bolt to their specified torque settings and ensure that the right-hand spindle retaining circlip is correctly seated in its groove. On ZX900 and ZX1000 A models refit the right-hand silencer and tighten its mounting bolt and clamp securely.

6 Finally, on all models pump the rear brake pedal until the pads are pushed back into contact with the disc and thoroughly check the operation of the rear brake before taking the machine on the road.

## 6 Wheel bearings - removal, examination and refitting




### Front wheel

1 Remove the front wheel from the machine as described in Section 2. Although it is not strictly necessary to remove the brake discs for this task, it is strongly advised due to the fact that this will make the task easier and prevent the discs being damaged.

2 Remove the circlip from the left-hand side of the hub and withdraw the speedometer drive plate. Working from the right-hand side of the hub carefully lever out the oil seal, using a large flat-bladed screwdriver, and remove the circlip behind it.

3 Support the wheel so that the hub is clear of the work surface. Pass a long drift through the hub, push the internal spacer to one side and drive out the right-hand bearing, tapping




5.2b ... then lift up the wheel and partially insert spindle


evenly all around its inner race. The spacer will drop out. Invert the wheel and drive out the remaining bearing.

4 Removing the bearings in this way will almost certainly damage them if they are a tight fit, but there is no alternative. Wash each bearing thoroughly removing all old grease, then spin each one. If any signs of roughness can be heard or felt, if any free play can be felt or if any pitting can be seen on the balls or their tracks, the bearings must be renewed. The oil seal should be renewed as a matter of course.


5 On reassembly, pack the bearings with high melting-point grease and refit the bearings with their sealed surface facing outwards. Drive the bearing into place using a tubular drift such as a socket spanner which bears only on the bearing's outer race (see illustration). Turn the wheel over and refit the



5.2c Slide the rear brake caliper assembly into position ...



5.2d ... push the spindle fully in and fit the washer and spindle nut



6.5a Drive first wheel bearing into position ...





6.5b . . . then invert the wheel and insert central spacer



6.5c Grease the cavity and fit the second bearing



6.5d On the front wheel locate speedometer drive plate with slots in hub . . .



6.5e . . . and secure with the circlip

spacer, then pack the central recess no more than 2/3 full with high melting-point grease and refit the right-hand bearing, sealed surface outwards, as described above (**see illustrations**). Refit the circlip and oil seal to the right-hand side of the hub. Refit the speedometer drive plate to the left-hand side of the hub, ensuring that the tangs on the plate are correctly engaged in the slots in the hub, followed by the circlip (**see illustrations**). Refit the brake discs, if removed, and tighten their mounting bolts to the specified torque setting.

## Rear wheel

6 Remove the rear wheel from the machine as described in Section 4 and remove the

sprocket carrier assembly. Lever out the oil seal from the right-hand side of the hub and remove the circlip behind it.

7 Remove, examine and install the bearings as described above for the front wheel.

## 7 Rear wheel cush drive - examination and renovation

1 Remove the rear wheel as described in Section 4. The sprocket is retained by six nuts, these being easier to slacken whilst the assembly is still fitted to the wheel.

2 Remove the carrier assembly from the wheel then remove the sprocket retaining nuts and lift off the sprocket. Pull out the spacers from each side of the assembly, noting which way round the shouldered inner spacer is fitted, then carefully lever out the oil seal and remove the circlip to allow the bearing to be driven out from the inside.

3 Remove the bearing, clean and examine it as described in Section 6, renewing it if necessary. Pack the bearing with high melting-point grease and fit it to the carrier, securing it with the circlip. The oil seal should be renewed regardless of its condition.

4 If the rear sprocket teeth are hooked, chipped, missing or worn the sprocket must be renewed, but this should be done only in conjunction with a new gearbox sprocket and

final drive chain. Refit the sprocket on the carrier and tighten all retaining nuts to the specified torque setting. Insert the spacers into both sides of the carrier assembly, ensuring that they are refitted in their original positions (**see illustration**).

5 Examine the cush drive rubber block; if perished, split, damaged or compressed to the extent that there is excessive movement between the sprocket carrier and wheel, it must be renewed (**see illustration**). It can be pulled out of the hub by hand. The new rubber block will be a tight fit; lubricate it with a very small amount of soapy water, not oil, to aid installation. Note that on some ZX1000B1 models instances have occurred of the cush drive rubbers distorting, leading to excessive backlash at the rear wheel. In such cases a modification is available from the manufacturer, consisting of three plastic inserts which are glued to the rubbers to strengthen them.

## 8 Brake discs - examination and renovation

1 Examine the brake discs for scoring, particularly the rear unit which is more vulnerable to accumulations of road dirt. Damaged discs will cause poor braking and will wear pads quickly, and should therefore be renewed. The disc thickness can be



7.4 Do not omit spacer from sprocket carrier on reassembly



7.5 Renew cush drive rubbers if perished





**8.3** Where discs show a stamped arrow ensure this faces in normal direction of wheel rotation

measured with a micrometer and should not be less than the service limit specified.

**2** Check for warpage with the relevant wheel raised clear of the ground, using a dial gauge probe running near the edge of the disc. Warpage must not exceed the maximum figure when the disc is rotated. Note that a warped disc will cause judder during braking.

**3** The discs can be removed after the appropriate wheel has been removed from the machine. Each disc is retained by a number of bolts. When refitting the disc, ensure that the mating surfaces are clean and that the chamfered hole side of the disc faces inwards or the marked surface outwards, as appropriate. Tighten the retaining bolts to the specified torque setting. On some models the brake discs are marked with an arrow; if this is the case the disc must be fitted with the arrow pointing in the normal direction of wheel rotation (see illustration).


## 9 Brake calipers - removal, overhaul and refitting

**Caution:** brake fluid will discolour or remove paint if contact is allowed. Avoid this where possible and remove accidental splashes immediately. Similarly, avoid contact between the fluid and plastic parts such as the instrument lenses and fairing.

**1** When working on the front brake dismantle the calipers separately to avoid interchanging components.

**2** To remove the caliper, slacken and remove the union bolt which secures the hose to the caliper having first placed a suitable container underneath it in which to drain the fluid. Stop the flow of fluid from the reservoir by holding the front brake lever in against the handlebars; this is easily done by using a stout elastic band. On the rear caliper the flow of fluid can be stopped simply by attaching the hose union to the highest possible point of the frame. It may be necessary to remove the hose clamps to enable this.

**3** When the fluid stops flowing from the hose union, clean the connections carefully and secure the hose end and fittings inside a clean



**9.5** Front brake caliper - ZX900 A1 to A6 and ZX1000 A models

polythene bag, to await reassembly. It is most important to keep each component scrupulously clean, and to prevent the ingress of any foreign matter. For this reason, it is as well to prepare a clean area in which to work, before further dismantling. Ensure that the outside of the caliper is thoroughly cleaned down.

**4** Remove the caliper from the machine and the brake pads from the caliper as described in Chapter 1.

### ZX900 A1 to A6 and ZX1000A models

**5** Separate the mounting bracket from the caliper by pushing it away from the piston, then displace the two rubber dust covers and the anti-rattle spring (see illustration). The piston may be expelled from the caliper body by an air jet - a foot pump if necessary. Remove the piston seal and dust seal from the caliper body. Under no circumstances should any attempt be made to lever or prise the piston out of the caliper. If the compressed air method fails, temporarily reconnect the caliper to the flexible hose, and use the handlebar lever to displace the piston hydraulically. Wrap some rag around the caliper to catch the inevitable shower of brake fluid. Whichever method is used take great care to avoid getting your fingers trapped by the emerging piston. Once the piston is out, remove both the dust and fluid seals, taking great care not to damage the piston bore.

**6** Clean all components carefully, removing all traces of road dirt, friction material and corrosion. Note that only clean hydraulic fluid (or ethyl or isopropyl alcohol) should be used to clean hydraulic components; all normal cleaning solvents will attack the rubber seals. It is permissible to use a wire brush gently to

remove dirt and corrosion except in the caliper bores and on the piston surfaces.

**7** Renew both fluid and dust seals as a matter of course. Never re-use a hydraulic seal after it has been disturbed and note that the piston seal must be in excellent condition as its secondary role is to return the piston when lever or pedal pressure is released, thus preventing brake drag. Carefully examine the mounting bracket dust covers, renewing them if they are perished, split or otherwise damaged. Similarly discard the sealing washers fitted each side of the brake hose union; these should be renewed as a matter of course.


**8** Examine the piston surface and caliper bore for signs of wear or scoring, normally caused by the presence of road dirt or corrosion. If wear is found, or deep scoring or scratches which might cause fluid leaks, the component concerned must be renewed.

**9** Check that there is no free play between the caliper body and its mounting bracket. Renew any components that are found to be worn. It is essential that single-piston brake calipers can slide smoothly on their mountings. Make a final check that there are no signs of damage on any other part of the caliper assembly.

**10** On reassembly, soak the new fluid and dust seals in clean hydraulic fluid and carefully fit them into the caliper bore, ensuring that each is correctly seated in its groove. Smear hydraulic fluid over the caliper bore and piston surface and refit the piston, rotating it slightly while keeping it square to the caliper bore so that it does not stick or displace either seal.

**11** Apply PBC (Poly Butyl Cuprysil) grease to all sliding surfaces on the caliper body and mounting bracket and refit the bracket to the caliper, ensuring that the rubber dust covers are correctly fitted and refit the anti-rattle





9.12 Front brake caliper - ZX1000 B models

- |                            |                       |
|----------------------------|-----------------------|
| 1 Caliper body             | 8 Pad spring          |
| 2 Bleed nipple             | 9 Anti-rattle springs |
| 3 Fluid seal - 2 off       | 10 Mounting bracket   |
| 4 Dust seal - 2 off        | 11 Dust cover         |
| 5 Piston 2 off             | 12 Dust cover         |
| 6 Piston insulator - 2 off | 13 Bolt - 2 off       |
| 7 Brake pads               |                       |

spring. Check that the caliper body moves smoothly from side to side and refit the pads as described in Chapter 1.


### ZX1000 B models

**12** The brake calipers fitted to these models are basically a dual piston version of that which is fitted to the ZX900 A1 to A6 and ZX1000 A models (see illustration). Therefore the caliper can be overhauled as described above noting the following points.

**13** When removing the pistons from the caliper ensure that both pistons leave the bores at the same time. If one sticks at any point the other piston must be restrained by firm hand pressure so that the full pressure can overcome the resistance. It would be very difficult to extract one piston alone from this type of caliper without risking damage. Note that the insulators fitted to the brake pad side of each piston are a push fit in the piston body.


### ZX900 A7-on, ZX1100 C and front on ZX1100 D models

**14** These models employ two different types of caliper. The front brake uses two four-piston opposed calipers while the rear brake uses a dual piston caliper which is similar to that fitted to the ZX1000 B models, and can be overhauled as described above (see illustrations). To overhaul the front calipers proceed as follows.




9.14a Front brake caliper - ZX900 A7-on and ZX1100 C/D models

- |                            |                      |
|----------------------------|----------------------|
| 1 Caliper half             | 8 Bleed nipple       |
| 2 Bolt - 6 off             | 9 Brake pads         |
| 3 Fluid seal - 4 off       | 10 Pad retaining pin |
| 4 Dust seal - 4 off        | 11 R-pin             |
| 5 Piston - 4 off           | 12 Seal - 2 off      |
| 6 Piston insulator - 4 off | 13 Caliper half      |
| 7 Pad spring               |                      |



9.14b Rear brake caliper - ZX900 A1 to A6 and ZX1000 A models

- |                |                       |
|----------------|-----------------------|
| 1 Caliper body | 7 Brake pads          |
| 2 Bleed nipple | 8 Mounting bracket    |
| 3 Fluid seal   | 9 Anti-rattle springs |
| 4 Piston       | 10 Dust cover         |
| 5 Dust seal    | 11 Dust cover         |
| 6 Pad spring   |                       |



9.14c Rear brake caliper - ZX1000 B and ZX1100 C models (ZX900 A7-on similar)

- |                            |                        |
|----------------------------|------------------------|
| 1 Caliper body             | 7 Mounting bracket     |
| 2 Fluid seal - 2 off       | 8 Dust cover           |
| 3 Dust seal - 2 off        | 9 Dust cover           |
| 4 Piston - 2 off           | 10 Anti-rattle springs |
| 5 Piston insulator - 2 off | 11 Pad spring          |
| 6 Bleed nipples            | 12 Brake pads          |



**15** After removing the brake pads temporarily refit the caliper to the fork leg and tighten its mounting bolts. With the caliper firmly held in place slacken the four bolts which secure the two halves of the caliper together and remove the caliper assembly from the fork leg. Remove the four bolts and separate the two halves of the caliper, noting the O-rings which fit in the oil passages. Deal with each half separately to avoid interchanging components.

**16** Before removing the pistons it will be necessary to block one or both sides of the fluid passages, depending on which half is being worked on. This can be achieved using a block of wood one side having a rubber surface which is bolted to the caliper half as shown (see illustration). When working on the inner half of the caliper, block one oil passage and apply compressed air into the opposite passage, and when working on the outer half of the caliper, block both oil passages and apply the air into the union bolt hole. Remove both pistons as described in paragraph 13. The caliper components can be checked and refitted as described above. Note that the insulators fitted to the brake pad side of each piston are a push fit in the piston body.

**17** Fit new O-rings to both oil passages and join the two halves together. Refit the four caliper bolts, tightening them to the specified torque setting, and refit the brake pads as described in Chapter 1.

## Rear on ZX1100 D models

### Removal


**18** Extract the split pin and unscrew the nut from the torque arm rear bolt. Displace the bolt and let the torque arm drop free. Remove the two Allen-head bolts which retain the caliper to its mounting bracket.

**19** If caliper overhaul is intended, remove the hose banjo bolt and allow the fluid to drain into a container. Wrap a plastic bag around the end of the hose to prevent the entry of dirt into the system and prevent further fluid loss. Manoeuvre the caliper off the disc.

### Overhaul

**20** Remove the brake pads from the caliper.  
**21** To extract the pistons the caliper halves must be separated by removing the two hex-head bolts (see illustrations). To enable the assembly to be held firmly whilst the bolts are slackened it is advised that the caliper be remounted on its bracket.

**22** Separate the caliper halves and mop up any lost fluid. The pistons must be removed from their bores using air pressure; attempts at prying them from position will almost certainly damage the bore and piston surface. When working on the inner half of the caliper apply air pressure via the fluid passage to force the piston free. On the outer half, use a block of wood with one side faced with a rubber pad to seal the fluid passage and allow air pressure to force the piston out (see



**9.16 Method of blocking brake fluid passages during piston removal - ZX900 A7-on and ZX1100 C models**

- |                 |                      |
|-----------------|----------------------|
| 1 Bolt and nut  | 4 Sealed passage     |
| 2 Rubber facing | 5 Open fluid passage |
| 3 Wooden block  |                      |

illustration 9.16). Make sure each piston leaves its bore squarely and take care to avoid trapped fingers as it emerges.


**23** Remove the fluid and dust seals from the piston bores and the O-ring from the fluid passage.

**24** Inspect each piston and its bore for signs of extreme wear and damage. Keep each piston with its matched bore. Inspect the bearing and dust seals in the torque arm mounting.

**25** Install new fluid and dust seals in the caliper bore and using only new hydraulic fluid, install the pistons.

**26** Using a new O-ring around the fluid passage join the two caliper halves together. Install the hex-head bolts and tighten them securely.

**27** Refit the brake pads.



**9.21a Caliper hex-head joining bolts (arrows) - ZX1100 D models**

### Refitting


**28** Offer the caliper up to the disc, if necessary pushing the pistons further into their bores to create enough clearance for the disc. Install the Allen-head mounting bracket bolts and tighten to the specified torque.

**29** Position the caliper so that it aligns with the torque arm fork and install the bolt and nut, tightening them to the specified torque. Install a new split pin.

**30** Using new sealing washers each side of the hose union, refit the banjo union bolt, tightening it to the specified torque.

**31** Fill the system with fresh brake fluid and bleed it of air. Check for correct operation of the brakes before taking the machine out on the road.

- |   |
|---|
| 1 Plastic cover                         |
| 2 Brake pads                            |
| 3 R-pin - 2 off                         |
| 4 Pad retaining pin - 2 off             |
| 5 Anti-rattle springs                   |
| 6 Caliper outer half                    |
| 7 Hex-head caliper joining bolt - 2 off |
| 8 O-ring                                |
| 9 Dust seals                            |
| 10 Pistons                              |
| 11 Fluid seals                          |
| 12 Caliper inner half                   |
| 13 Bleed valves                         |
| 14 Caliper mounting bracket             |
| 15 Allen-head mounting bolt - 2 off     |
| 16 Torque arm bearing                   |
| 17 Sealing washers                      |
| 18 Needle roller bearing                |
| 19 Grease seals                         |
| 20 Spacer                               |



<http://manuals.magnamaniac.com>

**9.21b Rear brake caliper - ZX1100 D models**



**All models**

**32** Refit the caliper to the machine and tighten its mounting bolts to the specified torque setting. Position a new sealing washer on each side of the hose union and tighten the union bolt to the specified torque setting. Bleed the system as described in Section 13 after filling the reservoir with new hydraulic fluid, then check for leakage of fluid whilst applying the brake lever. Push the machine forward and bring it to a halt by applying the brake. Do this several times to ensure that the brake is operating correctly before taking the machine for a test run. During the run, use the brakes as often as possible and on completion, recheck for signs of fluid loss.

## 10 Front brake master cylinder - removal and refitting



**Caution: brake fluid will discolour or remove paint if contact is allowed. Avoid this where possible and remove accidental splashes immediately. Similarly avoid contact between the fluid and plastic parts such as the instrument lenses and fairing.**

**1** Disconnect the stop lamp switch wires at the switch. The switch need not be disturbed unless the master cylinder is to be renewed. Place a clean container below one of the brake calipers and run a clear plastic tube from the caliper bleed nipple to the container. Unscrew the bleed nipple by one full turn and drain the system by operating the brake lever repeatedly until all fluid has drained from the reservoir.

**2** Position a wad of clean rag beneath the point where the brake hose joins the master cylinder to prevent drops of brake fluid contacting the components below. Pull back the rubber cover from the head of the union bolt and remove the bolt. Once any excess fluid has drained from the union connection, wrap the end of the hose in rag or polythene and then attach it to a point on the handlebars. Remove the brake lever by

unscrewing its locknut and shouldered bolt. Remove the reservoir cover and lift out the diaphragm. Release the two master cylinder clamp bolts and remove the master cylinder from the machine.

**3** Use the flat of a small screwdriver to prise out the rubber dust seal boot from the end of the piston assembly (**see illustration**). This will expose a retaining circlip which must be removed using a pair of circlip pliers which have long, straight jaws. With the circlip removed, the piston and cup assembly can be pulled out. Be very careful to note the exact order in which these components are fitted.

**4** Note that if a vice is used to hold the master cylinder at any time during dismantling and reassembly, its jaws must be padded with soft alloy or wooden covers and the master cylinder must be wrapped in soft cloth to prevent it being marked or distorted.

**5** Place all the master cylinder components in a clean container and clean each part thoroughly. Lay the parts out on a sheet of clean paper and examine each one as follows.

**6** Examine the piston surface and master cylinder bore for signs of wear or corrosion. Renew both components if damaged in any way; new seals will not compensate for scoring and will wear out quickly. Check the primary and secondary seals for damage or swelling, renewing them unless in perfect condition. The cups are sold as a kit together with the piston and spring. Renew the dust seal at the same time to preclude road dirt entering the assembly. Ensure that the supply port and the smaller relief port between the cylinder and reservoir are clear, especially where swollen or damaged cups have been noted. Inspect the threads of the brake hose union bolt for signs of failure and renew the bolt if in the slightest doubt. Renew the sealing washers located on each side of the union as a matter of course.

**7** Check before reassembly that any traces of contamination remaining in the reservoir body have been removed. Inspect the diaphragm to see that it is not perished or split. It must be noted at this point that any reassembly work must be undertaken in ultra-clean conditions.

Particles of dirt entering the components will serve only to score the working points of the cylinder and thereby cause early failure of the system.

**8** When reassembling and fitting the master cylinder, follow the removal and dismantling procedures in reverse, whilst paying attention to the following points. Make sure that the piston components are fitted the correct way round and in the correct order. Immerse the piston components in new brake fluid prior to reassembly and refer to the figure accompanying this text when in doubt as to their correct positions.

**9** When refitting the master cylinder assembly to the handlebar, position it so that the reservoir will be exactly horizontal when the machine is in use. Tighten the clamp top bolt first, and then the bottom bolt to the specified torque setting. Connect the brake hose to the master cylinder, ensuring that a new sealing washer is placed on each side of the hose union, and tighten the hose union bolt to the specified torque setting. Finally, refit the rubber union cover and reconnect the brake lamp switch wiring.

**10** Fill the reservoir with new brake fluid and bleed the system as described in Section 13. Check for fluid leakage with the brake lever applied, before taking the machine out on the road. During the run, use the brakes as often as possible and on completion, recheck for signs of fluid loss.

## 11 Rear brake master cylinder - removal, overhaul and refitting




**Caution: brake fluid will discolour or remove paint if contact is allowed. Avoid this where possible and remove accidental splashes immediately. Similarly, avoid contact between the fluid and plastic parts.**

**1** Remove the right-hand sidepanel and drain the hydraulic system as described in paragraph 1 of Section 10. Drain the system fully to ensure that all fluid has also drained from the reservoir to master cylinder hose. Release the reservoir mounting bolt and disconnect the hose which joins it to the master cylinder. Remove the reservoir from the machine and wipe up any spilt fluid. Disconnect the brake hose from the master cylinder and place the hose union and bolt inside a polythene bag, securing the bag with an elastic band. This will prevent dirt entering the system whilst the hose is disconnected.

### ZX900


**2** Disconnect the rear stop lamp switch wires from the main wiring loom and remove the bolt which secures the right-hand silencer to the footrest bracket. Slacken and remove the swinging arm pivot shaft nut and the five bolts which retain the footrest bracket to the frame, then remove the bracket assembly from the machine.

- 1 Cover
- 2 Screw - 2 off
- 3 Diaphragm
- 4 Reservoir
- 5 Brake stop lamp switch
- 6 Handlebar clamp
- 7 Bolt - 2 off
- 8 Spring
- 9 Primary piston assembly
- 10 Circlip
- 11 Dust boot
- 12 Brake lever
- 13 Hose union
- 14 Sealing washer - 2 off
- 15 Union bolt
- 16 Rubber cover



10.3 Front brake master cylinder - typical (clutch master cylinder similar)





**11.3 Rear brake master cylinder - ZX1000 B and ZX1100 C models (other models similar)**

- |                   |                     |
|-------------------|---------------------|
| 1 Cap             | 10 Primary piston   |
| 2 Diaphragm plate | assembly            |
| 3 Diaphragm       | 11 Circlip          |
| 4 Reservoir       | 12 Dust boot        |
| 5 Connecting      | 13 Operating rod    |
| hose              | 14 Clevis pin       |
| 6 Union           | 15 Split pin        |
| 7 Master cylinder | 16 Hose union       |
| 8 Bolt - 2 off    | 17 Sealing washer - |
| 9 Spring          | 2 off               |
|                   | 18 Union bolt       |

### All models

3 Remove the split pin and clevis pin which retain the forked end of the master cylinder pushrod to the brake pedal (see illustration). Release the two master cylinder mounting bolts and lift the cylinder away from the footrest bracket.

4 Pull off the dust seal and remove it together with the pushrod. Displace the retaining clip and continue dismantling and overhaul of the piston assembly as described in Section 10.

5 The master cylinder is refitted by reversing the removal sequence. Refit the master cylinder to the footrest bracket and tighten its mounting bolts to the specified torque setting. Insert the clevis pin into the pushrod end and secure it with a new split pin. On ZX900 models, refit the bracket assembly, tightening all mounting bolts and the swinging arm pivot shaft nut to their specified torque settings, and reconnect the stop lamp switch wires.

6 Position a new sealing washer on each side of the hose union and tighten the union bolt to the specified torque setting. Connect the reservoir hose to the master cylinder and refit the reservoir mounting bolt.

7 Bleed the brake system after refilling the reservoir with new hydraulic fluid, then check for leakage of fluid whilst applying the brake pedal. With the machine on its centre stand, spin the rear wheel and apply the rear brake. Do this several times to ensure that the brake is operating correctly, then check the brake pedal height and the operation of the rear brake lamp switch as described in Chapter 1, before taking the machine on a test run. During the test run, use the brakes as often as possible and on completion, recheck for any sign of fluid loss.

### 12 Brake hoses and pipes - general

**Caution: brake fluid will discolour or remove paint if contact is allowed. Avoid this where possible and remove accidental splashes immediately. Similarly, avoid contact between the fluid and plastic parts such as the instrument lenses and fairing.**

1 Brake hoses will deteriorate through age and must be renewed at the specified interval for safety reasons (see Chapter 1). If any splits, kinks, leaks or any other damage is found on a hose at any time, it must be renewed immediately.

2 Drain the hydraulic system completely as described in Section 10. Slacken the union bolts, noting the exact route of the hose and in particular the notches in the calipers and three-way union mounted on the bottom yoke. These notches should locate with the hose unions when the hose is correctly fitted. Remove the faulty hose and clean the union.


3 Fit the new hose, ensuring that it is correctly routed, and position a new sealing washer on each side of its unions. Refit the union bolts and tighten them to the specified torque setting. Refill and bleed the system as described in the following section, and check for leaks. Thoroughly check the operation of the braking system before taking the machine out on the road.

### 13 Bleeding the braking system

**Caution: brake fluid will discolour or remove paint if contact is allowed. Avoid this where possible and remove accidental splashes immediately. Similarly, avoid contact between the fluid and plastic parts such as the instrument lenses and fairing.**

1 If the brake action becomes spongy, or if any part of the hydraulic system is dismantled (such as when a hose is renewed) it is necessary to bleed the system in order to remove all traces of air. The procedure for bleeding the hydraulic system is best carried out by two people.

2 Check the fluid level in the reservoir and top



**13.3 Bleed the brakes as described in text**

up with new fluid of the specified type if required. Keep the reservoir at least half full during the bleeding procedure; if the level is allowed to fall too far, air will enter the system requiring that the procedure be started again from scratch. Refit the reservoir cap to prevent the ingress of dust or the ejection of a spout of fluid.

3 Remove the dust cap from the caliper bleed nipple and clean the area with a rag. Place a clean glass jar below the caliper and connect a pipe from the bleed nipple to the jar (see illustration). A clear plastic pipe should be used so that air bubbles can be more easily seen. Pour enough clean hydraulic fluid in the glass jar so that the pipe end is immersed below the fluid surface; ensure that the pipe end remains submerged (to prevent air returning to the system whenever the pressure is released) throughout the operation.

4 If parts of the system have been renewed, and thus the system must be filled, open the bleed nipple about one turn and pump the brake lever until fluid starts to issue from the clear pipe. Tighten the bleed nipple and then continue the normal bleeding operation as described in the following paragraphs. Keep a close check on the reservoir level whilst the system is being filled.



**If bleeding is difficult, it may be necessary to let the brake fluid in the system stabilize for a few hours (it may be aerated). Repeat the bleeding procedure when the tiny bubbles in the system have settled out.**

### Front brake

5 Remove the reservoir cap and starting from the brake caliper and working back to the master cylinder, lightly tap the brake hose. Slowly pump the brake lever or pedal several times until no air bubbles can be seen rising up through the fluid in the reservoir. This operation bleeds the air from the master cylinder and brake hose.

6 Operate the brake lever as far as it will go and hold it in this position against the fluid pressure. If spongy brake operation has



occurred it may be necessary to pump the brake lever rapidly a number of times until pressure is built up. With pressure applied, loosen the bleed nipple about half a turn. Tighten the nipple as soon as the lever has reached its full travel and then release the lever. Repeat this operation until no more air bubbles are expelled with the fluid into the glass jar.

**7** On ZX900 A1 to A6 and ZX1000 A models it will be necessary to repeat the operation using first the bleed nipple on the anti-dive unit and then the nipple on the union block which is situated on the lower fork leg, directly above the caliper.

**8** On all models complete the bleeding process by repeating the above on the opposite caliper and associated components (as applicable). When no more air bubbles are expelled, the air bleeding operation should be complete, resulting in a firm feel to the brake lever. If sponginess is still evident repeat the bleeding operation; it may be that an air bubble trapped at the top of the system has yet to work down through the caliper.

### Rear brake

**9** The rear brake system can be bled as described above for the front brake, noting that on ZX900 A7-on, ZX1000 B and ZX1100 C/D models, it will be necessary to repeat the process using the second bleed nipple fitted to the caliper.

### Front and rear brakes all models

**10** When all traces of air have been removed from the system, top up the reservoir and refit the diaphragm and cap. Check the entire system for leaks, and check also that the

brake system in general is functioning efficiently before using the machine on the road.

**11** Brake fluid drained from the system will almost certainly be contaminated, either by foreign matter or more commonly by the absorption of water from the air. All hydraulic fluids are to some degree hygroscopic, that is, they are capable of drawing water from the atmosphere, and thereby degrading their specifications. In view of this, and the relative cheapness of the fluid, old fluid should always be discarded.

### 14 Anti-dive system - testing and renewal ZX900 A1 to A6 and ZX1000 A models

**Caution: brake fluid will discolour or remove paint if contact is allowed. Avoid this where possible and remove accidental splashes immediately. Similarly, avoid contact between the fluid and plastic parts such as the instrument lenses and fairing.**

**1** The anti-dive system is activated by hydraulic pressure whenever the front brake is applied, pressure being transmitted via metal brake pipes from the union block at the top of each fork leg to the anti-dive units.

**2** To test the system, place the machine on its centre stand, unbolt the union block from each fork lower leg and remove the two Allen screws securing the plunger assembly to the top of the anti-dive valve unit, then withdraw the plunger assemblies, taking care not to distort the brake pipe.

**3** Lightly apply the front brake with a finger over each plunger in turn. The plunger should

move out by 2 mm when pressure is applied at the lever and should return easily under finger pressure when the lever is released.

**4** If this is not the case, or if any signs of hydraulic fluid leakage are discovered, the plunger assembly should be dismantled for examination. Drain the brake fluid as described in Section 10 and disconnect the brake pipe from the top of the plunger housing. Remove the large hexagon-headed top plug and withdraw the plunger and seal assembly. Examine the components for wear or damage and renew as necessary. Note that the seals should be renewed once disturbed in the interests of safety. On reassembly, tighten the top plug securely. Tighten the two Allen headed plunger housing screws and the metal brake pipe gland nuts to the specified torque setting.

**5** Note that the plunger assemblies must be renewed at fixed intervals for safety reasons alone, regardless of their apparent condition. Refer to Chapter 1.

### 15 Tyres - general information and fitting

#### General information

**1** The wheels fitted to all models are designed to take tubeless tyres only.


**2** Refer to *Daily (pre-ride) checks* at the beginning of this manual, and to the scheduled checks in Chapter 1 for tyre and wheel maintenance.

#### Fitting new tyres

**3** When selecting new tyres, refer to the tyre information label on the swingarm and the tyre options listed in the owners manual. Ensure that front and rear tyre types are compatible, the correct size and correct speed rating; if necessary seek advice from a Honda dealer or tyre fitting specialist (see illustration).

**4** It is recommended that tyres are fitted by a motorcycle tyre specialist rather than attempted in the home workshop. The force required to break the seal between the wheel rim and tyre bead is substantial, and is usually beyond the capabilities of an individual working with normal tyre levers. Additionally, the specialist will be able to balance the wheels after tyre fitting.

**5** Only certain types of puncture repair are suitable for tubeless motorcycle tyres. Refer to a tyre fitting specialist for advice and to your owners manual for details of the reduced speeds advised for a repaired tyre.



15.3 Common tyre sidewall markings



# Specifications

## Electrical system

Voltage .....	12
Earth (ground) .....	Negative

## Battery

Capacity:	
ZX1100 D models .....	12 Ah
All other models .....	14 Ah
Electrolyte specific gravity .....	1.280 @ 20°C (68°F)

## Alternator

Type .....	Three-phase AC
Rated output:	
ZX900 and ZX1000 A models .....	25A @ 6000 rpm, 14 volts
ZX1000 B models .....	24A @ 6000 rpm, 14 volts
ZX1100 C/D models .....	28.6A @ 6000 rpm, 14 volts
Charging voltage - headlight on:	
ZX900 and ZX1000 A models .....	13.5 volts @ 4000 rpm
ZX1000 B and ZX1100 C/D models .....	14.5 volts @ 4000 rpm
Stator coil resistance .....	Less than 1 ohm
Rotor coil resistance:	
ZX1000 B2 and B3 models .....	Approximately 6 ohms
All other models .....	Approximately 4 ohms
Slip ring diameter .....	14.4 mm (0.57 in)
Service limit .....	14.0 mm (0.55 in)
Carbon brush projection length .....	10.5 mm (0.41 in)
Service limit .....	4.5 mm (0.18 in)



## Starter motor

Carbon brush length:

ZX900 and ZX1000 B models	12 mm (0.47 in)
Service limit	8.5 mm (0.33 in)
ZX1000 A and ZX1100 C/D models	12 - 12.5 mm (0.47 - 0.49 in)
Service limit	6 mm (0.24 in)
Commutator diameter	28 mm (1.10 in)
Service limit	27 mm (1.06 in)

Commutator groove depth:

ZX900 models and ZX1000 A models	0.45 - 0.75 mm (0.018 - 0.030 in)
Service limit	0.2 mm (0.008 in)
ZX1000 B and ZX1100 C/D models	0.7 mm (0.028 in)
Service limit	0.2 mm (0.008 in)

## Fuel level sender unit resistances

ZX900 models:

Empty	70 - 120 ohms
Full	3 - 12 ohms

ZX1000 models:

Empty	90 - 100 ohms
Full	4 - 10 ohms

ZX1100 C models

see text

ZX1100 D models:

Empty	90 - 100 ohms
Full	4 - 10 ohms

## Fuses

ZX900 and ZX1000 A models:

Main	30A
Horn	10A
Tail	10A
Lights	10A
Turn signals	10A
Fan	10A
Accessory - ZX900 only	10A x 2

ZX1000 B and ZX1100 C models:

Main	30A
Headlamp	10A
Fan	10A
Accessory	10A

ZX1100 D1 and D2 models:

Main	30A
Headlamp	10A
Tail lamp	10A
Fan	10A
Accessory (US models only)	10A

ZX1100 D3, D4 and D5 models:

Main	30A
Horn	10A
Ignition	10A
Tail lamp	10A
Headlamp	10A
Fan	10A
Accessory (clock)	10A
Turn signal	10A

## Bulbs

Headlamp	12V 60/55W
Parking lamp - UK models only	12V 4W (ZX1100 D: 5W)
Stop/tail lamp:	
UK models	12V 5/21W
US models	12V 8/27W
Turn signal lamps:	
UK models	12V 21W
US models	12V 23W (ZX1100 D: 8/23W front, 12V 23W rear)
Instrument illuminating lamps	12V 3W (ZX1100 D: 1.7W)
Warning lamps	12V 3.4W
Licence plate lamp	12V 5W



**Torque settings**

	kgf m	lbf ft
Alternator coupling bolt .....	1.0	7.0
Radiator mounted fan switch:		
ZX900 and ZX1000 A models .....	0.75	5.5
ZX1000 B and ZX1100 C/D models .....	1.8	13.0
Coolant temperature sender unit:		
ZX900 and ZX1000 A models .....	0.8	6.0
ZX1000 B and ZX1100 C/D models .....	1.5	11.0
Thermostat housing fan switch - ZX900 models .....	0.8	6.0
Oil pressure switch .....	1.5	11.0
Oil temperature switch - ZX900 models .....	0.8	6.0

**1 General description**

The electrical system is powered by a three-phase alternator driven from the crankshaft via the starter clutch shaft by a chain on the right-hand end of the crankshaft. The shaft is fitted with two cush drive assemblies to damp out shock loads. The alternator is a self-contained unit which includes the regulator and rectifier.

The starter motor drives the crankshaft, through a series of reduction gears and the starter clutch, via the same chain which drives the alternator.

**2 Electrical system - general information and preliminary checks**

**1** In the event of an electrical system fault, always check the physical condition of the wiring and connectors before attempting any of the test procedures described here and in subsequent sections. Look for chafed, trapped or broken electrical leads and repair

or renew as necessary. Leads which have broken internally are not easily spotted, but may be checked using a multimeter or a simple battery and bulb circuit as a continuity tester (**see illustration**). The various multi-pin connectors are generally trouble-free but may corrode if exposed to water. Clean them carefully, scraping off any surface deposits, and pack with silicone grease during assembly to avoid recurrent problems. The same technique can be applied to the handlebar switches.

**2** The wiring harness is colour-coded and will correspond with the wiring diagrams at the end of this manual. Where socket connections are used, they are designed so that reconnection can be made only in the correct position.

**3** Visual inspection will usually show whether there are any breaks or frayed outer coverings which will give rise to short circuits. Occasionally a wire may become trapped between two components, breaking the inner core but leaving the more resilient outer cover intact. This can give rise to mysterious intermittent or total circuit failure. Another source of trouble may be the snap connectors or sockets, where the connector has not been pushed fully home in the outer housing, or where corrosion has occurred.

**4** Intermittent short circuits can often be traced to a chafed wire that passes through or is close to a metal component such as a frame member. Avoid tight bends in the lead or situations where a lead can become trapped between casings.

**5** A sound, fully charged battery, is essential to the normal operation of the system. There is no point in attempting to locate a fault if the battery is partly discharged or worn out. Check battery condition and recharge or renew the battery before proceeding further.

**6** Many of the test procedures described in this chapter require voltages or resistances to be checked. This necessitates the use of some form of test equipment such as a simple and inexpensive multimeter of the type sold by electronics or motor accessory shops.

**7** If you doubt your ability to check the electrical system, entrust the work to an authorized Kawasaki dealer. In any event have your findings double-checked before consigning expensive components to the scrap bin.

**3 Battery - examination and maintenance**


**1** Details of the regular checks needed to maintain the battery in good condition are given in Chapter 1, together with instructions on removal and refitting and general battery care. Batteries can be dangerous if mishandled; read the Safety first! section at the front of this manual before starting work, and always wear overalls or old clothing in case of accidental acid spillage. If acid is ever allowed to splash into your eyes or onto your skin, flush it away with copious quantities of fresh water and seek medical advice immediately.

**2** When new, the battery is filled with an electrolyte of dilute sulphuric acid having a specific gravity of 1.280 at 20°C (68°F). Subsequent evaporation, which occurs in normal use, can be compensated for by topping up with distilled or demineralised water only. Never use tap water as a substitute and do not add fresh electrolyte unless spillage has occurred.

**3** The state of charge of a battery can be checked using an hydrometer.

**4** The normal charge rate for a battery is 1/10 of its rated capacity, thus for a 14 ampere hour unit charging should take place at 1.4 amp. Exceeding this figure can cause the battery to overheat, buckling the plates and rendering it useless. Few owners will have access to an expensive current controlled charger, so if a normal domestic charger is used check that after a possible initial peak, the charge rate falls to a safe level. If the battery becomes hot during charging stop. Further charging will cause damage. Note that the cell caps should be loosened and the vents unobstructed during charging to avoid a build-up of pressure and risk of explosion.

**5** After charging top up with distilled water as required, then check the specific gravity and battery voltage. Specific gravity should be above 1.270 and a sound, fully charged battery should produce 13-14 volts. If the recharged battery discharges rapidly if left disconnected, it is likely that an internal short caused by physical damage or sulphation has occurred. A new battery will be required. A sound item will tend to lose its charge at about 1% per day.



**2.1 Simple testing equipment for checking the wiring**

- |                          |                  |
|--------------------------|------------------|
| A Multimeter or ohmmeter | C Battery        |
| B 12V bulb               | D Positive probe |
|                          | E Negative probe |



## 4 Alternator - general

To avoid damage to the alternator, and indeed many other components, the following precautions must be observed:


- Do not disconnect the battery or alternator whilst the engine is running
- Do not allow the engine to turn the alternator when the latter is not connected
- Do not test for output from the alternator by 'flashing' the output lead to earth
- Do not use a battery charger of more than 12 volts output, even as a starting aid
- Disconnect the battery and the alternator before carrying out any electric arc welding on the machine
- Always observe correct battery polarity
- When disconnecting the battery always remove the negative lead first and when reconnecting, connect it last

## 5 Alternator - checking the output

1 If the battery is known to be in a good condition yet fails to hold its charge when fitted to the machine, the alternator should be tested as follows.

2 Remove the three nuts which retain the alternator cover and lift the cover away from the alternator. Visually examine the alternator leads and connections for signs of corrosion or damage and repair as necessary. If all appears to be in order it will be necessary to check the alternator output. Note: for the following check to be accurate the battery must be fully charged.

3 Connect a dc voltmeter across the battery terminals and start the engine taking note of the voltage reading. If the alternator is in good condition the measured voltage should be higher than 13.5 volts, although not excessively high (see following paragraph). If



5.3 Ground the alternator F terminal (arrowed) to test regulator

the measured voltage is lower than 13.5 volts, stop the engine and repeat the above test having first grounded the F terminal of the regulator (see illustration) to earth using an insulated auxiliary wire. If the voltage reading obtained is now higher than 13.5 volts the regulator is at fault and should be tested further, if the reading is still below 13.5 volts the fault must lie in either the carbon brushes and slip rings, rectifier, stator coil or rotor coil.

4 Occasionally the condition may arise where the alternator output is excessive. Clues to this condition are constantly blowing bulbs with the brightness of the lights varying considerably with engine speed, and the battery overheating, needing the electrolyte level to be frequently topped up. This condition is almost certainly due to a faulty regulator which should be tested individually.

5 If the alternator has become noisy whilst the engine is running it is most likely that its bearings are worn. To check the bearings the alternator will have to be overhauled.

## 6 Alternator - overhaul

1 Note, it is not necessary to remove the alternator assembly from the machine to remove the regulator, rectifier or carbon brushes. However, if work on these

components is to be carried out with the assembly fitted to the engine unit, first disconnect the alternator block connector from the main wiring loom. Overhaul the relevant alternator components using the information given under the relevant sub-heading. If necessary, the alternator can be removed and refitted as described in Chapter 2.

## Carbon brushes


2 Release the three nuts which retain the alternator end cover and remove the cover from the alternator. Remove the two screws which retain the carbon brush holder and lift it off the slip rings. Measure the length of the projected portion of each of the carbon brushes fitted to the holder (see illustrations). If they are worn down to or below the service limit, the old brushes will have to be unsoldered and removed and new ones soldered into place. Some skill with a soldering iron will be required to do this, ensuring that the solder does not run down the brush leads. The brush springs should also be renewed if at all suspect. When fitted, the new brushes must move freely in the holder and be firmly in contact with the slip rings. If the original brushes are still serviceable, check that they are free to move easily in the holder and that their ends bear fully on the slip rings.

3 Whilst the brush holder is removed, take the opportunity to clean the slip rings with a cloth moistened with high flash-point solvent. If badly marked, tidy up the slip rings with a piece of 400 grade emery cloth. Using a vernier caliper, measure the slip ring diameter; this should not exceed the service limit at any point.


## Regulator

4 Remove the brush holder as described above then release the regulator mounting screws and remove it from the assembly (see illustration). The regulator can then be checked using either, or both, of the methods described in the following paragraph.


5 To conduct the first test two fully charged 12 volt batteries, a 12 volt 3.4 watt bulb and three auxiliary insulated wires will be needed



6.2a Remove the rubber brush holder cover . . .




6.2b . . . and measure projected length of each brush




6.4 Regulator is retained by two screws





6.5a Regulator terminal identification




Meter Range	Connections		Reading
	Meter (+) to	Meter (-) to	
x 100 $\Omega$	F	E	170 $\Omega$
x 1 k $\Omega$	E	F	4 k $\Omega$
x 100 $\Omega$	IG	E	800 $\Omega$
x 1 k $\Omega$	E	IG	2 k $\Omega$
x 1 k $\Omega$	F	IG	2 k $\Omega$
x 100 $\Omega$	IG	F	150 $\Omega$

6.5b Regulator test connections and table  
- see text

rectifier's diodes could be damaged by excessive heat.

7 The condition of the rectifier can then be determined by measuring the resistance of each of its six diodes in both directions, as shown in the accompanying illustration. Never use a multimeter with a large capacity battery to test the rectifier; severe damage could result.

8 With the meter set to the ohms x 1 scale connect the positive probe to the P1 terminal and the negative probe to the B terminal and note the reading obtained (see illustration). Swap the meter probes around, again noting the reading. Repeat this test between the P2 terminal and B terminal, and the P3 terminal and B terminal. Then carry out the same tests as described above but instead of using the B terminal, use the E (earth) point, making six further tests. Compare the two readings obtained for each diode. One value should be considerably higher than the other. Note that



6.6 Unsolder terminal wires quickly to avoid damaging the rectifier

the actual values obtained will vary depending on the type of test meter used, but if the unit is functioning correctly, there should be continuity (very low resistance) in one direction and no continuity (infinite resistance) with the meter probes reversed. If either condition exists in both directions for any diode, the rectifier is faulty and must be renewed.

9 On refitting, the wires must be soldered quickly and cleanly to the rectifier terminals to prevent excess heat building up and damaging the rectifier unit.


### Rotor coil, stator coil and alternator bearings

10 To remove these components the alternator must first be removed from the machine and the carbon brush holder, regulator and rectifier units removed as described above.

11 Slacken and remove the alternator drive coupling retaining bolt whilst holding the blades of the coupling with a self-locking wrench. Lift off the coupling and remove the three screws situated behind the coupling which retain the right-hand side of the alternator housing to the bearing plate (see illustration). Tape over the splined end of the rotor shaft to protect the oil seal and lift off the right-hand side of the alternator housing along with the stator coil.

12 Using a multimeter set to the ohms x 1 scale measure the resistance between the three stator coil wires (3 tests). If the resistance between any two of the wires greatly exceeds 1 ohm the stator coil windings can be considered faulty and must be renewed. Set the meter to the highest resistance scale possible and check for continuity between each stator coil winding and the core of the coil. If there is any reading at all, the stator coil windings have short circuited and must be renewed. Examine the oil seal fitted to the right-hand alternator for signs of wear or damage, renewing as necessary.

13 To check the rotor coil windings set the meter to the ohms x 1 scale and measure the resistance between the two slip rings. If the reading obtained does not resemble that




6.8 Rectifier test



6.11 Stator coil is retained by three screws situated behind drive coupling





**7.1a Junction box components - ZX900 (UK) models**



**7.1b On ZX1000 B and ZX1100 C/D models main fuse is fitted to starter relay - ZX1100 C shown**

given in the specifications the rotor coil windings can be considered defective and must be renewed. Set the meter to the highest ohms scale possible and check for continuity between the rotor shaft and each of the slip rings. If any reading is obtained, the slip rings have short circuited on the shaft and the rotor coil must also be renewed. Note that if the slip rings are contaminated in any way clean them prior to this test as described in paragraph 3 above.

**14** Examine the bearing on the right-hand end of the rotor coil shaft for any signs of freeplay and check that it spins freely without any trace of notchiness. The left-hand bearing can be checked by holding the rotor coil and spinning the alternator housing. The housing should spin easily and smoothly on the shaft without binding. If either bearing is faulty, renew them both as a pair.

**15** To remove the rotor coil from the alternator housing access to a hydraulic press will be needed. Therefore it is recommended that if the alternator rotor coil and (or) bearings require renewal the work should be entrusted to an authorized Kawasaki dealer who will have the necessary equipment. On no account attempt to tap the rotor coil out of the housing using a hammer. This will almost certainly damage the slip rings.

**16** On reassembly, tape over the splined end of the rotor shaft and carefully fit the right-hand alternator housing to the rotor shaft. Ease the housing into position, aligning the bolt holes in the housing with the bearing

plate. Fit the three bearing plate screws and tighten them securely. Remove the tape from the end of the rotor shaft and locate the alternator drive coupling on the splines of the shaft. Tighten the coupling retaining bolt to its specified torque setting whilst holding the coupling with a self-locking wrench. Refit the rectifier, regulator and brush holder and refit the cover. Tighten all screws and nuts securely.

## 7 Fuses - general

**HAYNES HINT** *Corrosion of the fuse ends and fuse block terminals may occur and cause poor fuse contact. If this happens, remove the corrosion with a wire brush or emery paper, then spray the fuse end and terminals with electrical contact cleaner.*

**1** Most circuits are protected by fuses of different ratings. On ZX900 and ZX1000 A models all fuses can be found in the junction box, located behind the left-hand sidepanel (see illustration). On ZX1000 B and ZX1100 C/D models all fuses except the main fuse are located in the junction box which is directly under the seat. The main fuse is fitted to the

starter relay which is under the right-hand sidepanel on ZX1000 B models, and under the left-hand sidepanel on ZX1100 C/D models (see illustration). On all models the junction box fuses are labelled for ease of identification.

**2** Blown fuses can be easily recognised by the melted metal strip. Each is clearly marked with its rating and must be replaced only by a fuse of the correct rating. Never put in a fuse of a higher rating or bridge the terminals with any other substitute, however temporary it may be. Serious damage may be done to the circuit, or a fire might start. Always carry a spare supply of spare fuses of each rating (10 and 30 Amps) on the machine.

**3** While an isolated fault may occasionally blow a fuse and never occur again, such cases are rare and generally due to faulty connections, although fuses do sometimes blow due to old age or similar factors. However, if the fuse for any circuit blows repeatedly, a more serious fault is indicated which must be traced and remedied as soon as possible.

## 8 Starter system - checks


**1** In the event of a starter malfunction, always check first that the battery is fully charged. A partially discharged battery may be able to provide enough power for the lighting circuit, but not the heavy current required for starting the engine. Look also for broken, chafed or corroded wiring before proceeding further.

### Starter motor power supply

**2** Disconnect the starter motor lead from its terminal on the motor. Set the test meter to the x 20 volts dc scale and connect its positive probe to the starter lead and its negative probe to earth. Ensure the transmission is in neutral, the side stand is up and the engine kill switch is in the RUN position. Turn the ignition switch on, pull in the clutch lever and operate the starter button. As the button is pressed a reading of approximately 12 volts (battery voltage) should be obtained, if not the fault lies in either the starter relay or the starter switch circuit. If the correct voltage reading is obtained the starter motor itself is at fault, and the unit should be overhauled as described in the following section. Reconnect the machine's battery.

### Starter relay (solenoid)

**3** On ZX1000 B models the starter relay is situated behind the right-hand sidepanel, on ZX1100 D models the relay is mounted just to the left of the battery, under the frame cross-member (see illustration). It can be accessed from above, once the seat has been removed, or from underneath after removing the tail unit. The main fuse is incorporated in the starter relay, and on all other models it is behind the left-hand sidepanel (see illustration). Disconnect the battery terminals prior to this test to prevent the risk of short circuits.



**8.3a Main fuse (A) on starter relay can be accessed from above. Fuel pump relay location (B) - ZX1100 D models**



**8.3b Starter relay location - ZX900 models**



Remove the sidepanel and disconnect the starter motor lead and the positive power supply lead from the starter motor relay. Disconnect the block connector from the relay and remove it from the machine.


4 Set a test meter to the ohms x 1 scale and connect it across the relay terminals. Using a fully charged 12 volt battery and two insulated auxiliary wires, connect the positive terminal of the battery to the yellow/red terminal of the relay, and the negative terminal to the black/yellow terminal of the relay. At this point the relay should click and the multimeter read 0 ohms. If this is the case the relay is serviceable and the fault lies in the starter switch circuit, if not, the relay is faulty and must be renewed.

### Starter switch circuit

5 Disconnect the block connector from the starter relay. Make the test on the wiring harness side of the block connector. Set the test meter to the dc volts x 20 scale and connect its positive probe to the yellow/red terminal of the block connector, and its negative probe to the black/yellow terminal. Ensure that the transmission is in neutral, the side stand is up and the engine kill switch is in the RUN position. Turn the ignition switch on, pull in the clutch lever and operate the starter button. As the button is pressed a reading of approximately 12 volts (battery voltage) should be shown on the multimeter. If not, one or more of the components in the starter circuit are faulty and should be checked as follows.

### Starter switch circuit relay - ZX900 and ZX1000 A models

6 Remove the starter circuit relay (bottom




8.6 Starter switch circuit relay test connections

relay) from the junction box. To test the relay an ohmmeter or multimeter, a 12 volt battery and two insulated auxiliary wires will be needed. Set the meter to the ohms x 1 scale and connect the battery and meter to the relay as shown (see illustration). When the battery is connected to the relay a reading of 0 ohms should be shown on the meter, and when the battery is disconnected there should be an open circuit indicated (infinite resistance). If this is not the case, the relay must be renewed.

### Starter switch circuit relay - ZX1000 B and ZX1100 C/D models


7 Disconnect the junction box from its block connectors and remove it from the machine. To test the relay an ohmmeter or multimeter, a

12 volt battery and two insulated auxiliary wires are needed. Refer to illustration 8.7a or 8.7b to identify the junction box terminals, set the meter to the ohms x 1 scale, and connect its probes first to terminals 11 and 13, and then to terminals 12 and 13. If the relay is functioning correctly, there should be an open circuit (infinite resistance) indicated in each test. Connect a wire from the battery positive terminal to the terminal 11 on the junction box, and another wire from its negative terminal to terminal 12 on the junction box. With the battery connected in this way, connect the test meter across terminals 11 and 13 of the junction box; continuity (low resistance) should be indicated on the meter (see illustrations). If the results are not as shown, the junction box should be renewed.



8.7a Junction box circuit diagram - ZX1000 B, ZX1100 C and ZX1100 D1/D2 models

Hatched lines indicate US fitment only



8.7b Junction box circuit diagram and terminal identification - ZX1100 D3, D4 and D5 models

A Accessory/clock fuse	F Headlamp fuse	J Starter switch circuit relay
B Fan fuse	G Headlamp relay*	K Starter circuit diodes
C Turn signal fuse	H Headlamp relay diodes*	L Tail lamp fuse
D Horn fuse	I Diode	*US fitment only
E Ignition fuse		



### Starter switch circuit diode - ZX900 and ZX1000 A models

8 The diode is situated in the junction box, just to the right of the starter switch circuit relay. Remove the diode from the junction box and using a test meter set to the ohms scale, measure the resistance between its terminals in both directions. A low resistance reading should be obtained in one direction, and a significantly higher reading in the other (approximately ten times higher), if the diode is functioning correctly. If not, the diode should be renewed.

### Starter circuit diodes - ZX1000 B and ZX1100 C/D models

9 The diodes are an integral part of the junction box. Disconnect its wiring block connectors and remove the junction box from the machine for testing. Refer to illustration 8.7a or 8.7b to identify the terminals, and using a test meter set to the resistance range, measure the resistance between terminals 12 and 14, 15 and 14, and 16 and 14. Make these

tests in both directions so that a total of six readings are obtained. In each case there should be low resistance in one direction and high resistance in the other (approximately ten times higher) if the diodes are functioning correctly. If the results are not as shown the junction box must be renewed.

### Starter button

10 Trace the wiring from the right-hand handlebar switch back to its block connectors, disconnect them and make the following test on the switch side of the wiring. Using a multimeter set to the ohms x 1 scale check for continuity between the two black terminals on ZX900 and ZX1000 A models, and the two black/red terminals on ZX1000 B and ZX1100 C/D models. When the button is pressed there should be continuity between the two, and when the button is released there should be an open circuit. If not the starter button is faulty and must either be repaired or the right-hand handlebar switch renewed.

### Ignition and engine kill switches

11 The test procedure for these is described in Section 5 of Chapter 5.


### Neutral switch

12 Pull off the neutral switch lead from the switch itself and connect one probe of the multimeter set to the resistance function to the switch terminal and the other to earth. There should be continuity between the switch and earth when the transmission is in neutral and an open circuit when the transmission is put into gear. If not the neutral switch is defective and must be renewed.

### Clutch lever switch

13 Trace the wiring back from the left-hand handlebar switch and disconnect its block connectors from the wiring harness. Check for continuity between the three terminals on the switch side of the wiring with the clutch lever pulled into the handlebar, and then with the lever released. With the lever pulled in there should be continuity (low resistance) between the black/yellow and yellow/green terminals only. Whereas with the lever released there should be continuity (low resistance) between the yellow/green and light green terminals only. If the results are other than expected the switch should be renewed, although note that nothing is lost by attempting a repair.

## 9 Starter motor - overhaul



9.2 Starter motor - ZX900 models

- |                        |                         |                          |
|------------------------|-------------------------|--------------------------|
| 1 Motor lead           | 7 Bolt - 2 off          | 12 O-ring                |
| 2 Nut                  | 8 Left-hand end cover   | 13 Screw - 2 off         |
| 3 Spring washer        | 9 O-ring - 2 off        | 14 Spring washer - 2 off |
| 4 Positive brush lead  | 10 Motor body/armature  | 15 Washer - 2 off        |
| 5 Brush holder plate   | 11 Right-hand end cover | 16 O-ring - 2 off        |
| 6 Brush spring - 2 off |                         |                          |


1 Remove the starter motor as described in Chapter 2.

2 On ZX900 models, mark the front and rear ends of the motor body and the end covers so that all can be refitted in their original positions. Also tape over the starter pinion teeth to prevent the seal being damaged. Remove the two long retaining screws from the front of the starter motor and carefully lift off the front cover. Withdraw the rear cover, until the brushes slide off the commutator end, and remove the cover and brush holder plate as a single unit. Withdraw the commutator from the starter motor body (see illustration).

3 On ZX1000 and ZX1100 C/D models, tape over the teeth of the starter pinion and remove the two long retaining screws from the rear of the motor. Lift off the front cover and remove all shims from the front end of the commutator. Make a note of how these shims are arranged to use as a reference for reassembly. Remove the rear cover together with any shims fitted to the commutator. Withdraw the commutator from the front end of the motor body (see illustration).

4 On all models, disengage the carbon brushes from the brush holder plate and





### 9.3 Starter motor - ZX1000 and ZX1100 C/D models

- |                           |                             |                         |
|---------------------------|-----------------------------|-------------------------|
| 1 Screw - 2 off           | 7 Brush spring - 4 off      | 13 Shims - as required  |
| 2 Spring washer - 2 off   | 8 Positive brush assembly   | 14 Washer               |
| 3 Bolt - 2 off            | 9 Brush holder              | 15 Motor body/armature  |
| 4 Left-hand end cover     | 10 Motor lead               | 16 Shims - as required  |
| 5 O-ring - 2 off          | 11 Nut - 2 off              | 17 Toothed washer       |
| 6 Negative brush assembly | 12 Terminal washer assembly | 18 Right-hand end cover |
|                           |                             | 19 O-ring               |

measure the length of each brush (see illustration). If any brush has worn to or beyond the service limit given in the

Specifications, renew the brushes as a set. As the brushes are soldered to either the brush holder plate (negative brushes) or the terminal bolt (positive brushes), they cannot be renewed separately; both the brush plate and terminal bolt assemblies will be required.

5 If the brush lengths are within the service limits check the brush wiring as follows. Using an ohmmeter or multimeter set to the ohms x 1 scale, check for continuity between the terminal bolt and positive brush(es). Continuity should be shown; if no continuity (high resistance) is shown, renewal is required. Repeat the test between the brush plate and negative brush tips; renew if no continuity (high resistance) is indicated. Set the meter to the K ohm scale and measure the resistance between the brush plate and brush holder and then between the terminal bolt and brush plate; in each case no continuity

(high resistance) should be shown. If continuity is shown, it is likely that the insulation has broken down at some point. If this is the case, remove the terminal bolt retaining nut, followed by all the washers. Make a careful note of how these washers are arranged as a guide to reassembly. Examine the insulating washers for cracks or other damage and renew if necessary. Note that although they are not listed as being available separately, suitable replacements can be purchased from most automotive suppliers.

6 Examine the brush retaining springs for any signs of damage. Spring tension can only be ascertained by comparison with a new item. Renew the springs if in any doubt about their condition.


7 Clean the commutator segments and grooves with a rag soaked in high flash-point solvent. If necessary, smooth the surface of the commutator with a piece of fine emery cloth. Measure its diameter using a vernier caliper; if worn beyond the service limit the complete starter motor must be renewed because the commutator cannot be purchased separately.

8 On ZX900 and ZX1000 B models, measure the depth of the grooves between the commutator segments. If less than the service limit, the starter motor should be renewed. Alternatively, it may be possible to undercut the grooves using a hacksaw blade of the correct width. Be very careful not to cut into the segment material if this is done, and ensure that the groove is left square-sided. Also do not cut beyond the standard groove depth specification.

9 On all models, check the condition of the commutator windings. Using a multimeter set to the ohms x 1 scale, check the resistance between various pairs of commutator segments. If a high resistance is shown between any two segments, one of the windings is open and the starter motor should be renewed. Set the meter to the K ohms scale and measure the resistance between each commutator segment and the armature core. No continuity (high resistance) should be shown. Continuity will indicate a short between the commutator and shaft and will necessitate starter motor renewal.

10 If oil is found in the starter motor assembly, the seal pressed into the front cover is faulty and must be renewed. However, this seal is not listed as a separate part and is only available as part of the complete starter motor assembly. The same applies to the commutator bearings (where fitted). To avoid unnecessary expense, it is worth contacting an automotive parts supplier, who may be able to supply a suitable substitute. Ensure that all the relevant seal or bearing markings are quoted so that the correct item is selected. If necessary take the complete motor or old components along as a pattern.


11 Hook the brush retaining springs over the end of the holder and refit the brushes in their




9.4 Measure the length of all starter motor brushes

<http://www.bmw-uk.com>







**9.11a** Hook springs over the brush holders to allow commutator to be refitted ...




**9.11b** ... then locate springs in brush grooves - ZX1100 C/D shown



**9.11c** Refit any shims in original positions using notes made on dismantling



**9.11d** Fit a new O-ring ...



**9.11e** ... and install the rear cover ensuring peg in the body locates with the groove in the cover

front of the motor body and carefully refit the front cover to the motor body (see illustration). On ZX900 models, ensure that the projection in the motor body engages with the slot in the front cover and that the marks made prior to dismantling align. On ZX1000 A models, all lines cast on the motor body and end covers should align. On ZX1000 B and ZX1100 C/D models, position the cover by aligning the line cast on its edge with the motor terminal bolt.

**14** Refit the two long retaining screws and tighten them securely. Remove the tape from the teeth of the starter motor pinion and refit the motor as described in Chapter 2.

original positions (see illustration). Insert the commutator into the brush plate and push the brush springs into place, ensuring that the end of each spring is correctly seated in the groove in each brush. Check that the brushes are seated fully against the commutator and are also free to move in their holders (see illustration). On ZX900 models, refit the commutator and brush plate assembly to the rear starter motor cover. On ZX1000 and ZX1100 C/D models refit the shims (where fitted) to the rear of the armature (see illustration). Ensure that the brush plate is correctly located in the rear cover or body (as applicable). Fit a new O-ring to the rear cover and assemble the rear cover and starter motor

body, ensuring that the locating peg on the motor body engages with the groove in the rear cover (see illustrations). Note that on ZX900 models the peg is on the rear cover and the groove is in the body.

**12** On ZX1000 and ZX1100 C/D models, use the notes taken on dismantling to return the shims to their original positions (see illustration). Refit the toothed washer to the front cover so that its teeth locate with the ribs on the cover (see illustration).

**13** Grease the lips of the front cover oil seal and ensure that the teeth of the starter motor pinion are covered with tape to protect the seal on installation. Fit a new O-ring to the


## 10 Oil pressure warning lamp circuit - testing

**1** This circuit consists of a simple pressure switch mounted on the sump, which lights a warning lamp in the instrument panel whenever the ignition is switched on. As soon as the engine is started, and the oil pressure rises above a certain point, the lamp should go out.


**2** If the lamp fails to light, first check the bulb and renew it if blown. If this fails to cure the fault, disconnect the switch lead and earth it briefly on the sump. If the lamp comes on when the lead is earthed, the switch is



**9.12a** On ZX1000 and ZX1100 C/D models refit front commutator shims in their original positions ...



**9.12b** ... and fit toothed washer to the front cover



**9.13** Fit a new O-ring and install front cover as described in text



defective and must be renewed. If the lamp still fails to come on the wiring between the switch and warning lamp is at fault, and this should be checked with a continuity tester as described in Section 2 to trace the wire breakage.

3 If the lamp lights while the engine is running, pull over and stop the engine immediately; serious engine damage is likely if the engine is run with low oil pressure. Check first the level of the engine oil and top up if necessary. If this does not cure the problem check the oil pressure, as described in Chapter 4, at the earliest possible opportunity. If the oil pressure is correct the oil pressure switch is likely to be faulty. The switch can be tested only by the substitution of a new component.

## 11 Switches - general



1 While the switches should give little trouble, they can be tested using a multimeter set to the resistance function or a battery and bulb test circuit. (See Section 2.) Using the information given in the wiring diagrams at the end of this Manual, check that full continuity exists in all switch positions and between the relevant pairs of wires. When checking a particular circuit follow a logical sequence to eliminate the switch concerned.

2 As a simple precaution always disconnect the battery (negative lead first) before removing any of the switches, to prevent the possibility of a short circuit. Most troubles are

caused by dirty contacts, which can be cleaned, but in the event of the breakage of some internal part, it will be necessary to renew the complete switch.


3 If a switch is tested and found to be faulty, there is nothing to be lost by attempting a repair. It may be that worn contacts can be built up with solder, or that a broken wire terminal can be repaired, again using a soldering iron. The handlebar switches may be dismantled to a certain extent. It is however up to the owner to decide if he has the skill to carry out this sort of work.

4 While none of the switches require routine maintenance, some regular attention will prolong their life. The regular and constant application of WD40 or a similar water-dispersant spray not only prevents problems occurring due to water-logged switches and the resulting corrosion, but also makes the switches much easier and more positive to use. Alternatively, the switch may be packed with a silicone based grease to achieve the same result.

## 12 Cooling fan system - testing



1 In the event of a malfunction in the cooling fan system, check first that the fan fuse is intact. Refer to the accompanying circuit diagrams and examine all the relevant wiring and connectors for signs of broken or chafed wires or corroded connections. If the fault cannot be traced to the wiring, test the circuit components as described below.



12.2a Cooling system fan switch relay test connections - ZX900 models

### ZX900 models


2 Disconnect the 6-pin block connector from the fan switch relay situated below the headlamp unit in the upper fairing section. Using an auxiliary wire connect the red/white wire from the wiring side of the connector to earth (see illustrations). If the fan operates, the fault lies in either the fan switch relay or the fan and oil temperature switches. If not, either the fan relay or the cooling fan itself is at fault.

### ZX1000 A models


3 Disconnect the red/white lead from the fan switch on the radiator and ground it to earth (see illustration). If the fan comes on the switch is at fault, and if not either the fan relay or the cooling fan is defective.

### ZX1000 B and ZX1100 C/D models

4 Disconnect the two wires from the fan



12.2b Cooling fan circuit - ZX900 models




12.3 Cooling fan circuit - ZX1000 A models

BK Black BL Blue BR Brown G Green R Red W White Y Yellow

BK Black BL Blue BR Brown G Green R Red W White Y Yellow





12.4 Cooling fan circuit - ZX1000 B and ZX1100 C/D models

- |                 |           |
|-----------------|-----------|
| 1 Junction box  | 7 Battery |
| 2 Fan fuse      | BK Black  |
| 3 Fan           | BL Blue   |
| 4 Fan switch    | W White   |
| 5 Starter relay | Y Yellow  |
| 6 Main fuse     |           |

switch on the radiator and using an auxiliary wire connect them together (see illustration). If when the wires are joined the fan comes on then the fan switch is at fault, if the fan fails to come on the cooling fan is defective.

#### Fan switch relay - ZX900 models only


5 Remove the relay from the machine (see illustration). Connect a 12 volt battery to the terminals of the relay, as shown in the accompanying figure, and check for continuity between the three other terminals using a multimeter set to the ohms x 1 scale. When the battery is connected there should be continuity between terminals 3 and 5 only (red/white and white/green), and when the battery is disconnected there should be continuity between numbers 1 and 3 only (yellow and red/white). If this is not the case the relay is defective and must be renewed.

#### Fan relay - ZX900 and ZX1000 A models only

6 On ZX900 models the fan relay is situated just in front of the junction box (see illustration), and on ZX1000 A models it can be found behind the right-hand sidepanel where it is mounted in front of the rear suspension unit damping adjuster. The fan relay is identical to the starter circuit relay and can be tested as described in paragraph 6 of Section 8 of this Chapter. If faulty, the relay must be renewed.

#### Radiator mounted fan switch - all models

7 Disconnect the wire(s) from the switch and slacken it using a suitable spanner (see illustration). Unscrew the switch as fast as



12.5 Fan switch relay is mounted on the upper fairing bracket - ZX900

possible, withdraw it from the radiator and plug the opening to stop the coolant escaping. To test the switch a heatproof container, a small gas-powered camping stove, a thermometer capable of reading up to 100°C (212°F) and an ohmmeter or multimeter will be required.

8 Fill the container with water and suspend the switch on some wire so that just the sensing portion and the threads are submerged. On ZX900 and ZX1000 A models connect one probe of the meter to the switch terminal and the other to the body of the switch, and on ZX1000 B and ZX1100 C/D models connect the meter probes to both switch terminals. Suspend the thermometer so that its bulb is close to the switch. Note that no component should be allowed to touch the container.

9 Start to heat the water up, stirring it gently, until the water is between 95 - 100°C (203 - 212°F). This must be done very carefully to avoid the risk of personal injury. With the water at this temperature the resistance of the fan switch should be less than 0.5 ohms (switch on). Carry on heating the water until it reaches 100°C (212°F) then turn the stove off. Note the resistance reading of the fan switch as the water temperature falls. As the water temperature falls the resistance of the switch should rise so that by the time the water temperature is down to 91°C (196°F) the resistance of the switch should be greater than 1 M ohm (switch off). If this is not the



12.6 Fan relay is situated beside the junction box - ZX900

case the switch is defective and must be renewed. On refitting, tighten the switch to its specified torque setting and replace any lost coolant.

#### Thermostat housing fan switch and oil temperature switch - ZX900 models only


10 Remove the fuel tank as described in Section 3 of Chapter 4, and disconnect the wire from the thermostat housing fan switch which is situated in the bottom half of the housing (see illustration). Do not confuse this with the temperature sender unit which is in the top half of the thermostat housing. Unscrew the switch as fast as possible, withdraw it from the housing and plug the opening to stop the coolant escaping. The oil temperature switch is removed as described in Section 21 of Chapter 4.

11 Both these switches are tested using the equipment described previously. Set up the equipment as described in paragraph 8 noting the container should be filled with oil instead of water. Great care must be taken to avoid the risk of personal injury.

12 When testing the fan switch, heat the oil up gently until it is between 107 - 113°C (225 - 235°F). With the oil at this temperature the switch should have a resistance of less than 0.5 ohms (switch on). Carry on heating the oil until it reaches 115°C (239°F), then switch off the stove and allow the oil to cool. As the oil cools, the resistance of the fan switch should



12.7 Fan switch is situated on the left-hand side of the radiator



12.10 On ZX900 models do not confuse the thermostat fan switch (arrowed) with the temperature sender unit



increase so that by the time the oil temperature falls to 104°C (219°F) the resistance of the switch should be greater than 1 M ohm. If not, the switch is faulty and must be renewed. Allow the oil to cool sufficiently then test the oil temperature switch as follows.

**13** Gently heat the oil until it is between 117 - 123°C (243 - 253°F), with the oil at this temperature the switch should have a resistance reading greater than 1 M ohm (switch off). Carry on heating the oil until it reaches 125°C (257°F), then turn off the stove and allow the oil to cool. As the oil cools, the resistance of the oil temperature switch should decrease so that by the time the oil has cooled to 113°C (235°F) the switch should have a reading of less than 0.5 ohms. If this is not the case, the oil temperature switch is faulty and must be renewed.

**14** On refitting, apply a silicone sealant to the threads of the thermostat fan switch, and thread-locking compound to the threads of the oil temperature switch. Tighten both to their specified torque settings.

### Cooling fan - all models

**15** Remove the fuel tank as described in Section 3 of Chapter 4, and disconnect the 2-pin block connector from the cooling fan, which is mounted on the back of the radiator. Using a 12 volt battery and two insulated

auxiliary wires, connect the battery across the two terminals on the fan side of the connector. Once connected the fan should operate. If not, the fan motor is defective and must be renewed. The radiator and cooling fan assembly can be removed and refitted as described in Chapter 3.

### 13 Coolant temperature gauge circuit - testing

**1** The circuit consists of the sender unit mounted in the thermostat housing and the gauge assembly mounted in the instrument panel. If the system malfunctions check first that the battery is fully charged and that the horn and main fuses (ZX900 and ZX1000 A) or main fuse (ZX1000 B and ZX1100 C/D) are intact. Then, referring to illustration 13.1b or 13.1c, as applicable, examine the wiring for broken or chafed wires or corroded connections (see illustrations).

**2** To test the circuit, turn the ignition switch ON and disconnect the wire from the temperature sender unit. The temperature needle should point to C on the temperature gauge. Ground the sender unit wire to earth. When the wire is earthed the needle should swing immediately over to H on the gauge. Do not earth the lead any longer than is necessary to take the reading, or the gauge may be damaged. If the needle moves as described above, the sender unit is defective and must be renewed, although a more comprehensive test is described in paragraph 3 below. If the needle's movement is still faulty, or if it does not move at all, the fault lies in the main relay (ZX900 and ZX1000 A models only), ignition switch or the gauge itself which should be tested as described in paragraph 4 onwards.

**3** Unscrew the temperature sender unit as quickly as possible, remove it from the thermostat housing and plug the opening to prevent the coolant escaping. The sender unit is tested in the same way as the fan switch, referring to paragraph 8 of Section 12. Heat

the water gently, stirring it slowly to keep a uniform temperature throughout, and note the resistance readings obtained. A serviceable sender should have a resistance of about 52 ohms at 80°C (176°F), and about 27 ohms at 100°C (212°F). If not, the sender must be renewed. On refitting apply a silicone sealant to the threads of the sender unit and tighten it to its specified torque setting.

**4** Disconnect the ignition switch from the main wiring loom and check for continuity between the brown and white terminals on the switch side of the wiring. When the switch is in the ON position there should be continuity between the two, and when the switch is in the OFF position there should be an open circuit. If this is not the case, the switch is faulty and must be either repaired or renewed.


**5** On ZX900 and ZX1000 A models the main relay is also in the temperature gauge circuit. On US models the main relay is the top right-hand of the three circular relays situated in the centre of the junction box, and on UK models it is the uppermost of the two (the headlamp relay not being fitted). The relay is identical to the starter relay and can be tested as described in paragraph 6 of Section 8. If faulty, the relay must be renewed.

**6** If the switch and main relay (as applicable) are satisfactory and the wiring is known to be good, the gauge itself is at fault and it must be renewed. Refer to Section 20 of Chapter 6 for information on dismantling and reassembling the instrument panel.


### 14 Tachometer - testing

**1** All models use an electronic tachometer which is operated by the ignition system. On ZX900 and ZX1000 A models the tachometer also doubles as a voltmeter which can be used to measure the battery and charging voltage. This is controlled by a button on the instrument panel.

**2** If the tachometer malfunctions, yet the ignition system is still operating correctly, first



**13.1a** Temperature sender unit (arrowed) is situated in thermostat housing - ZX900 shown




**13.1b** Temperature and fuel gauge circuits - ZX900 and ZX1000 A models

BK Black  
BL Blue

BR Brown  
R Red

W White  
Y Yellow



**13.1c** Temperature and fuel gauge circuits - ZX1000 B and ZX1100 C/D models

BK Black  
BR Brown  
W White  
Y Yellow


<http://www.auals.magnamaniac.com>

Fuel gauge circuit applies to ZX1000 B only









**16.4 Location of fuel level warning lamp relay (A) and sensor relay (B)**

3 Referring to the accompanying circuit diagram (see illustration), examine all the wiring for signs of broken or chafed wires and corroded connections. If no fault can be found in the wiring, it will be necessary to test the fuel level warning lamp and sensor relays.


4 Both the fuel level warning lamp relay and the sensor relays are situated behind the left-hand sidepanel where they are mounted onto the rear of the frame (see illustration). The fuel level warning lamp relay is the front one of the two relays and is easily identified by its 3-pin block connector.

5 To test the fuel level warning lamp relay a fully charged 12 volt battery, two 12 volt 3 watt bulbs and some insulated auxiliary wires will be needed. Connect the battery and two bulbs to the relay as shown (see illustration), and then count how many times the bulbs flash in one minute. Then disconnect one of the bulbs and again count the number of times the single bulb flashes in one minute. With the two bulbs connected to the relay the bulbs should flash between 70 and 100 times in a minute, and when only the single bulb is connected between 140 and 200 times. If this is not the case, the relay is faulty and must be renewed.


6 To test the fuel level sensor relay a multimeter, a fully charged 12 volt battery and two insulated auxiliary wires will be needed. Remove the relay from the machine, set the meter to the ohms x 1 scale and connect the battery and meter to the relay as shown (see illustration). When the battery is connected to the relay a reading of 0 ohms should be shown on the meter, yet when the battery is disconnected there should be an open circuit. If this is not the case, the relay is defective and must be renewed.

7 Remove the fuel level circuit diode which is located just to the rear of the junction box. Note that on US models there are two diodes, the fuel level circuit diode being connected to the blue/red and white/yellow wires. Using a multimeter set to the appropriate ohms scale, measure the resistance between its terminals in both directions. If the relay is serviceable, one of the resistance readings will be low and the other at least ten times higher. If this is not the case, renew the diode.

8 If the relays and diode are serviceable



**16.5 Fuel level sensor unit relay test - ZX1100 C models**



**16.6 Fuel level warning lamp relay test - ZX1100 C models**

remove the fuel tank as described in Section 3 of Chapter 4 and drain its contents into a clean metal container. Place the tank on some soft cloth, release the two screws which secure the fuel sensor and remove it from the tank (see illustration). Reconnect the sensor block connector to the main wiring loom.

9 Turn the ignition switch to the ON position. With the switch on and the sensor unit held in the open air both fuel lamps should be flashing. Then taking great care to avoid the risk of fire, submerge the cylindrical thermistor at the top end of the sensor in the fuel which has been drained from the tank. As soon as the thermistor is submerged in the fuel both

the fuel lamps should extinguish. Remove the sensor from the fuel and leave it in the open air. After the sensor has been left in the air for some time both warning lamps should again begin to flash, noting that it could take up to three minutes for the sensor to warm up. If the fuel warning lamps do not perform as expected the sensor unit is defective and must be renewed.

## 17 Fuel pump circuit (ZX1000 B and ZX1100 C/D models) - testing




**Warning: Petrol (gasoline) is extremely flammable, especially when in the form of vapour. Take all precautions to prevent the risk of fire and read the Safety first! section of this manual before starting work.**

1 The fuel pump should operate whenever the starter button is pressed or the engine is running, providing the fuel level in the carburetors is low. When the fuel level in the carburetors is correct the pressure in the fuel line rises and the pump will automatically shut off. If the fuel pump fails to operate correctly first refer to the accompanying circuit diagram checking all the wiring and connections before proceeding further.



**16.8 Fuel level sensor unit is retained by two screws**





Tester (-) Lead Connection	Tester (+) Lead Connection			
	1	2	3	4
1	-	∞	∞	∞
2	∞	-	∞	∞
3	∞	10~100	-	∞
4	∞	20~200	1~5	-

### 17.2 Fuel pump relay test - ZX1100 C/D models

#### Fuel pump relay - ZX1100 C/D models only

2 On ZX1100 C models the fuel pump relay is situated inside the tail section where it is mounted to the rear mudguard just in front of the rear lamp assembly. Remove the left-hand sidepanel, disconnect the relay block connector and remove it from the machine. On ZX1100 D models the relay is positioned to the left of the battery and forward of the starter relay; remove the seat for access. Check the resistances between the various relay terminals (see illustration). Never use a meter with a large capacity battery to test the fuel pump relay as this will almost certainly

damage it. Kawasaki also state that only their own meter, Part Number 57001-983, should be used to test the relay as another meter could produce different values. If the readings obtained differ greatly from those given in the table, the relay is faulty and must be renewed.

#### Fuel pump

3 Remove the fuel pump and filter assembly from the machine as described in Chapter 4. The fuel pump can then be tested using a 12 volt battery, some insulated auxiliary wires and a container of paraffin (kerosene). Submerge the filter inlet hose into the paraffin (kerosene) and hold the pump outlet hose above the surface of the liquid. On ZX1000 B models use the auxiliary wires to connect the positive terminal of the battery to both the red and yellow wires, and the negative terminal to the black/yellow wire. On ZX1100 C/D models connect the positive terminal to the red wire, and the negative terminal to the black wire. With the pump connected thus, it should function and paraffin should be pumped out of the outlet hose. If not, the pump is faulty and must be renewed. With the pump functioning, block the end of the outlet hose to stop the flow of liquid. The pump should cut out as soon as the hose is blocked, if not the pump is defective and must be renewed.

4 If a pressure gauge capable of reading approximately 0 - 5 psi is available, the pump operating pressure can be checked as follows. Fit the pressure gauge to the outlet hose of the pump and set up the circuit described above. With the pump functioning,

block the end of the outlet pipe to stop the flow of the paraffin (kerosene) and note the pressure reading obtained on the gauge. If the pump is serviceable this reading should be between 1.6 - 2.3 psi. If any of the above tests show the pump to be faulty, it must be renewed.


### 18 Headlamp relay and reserve lighting system - testing US models only

1 The US models are fitted with a headlamp relay. The headlamp remains off when the ignition switch is first switched on, and does not light until the starter button is pressed. The headlamp then stays on until the ignition switch is turned off. Note that the headlamp will go out temporarily if the starter button is pressed to restart the engine after it has stalled.

2 US ZX900 and ZX1000 A models are also fitted with a reserve lighting system and headlamp bulb failure warning lamp (see illustration 18.3a).

3 If on any model the lighting system malfunctions, first check the bulbs are intact and of the correct wattage, and that all the fuses are intact. Examine the wiring for broken or chafed wires and corroded connections (see illustrations), and check the switches as described in Section 11. If no fault can be traced, test the headlamp relay and diodes as follows.


- 1 Ignition HT coils
  - 2 Fuel pump relay
  - 3 Fuel pump
  - 4 Starter circuit connections
  - 5 Starter button
  - 6 Engine kill switch
  - 7 Ignition switch
  - 8 Main fuse
  - 9 Starter relay
  - 10 Battery
  - 11 Applies to US only
  - 12 Except US
- BK Black  
BL Blue  
R Red  
W White  
Y Yellow





BK Black  
BL Blue  
BR Brown  
G Green  
LG Light green  
O Orange  
P Pink  
R Red  
W White  
Y Yellow


- (A) MAIN RELAY  
(B) STARTER RELAY  
(C) HEADLAMP RELAY  
(D) LIGHTING FUSE  
(E) DIODES  
(F) MAIN FUSE



18.3A Headlamp circuit - ZX900 and ZX1000 A US models

BK Black  
BL Blue  
BR Brown  
R Red  
W White  
Y Yellow

- (A) STARTER CIRCUIT RELAY  
(B) HEADLAMP RELAY  
(C) DIODES  
(D) HEADLAMP FUSE



18.3b Headlamp circuit - ZX1000 B and ZX1100 C/D US models



**ZX900 and ZX1000 A models**

4 The headlamp relay is the top left-hand of the three circular relays in the centre of the junction box, and the diode is located directly below it. Both the headlamp relay and diode are identical to those in the starter switch circuit and can be tested as described in paragraphs 6 and 8 of Section 8. If either the relay or diode are faulty, they must be renewed. However, if both are found to be serviceable, the reserve lighting unit must be defective. The only means of testing the reserve lighting unit, which is situated in the upper fairing section, is to substitute it with a new item.

**ZX1000 B and ZX1100 C/D models**

5 The headlamp relay and all but one of the diodes are an internal part of the junction box. Disconnect the junction box from its block connectors and remove it from the machine. To test the relay a multimeter, a 12 volt battery and two insulated auxiliary wires will be needed. Refer to illustration 8.7a or 8.7b to identify the junction box terminals, set the meter to the ohms x 1 scale, and then connect the meter probes first to terminals 7 and 8, and then to terminals 7 and 13. If the relay is serviceable there should be an open circuit (very high resistance) between both pairs of terminals. Then connect the positive terminal of the battery to terminal 9 of the junction box, and the negative terminal to terminal 13. With the battery connected check for continuity between terminals 7 and 8. If the relay is serviceable a reading of 0 ohms will be obtained. If either test fails to produce the above results the relay is faulty.

6 To test the junction box diodes use a multimeter, set to the resistance range, to measure the resistance in both directions between terminals 8 and 13, and 9 and 13, so that two readings are obtained for each pair. Of the two readings obtained, one should be a low reading and the other should be at least ten times larger. If this is not the case for either pair of terminals, the diode assembly is faulty. If either the relay or diodes are found to be defective, the junction box assembly must be renewed.

7 An additional diode is incorporated in the headlamp circuit. On ZX1000 B models it is situated between the battery and junction box, and on ZX1100 C/D models it is situated beneath the seat, just to the rear of the junction box. Note on ZX1100 C/D models there are two diodes, the headlamp circuit diode being connected to the black and black/red wires. Remove the diode from the machine and measure the resistance between its terminals in both directions. If the relay is serviceable, one of the resistance readings should be low and the other at least ten times higher. If this is not the case, renew the diode.

**19 Turn signal relay - location and testing**

1 On ZX900 and ZX1000 A models the turn signal relay is the large square relay situated in the junction box (see illustration), on ZX1000 B models it is situated on the inside of the upper fairing section where it is mounted just to the left of the headlamp, and on ZX1100 C models it is behind the left-hand sidepanel where it is mounted just to the rear of the starter relay. On ZX1100 D models the relay is mounted on the left-hand rear frame rails (see illustration). Remove the seat and tail unit as described in Section 7 of this Chapter for access. Unplug its wiring connector and pull the relay out of its mounting.

2 If the turn signal lamps cease to function correctly, there may be several possible causes before the relay is suspected. First check that the fuses are intact and that the battery is fully charged. Check that the turn signal lamps are securely mounted and that all the earth connections are clean and tight. Check that the bulbs are all of the correct wattage and that corrosion has not developed on the bulbs or in their holders. Any such corrosion must be thoroughly cleaned off to ensure proper bulb contact. Also check that the turn signal switch is functioning correctly and that the wiring is in good order.

3 Faults in any one of the above items will produce symptoms for which the turn signal relay may be unfairly blamed. If the fault persists even after the preliminary checks have been made the relay is at fault and must be renewed, no further test details are available.

4 All US models are fitted with hazard warning lights, operated from a switch on the left-hand handlebar cluster. With the hazard switch in the ON position and the ignition switch in the ON or PARK positions, all four turn signal lamps, plus the warning lamps, should flash. If a fault develops check the turn signal circuit and relay as described above. If this fails to cure the problem, the hazard switch itself must be at fault. Identify the switch wires using the appropriate wiring diagram at the end of this chapter, disconnect the handlebar switch block connector and check for continuity across the pairs of switch terminals as shown in the switch boxes at the base of the diagram.

**20 Horns - location and testing**


1 The horns are mounted inside the fairing on each side of the radiator (see illustration). To gain access to the horns it will be necessary to remove the lower and side fairing sections as described in Chapter 6.

2 If the horns fail to work, first check that the fuses are intact. Check that power is reaching the horns by disconnecting their wires and connecting them to two 12 volt bulbs. Switch on the ignition and press the horn button. If the bulbs light, the horn circuit is proved good and the horn is at fault. If not, there is a fault in either the wiring or horn button which must be found and rectified.


3 To test a horn, connect a fully charged 12 volt battery directly to the horn itself. If it does not sound, a gentle tap on the outside of the horn may free the internal contacts. If this fails the horn must be renewed; repairs are not possible.



19.1a On ZX1100 C models turn signal relay is situated next to starter relay



19.1b Turn signal relay location on rear frame rails - ZX1100 D models



20.1 Horns are mounted on each side of the radiator






21.3a Fit the bulb to the headlamp unit . . .



21.3b . . . and secure it with the retaining clip (or holder)



21.3c Ensure rubber bulb cover is correctly installed and refit the headlamp connector

## 21 Bulbs - renewal



### Headlamp and parking lamp

1 The headlamp bulb is of the quartz-halogen type with a conventional H4 fitting. Do not touch the bulb's glass envelope as skin acids will shorten the bulb's service life.



**If a QH bulb is accidentally touched, it should be wiped carefully when cold with a rag soaked in methylated spirits (stoddard solvent) and dried before being refitted.**

2 To renew the headlamp bulb it will probably be necessary to remove the fairing, however, some owners might find it possible to renew the bulb with the fairing still fitted to the machine. Due to the amount of work necessary to remove the fairing it is therefore recommended that an attempt be made to carry out the operation with the fairing on the machine. If this proves unsuccessful, the fairing should be removed as described in Chapter 6. The same applies to the parking/pilot lamp bulb although this will be considerably easier to renew. On ZX900 and ZX1000 A models both operations can be made easier by removing the small cover situated below the headlamp on the underside of the upper fairing section.


3 Unplug the headlamp bulb connector and remove the rubber bulb cover from the back of the headlamp unit noting its correct position. On ZX900 models remove the bulb holder by pushing it in towards the headlamp unit and turning it anti-clockwise, and on ZX1000 and ZX1100 C/D models disengage the bulb retaining spring clip from the headlamp unit. On all models withdraw the headlamp bulb. On refitting, note that the locating tangs on the metal bulb collar are offset so that the bulb can only be fitted one way. Secure the bulb with its holder or clip (as applicable) and fit the rubber bulb cover ensuring that it is fitted in its original position and is correctly seated (**see illustrations**). Refit the headlamp connector (**see**

**illustration**). Check the headlamp beam setting as described in Chapter 1.

4 The parking/pilot lamp bulb holder is a push fit in the headlamp assembly (**see illustration**). The bulb is a bayonet fit into the holder and can be removed by pressing it in and turning it anti-clockwise (**see illustration**).

### Stop and tail lamp

5 Most models are fitted with twin stop/tail lamp bulbs which can be accessed from inside the tail section once the seat has been removed (**see illustration**). Remove the bulb holders from the back of the tail lamp assembly by turning them anti-clockwise. The bulbs are a bayonet fit and can be removed from their holders by pressing them in and turning them anti-clockwise. The bulbs are refitted by a reversal of the removal procedure noting that the pins on each bulb are offset to prevent it from being incorrectly fitted (**see illustration**). On ZX1100 D models access is limited to the two lens retaining screws with the tail unit in place, necessitating either removal of the tail unit or removal of the lamp mounting bolts so that the lamp can be angled down to provide access. Remove the two screws and carefully separate the lens from the reflector, taking care not to tear the seal. To remove the bulb push it in and twist it anti-clockwise. To install a new bulb, push it in and turn clockwise. Refit the seal and lens, taking care not to overtighten its screws.



21.4a Parking lamp bulbholder is a push fit in the headlamp unit . . .



21.4b . . . bulb is a bayonet fit in its holder



21.5a Stop/tail lamp bulbholders are removed from inside the tail section



21.5b Note offset pins on bulb to prevent incorrect installation






21.6a On ZX900 models release screw from the back of the lamp . . .



21.6b . . . remove lens assembly and slacken two screws which secure lens to the bulbholder



21.9a On ZX1100 C/D models remove the retaining screw and pull the lamp out of position

### Turn signal lamps

6 To renew the turn signal bulbs on ZX900 models remove the screw from the back of the lamp and remove the lens and bulbholder assembly (see illustrations). Release the two small screws which secure the bulbholder to the lens and remove the lens. The bulb can then be removed by pressing it in and turning it anti-clockwise. On refitting ensure the rubber lens gasket is correctly positioned and take care not to overtighten the lens retaining screws.

7 On ZX1000 A models to renew the front bulbs, lever out the two plugs from the turn signal assembly and remove the two screws which secure each unit to the fairing. Partially withdraw the turn signal, remove the bulb holder by turning it anti-clockwise, and lower the assembly away from the machine. The bulb can then be removed from its holder by pressing it in and turning it anti-clockwise. The bulb is refitted by a reversal of the removal procedure ensuring that the rubber damper is correctly positioned between the turn signal and the fairing.

8 To gain access to the front bulbs on ZX1000 B models it will first be necessary to remove the inner fairing sections as described in Chapter 6. The bulb holder can then be reached from inside the fairing and removed from the back of the turn signal lamp by turning it anti-clockwise. The bulb can then be removed by pressing it in and turning it anti-clockwise, and is refitted by reversing the removal sequence.

9 Both front and rear turn signal bulbs on

ZX1100 C/D models, and the rear bulbs on ZX1000 models are renewed by removing the screw(s) which secure the lamp, and withdrawing the lamp from the bodywork (see illustration). Remove the bulb holder and bulb as described above (see illustration). On refitting do not overtighten the lamp retaining screw(s).


### Instrument panel bulbs

10 Remove the instrument panel from the machine as described in Section 20 of Chapter 6. All instrument panel bulbs are of the capless type being pressed into their holders, which are also a push fit into the underside of the instrument panel (see illustration). Be careful not to damage the delicate wire terminals of the bulbs when removing or refitting them.

### 22 Fuel level sender unit (ZX1100 D models) - removal and refitting

1 Remove and drain the fuel tank. Displace the cap from the base of the sender unit and remove the six screws to release the sender unit from the tank (see illustration). Be very careful not to bend the float arm as the sender unit is manoeuvred out of the tank.

2 Refit in the reverse of the removal procedure, noting that a new seal should be installed between the tank and sender unit. Note that while the tank is drained of fuel it is a good opportunity to clean its internal filters.



21.9b Bulbholder is a screw fit into the lamp

### 23 Fuel gauge (ZX1100 D models) - removal and refitting

1 Remove the main fairing. Disconnect both wiring block connectors to the instruments and unscrew the speedometer drive cable, then remove the three nuts and two bolts to free the instrument panel from the fairing mounting bracket. **Note:** Always keep the instruments facing the correct way up otherwise damage to their movement will occur.

2 Identify the three wiring connections to the rear of the fuel gauge and unscrew them (see illustration). Remove all screws retaining the instrument top and bottom halves and separate them to gain access to the fuel gauge.

3 Refit in a reverse of the removal procedure, making sure that the wiring connections are made correctly.



21.10 Instrument panel bulbs are of the capless type




22.1 Fuel level sender unit is retained by six screws



23.2 Make note of wire connections to fuel gauge before disconnection






ZX900 A UK models


\* Note:  
Sidestand w/L  
not fitted to  
ZX900 A7-on






ZX900 A US models






## ZX1000 A UK models















ZX1000 B US models

C.J. Turk  
H29822






ZX100 C UK models











ZX1100 D1 and D2 UK models






ZX1100 D1 and D2 US models





ZX1100 D3, D4 and D5 UK models






C.J. York  
H29228


ZX1100 D3, D4 and D5 US models






ZX900 A UK models






ZX900 A US models











## ZX1000 A US models






<http://www.motocycleparts.com>











ZX100 C UK models











ZX1100 D1 and D2 UK models










### ZX1100 D3, D4 and D5 UK models






ZX1100 D3, D4 and D5 US models



## Buying tools

A toolkit is a fundamental requirement for servicing and repairing a motorcycle. Although there will be an initial expense in building up enough tools for servicing, this will soon be offset by the savings made by doing the job yourself. As experience and confidence grow, additional tools can be added to enable the repair and overhaul of the motorcycle. Many of the specialist tools are expensive and not often used so it may be preferable to hire them, or for a group of friends or motorcycle club to join in the purchase.

As a rule, it is better to buy more expensive, good quality tools. Cheaper tools are likely to wear out faster and need to be renewed more often, nullifying the original saving.



**Warning:** To avoid the risk of a poor quality tool breaking in use, causing injury or damage to the component being worked on, always aim to purchase tools which meet the relevant national safety standards.

The following lists of tools do not represent the manufacturer's service tools, but serve as a guide to help the owner decide which tools are needed for this level of work. In addition, items such as an electric drill, hacksaw, files, soldering iron and a workbench equipped with a vice, may be needed. Although not classed as tools, a selection of bolts, screws, nuts, washers and pieces of tubing always come in useful.


For more information about tools, refer to the Haynes Motorcycle Workshop Practice TechBook (Bk. No. 3470).

## Manufacturer's service tools

Inevitably certain tasks require the use of a service tool. Where possible an alternative tool or method of approach is recommended, but sometimes there is no option if personal injury or damage to the component is to be avoided. Where required, service tools are referred to in the relevant procedure.

Service tools can usually only be purchased from a motorcycle dealer and are identified by a part number. Some of the commonly-used tools, such as rotor pullers, are available in aftermarket form from mail-order motorcycle tool and accessory suppliers.


## Maintenance and minor repair tools



- |   |   |  |  |  |
|---|---|--|--|--|
| 1 Set of flat-bladed screwdrivers         | 6 Set of Torx keys or bits                            | 11 Cable oiler clamp                       | 16 Calibrated syringe, measuring vessel and funnel | 21 Straight-edge and steel rule                    |
| 2 Set of Phillips head screwdrivers       | 7 Pliers, cutters and self-locking grips (Mole grips) | 12 Feeler gauges                           | 17 Oil filter adapters                             | 22 Continuity tester                               |
| 3 Combination open-end and ring spanners  | 8 Adjustable spanners                                 | 13 Spark plug gap measuring tool           | 18 Oil drainer can or tray                         | 23 Battery charger                                 |
| 4 Socket set (3/8 inch or 1/2 inch drive) | 9 C-spanners  | 14 Spark plug spanner or deep plug sockets | 19 Pump type oil can                               | 24 Hydrometer (for battery specific gravity check) |
| 5 Set of Allen keys or bits               | 10 Tread depth gauge and tyre pressure gauge          | 15 Wire brush and emery paper              | 20 Grease gun                                      | 25 Anti-freeze tester (for liquid-cooled engines)  |




## Repair and overhaul tools



- 1 Torque wrench (small and mid-ranges)
- 2 Conventional, plastic or soft-faced hammers
- 3 Impact driver set
- 4 Vernier gauge
- 5 Circlip pliers (internal and external, or combination)
- 6 Set of cold chisels and punches
- 7 Selection of pullers
- 8 Breaker bars
- 9 Chain breaking/ripping tool set
- 10 Wire stripper and crimper tool
- 11 Multimeter (measures amps, volts and ohms)
- 12 Stroboscope (for dynamic timing checks)
- 13 Hose clamp (wingnut type shown)
- 14 Clutch holding tool
- 15 One-man brake/clutch bleeder kit

## Specialist tools



- 1 Micrometers (external type)
- 2 Telescoping gauges
- 3 Dial gauge
- 4 Cylinder compression gauge
- 5 Vacuum gauges (left) or manometer (right)
- 6 Oil pressure gauge
- 7 Plastigauge kit
- 8 Valve spring compressor (4-stroke engines)
- 9 Piston pin draw bolt tool
- 10 Piston ring removal and installation tool
- 11 Piston ring clamp
- 12 Cylinder bore hone (stone type shown)
- 13 Stud extractor
- 14 Screw extractor set
- 15 Bearing driver set



## 1 Workshop equipment and facilities

### The workbench

● Work is made much easier by raising the bike up on a ramp - components are much more accessible if raised to waist level. The hydraulic or pneumatic types seen in the dealer's workshop are a sound investment if you undertake a lot of repairs or overhauls (see illustration 1.1).



1.1 Hydraulic motorcycle ramp


● If raised off ground level, the bike must be supported on the ramp to avoid it falling. Most ramps incorporate a front wheel locating clamp which can be adjusted to suit different diameter wheels. When tightening the clamp, take care not to mark the wheel rim or damage the tyre - use wood blocks on each side to prevent this.

● Secure the bike to the ramp using tie-downs (see illustration 1.2). If the bike has only a sidestand, and hence leans at a dangerous angle when raised, support the bike on an auxiliary stand.



1.2 Tie-downs are used around the passenger footrests to secure the bike

● Auxiliary (paddock) stands are widely available from mail order companies or motorcycle dealers and attach either to the wheel axle or swingarm pivot (see illustration 1.3). If the motorcycle has a centrestand, you can support it under the crankcase to prevent it toppling whilst either wheel is removed (see illustration 1.4).



1.3 This auxiliary stand attaches to the swingarm pivot



1.4 Always use a block of wood between the engine and jack head when supporting the engine in this way

### Fumes and fire

● Refer to the Safety first! page at the beginning of the manual for full details. Make sure your workshop is equipped with a fire extinguisher suitable for fuel-related fires (Class B fire - flammable liquids) - it is not sufficient to have a water-filled extinguisher.

● Always ensure adequate ventilation is available. Unless an exhaust gas extraction system is available for use, ensure that the engine is run outside of the workshop.

● If working on the fuel system, make sure the workshop is ventilated to avoid a build-up of fumes. This applies equally to fume build-up when charging a battery. Do not smoke or allow anyone else to smoke in the workshop.

### Fluids

● If you need to drain fuel from the tank, store it in an approved container marked as suitable for the storage of petrol (gasoline) (see illustration 1.5). Do not store fuel in glass jars or bottles.



1.5 Use an approved can only for storing petrol (gasoline)

● Use proprietary engine degreasers or solvents which have a high flash-point, such as paraffin (kerosene), for cleaning off oil, grease and dirt - never use petrol (gasoline) for cleaning. Wear rubber gloves when handling solvent and engine degreaser. The fumes from certain solvents can be dangerous - always work in a well-ventilated area.

### Dust, eye and hand protection

● Protect your lungs from inhalation of dust particles by wearing a filtering mask over the nose and mouth. Many frictional materials still contain asbestos which is dangerous to your health. Protect your eyes from spouts of liquid and sprung components by wearing a pair of protective goggles (see illustration 1.6).



1.6 A fire extinguisher, goggles, mask and protective gloves should be at hand in the workshop

● Protect your hands from contact with solvents, fuel and oils by wearing rubber gloves. Alternatively apply a barrier cream to your hands before starting work. If handling hot components or fluids, wear suitable gloves to protect your hands from scalding and burns.

### What to do with old fluids

● Old cleaning solvent, fuel, coolant and oils should not be poured down domestic drains or onto the ground. Package the fluid up in old oil containers, label it accordingly, and take it to a garage or disposal facility. Contact your local authority for location of such sites or ring the oil care hotline.



**Note: It is antisocial and illegal to dump oil down the drain. To find the location of your local oil recycling bank, call this number free.**

**In the USA, note that any oil supplier must accept used oil for recycling.**




## 2 Fasteners - screws, bolts and nuts


### Fastener types and applications

#### Bolts and screws

● Fastener head types are either of hexagonal, Torx or splined design, with internal and external versions of each type (see illustrations 2.1 and 2.2); splined head fasteners are not in common use on motorcycles. The conventional slotted or Phillips head design is used for certain screws. Bolt or screw length is always measured from the underside of the head to the end of the item (see illustration 2.11).



2.1 Internal hexagon/Allen (A), Torx (B) and splined (C) fasteners, with corresponding bits




2.2 External Torx (A), splined (B) and hexagon (C) fasteners, with corresponding sockets

● Certain fasteners on the motorcycle have a tensile marking on their heads, the higher the marking the stronger the fastener. High tensile fasteners generally carry a 10 or higher marking. Never replace a high tensile fastener with one of a lower tensile strength.

#### Washers (see illustration 2.3)

● Plain washers are used between a fastener head and a component to prevent damage to the component or to spread the load when torque is applied. Plain washers can also be used as spacers or shims in certain assemblies. Copper or aluminium plain washers are often used as sealing washers on drain plugs.



2.3 Plain washer (A), penny washer (B), spring washer (C) and serrated washer (D)

● The split-ring spring washer works by applying axial tension between the fastener head and component. If flattened, it is fatigued and must be renewed. If a plain (flat) washer is used on the fastener, position the spring washer between the fastener and the plain washer.

● Serrated star type washers dig into the fastener and component faces, preventing loosening. They are often used on electrical earth (ground) connections to the frame.


● Cone type washers (sometimes called Belleville) are conical and when tightened apply axial tension between the fastener head and component. They must be installed with the dished side against the component and often carry an OUTSIDE marking on their outer face. If flattened, they are fatigued and must be renewed.

● Tab washers are used to lock plain nuts or bolts on a shaft. A portion of the tab washer is bent up hard against one flat of the nut or bolt to prevent it loosening. Due to the tab washer being deformed in use, a new tab washer should be used every time it is disturbed.

● Wave washers are used to take up endfloat on a shaft. They provide light springing and prevent excessive side-to-side play of a component. Can be found on rocker arm shafts.

#### Nuts and split pins


● Conventional plain nuts are usually six-sided (see illustration 2.4). They are sized by thread diameter and pitch. High tensile nuts carry a number on one end to denote their tensile strength.




2.4 Plain nut (A), shouldered locknut (B), nylon insert nut (C) and castellated nut (D)

● Self-locking nuts either have a nylon insert, or two spring metal tabs, or a shoulder which is staked into a groove in the shaft - their advantage over conventional plain nuts is a resistance to loosening due to vibration. The nylon insert type can be used a number of times, but must be renewed when the friction of the nylon insert is reduced, ie when the nut spins freely on the shaft. The spring tab type can be reused unless the tabs are damaged. The shouldered type must be renewed every time it is disturbed.

● Split pins (cotter pins) are used to lock a castellated nut to a shaft or to prevent slackening of a plain nut. Common applications are wheel axles and brake torque arms. Because the split pin arms are deformed to lock around the nut a new split pin must always be used on installation - always fit the correct size split pin which will fit snugly in the shaft hole. Make sure the split pin arms are correctly located around the nut (see illustrations 2.5 and 2.6).



2.5 Bend split pin (cotter pin) arms as shown (arrows) to secure a castellated nut




2.6 Bend split pin (cotter pin) arms as shown to secure a plain nut

**Caution:** If the castellated nut slots do not align with the shaft hole after tightening to the torque setting, tighten the nut until the next slot aligns with the hole - never slacken the nut to align its slot.

● R-pins (shaped like the letter R), or slip pins as they are sometimes called, are sprung and can be reused if they are otherwise in good condition. Always install R-pins with their closed end facing forwards (see illustration 2.7).






2.7 Correct fitting of R-pin.  
Arrow indicates forward direction


**Circlips** (see illustration 2.8)

● Circlips (sometimes called snap-rings) are used to retain components on a shaft or in a housing and have corresponding external or internal ears to permit removal. Parallel-sided (machined) circlips can be installed either way round in their groove, whereas stamped circlips (which have a chamfered edge on one face) must be installed with the chamfer facing away from the direction of thrust load (see illustration 2.9).




2.8 External stamped circlip (A), internal stamped circlip (B), machined circlip (C) and wire circlip (D)

● Always use circlip pliers to remove and install circlips; expand or compress them just enough to remove them. After installation, rotate the circlip in its groove to ensure it is securely seated. If installing a circlip on a splined shaft, always align its opening with a shaft channel to ensure the circlip ends are well supported and unlikely to catch (see illustration 2.10).



2.9 Correct fitting of a stamped circlip



2.10 Align circlip opening  
with shaft channel

● Circlips can wear due to the thrust of components and become loose in their grooves, with the subsequent danger of becoming dislodged in operation. For this reason, renewal is advised every time a circlip is disturbed.


● Wire circlips are commonly used as piston pin retaining clips. If a removal tang is provided, long-nosed pliers can be used to dislodge them, otherwise careful use of a small flat-bladed screwdriver is necessary. Wire circlips should be renewed every time they are disturbed.

**Thread diameter and pitch**

● Diameter of a male thread (screw, bolt or stud) is the outside diameter of the threaded portion (see illustration 2.11). Most motorcycle manufacturers use the ISO (International Standards Organisation) metric system expressed in millimetres, eg M6 refers to a 6 mm diameter thread. Sizing is the same for nuts, except that the thread diameter is measured across the valleys of the nut.

● Pitch is the distance between the peaks of the thread (see illustration 2.11). It is expressed in millimetres, thus a common bolt size may be expressed as 6.0 x 1.0 mm (6 mm thread diameter and 1 mm pitch). Generally pitch increases in proportion to thread diameter, although there are always exceptions.

● Thread diameter and pitch are related for conventional fastener applications and the accompanying table can be used as a guide. Additionally, the AF (Across Flats), spanner or socket size dimension of the bolt or nut (see illustration 2.11) is linked to thread and pitch specification. Thread pitch can be measured with a thread gauge (see illustration 2.12).



2.11 Fastener length (L), thread diameter (D), thread pitch (P) and head size (AF)



2.12 Using a thread gauge  
to measure pitch

AF size	Thread diameter x pitch (mm)
8 mm	M5 x 0.8
8 mm	M6 x 1.0
10 mm	M6 x 1.0
12 mm	M8 x 1.25
14 mm	M10 x 1.25
17 mm	M12 x 1.25

● The threads of most fasteners are of the right-hand type, ie they are turned clockwise to tighten and anti-clockwise to loosen. The reverse situation applies to left-hand thread fasteners, which are turned anti-clockwise to tighten and clockwise to loosen. Left-hand threads are used where rotation of a component might loosen a conventional right-hand thread fastener.

**Seized fasteners**

● Corrosion of external fasteners due to water or reaction between two dissimilar metals can occur over a period of time. It will build up sooner in wet conditions or in countries where salt is used on the roads during the winter. If a fastener is severely corroded it is likely that normal methods of removal will fail and result in its head being ruined. When you attempt removal, the fastener thread should be heard to crack free and unscrew easily - if it doesn't, stop there before damaging something.

● A smart tap on the head of the fastener will often succeed in breaking free corrosion which has occurred in the threads (see illustration 2.13).

● An aerosol penetrating fluid (such as WD-40) applied the night beforehand may work its way down into the thread and ease removal. Depending on the location, you may be able to make up a Plasticine well around the fastener head and fill it with penetrating fluid.



2.13 A sharp tap on the head of a fastener will often break free a corroded thread




● If you are working on an engine internal component, corrosion will most likely not be a problem due to the well lubricated environment. However, components can be very tight and an impact driver is a useful tool in freeing them (see illustration 2.14).



2.14 Using an impact driver to free a fastener


● Where corrosion has occurred between dissimilar metals (eg steel and aluminium alloy), the application of heat to the fastener head will create a disproportionate expansion rate between the two metals and break the seizure caused by the corrosion. Whether heat can be applied depends on the location of the fastener - any surrounding components likely to be damaged must first be removed (see illustration 2.15). Heat can be applied using a paint stripper heat gun or clothes iron, or by immersing the component in boiling water - wear protective gloves to prevent scalding or burns to the hands.



2.15 Using heat to free a seized fastener

● As a last resort, it is possible to use a hammer and cold chisel to work the fastener head unscrewed (see illustration 2.16). This will damage the fastener, but more importantly extreme care must be taken not to damage the surrounding component.


**Caution: Remember that the component being secured is generally of more value than the bolt, nut or screw - when the fastener is freed, do not unscrew it with force, instead work the fastener back and forth when resistance is felt to prevent thread damage.**



2.16 Using a hammer and chisel to free a seized fastener

### Broken fasteners and damaged heads

● If the shank of a broken bolt or screw is accessible you can grip it with self-locking grips. The knurled wheel type stud extractor tool or self-gripping stud puller tool is particularly useful for removing the long studs which screw into the cylinder mouth surface of the crankcase or bolts and screws from which the head has broken off (see illustration 2.17). Studs can also be removed by locking two nuts together on the threaded end of the stud and using a spanner on the lower nut (see illustration 2.18).



2.17 Using a stud extractor tool to remove a broken crankcase stud



2.18 Two nuts can be locked together to unscrew a stud from a component

● A bolt or screw which has broken off below or level with the casing must be extracted using a screw extractor set. Centre punch the fastener to centralise the drill bit, then drill a hole in the fastener (see illustration 2.19). Select a drill bit which is approximately half to three-quarters the



2.19 When using a screw extractor, first drill a hole in the fastener . . .

diameter of the fastener and drill to a depth which will accommodate the extractor. Use the largest size extractor possible, but avoid leaving too small a wall thickness otherwise the extractor will merely force the fastener walls outwards wedging it in the casing thread.

● If a spiral type extractor is used, thread it anti-clockwise into the fastener. As it is screwed in, it will grip the fastener and unscrew it from the casing (see illustration 2.20).



2.20 . . . then thread the extractor anti-clockwise into the fastener

● If a taper type extractor is used, tap it into the fastener so that it is firmly wedged in place. Unscrew the extractor (anti-clockwise) to draw the fastener out.




**Warning: Stud extractors are very hard and may break off in the fastener if care is not taken - ask an engineer about spark erosion if this happens.**

● Alternatively, the broken bolt/screw can be drilled out and the hole retapped for an oversize bolt/screw or a diamond-section thread insert. It is essential that the drilling is carried out squarely and to the correct depth, otherwise the casing may be ruined - if in doubt, entrust the work to an engineer.

● Bolts and nuts with rounded corners cause the correct size spanner or socket to slip when force is applied. Of the types of spanner/socket available always use a six-point type rather than an eight or twelve-point type - better grip






**2.21 Comparison of surface drive ring spanner (left) with 12-point type (right)**

is obtained. Surface drive spanners grip the middle of the hex flats, rather than the corners, and are thus good in cases of damaged heads (see illustration 2.21).

● Slotted-head or Phillips-head screws are often damaged by the use of the wrong size screwdriver. Allen-head and Torx-head screws are much less likely to sustain damage. If enough of the screw head is exposed you can use a hacksaw to cut a slot in its head and then use a conventional flat-bladed screwdriver to remove it. Alternatively use a hammer and cold chisel to tap the head of the fastener around to slacken it. Always replace damaged fasteners with new ones, preferably Torx or Allen-head type.



**HAYNES HINT**  
*A dab of valve grinding compound between the screw head and screw-driver tip will often give a good grip.*

## Thread repair

● Threads (particularly those in aluminium alloy components) can be damaged by overtightening, being assembled with dirt in the threads, or from a component working loose and vibrating. Eventually the thread will fail completely, and it will be impossible to tighten the fastener.

● If a thread is damaged or clogged with old locking compound it can be renovated with a thread repair tool (thread chaser) (see illustrations 2.22 and 2.23); special thread




**2.22 A thread repair tool being used to correct an internal thread**



**2.23 A thread repair tool being used to correct an external thread**


chasers are available for spark plug hole threads. The tool will not cut a new thread, but clean and true the original thread. Make sure that you use the correct diameter and pitch tool. Similarly, external threads can be cleaned up with a die or a thread restorer file (see illustration 2.24).



**2.24 Using a thread restorer file**

● It is possible to drill out the old thread and retap the component to the next thread size. This will work where there is enough surrounding material and a new bolt or screw can be obtained. Sometimes, however, this is not possible - such as where the bolt/screw passes through another component which must also be suitably modified, also in cases where a spark plug or oil drain plug cannot be obtained in a larger diameter thread size.

● The diamond-section thread insert (often known by its popular trade name of Heli-Coil) is a simple and effective method of renewing the thread and retaining the original size. A kit can be purchased which contains the tap, insert and installing tool (see illustration 2.25). Drill out the damaged thread with the size drill specified (see illustration 2.26). Carefully retap the thread (see illustration 2.27). Install the



**2.25 Obtain a thread insert kit to suit the thread diameter and pitch required**



**2.26 To install a thread insert, first drill out the original thread ...**



**2.27 ... tap a new thread ...**



**2.28 ... fit insert on the installing tool ...**



**2.29 ... and thread into the component ...**



**2.30 ... break off the tang when complete**

insert on the installing tool and thread it slowly into place using a light downward pressure (see illustrations 2.28 and 2.29). When positioned between a 1/4 and 1/2 turn below the surface withdraw the installing tool and use the break-off tool to press down on the tang, breaking it off (see illustration 2.30).

● There are epoxy thread repair kits on the market which can rebuild stripped internal threads, although this repair should not be used on high load-bearing components.



### Thread locking and sealing compounds

● Locking compounds are used in locations where the fastener is prone to loosening due to vibration or on important safety-related items which might cause loss of control of the motorcycle if they fail. It is also used where important fasteners cannot be secured by other means such as lockwashers or split pins.

● Before applying locking compound, make sure that the threads (internal and external) are clean and dry with all old compound removed. Select a compound to suit the component being secured - a non-permanent general locking and sealing type is suitable for most applications, but a high strength type is needed for permanent fixing of studs in castings. Apply a drop or two of the compound to the first few threads of the fastener, then thread it into place and tighten to the specified torque. Do not apply excessive thread locking compound otherwise the thread may be damaged on subsequent removal.

● Certain fasteners are impregnated with a dry film type coating of locking compound on their threads. Always renew this type of fastener if disturbed.

● Anti-seize compounds, such as copper-based greases, can be applied to protect threads from seizure due to extreme heat and corrosion. A common instance is spark plug threads and exhaust system fasteners.

## 3 Measuring tools and gauges

### Feeler gauges

● Feeler gauges (or blades) are used for measuring small gaps and clearances (see illustration 3.1). They can also be used to measure endfloat (sideplay) of a component on a shaft where access is not possible with a dial gauge.

● Feeler gauge sets should be treated with care and not bent or damaged. They are etched with their size on one face. Keep them clean and very lightly oiled to prevent corrosion build-up.



3.1 Feeler gauges are used for measuring small gaps and clearances - thickness is marked on one face of gauge

● When measuring a clearance, select a gauge which is a light sliding fit between the two components. You may need to use two gauges together to measure the clearance accurately.

### Micrometers

● A micrometer is a precision tool capable of measuring to 0.01 or 0.001 of a millimetre. It should always be stored in its case and not in the general toolbox. It must be kept clean and never dropped, otherwise its frame or measuring anvils could be distorted resulting in inaccurate readings.


● External micrometers are used for measuring outside diameters of components and have many more applications than internal micrometers. Micrometers are available in different size ranges, eg 0 to 25 mm, 25 to 50 mm, and upwards in 25 mm steps; some large micrometers have interchangeable anvils to allow a range of measurements to be taken. Generally the largest precision measurement you are likely to take on a motorcycle is the piston diameter.

● Internal micrometers (or bore micrometers) are used for measuring inside diameters, such as valve guides and cylinder bores. Telescoping gauges and small hole gauges are used in conjunction with an external micrometer, whereas the more expensive internal micrometers have their own measuring device.

### External micrometer

**Note:** The conventional analogue type instrument is described. Although much easier to read, digital micrometers are considerably more expensive.

● Always check the calibration of the micrometer before use. With the anvils closed (0 to 25 mm type) or set over a test gauge (for




3.2 Check micrometer calibration before use

the larger types) the scale should read zero (see illustration 3.2); make sure that the anvils (and test piece) are clean first. Any discrepancy can be adjusted by referring to the instructions supplied with the tool. Remember that the micrometer is a precision measuring tool - don't force the anvils closed, use the ratchet (4) on the end of the micrometer to close it. In this way, a measured force is always applied.

● To use, first make sure that the item being measured is clean. Place the anvil of the micrometer (1) against the item and use the thimble (2) to bring the spindle (3) lightly into contact with the other side of the item (see illustration 3.3). Don't tighten the thimble down because this will damage the micrometer - instead use the ratchet (4) on the end of the micrometer. The ratchet mechanism applies a measured force preventing damage to the instrument.

● The micrometer is read by referring to the linear scale on the sleeve and the annular scale on the thimble. Read off the sleeve first to obtain the base measurement, then add the fine measurement from the thimble to obtain the overall reading. The linear scale on the sleeve represents the measuring range of the micrometer (eg 0 to 25 mm). The annular scale



3.3 Micrometer component parts

1 Anvil  
2 Thimble  
3 Spindle  
4 Ratchet


5 Frame  
6 Locking lever




on the thimble will be in graduations of 0.01 mm (or as marked on the frame) - one full revolution of the thimble will move 0.5 mm on the linear scale. Take the reading where the datum line on the sleeve intersects the thimble's scale. Always position the eye directly above the scale otherwise an inaccurate reading will result.

In the example shown the item measures 2.95 mm (see illustration 3.4):


Linear scale	2.00 mm
Linear scale	0.50 mm
Annular scale	0.45 mm
Total figure	2.95 mm



3.4 Micrometer reading of 2.95 mm




3.5 Micrometer reading of 46.99 mm on linear and annular scales ...



3.6 ... and 0.004 mm on vernier scale



3.7 Expand the telescoping gauge in the bore, lock its position ...



3.8 ... then measure the gauge with a micrometer

Most micrometers have a locking lever (6) on the frame to hold the setting in place, allowing the item to be removed from the micrometer.

- Some micrometers have a vernier scale on their sleeve, providing an even finer measurement to be taken, in 0.001 increments of a millimetre. Take the sleeve and thimble measurement as described above, then check which graduation on the vernier scale aligns with that of the annular scale on the thimble **Note:** The eye must be perpendicular to the scale when taking the vernier reading - if necessary rotate the body of the micrometer to ensure this. Multiply the vernier scale figure by 0.001 and add it to the base and fine measurement figures.

In the example shown the item measures 46.994 mm (see illustrations 3.5 and 3.6):

Linear scale (base)	46.000 mm
Linear scale (base)	00.500 mm
Annular scale (fine)	00.490 mm
Vernier scale	00.004 mm
Total figure	46.994 mm

## Internal micrometer

- Internal micrometers are available for measuring bore diameters, but are expensive and unlikely to be available for home use. It is suggested that a set of telescoping gauges and small hole gauges, both of which must be used with an external micrometer, will suffice for taking internal measurements on a motorcycle.
- Telescoping gauges can be used to


measure internal diameters of components. Select a gauge with the correct size range, make sure its ends are clean and insert it into the bore. Expand the gauge, then lock its position and withdraw it from the bore (see illustration 3.7). Measure across the gauge ends with a micrometer (see illustration 3.8).

- Very small diameter bores (such as valve guides) are measured with a small hole gauge. Once adjusted to a slip-fit inside the component, its position is locked and the gauge withdrawn for measurement with a micrometer (see illustrations 3.9 and 3.10).

## Vernier caliper

**Note:** The conventional linear and dial gauge type instruments are described. Digital types are easier to read, but are far more expensive.

- The vernier caliper does not provide the precision of a micrometer, but is versatile in being able to measure internal and external diameters. Some types also incorporate a depth gauge. It is ideal for measuring clutch plate friction material and spring free lengths.
- To use the conventional linear scale vernier, slacken off the vernier clamp screws (1) and set its jaws over (2), or inside (3), the item to be measured (see illustration 3.11). Slide the jaw into contact, using the thumb-wheel (4) for fine movement of the sliding scale (5) then tighten the clamp screws (1). Read off the main scale (6) where the zero on the sliding scale (5) intersects it, taking the whole number to the left of the zero; this provides the base measurement. View along the sliding scale and select the division which




3.9 Expand the small hole gauge in the bore, lock its position ...



3.10 ... then measure the gauge with a micrometer

lines up exactly with any of the divisions on the main scale, noting that the divisions usually represents 0.02 of a millimetre. Add this fine measurement to the base measurement to obtain the total reading.







3.11 Vernier component parts (linear gauge)

- |                 |                 |                 |               |
|-----------------|-----------------|-----------------|---------------|
| 1 Clamp screws  | 3 Internal jaws | 5 Sliding scale | 7 Depth gauge |
| 2 External jaws | 4 Thumbwheel    | 6 Main scale    |               |

In the example shown the item measures 55.92 mm (see illustration 3.12):



3.12 Vernier gauge reading of 55.92 mm



3.13 Vernier component parts (dial gauge)


- |                 |                 |
|-----------------|-----------------|
| 1 Clamp screw   | 5 Main scale    |
| 2 External jaws | 6 Sliding scale |
| 3 Internal jaws | 7 Dial gauge    |
| 4 Thumbwheel    |                 |

Base measurement	55.00 mm
Fine measurement	00.92 mm
Total figure	55.92 mm

Some vernier calipers are equipped with a dial gauge for fine measurement. Before use, check that the jaws are clean, then close them fully and check that the dial gauge reads zero. If necessary adjust the gauge ring accordingly. Slacken the vernier clamp screw (1) and set its jaws over (2), or inside (3), the item to be measured (see illustration 3.13). Slide the jaws into contact, using the thumbwheel (4) for fine movement. Read off the main scale (5) where the edge of the sliding scale (6) intersects it, taking the whole number to the left of the zero; this provides the base measurement. Read off the needle position on the dial gauge (7) scale to provide the fine measurement; each division represents 0.05 of a millimetre. Add this fine measurement to the base measurement to obtain the total reading.

In the example shown the item measures 55.95 mm (see illustration 3.14):

Base measurement	55.00 mm
Fine measurement	00.95 mm
Total figure	55.95 mm



3.14 Vernier gauge reading of 55.95 mm

## Plastigauge

Plastigauge is a plastic material which can be compressed between two surfaces to measure the oil clearance between them. The width of the compressed Plastigauge is measured against a calibrated scale to determine the clearance.

Common uses of Plastigauge are for measuring the clearance between crankshaft journal and main bearing inserts, between crankshaft journal and big-end bearing inserts, and between camshaft and bearing surfaces. The following example describes big-end oil clearance measurement.

Handle the Plastigauge material carefully to prevent distortion. Using a sharp knife, cut a length which corresponds with the width of the bearing being measured and place it carefully across the journal so that it is parallel with the shaft (see illustration 3.15). Carefully install both bearing shells and the connecting rod. Without rotating the rod on the journal tighten its bolts or nuts (as applicable) to the specified torque. The connecting rod and bearings are then disassembled and the crushed Plastigauge examined.



3.15 Plastigauge placed across shaft journal

Using the scale provided in the Plastigauge kit, measure the width of the material to determine the oil clearance (see illustration 3.16). Always remove all traces of Plastigauge after use using your fingernails.

**Caution:** Arriving at the correct clearance demands that the assembly is torqued correctly, according to the settings and sequence (where applicable) provided by the motorcycle manufacturer.



3.16 Measuring the width of the crushed Plastigauge



### Dial gauge or DTI (Dial Test Indicator)

- A dial gauge can be used to accurately measure small amounts of movement. Typical uses are measuring shaft runout or shaft endfloat (sideplay) and setting piston position for ignition timing on two-strokes. A dial gauge set usually comes with a range of different probes and adapters and mounting equipment.
- The gauge needle must point to zero when at rest. Rotate the ring around its periphery to zero the gauge.

● Check that the gauge is capable of reading the extent of movement in the work. Most gauges have a small dial set in the face which records whole millimetres of movement as well as the fine scale around the face periphery which is calibrated in 0.01 mm divisions. Read off the small dial first to obtain the base measurement, then add the measurement from the fine scale to obtain the total reading.


In the example shown the gauge reads 1.48 mm (see illustration 3.17):

Base measurement	1.00 mm
Fine measurement	0.48 mm
Total figure	1.48 mm



3.17 Dial gauge reading of 1.48 mm


- If measuring shaft runout, the shaft must be supported in vee-blocks and the gauge mounted on a stand perpendicular to the shaft. Rest the tip of the gauge against the centre of the shaft and rotate the shaft slowly whilst watching the gauge reading (see illustration 3.18). Take several measurements along the length of the shaft and record the



3.18 Using a dial gauge to measure shaft runout

maximum gauge reading as the amount of runout in the shaft. **Note:** The reading obtained will be total runout at that point - some manufacturers specify that the runout figure is halved to compare with their specified runout limit.

- Endfloat (sideplay) measurement requires that the gauge is mounted securely to the surrounding component with its probe touching the end of the shaft. Using hand pressure, push and pull on the shaft noting the maximum endfloat recorded on the gauge (see illustration 3.19).



3.19 Using a dial gauge to measure shaft endfloat

- A dial gauge with suitable adapters can be used to determine piston position BTDC on two-stroke engines for the purposes of ignition timing. The gauge, adapter and suitable length probe are installed in the place of the spark plug and the gauge zeroed at TDC. If the piston position is specified as 1.14 mm BTDC, rotate the engine back to 2.00 mm BTDC, then slowly forwards to 1.14 mm BTDC.

### Cylinder compression gauges

- A compression gauge is used for measuring cylinder compression. Either the rubber-cone type or the threaded adapter type can be used. The latter is preferred to ensure a perfect seal against the cylinder head. A 0 to 300 psi (0 to 20 Bar) type gauge (for petrol/gasoline engines) will be suitable for motorcycles.
- The spark plug is removed and the gauge either held hard against the cylinder head (cone type) or the gauge adapter screwed into the cylinder head (threaded type) (see illustration 3.20). Cylinder compression is measured with the engine turning over, but not running - carry out the compression test as described in



3.20 Using a rubber-cone type cylinder compression gauge

**Fault Finding Equipment.** The gauge will hold the reading until manually released.

### Oil pressure gauge

- An oil pressure gauge is used for measuring engine oil pressure. Most gauges come with a set of adapters to fit the thread of the take-off point (see illustration 3.21). If the take-off point specified by the motorcycle manufacturer is an external oil pipe union, make sure that the specified replacement union is used to prevent oil starvation.



3.21 Oil pressure gauge and take-off point adapter (arrow)


- Oil pressure is measured with the engine running (at a specific rpm) and often the manufacturer will specify pressure limits for a cold and hot engine.

### Straight-edge and surface plate

- If checking the gasket face of a component for warpage, place a steel rule or precision straight-edge across the gasket face and measure any gap between the straight-edge and component with feeler gauges (see illustration 3.22). Check diagonally across the component and between mounting holes (see illustration 3.23).



3.22 Use a straight-edge and feeler gauges to check for warpage



3.23 Check for warpage in these directions



● Checking individual components for warpage, such as clutch plain (metal) plates, requires a perfectly flat plate or piece of plate glass and feeler gauges.

## 4 Torque and leverage

### What is torque?

● Torque describes the twisting force about a shaft. The amount of torque applied is determined by the distance from the centre of the shaft to the end of the lever and the amount of force being applied to the end of the lever; distance multiplied by force equals torque.


● The manufacturer applies a measured torque to a bolt or nut to ensure that it will not slacken in use and to hold two components securely together without movement in the joint. The actual torque setting depends on the thread size, bolt or nut material and the composition of the components being held.

● Too little torque may cause the fastener to loosen due to vibration, whereas too much torque will distort the joint faces of the component or cause the fastener to shear off. Always stick to the specified torque setting.

### Using a torque wrench

● Check the calibration of the torque wrench and make sure it has a suitable range for the job. Torque wrenches are available in Nm (Newton-metres), kgf m (kilograms-force metre), lbf ft (pounds-feet), lbf in (inch-pounds). Do not confuse lbf ft with lbf in.

● Adjust the tool to the desired torque on the scale (see illustration 4.1). If your torque wrench is not calibrated in the units specified, carefully convert the figure (see *Conversion Factors*). A manufacturer sometimes gives a torque setting as a range (8 to 10 Nm) rather than a single figure - in this case set the tool midway between the two settings. The same torque may be expressed as 9 Nm  $\pm$  1 Nm. Some torque wrenches have a method of locking the setting so that it isn't inadvertently altered during use.



4.1 Set the torque wrench index mark to the setting required, in this case 12 Nm

● Install the bolts/nuts in their correct location and secure them lightly. Their threads must be clean and free of any old locking compound. Unless specified the threads and flange should be dry - oiled threads are necessary in certain circumstances and the manufacturer will take this into account in the specified torque figure. Similarly, the manufacturer may also specify the application of thread-locking compound.


● Tighten the fasteners in the specified sequence until the torque wrench clicks, indicating that the torque setting has been reached. Apply the torque again to double-check the setting. Where different thread diameter fasteners secure the component, as a rule tighten the larger diameter ones first.

● When the torque wrench has been finished with, release the lock (where applicable) and fully back off its setting to zero - do not leave the torque wrench tensioned. Also, do not use a torque wrench for slackening a fastener.


### Angle-tightening

● Manufacturers often specify a figure in degrees for final tightening of a fastener. This usually follows tightening to a specific torque setting.

● A degree disc can be set and attached to the socket (see illustration 4.2) or a protractor can be used to mark the angle of movement on the bolt/nut head and the surrounding casting (see illustration 4.3).



4.2 Angle tightening can be accomplished with a torque-angle gauge...




4.3 ...or by marking the angle on the surrounding component

### Loosening sequences

● Where more than one bolt/nut secures a component, loosen each fastener evenly a little at a time. In this way, not all the stress of the joint is held by one fastener and the components are not likely to distort.

● If a tightening sequence is provided, work in the REVERSE of this, but if not, work from the outside in, in a criss-cross sequence (see illustration 4.4).




4.4 When slackening, work from the outside inwards

### Tightening sequences

● If a component is held by more than one fastener it is important that the retaining bolts/nuts are tightened evenly to prevent uneven stress build-up and distortion of sealing faces. This is especially important on high-compression joints such as the cylinder head.

● A sequence is usually provided by the manufacturer, either in a diagram or actually marked in the casting. If not, always start in the centre and work outwards in a criss-cross pattern (see illustration 4.5). Start off by securing all bolts/nuts finger-tight, then set the torque wrench and tighten each fastener by a small amount in sequence until the final torque is reached. By following this practice,




4.5 When tightening, work from the inside outwards



the joint will be held evenly and will not be distorted. Important joints, such as the cylinder head and big-end fasteners often have two- or three-stage torque settings.

### Applying leverage

● Use tools at the correct angle. Position a socket wrench or spanner on the bolt/nut so that you pull it towards you when loosening. If this can't be done, push the spanner without curling your fingers around it (see illustration 4.6) - the spanner may slip or the fastener loosen suddenly, resulting in your fingers being crushed against a component.



4.6 If you can't pull on the spanner to loosen a fastener, push with your hand open

● Additional leverage is gained by extending the length of the lever. The best way to do this is to use a breaker bar instead of the regular length tool, or to slip a length of tubing over the end of the spanner or socket wrench.

● If additional leverage will not work, the fastener head is either damaged or firmly corroded in place (see *Fasteners*).

## 5 Bearings

### Bearing removal and installation


#### Drivers and sockets

● Before removing a bearing, always inspect the casing to see which way it must be driven out - some casings will have retaining plates or a cast step. Also check for any identifying markings on the bearing and if installed to a certain depth, measure this at this stage. Some roller bearings are sealed on one side - take note of the original fitted position.

● Bearings can be driven out of a casing using a bearing driver tool (with the correct size head) or a socket of the correct diameter. Select the driver head or socket so that it contacts the outer race of the bearing, not the balls/rollers or inner race. Always support the casing around the bearing housing with wood blocks, otherwise there is a risk of fracture. The bearing is driven out with a few blows on the driver or socket from a heavy mallet. Unless access is severely restricted (as with wheel bearings), a pin-punch is not recommended unless it is moved around the bearing to keep it square in its housing.

● The same equipment can be used to install bearings. Make sure the bearing housing is supported on wood blocks and line up the bearing in its housing. Fit the bearing as noted on removal - generally they are installed with their marked side facing outwards. Tap the bearing squarely into its housing using a driver or socket which bears only on the bearing's outer race - contact with the bearing balls/rollers or inner race will destroy it (see illustrations 5.1 and 5.2).

● Check that the bearing inner race and balls/rollers rotate freely.



5.1 Using a bearing driver against the bearing's outer race



5.2 Using a large socket against the bearing's outer race

#### Pullers and slide-hammers


● Where a bearing is pressed on a shaft a puller will be required to extract it (see illustration 5.3). Make sure that the puller clamp or legs fit securely behind the bearing and are unlikely to slip out. If pulling a bearing



5.3 This bearing puller clamps behind the bearing and pressure is applied to the shaft end to draw the bearing off

off a gear shaft for example, you may have to locate the puller behind a gear pinion if there is no access to the race and draw the gear pinion off the shaft as well (see illustration 5.4).

**Caution:** Ensure that the puller's centre bolt locates securely against the end of the shaft and will not slip when pressure is applied. Also ensure that puller does not damage the shaft end.



5.4 Where no access is available to the rear of the bearing, it is sometimes possible to draw off the adjacent component

● Operate the puller so that its centre bolt exerts pressure on the shaft end and draws the bearing off the shaft.

● When installing the bearing on the shaft, tap only on the bearing's inner race - contact with the balls/rollers or outer race will destroy the bearing. Use a socket or length of tubing as a drift which fits over the shaft end (see illustration 5.5).



5.5 When installing a bearing on a shaft use a piece of tubing which bears only on the bearing's inner race

● Where a bearing locates in a blind hole in a casing, it cannot be driven or pulled out as described above. A slide-hammer with knife-edged bearing puller attachment will be required. The puller attachment passes through the bearing and when tightened expands to fit firmly behind the bearing (see illustration 5.6). By operating the slide-hammer part of the tool the bearing is jarred out of its housing (see illustration 5.7).

● It is possible, if the bearing is of reasonable weight, for it to drop out of its housing if the casing is heated as described opposite. If this





5.6 Expand the bearing puller so that it locks behind the bearing . . .



5.7 . . . attach the slide hammer to the bearing puller

method is attempted, first prepare a work surface which will enable the casing to be tapped face down to help dislodge the bearing - a wood surface is ideal since it will not damage the casing's gasket surface. Wearing protective gloves, tap the heated casing several times against the work surface to dislodge the bearing under its own weight (see illustration 5.8).




5.8 Tapping a casing face down on wood blocks can often dislodge a bearing

● Bearings can be installed in blind holes using the driver or socket method described above.


## Drawbolts

● Where a bearing or bush is set in the eye of a component, such as a suspension linkage arm or connecting rod small-end, removal by drift may damage the component. Furthermore, a rubber bushing in a shock absorber eye cannot successfully be driven out of position. If access is available to an engineering press, the task is straightforward. If not, a drawbolt can be fabricated to extract the bearing or bush.



5.9 Drawbolt component parts assembled on a suspension arm


- 1 Bolt or length of threaded bar
- 2 Nuts
- 3 Washer (external diameter greater than tubing internal diameter)
- 4 Tubing (internal diameter sufficient to accommodate bearing)
- 5 Suspension arm with bearing
- 6 Tubing (external diameter slightly smaller than bearing)
- 7 Washer (external diameter slightly smaller than bearing)



5.10 Drawing the bearing out of the suspension arm

● To extract the bearing/bush you will need a long bolt with nut (or piece of threaded bar with two nuts), a piece of tubing which has an internal diameter larger than the bearing/bush, another piece of tubing which has an external diameter slightly smaller than the bearing/bush, and a selection of washers (see illustrations 5.9 and 5.10). Note that the pieces of tubing must be of the same length, or longer, than the bearing/bush.

● The same kit (without the pieces of tubing) can be used to draw the new bearing/bush back into place (see illustration 5.11).



5.11 Installing a new bearing (1) in the suspension arm

## Temperature change

● If the bearing's outer race is a tight fit in the casing, the aluminium casing can be heated to release its grip on the bearing. Aluminium will expand at a greater rate than the steel bearing outer race. There are several ways to do this, but avoid any localised extreme heat (such as a blow torch) - aluminium alloy has a low melting point.

● Approved methods of heating a casing are using a domestic oven (heated to 100°C) or immersing the casing in boiling water (see illustration 5.12). Low temperature range localised heat sources such as a paint stripper heat gun or clothes iron can also be used (see illustration 5.13). Alternatively, soak a rag in boiling water, wring it out and wrap it around the bearing housing.



**Warning: All of these methods require care in use to prevent scalding and burns to the hands. Wear protective gloves when handling hot components.**



5.12 A casing can be immersed in a sink of boiling water to aid bearing removal



5.13 Using a localised heat source to aid bearing removal

● If heating the whole casing note that plastic components, such as the neutral switch, may suffer - remove them beforehand.

● After heating, remove the bearing as described above. You may find that the expansion is sufficient for the bearing to fall out of the casing under its own weight or with a light tap on the driver or socket.


● If necessary, the casing can be heated to aid bearing installation, and this is sometimes the recommended procedure if the motorcycle manufacturer has designed the housing and bearing fit with this intention.




● Installation of bearings can be eased by placing them in a freezer the night before installation. The steel bearing will contract slightly, allowing easy insertion in its housing. This is often useful when installing steering head outer races in the frame.

### Bearing types and markings

● Plain shell bearings, ball bearings, needle roller bearings and tapered roller bearings will all be found on motorcycles (see illustrations 5.14 and 5.15). The ball and roller types are usually caged between an inner and outer race, but uncaged variations may be found.



5.14 Shell bearings are either plain or grooved. They are usually identified by colour code (arrow)



5.15 Tapered roller bearing (A), needle roller bearing (B) and ball journal bearing (C)

● Shell bearings (often called inserts) are usually found at the crankshaft main and connecting rod big-end where they are good at coping with high loads. They are made of a phosphor-bronze material and are impregnated with self-lubricating properties.

● Ball bearings and needle roller bearings consist of a steel inner and outer race with the balls or rollers between the races. They require constant lubrication by oil or grease and are good at coping with axial loads. Taper roller bearings consist of rollers set in a tapered cage set on the inner race; the outer race is separate. They are good at coping with axial loads and prevent movement along the shaft - a typical application is in the steering head.

● Bearing manufacturers produce bearings to ISO size standards and stamp one face of the bearing to indicate its internal and external diameter, load capacity and type (see illustration 5.16).

● Metal bushes are usually of phosphor-bronze material. Rubber bushes are used in suspension mounting eyes. Fibre bushes have also been used in suspension pivots.




5.16 Typical bearing marking

### Bearing fault finding

● If a bearing outer race has spun in its housing, the housing material will be damaged. You can use a bearing locking compound to bond the outer race in place if damage is not too severe.

● Shell bearings will fail due to damage of their working surface, as a result of lack of lubrication, corrosion or abrasive particles in the oil (see illustration 5.17). Small particles of dirt in the oil may embed in the bearing material whereas larger particles will score the bearing and shaft journal. If a number of short journeys are made, insufficient heat will be generated to drive off condensation which has built up on the bearings.



5.17 Typical bearing failures

● Ball and roller bearings will fail due to lack of lubrication or damage to the balls or rollers. Tapered-roller bearings can be damaged by overloading them. Unless the bearing is sealed on both sides, wash it in paraffin (kerosene) to remove all old grease then allow it to dry. Make a visual inspection looking to dented balls or rollers, damaged cages and worn or pitted races (see illustration 5.18).

● A ball bearing can be checked for wear by listening to it when spun. Apply a film of light oil to the bearing and hold it close to the ear. Hold the outer race with one hand and spin the inner



5.18 Example of ball journal bearing with damaged balls and cages



5.19 Hold outer race and listen to inner race when spun

race with the other hand (see illustration 5.19). The bearing should be almost silent when spun; if it grates or rattles it is worn.

## 6 Oil seals

### Oil seal removal and installation

● Oil seals should be renewed every time a component is dismantled. This is because the seal lips will become set to the sealing surface and will not necessarily reseal.

● Oil seals can be prised out of position using a large flat-bladed screwdriver (see illustration 6.1). In the case of crankcase seals, check first that the seal is not lipped on the inside, preventing its removal with the crankcases joined.



6.1 Prise out oil seals with a large flat-bladed screwdriver

● New seals are usually installed with their marked face (containing the seal reference code) outwards and the spring side towards the fluid being retained. In certain cases, such as a two-stroke engine crankshaft seal, a double lipped seal may be used due to there being fluid or gas on each side of the joint.



- Use a bearing driver or socket which bears only on the outer hard edge of the seal to install it in the casing - tapping on the inner edge will damage the sealing lip.

### Oil seal types and markings

- Oil seals are usually of the single-lipped type. Double-lipped seals are found where a liquid or gas is on both sides of the joint.
- Oil seals can harden and lose their sealing ability if the motorcycle has been in storage for a long period - renewal is the only solution.
- Oil seal manufacturers also conform to the ISO markings for seal size - these are moulded into the outer face of the seal (see illustration 6.2).



6.2 These oil seal markings indicate inside diameter, outside diameter and seal thickness

## 7 Gaskets and sealants

### Types of gasket and sealant

- Gaskets are used to seal the mating surfaces between components and keep lubricants, fluids, vacuum or pressure contained within the assembly. Aluminium gaskets are sometimes found at the cylinder joints, but most gaskets are paper-based. If the mating surfaces of the components being joined are undamaged the gasket can be installed dry, although a dab of sealant or grease will be useful to hold it in place during assembly.

- RTV (Room Temperature Vulcanising) silicone rubber sealants cure when exposed to moisture in the atmosphere. These sealants are good at filling pits or irregular gasket faces, but will tend to be forced out of the joint under very high torque. They can be used to replace a paper gasket, but first make sure that the width of the paper gasket is not essential to the shimming of internal components. RTV sealants should not be used on components containing petrol (gasoline).

- Non-hardening, semi-hardening and hard setting liquid gasket compounds can be used with a gasket or between a metal-to-metal joint. Select the sealant to suit the application: universal non-hardening sealant can be used on virtually all joints; semi-hardening on joint faces which are rough or damaged; hard setting sealant on joints which require a permanent bond and are subjected to high temperature and pressure. **Note:** Check first if the paper gasket has a bead of sealant

impregnated in its surface before applying additional sealant.

- When choosing a sealant, make sure it is suitable for the application, particularly if being applied in a high-temperature area or in the vicinity of fuel. Certain manufacturers produce sealants in either clear, silver or black colours to match the finish of the engine. This has a particular application on motorcycles where much of the engine is exposed.


- Do not over-apply sealant. That which is squeezed out on the outside of the joint can be wiped off, whereas an excess of sealant on the inside can break off and clog oilways.

### Breaking a sealed joint


- Age, heat, pressure and the use of hard setting sealant can cause two components to stick together so tightly that they are difficult to separate using finger pressure alone. Do not resort to using levers unless there is a pry point provided for this purpose (see illustration 7.1) or else the gasket surfaces will be damaged.

- Use a soft-faced hammer (see illustration 7.2) or a wood block and conventional hammer to strike the component near the mating surface. Avoid hammering against cast extremities since they may break off. If this method fails, try using a wood wedge between the two components.

**Caution:** If the joint will not separate, double-check that you have removed all the fasteners.



7.1 If a pry point is provided, apply gently pressure with a flat-bladed screwdriver



7.2 Tap around the joint with a soft-faced mallet if necessary - don't strike cooling fins

### Removal of old gasket and sealant

- Paper gaskets will most likely come away complete, leaving only a few traces stuck on

HAYNES  
HINT



Most components have one or two hollow locating dowels between the two gasket faces. If a dowel cannot be removed, do not resort to gripping it with pliers - it will almost certainly be distorted. Install a close-fitting socket or Phillips screwdriver into the dowel and then grip the outer edge of the dowel to free it.

the sealing faces of the components. It is imperative that all traces are removed to ensure correct sealing of the new gasket.

- Very carefully scrape all traces of gasket away making sure that the sealing surfaces are not gouged or scored by the scraper (see illustrations 7.3, 7.4 and 7.5). Stubborn deposits can be removed by spraying with an aerosol gasket remover. Final preparation of



7.3 Paper gaskets can be scraped off with a gasket scraper tool . . .




7.4 . . . a knife blade . . .



7.5 . . . or a household scraper





**7.6** Fine abrasive paper is wrapped around a flat file to clean up the gasket face



**7.7** A kitchen scourer can be used on stubborn deposits

the gasket surface can be made with very fine abrasive paper or a plastic kitchen scourer (see illustrations 7.6 and 7.7).

- Old sealant can be scraped or peeled off components, depending on the type originally used. Note that gasket removal compounds are available to avoid scraping the components clean; make sure the gasket remover suits the type of sealant used.

## 8 Chains


### Breaking and joining final drive chains

- Drive chains for all but small bikes are continuous and do not have a clip-type connecting link. The chain must be broken using a chain breaker tool and the new chain securely riveted together using a new soft rivet-type link. Never use a clip-type connecting link instead of a rivet-type link, except in an emergency. Various chain breaking and riveting tools are available, either as separate tools or combined as illustrated in the accompanying photographs - read the instructions supplied with the tool carefully.



**Warning:** The need to rivet the new link pins correctly cannot be overstressed - loss of control of the motorcycle is very likely to result if the chain breaks in use.

- Rotate the chain and look for the soft link. The soft link pins look like they have been



**8.1** Tighten the chain breaker to push the pin out of the link ...



**8.2** ... withdraw the pin, remove the tool ...



**8.3** ... and separate the chain link

deeply centre-punched instead of peened over like all the other pins (see illustration 8.9) and its sideplate may be a different colour. Position the soft link midway between the sprockets and assemble the chain breaker tool over one of the soft link pins (see illustration 8.1). Operate the tool to push the pin out through the chain (see illustration 8.2). On an O-ring chain, remove the O-rings (see illustration 8.3). Carry out the same procedure on the other soft link pin.

**Caution:** Certain soft link pins (particularly on the larger chains) may require their ends to be filed or ground off before they can be pressed out using the tool.

- Check that you have the correct size and strength (standard or heavy duty) new soft link - do not reuse the old link. Look for the size marking on the chain sideplates (see illustration 8.10).

- Position the chain ends so that they are engaged over the rear sprocket. On an O-ring



**8.4** Insert the new soft link, with O-rings, through the chain ends ...



**8.5** ... install the O-rings over the pin ends ...



**8.6** ... followed by the sideplate


chain, install a new O-ring over each pin of the link and insert the link through the two chain ends (see illustration 8.4). Install a new O-ring over the end of each pin, followed by the sideplate (with the chain manufacturer's marking facing outwards) (see illustrations 8.5 and 8.6). On an unsealed chain, insert the link through the two chain ends, then install the sideplate with the chain manufacturer's marking facing outwards.

- Note that it may not be possible to install the sideplate using finger pressure alone. If using a joining tool, assemble it so that the plates of the tool clamp the link and press the sideplate over the pins (see illustration 8.7). Otherwise, use two small sockets placed over



**8.7** Push the sideplate into position using a clamp






8.8 Assemble the chain riveting tool over one pin at a time and tighten it fully



8.9 Pin end correctly riveted (A), pin end unriveted (B)



8.11 Chain dimensions

Sizes commencing with a 4 (eg 428) have a pitch of 1/2 inch (12.7 mm)

Sizes commencing with a 5 (eg 520) have a pitch of 5/8 inch (15.9 mm)

Sizes commencing with a 6 (eg 630) have a pitch of 3/4 inch (19.1 mm)


● The second and third digits of the chain size relate to the width of the rollers, again in imperial units, eg the 525 shown has 5/16 inch (7.94 mm) rollers (see illustration 8.11).

## 9 Hoses

### Clamping to prevent flow

● Small-bore flexible hoses can be clamped to prevent fluid flow whilst a component is worked on. Whichever method is used, ensure that the hose material is not permanently distorted or damaged by the clamp.

- A brake hose clamp available from auto accessory shops (see illustration 9.1).
- A wingnut type hose clamp (see illustration 9.2).




9.1 Hoses can be clamped with an automotive brake hose clamp ...




9.2 ... a wingnut type hose clamp ...

c) Two sockets placed each side of the hose and held with straight-jawed self-locking grips (see illustration 9.3).

d) Thick card each side of the hose held between straight-jawed self-locking grips (see illustration 9.4).



9.3 ... two sockets and a pair of self-locking grips ...



9.4 ... or thick card and self-locking grips

### Freeing and fitting hoses

● Always make sure the hose clamp is moved well clear of the hose end. Grip the hose with your hand and rotate it whilst pulling it off the union. If the hose has hardened due to age and will not move, slit it with a sharp knife and peel its ends off the union (see illustration 9.5).

● Resist the temptation to use grease or soap on the unions to aid installation; although it helps the hose slip over the union it will equally aid the escape of fluid from the joint. It is preferable to soften the hose ends in hot water and wet the inside surface of the hose with water or a fluid which will evaporate.



9.5 Cutting a coolant hose free with a sharp knife

**Warning:** Check that the pin ends are secure and that there is no danger of the sideplate coming loose. If the pin ends are cracked the soft link must be renewed.

### Final drive chain sizing

● Chains are sized using a three digit number, followed by a suffix to denote the chain type (see illustration 8.10). Chain type is either standard or heavy duty (thicker sideplates), and also unsealed or O-ring/X-ring type.

● The first digit of the number relates to the pitch of the chain, ie the distance from the centre of one pin to the centre of the next pin (see illustration 8.11). Pitch is expressed in eighths of an inch, as follows:



8.10 Typical chain size and type marking



**Length (distance)**

Inches (in)	x 25.4 =	Millimetres (mm)	x 0.0394 =	Inches (in)
Feet (ft)	x 0.305 =	Metres (m)	x 3.281 =	Feet (ft)
Miles	x 1.609 =	Kilometres (km)	x 0.621 =	Miles

**Volume (capacity)**

Cubic inches (cu in; in <sup>3</sup> )	x 16.387 =	Cubic centimetres (cc; cm <sup>3</sup> )	x 0.061 =	Cubic inches (cu in; in <sup>3</sup> )
Imperial pints (Imp pt)	x 0.568 =	Litres (l)	x 1.76 =	Imperial pints (Imp pt)
Imperial quarts (Imp qt)	x 1.137 =	Litres (l)	x 0.88 =	Imperial quarts (Imp qt)
Imperial quarts (Imp qt)	x 1.201 =	US quarts (US qt)	x 0.833 =	Imperial quarts (Imp qt)
US quarts (US qt)	x 0.946 =	Litres (l)	x 1.057 =	US quarts (US qt)
Imperial gallons (Imp gal)	x 4.546 =	Litres (l)	x 0.22 =	Imperial gallons (Imp gal)
Imperial gallons (Imp gal)	x 1.201 =	US gallons (US gal)	x 0.833 =	Imperial gallons (Imp gal)
US gallons (US gal)	x 3.785 =	Litres (l)	x 0.264 =	US gallons (US gal)

**Mass (weight)**

Ounces (oz)	x 28.35 =	Grams (g)	x 0.035 =	Ounces (oz)
Pounds (lb)	x 0.454 =	Kilograms (kg)	x 2.205 =	Pounds (lb)

**Force**

Ounces-force (ozf; oz)	x 0.278 =	Newtons (N)	x 3.6 =	Ounces-force (ozf; oz)
Pounds-force (lbf; lb)	x 4.448 =	Newtons (N)	x 0.225 =	Pounds-force (lbf; lb)
Newtons (N)	x 0.1 =	Kilograms-force (kgf; kg)	x 9.81 =	Newtons (N)

**Pressure**

Pounds-force per square inch (psi; lbf/in <sup>2</sup> ; lb/in <sup>2</sup> )	x 0.070 =	Kilograms-force per square centimetre (kgf/cm <sup>2</sup> ; kg/cm <sup>2</sup> )	x 14.223 =	Pounds-force per square inch (psi; lbf/in <sup>2</sup> ; lb/in <sup>2</sup> )
Pounds-force per square inch (psi; lbf/in <sup>2</sup> ; lb/in <sup>2</sup> )	x 0.068 =	Atmospheres (atm)	x 14.696 =	Pounds-force per square inch (psi; lbf/in <sup>2</sup> ; lb/in <sup>2</sup> )
Pounds-force per square inch (psi; lbf/in <sup>2</sup> ; lb/in <sup>2</sup> )	x 0.069 =	Bars	x 14.5 =	Pounds-force per square inch (psi; lbf/in <sup>2</sup> ; lb/in <sup>2</sup> )
Pounds-force per square inch (psi; lbf/in <sup>2</sup> ; lb/in <sup>2</sup> )	x 6.895 =	Kilopascals (kPa)	x 0.145 =	Pounds-force per square inch (psi; lbf/in <sup>2</sup> ; lb/in <sup>2</sup> )
Kilopascals (kPa)	x 0.01 =	Kilograms-force per square centimetre (kgf/cm <sup>2</sup> ; kg/cm <sup>2</sup> )	x 98.1 =	Kilopascals (kPa)
Millibar (mbar)	x 100 =	Pascals (Pa)	x 0.01 =	Millibar (mbar)
Millibar (mbar)	x 0.0145 =	Pounds-force per square inch (psi; lbf/in <sup>2</sup> ; lb/in <sup>2</sup> )	x 68.947 =	Millibar (mbar)
Millibar (mbar)	x 0.75 =	Millimetres of mercury (mmHg)	x 1.333 =	Millibar (mbar)
Millibar (mbar)	x 0.401 =	Inches of water (inH <sub>2</sub> O)	x 2.491 =	Millibar (mbar)
Millimetres of mercury (mmHg)	x 0.535 =	Inches of water (inH <sub>2</sub> O)	x 1.868 =	Millimetres of mercury (mmHg)
Inches of water (inH <sub>2</sub> O)	x 0.036 =	Pounds-force per square inch (psi; lbf/in <sup>2</sup> ; lb/in <sup>2</sup> )	x 27.68 =	Inches of water (inH <sub>2</sub> O)

**Torque (moment of force)**

Pounds-force inches (lbf in; lb in)	x 1.152 =	Kilograms-force centimetre (kgf cm; kg cm)	x 0.868 =	Pounds-force inches (lbf in; lb in)
Pounds-force inches (lbf in; lb in)	x 0.113 =	Newton metres (Nm)	x 8.85 =	Pounds-force inches (lbf in; lb in)
Pounds-force inches (lbf in; lb in)	x 0.083 =	Pounds-force feet (lbf ft; lb ft)	x 12 =	Pounds-force inches (lbf in; lb in)
Pounds-force feet (lbf ft; lb ft)	x 0.138 =	Kilograms-force metres (kgf m; kg m)	x 7.233 =	Pounds-force feet (lbf ft; lb ft)
Pounds-force feet (lbf ft; lb ft)	x 1.356 =	Newton metres (Nm)	x 0.738 =	Pounds-force feet (lbf ft; lb ft)
Newton metres (Nm)	x 0.102 =	Kilograms-force metres (kgf m; kg m)	x 9.804 =	Newton metres (Nm)

**Power**

Horsepower (hp)	x 745.7 =	Watts (W)	x 0.0013 =	Horsepower (hp)
-----------------	-----------	-----------	------------	-----------------

**Velocity (speed)**

Miles per hour (miles/hr; mph)	x 1.609 =	Kilometres per hour (km/hr; kph)	x 0.621 =	Miles per hour (miles/hr; mph)
--------------------------------	-----------	----------------------------------	-----------	--------------------------------

**Fuel consumption\***

Miles per gallon (mpg)	x 0.354 =	Kilometres per litre (km/l)	x 2.825 =	Miles per gallon (mpg)
------------------------	-----------	-----------------------------	-----------	------------------------

**Temperature**

Degrees Fahrenheit = (°C x 1.8) + 32	Degrees Celsius (Degrees Centigrade: °C) = (°F - 32) x 0.56
--------------------------------------	---

\* It is common practice to convert from miles per gallon (mpg) to litres/100 kilometres (l/100km), where mpg x l/100 km = 282



A number of chemicals and lubricants are available for use in motorcycle maintenance and repair. They include a wide variety of products ranging from cleaning solvents and degreasers to lubricants and protective sprays for rubber, plastic and vinyl.

- **Contact point/spark plug cleaner** is a solvent used to clean oily film and dirt from points, grime from electrical connectors and oil deposits from spark plugs. It is oil free and leaves no residue. It can also be used to remove gum and varnish from carburettor jets and other orifices.

- **Carburettor cleaner** is similar to contact point/spark plug cleaner but it usually has a stronger solvent and may leave a slight oily residue. It is not recommended for cleaning electrical components or connections.

- **Brake system cleaner** is used to remove grease or brake fluid from brake system components (where clean surfaces are absolutely necessary and petroleum-based solvents cannot be used); it also leaves no residue.

- **Silicone-based lubricants** are used to protect rubber parts such as hoses and grommets, and are used as lubricants for hinges and locks.

- **Multi-purpose grease** is an all purpose lubricant used wherever grease is more practical than a liquid lubricant such as oil. Some multi-purpose grease is coloured white and specially formulated to be more resistant to water than ordinary grease.

- **Gear oil** (sometimes called gear lube) is a specially designed oil used in transmissions and final drive units, as well as other areas where high friction, high temperature lubrication is required. It is available in a number of viscosities (weights) for various applications.

- **Motor oil**, of course, is the lubricant specially formulated for use in the engine. It normally contains a wide

variety of additives to prevent corrosion and reduce foaming and wear. Motor oil comes in various weights (viscosity ratings) of from 5 to 80. The recommended weight of the oil depends on the seasonal temperature and the demands on the engine. Light oil is used in cold climates and under light load conditions; heavy oil is used in hot climates and where high loads are encountered. Multi-viscosity oils are designed to have characteristics of both light and heavy oils and are available in a number of weights from 5W-20 to 20W-50.

- **Petrol additives** perform several functions, depending on their chemical makeup. They usually contain solvents that help dissolve gum and varnish that build up on carburettor and inlet parts. They also serve to break down carbon deposits that form on the inside surfaces of the combustion chambers. Some additives contain upper cylinder lubricants for valves and piston rings.

- **Brake and clutch fluid** is a specially formulated hydraulic fluid that can withstand the heat and pressure encountered in brake/clutch systems. Care must be taken that this fluid does not come in contact with painted surfaces or plastics. An opened container should always be resealed to prevent contamination by water or dirt.

- **Chain lubricants** are formulated especially for use on motorcycle final drive chains. A good chain lube should adhere well and have good penetrating qualities to be effective as a lubricant inside the chain and on the side plates, pins and rollers. Most chain lubes are either the foaming type or quick drying type and are usually marketed as sprays. Take care to use a lubricant marked as being suitable for O-ring chains.

- **Degreasers** are heavy duty solvents used to remove grease and grime that may accumulate on engine and frame components. They can be sprayed or

brushed on and, depending on the type, are rinsed with either water or solvent.

- **Solvents** are used alone or in combination with degreasers to clean parts and assemblies during repair and overhaul. The home mechanic should use only solvents that are non-flammable and that do not produce irritating fumes.

- **Gasket sealing compounds** may be used in conjunction with gaskets, to improve their sealing capabilities, or alone, to seal metal-to-metal joints. Many gasket sealers can withstand extreme heat, some are impervious to petrol and lubricants, while others are capable of filling and sealing large cavities. Depending on the intended use, gasket sealers either dry hard or stay relatively soft and pliable. They are usually applied by hand, with a brush, or are sprayed on the gasket sealing surfaces.

- **Thread locking compound** is an adhesive locking compound that prevents threaded fasteners from loosening because of vibration. It is available in a variety of types for different applications.

- **Moisture dispersants** are usually sprays that can be used to dry out electrical components such as the fuse block and wiring connectors. Some types can also be used as treatment for rubber and as a lubricant for hinges, cables and locks.

- **Waxes and polishes** are used to help protect painted and plated surfaces from the weather. Different types of paint may require the use of different types of wax polish. Some polishes utilise a chemical or abrasive cleaner to help remove the top layer of oxidised (dull) paint on older vehicles. In recent years, many non-wax polishes (that contain a wide variety of chemicals such as polymers and silicones) have been introduced. These non-wax polishes are usually easier to apply and last longer than conventional waxes and polishes.



## About the MOT Test

In the UK, all vehicles more than three years old are subject to an annual test to ensure that they meet minimum safety requirements. A current test certificate must be issued before a machine can be used on public roads, and is required before a road fund licence can be issued. Riding without a current test certificate will also invalidate your insurance.

For most owners, the MOT test is an annual cause for anxiety, and this is largely due to owners not being sure what needs to be checked prior to submitting the motorcycle for testing. The simple answer is that a fully roadworthy motorcycle will have no difficulty in passing the test.

This is a guide to getting your motorcycle through the MOT test. Obviously it will not be possible to examine the motorcycle to the same standard as the professional MOT

tester, particularly in view of the equipment required for some of the checks. However, working through the following procedures will enable you to identify any problem areas before submitting the motorcycle for the test.

It has only been possible to summarise the test requirements here, based on the regulations in force at the time of printing. Test standards are becoming increasingly stringent, although there are some exemptions for older vehicles. More information about the MOT test can be obtained from the TSO publications, *How Safe is your Motorcycle* and *The MOT Inspection Manual for Motorcycle Testing*.

Many of the checks require that one of the wheels is raised off the ground. If the motorcycle doesn't have a centre stand, note that an auxiliary stand will be required. Additionally, the help of an assistant may prove useful.

Certain exceptions apply to machines under 50 cc, machines without a lighting system, and Classic bikes - if in doubt about any of the requirements listed below seek confirmation from an MOT tester prior to submitting the motorcycle for the test.

Check that the frame number is clearly visible.

### HAYNES HiNT

*If a component is in borderline condition, the tester has discretion in deciding whether to pass or fail it. If the motorcycle presented is clean and evidently well cared for, the tester may be more inclined to pass a borderline component than if the motorcycle is scruffy and apparently neglected.*

## Electrical System

### Lights, turn signals, horn and reflector

✓ With the ignition on, check the operation of the following electrical components. **Note:** The electrical components on certain small-capacity machines are powered by the generator, requiring that the engine is run for this check.

- Headlight and tail light.** Check that both illuminate in the low and high beam switch positions.
  - Position lights.** Check that the front position (or sidelight) and tail light illuminate in this switch position.
  - Turn signals.** Check that all flash at the correct rate, and that the warning light(s) function correctly. Check that the turn signal switch works correctly.
  - Hazard warning system (where fitted).** Check that all four turn signals flash in this switch position.
  - Brake stop light.** Check that the light comes on when the front and rear brakes are independently applied. Models first used on or after 1st April 1986 must have a brake light switch on each brake.
  - Horn.** Check that the sound is continuous and of reasonable volume.
- ✓ Check that there is a red reflector on the rear of the machine, either mounted separately or as part of the tail light lens.
- ✓ Check the condition of the headlight, tail light and turn signal lenses.

### Headlight beam height


✓ The MOT tester will perform a headlight beam height check using specialised beam setting equipment (see illustration 1). This equipment will not be available to the home mechanic, but if you suspect that the headlight is incorrectly set or may have been maladjusted in the past, you can perform a rough test as follows.

✓ Position the bike in a straight line facing a brick wall. The bike must be off its stand, upright and with a rider seated. Measure the height from the ground to the centre of the headlight and mark a horizontal line on the wall at this height. Position the motorcycle 3.8 metres from the wall and draw a vertical



Headlight beam height checking equipment

line up the wall central to the centreline of the motorcycle. Switch to dipped beam and check that the beam pattern falls slightly lower than the horizontal line and to the left of the vertical line (see illustration 2).



Home workshop beam alignment check



# Exhaust System and Final Drive

## Exhaust

- ✓ Check that the exhaust mountings are secure and that the system does not foul any of the rear suspension components.
- ✓ Start the motorcycle. When the revs are increased, check that the exhaust is neither holed nor leaking from any of its joints. On a linked system, check that the collector box is not leaking due to corrosion.

✓ Note that the exhaust decibel level ("loudness" of the exhaust) is assessed at the discretion of the tester. If the motorcycle was first used on or after 1st January 1985 the silencer must carry the BSAU 193 stamp, or a marking relating to its make and model, or be of OE (original equipment) manufacture. If the silencer is marked NOT FOR ROAD USE, RACING USE ONLY or similar, it will fail the MOT.

## Final drive

- ✓ On chain or belt drive machines, check that the chain/belt is in good condition and does not have excessive slack. Also check that the sprocket is securely mounted on the rear wheel hub. Check that the chain/belt guard is in place.
- ✓ On shaft drive bikes, check for oil leaking from the drive unit and fouling the rear tyre.

# Steering and Suspension

## Steering

- ✓ With the front wheel raised off the ground, rotate the steering from lock to lock. The handlebar or switches must not contact the fuel tank or be close enough to trap the rider's hand. Problems can be caused by damaged lock stops on the lower yoke and frame, or by the fitting of non-standard handlebars.
- ✓ When performing the lock to lock check, also ensure that the steering moves freely without drag or notchiness. Steering movement can be impaired by poorly routed cables, or by overtight head bearings or worn bearings. The tester will perform a check of the steering head bearing lower race by mounting the front wheel on a surface plate, then performing a lock to

lock check with the weight of the machine on the lower bearing (see illustration 3).

- ✓ Grasp the fork sliders (lower legs) and attempt to push and pull on the forks (see



Front wheel mounted on a surface plate for steering head bearing lower race check

illustration 4). Any play in the steering head bearings will be felt. Note that in extreme cases, wear of the front fork bushes can be misinterpreted for head bearing play.


- ✓ Check that the handlebars are securely mounted.
- ✓ Check that the handlebar grip rubbers are secure. They should be bonded to the bar left end and to the throttle cable pulley on the right end.

## Front suspension

- ✓ With the motorcycle off the stand, hold the front brake on and pump the front forks up and down (see illustration 5). Check that they are adequately damped.




Checking the steering head bearings for freeplay



Hold the front brake on and pump the front forks up and down to check operation





Inspect the area around the fork dust seal for oil leakage (arrow)



Bounce the rear of the motorcycle to check rear suspension operation



Checking for rear suspension linkage play

✓ Inspect the area above and around the front fork oil seals (see illustration 6). There should be no sign of oil on the fork tube (stanchion) nor leaking down the slider (lower

leg). On models so equipped, check that there is no oil leaking from the anti-dive units.

✓ On models with swingarm front suspension, check that there is no freeplay in the linkage when moved from side to side.

#### Rear suspension

✓ With the motorcycle off the stand and an assistant supporting the motorcycle by its handlebars, bounce the rear suspension (see illustration 7). Check that the suspension components do not foul on any of the cycle parts and check that the shock absorber(s) provide adequate damping.


✓ Visually inspect the shock absorber(s) and

check that there is no sign of oil leakage from its damper. This is somewhat restricted on certain single shock models due to the location of the shock absorber.

✓ With the rear wheel raised off the ground, grasp the wheel at the highest point and attempt to pull it up (see illustration 8). Any play in the swingarm pivot or suspension linkage bearings will be felt as movement.

**Note:** Do not confuse play with actual suspension movement. Failure to lubricate suspension linkage bearings can lead to bearing failure (see illustration 9).

✓ With the rear wheel raised off the ground, grasp the swingarm ends and attempt to move the swingarm from side to side and forwards and backwards - any play indicates wear of the swingarm pivot bearings (see illustration 10).




Worn suspension linkage pivots (arrows) are usually the cause of play in the rear suspension



Grasp the swingarm at the ends to check for play in its pivot bearings





Brake pad wear can usually be viewed without removing the caliper. Most pads have wear indicator grooves (1) and some also have indicator tangs (2)



On drum brakes, check the angle of the operating lever with the brake fully applied. Most drum brakes have a wear indicator pointer and scale.

## Brakes, Wheels and Tyres

### Brakes

- ✓ With the wheel raised off the ground, apply the brake then free it off, and check that the wheel is about to revolve freely without brake drag.
- ✓ On disc brakes, examine the disc itself. Check that it is securely mounted and not cracked.
- ✓ On disc brakes, view the pad material through the caliper mouth and check that the pads are not worn down beyond the limit (see illustration 11).
- ✓ On drum brakes, check that when the brake is applied the angle between the operating lever and cable or rod is not too great (see illustration 12). Check also that the operating lever doesn't foul any other components.
- ✓ On disc brakes, examine the flexible


hoses from top to bottom. Have an assistant hold the brake on so that the fluid in the hose is under pressure, and check that there is no sign of fluid leakage, bulges or cracking. If there are any metal brake pipes or unions, check that these are free from corrosion and damage. Where a brake-linked anti-dive system is fitted, check the hoses to the anti-dive in a similar manner.

- ✓ Check that the rear brake torque arm is secure and that its fasteners are secured by self-locking nuts or castellated nuts with split-pins or R-pins (see illustration 13).
- ✓ On models with ABS, check that the self-check warning light in the instrument panel works.
- ✓ The MOT tester will perform a test of the motorcycle's braking efficiency based on a calculation of rider and motorcycle weight. Although this cannot be carried out at home, you can at least ensure that the braking systems are properly maintained. For hydraulic disc brakes, check the fluid level,


lever/pedal feel (bleed of air if its spongy) and pad material. For drum brakes, check adjustment, cable or rod operation and shoe lining thickness.

### Wheels and tyres

- ✓ Check the wheel condition. Cast wheels should be free from cracks and if of the built-up design, all fasteners should be secure. Spoked wheels should be checked for broken, corroded, loose or bent spokes.
- ✓ With the wheel raised off the ground, spin the wheel and visually check that the tyre and wheel run true. Check that the tyre does not foul the suspension or mudguards.
- ✓ With the wheel raised off the ground, grasp the wheel and attempt to move it about the axle (spindle) (see illustration 14). Any play felt here indicates wheel bearing failure.




Brake torque arm must be properly secured at both ends



Check for wheel bearing play by trying to move the wheel about the axle (spindle)







Checking the tyre tread depth



Tyre direction of rotation arrow can be found on tyre sidewall



Castellated type wheel axle (spindle) nut must be secured by a split pin or R-pin



Two straightedges are used to check wheel alignment

✓ Check the tyre tread depth, tread condition and sidewall condition (see illustration 15).

✓ Check the tyre type. Front and rear tyre

types must be compatible and be suitable for road use. Tyres marked NOT FOR ROAD USE, COMPETITION USE ONLY or similar, will fail the MOT.

✓ If the tyre sidewall carries a direction of rotation arrow, this must be pointing in the direction of normal wheel rotation (see illustration 16).

✓ Check that the wheel axle (spindle) nuts (where applicable) are properly secured. A self-locking nut or castellated nut with a split-pin or R-pin can be used (see illustration 17).

✓ Wheel alignment is checked with the motorcycle off the stand and a rider seated. With the front wheel pointing straight ahead, two perfectly straight lengths of metal or wood and placed against the sidewalls of both tyres (see illustration 18). The gap each side of the front tyre must be equidistant on both sides. Incorrect wheel alignment may be due to a cocked rear wheel (often as the result of poor chain adjustment) or in extreme cases, a bent frame.

## General checks and condition

✓ Check the security of all major fasteners, bodypanels, seat, fairings (where fitted) and mudguards.

✓ Check that the rider and pillion footrests, handlebar levers and brake pedal are securely mounted.

✓ Check for corrosion on the frame or any load-bearing components. If severe, this may affect the structure, particularly under stress.

## Sidecars

A motorcycle fitted with a sidecar requires additional checks relating to the stability of the machine and security of attachment and

swivel joints, plus specific wheel alignment (toe-in) requirements. Additionally, tyre and lighting requirements differ from conventional

motorcycle use. Owners are advised to check MOT test requirements with an official test centre.



# Preparing for storage

## Before you start

If repairs or an overhaul is needed, see that this is carried out now rather than left until you want to ride the bike again.

Give the bike a good wash and scrub all dirt from its underside. Make sure the bike dries completely before preparing for storage.

## Engine

● Remove the spark plug(s) and lubricate the cylinder bores with approximately a teaspoon of motor oil using a spout-type oil can (see illustration 1). Reinstall the spark plug(s). Crank the engine over a couple of times to coat the piston rings and bores with oil. If the bike has a kickstart, use this to turn the engine over. If not, flick the kill switch to the OFF position and crank the engine over on the starter (see illustration 2). If the nature on the ignition system prevents the starter operating with the kill switch in the OFF position,

remove the spark plugs and fit them back in their caps; ensure that the plugs are earthed (grounded) against the cylinder head when the starter is operated (see illustration 3).



**Warning:** It is important that the plugs are earthed (grounded) away from the spark plug holes otherwise there is a risk of atomised fuel from the cylinders igniting.



**On a single cylinder four-stroke engine, you can seal the combustion chamber completely by positioning the piston at TDC on the compression stroke.**

● Drain the carburettor(s) otherwise there is a risk of jets becoming blocked by gum deposits from the fuel (see illustration 4).

● If the bike is going into long-term storage, consider adding a fuel stabiliser to the fuel in the tank. If the tank is drained completely, corrosion of its internal surfaces may occur if left unprotected for a long period. The tank can be treated with a rust preventative especially for this purpose. Alternatively, remove the tank and pour half a litre of motor oil into it, install the filler cap and shake the tank to coat its internals with oil before draining off the excess. The same effect can also be achieved by spraying WD40 or a similar water-dispersant around the inside of the tank via its flexible nozzle.

● Make sure the cooling system contains the correct mix of antifreeze. Antifreeze also contains important corrosion inhibitors.


● The air intakes and exhaust can be sealed off by covering or plugging the openings. Ensure that you do not seal in any condensation; run the engine until it is hot,



Squirt a drop of motor oil into each cylinder



Flick the kill switch to OFF ...



... and ensure that the metal bodies of the plugs (arrows) are earthed against the cylinder head




Connect a hose to the carburettor float chamber drain stub (arrow) and unscrew the drain screw






Exhausts can be sealed off with a plastic bag



Disconnect the negative lead (A) first, followed by the positive lead (B)



Use a suitable battery charger - this kit also assess battery condition

- Check the electrolyte level and top up if necessary (conventional refillable batteries). Clean the terminals.
- Store the battery off the motorcycle and away from any sources of fire. Position a wooden block under the battery if it is to sit on the ground.
- Give the battery a trickle charge for a few hours every month (see illustration 7).

### Tyres

- Place the bike on its centrestand or an auxiliary stand which will support the motorcycle in an upright position. Position wood blocks under the tyres to keep them off the ground and to provide insulation from damp. If the bike is being put into long-term storage, ideally both tyres should be off the ground; not only will this protect the tyres, but will also ensure that no load is placed on the steering head or wheel bearings.
- Deflate each tyre by 5 to 10 psi, no more or the beads may unseat from the rim, making subsequent inflation difficult on tubeless tyres.

### Pivots and controls

- Lubricate all lever, pedal, stand and

- footrest pivot points. If grease nipples are fitted to the rear suspension components, apply lubricant to the pivots.
- Lubricate all control cables.

### Cycle components

- Apply a wax protectant to all painted and plastic components. Wipe off any excess, but don't polish to a shine. Where fitted, clean the screen with soap and water.
- Coat metal parts with Vaseline (petroleum jelly). When applying this to the fork tubes, do not compress the forks otherwise the seals will rot from contact with the Vaseline.
- Apply a vinyl cleaner to the seat.

### Storage conditions

- Aim to store the bike in a shed or garage which does not leak and is free from damp.
- Drape an old blanket or bedspread over the bike to protect it from dust and direct contact with sunlight (which will fade paint). This also hides the bike from prying eyes. Beware of tight-fitting plastic covers which may allow condensation to form and settle on the bike.

then switch off and allow to cool. Tape a piece of thick plastic over the silencer end(s) (see illustration 5). Note that some advocate pouring a tablespoon of motor oil into the silencer(s) before sealing them off.

### Battery

- Remove it from the bike - in extreme cases of cold the battery may freeze and crack its case (see illustration 6).

## Getting back on the road

### Engine and transmission

- Change the oil and replace the oil filter. If this was done prior to storage, check that the oil hasn't emulsified - a thick whitish substance which occurs through condensation.
- Remove the spark plugs. Using a spout-type oil can, squirt a few drops of oil into the cylinder(s). This will provide initial lubrication as the piston rings and bores come back into contact. Service the spark plugs, or fit new ones, and install them in the engine.

- Check that the clutch isn't stuck on. The plates can stick together if left standing for some time, preventing clutch operation. Engage a gear and try rocking the bike back and forth with the clutch lever held against the handlebar. If this doesn't work on cable-operated clutches, hold the clutch lever back against the handlebar with a strong elastic band or cable tie for a couple of hours (see illustration 8).

- If the air intakes or silencer end(s) were blocked off, remove the bung or cover used.
- If the fuel tank was coated with a rust



Hold clutch lever back against the handlebar with elastic bands or a cable tie



preventative, oil or a stabiliser added to the fuel, drain and flush the tank and dispose of the fuel sensibly. If no action was taken with the fuel tank prior to storage, it is advised that the old fuel is disposed of since it will go off over a period of time. Refill the fuel tank with fresh fuel.

## Frame and running gear

- Oil all pivot points and cables.
- Check the tyre pressures. They will definitely need inflating if pressures were reduced for storage.
- Lubricate the final drive chain (where applicable).
- Remove any protective coating applied to the fork tubes (stanchions) since this may well destroy the fork seals. If the fork tubes weren't protected and have picked up rust spots, remove them with very fine abrasive paper and refinish with metal polish.
- Check that both brakes operate correctly. Apply each brake hard and check that it's not possible to move the motorcycle forwards, then check that the brake frees off again once released. Brake caliper pistons can stick due to corrosion around the piston head, or on the sliding caliper types, due to corrosion of the slider pins. If the brake doesn't free after repeated operation, take the caliper off for examination. Similarly drum brakes can stick

due to a seized operating cam, cable or rod linkage.

- If the motorcycle has been in long-term storage, renew the brake fluid and clutch fluid (where applicable).
- Depending on where the bike has been stored, the wiring, cables and hoses may have been nibbled by rodents. Make a visual check and investigate disturbed wiring loom tape.

## Battery

- If the battery has been previously removed and given top up charges it can simply be reconnected. Remember to connect the positive cable first and the negative cable last.
- On conventional refillable batteries, if the battery has not received any attention, remove it from the motorcycle and check its electrolyte level. Top up if necessary then charge the battery. If the battery fails to hold a charge and a visual check shows heavy white sulphation of the plates, the battery is probably defective and must be renewed. This is particularly likely if the battery is old. Confirm battery condition with a specific gravity check.
- On sealed (MF) batteries, if the battery has not received any attention, remove it from the motorcycle and charge it according to the information on the battery case. If the battery fails to hold a charge it must be renewed.

## Starting procedure

- If a kickstart is fitted, turn the engine over a couple of times with the ignition OFF to distribute oil around the engine. If no kickstart is fitted, flick the engine kill switch OFF and the ignition ON and crank the engine over a couple of times to work oil around the upper cylinder components. If the nature of the ignition system is such that the starter won't work with the kill switch OFF, remove the spark plugs, fit them back into their caps and earth (ground) their bodies on the cylinder head. Reinstall the spark plugs afterwards.
- Switch the kill switch to RUN, operate the choke and start the engine. If the engine won't start don't continue cranking the engine - not only will this flatten the battery, but the starter motor will overheat. Switch the ignition off and try again later. If the engine refuses to start, go through the fault finding procedures in this manual. **Note:** *If the bike has been in storage for a long time, old fuel or a carburettor blockage may be the problem. Gum deposits in carburettors can block jets - if a carburettor cleaner doesn't prove successful the carburettors must be dismantled for cleaning.*
- Once the engine has started, check that the lights, turn signals and horn work properly.
- Treat the bike gently for the first ride and check all fluid levels on completion. Settle the bike back into the maintenance schedule.



This Section provides an easy reference-guide to the more common faults that are likely to afflict your machine. Obviously, the opportunities are almost limitless for faults to occur as a result of obscure failures, and to try and cover all eventualities would require a book. Indeed, a number have been written on the subject.

Successful troubleshooting is not a mysterious 'black art' but the application of a bit of knowledge combined with a systematic and logical approach to the problem. Approach any troubleshooting by first accurately identifying the symptom and then checking through the list

of possible causes, starting with the simplest or most obvious and progressing in stages to the most complex. Take nothing for granted, but above all apply liberal quantities of common sense.

The main symptom of a fault is given in the text as a major heading below which are listed the various systems or areas which may contain the fault. Details of each possible cause for a fault and the remedial action to be taken are given. Further information should be sought in the relevant Chapter.

### **1 Starter motor problems**

- ☐ Starter motor not rotating
- ☐ Starter motor rotates but engine does not turn over
- ☐ Starter motor and clutch function but engine will not turn over

### **2 Engine does not start when turned over**

- ☐ No fuel flow to carburettor
- ☐ Fuel not reaching cylinder
- ☐ Engine flooding
- ☐ No spark at plug
- ☐ Weak spark at plug
- ☐ Compression low

### **3 Engine stalls after starting**

- ☐ General causes

### **4 Poor running at idle and low speed**

- ☐ Weak spark at plug or erratic firing
- ☐ Fuel/air mixture incorrect
- ☐ Compression low

### **5 Acceleration poor**

- ☐ General causes

### **6 Poor running or lack of power at high speeds**

- ☐ Weak spark at plug or erratic firing
- ☐ Fuel/air mixture incorrect
- ☐ Compression low

### **7 Knocking or pinking**

- ☐ General causes

### **8 Overheating**

- ☐ Firing incorrect
- ☐ Fuel/air mixture incorrect
- ☐ Lubrication inadequate
- ☐ Miscellaneous causes

### **9 Clutch operating problems**

- ☐ Clutch slip
- ☐ Clutch drag

### **10 Gear selection problems**

- ☐ Gear lever does not return
- ☐ Gear selection difficult or impossible
- ☐ Jumping out of gear
- ☐ Overselection

### **11 Abnormal engine noise**

- ☐ Knocking or pinking
- ☐ Piston slap or rattling from cylinder
- ☐ Valve noise or tapping from cylinder head
- ☐ Other noises

### **12 Abnormal transmission noise**

- ☐ Clutch noise
- ☐ Transmission noise

### **13 Exhaust smokes excessively**

- ☐ White/blue smoke (caused by oil burning)
- ☐ Black smoke (caused by over-rich mixture)

### **14 Oil pressure indicator lamp goes on**

- ☐ Engine lubrication system failure
- ☐ Electrical system failure

### **15 Poor handling or roadholding**

- ☐ Directional instability
- ☐ Steering bias to left or right
- ☐ Handlebar vibrates or oscillates
- ☐ Poor front fork performance
- ☐ Front fork judder when braking
- ☐ Poor rear suspension performance

### **16 Abnormal frame and suspension noise**

- ☐ Front end noise
- ☐ Rear suspension noise

### **17 Brake problems**

- ☐ Brakes are spongy or ineffective
- ☐ Brakes drag
- ☐ Brake lever or pedal pulsates in operation
- ☐ Disc brake noise
- ☐ Brake induced fork judder

### **18 Electrical problems**

- ☐ Battery dead or weak
- ☐ Battery overcharged
- ☐ Total electrical failure
- ☐ Circuit failure
- ☐ Bulbs blowing repeatedly



# 1 Starter motor problems

## ***Starter motor not rotating***

- ☐ Engine stop switch off.
- ☐ Fuse blown. Check the main fuse located behind the battery side cover.
- ☐ Battery voltage low. Switching on the headlamp and operating the horn will give a good indication of the charge level. If necessary recharge the battery from an external source.
- ☐ Neutral gear not selected. Where a neutral indicator switch is fitted.
- ☐ Faulty neutral indicator switch or clutch interlock switch (where fitted). Check the switch wiring and switches for correct operation.
- ☐ Ignition switch defective. Check switch for continuity and connections for security.
- ☐ Engine stop switch defective. Check switch for continuity in 'Run' position. Fault will be caused by broken, wet or corroded switch contacts. Clean or renew as necessary.
- ☐ Starter button switch faulty. Check continuity of switch. Faults as for engine stop switch.
- ☐ Starter relay (solenoid) faulty. If the switch is functioning correctly a pronounced click should be heard when the starter button is depressed. This presupposes that current is flowing to the solenoid when the button is depressed.
- ☐ Wiring open or shorted. Check first that the battery terminal connections are tight and corrosion free. Follow this by checking that all wiring connections are dry, tight and corrosion free. Check also for frayed or broken wiring. Occasionally a wire may become trapped between two moving components, particularly in the

vicinity of the steering head, leading to breakage of the internal core but leaving the softer but more resilient outer cover intact. This can cause mysterious intermittent or total power loss.

- ☐ Starter motor defective. A badly worn starter motor may cause high current drain from a battery without the motor rotating. If current is found to be reaching the motor, after checking the starter button and starter relay, suspect a damaged motor. The motor should be removed for inspection.

## ***Starter motor rotates but engine does not turn over***

- ☐ Starter motor clutch defective. Suspect jammed or worn engagement rollers, plungers and springs.
- ☐ Damaged starter motor drive train. Inspect and renew component where necessary. Failure in this area is unlikely.

## ***Starter motor and clutch function but engine will not turn over***

- ☐ Engine seized. Seizure of the engine is always a result of damage to internal components due to lubrication failure, or component breakage resulting from abuse, neglect or old age. A seizing or partially seized component may go un-noticed until the engine has cooled down and an attempt is made to restart the engine. Suspect first seizure of the valves, valve gear and the pistons. Instantaneous seizure whilst the engine is running indicates component breakage. In either case major dismantling and inspection will be required.

# 2 Engine does not start when turned over

## ***No fuel flow to carburettor***

- ☐ No fuel or insufficient fuel in tank.
- ☐ Fuel tap lever position incorrectly selected.
- ☐ Float chambers require priming after running dry (vacuum taps only).
- ☐ Tank filler cap air vent obstructed. Usually caused by dirt or water. Clean the vent orifice.
- ☐ Fuel tap or filter blocked. Blockage may be due to accumulation of rust or paint flakes from the tank's inner surface or of foreign matter from contaminated fuel. Remove the tap and clean it and the filter. Look also for water droplets in the fuel.
- ☐ Fuel line blocked. Blockage of the fuel line is more likely to result from a kink in the line rather than the accumulation of debris.
- ☐ Faulty fuel pump (where fitted).

## ***Fuel not reaching cylinder***

- ☐ Float chamber not filling. Caused by float needle or floats sticking in up position. This may occur after the machine has been left standing for an extended length of time allowing the fuel to evaporate. When this occurs a gummy residue is often left which hardens to a varnish-like substance. This condition may be worsened by corrosion and crystalline deposits produced prior to the total evaporation of contaminated fuel. Sticking of the float needle may also be caused by wear. In any case removal of the float chamber will be necessary for inspection and cleaning.
- ☐ Blockage in starting circuit, slow running circuit or jets. Blockage of these items may be attributable to debris from the fuel tank by-

passing the filter system or to gumming up as described in paragraph 1. Water droplets in the fuel will also lock jets and passages. The carburettor should be dismantled for cleaning.

- ☐ Fuel level too low. The fuel level in the float chamber is controlled by float height. The float height may increase with wear or damage but will never reduce, thus a low float height is an inherent rather than developing condition. Check the float height and make any necessary adjustment.

## ***Engine flooding***

- ☐ Float valve needle worn or stuck open. A piece of rust or other debris can prevent correct seating of the needle against the valve seat thereby permitting an uncontrolled flow of fuel. Similarly, a worn needle or needle seat will prevent valve closure. Dismantle the carburettor float bowl for cleaning and, if necessary, renewal of the worn components.
- ☐ Fuel level too high. The fuel level is controlled by the float height which may increase due to wear of the float needle, pivot pin or operating tang. Check the float height, and make any necessary adjustment. A leaking float will cause an increase in fuel level, and thus should be renewed.
- ☐ Cold starting mechanism. Check the choke (starter mechanism) for correct operation. If the mechanism jams in the 'On' position subsequent starting of a hot engine will be difficult.
- ☐ Blocked air filter. A badly restricted air filter will cause flooding. Check the filter and clean or renew as required. A collapsed inlet hose will have a similar effect.



## 2 Engine does not start when turned over (continued)

### No spark at plug

- ☐ Ignition switch not on.
- ☐ Engine stop switch off.
- ☐ Fuse blown. Check fuse for ignition circuit. See wiring diagram.
- ☐ Battery voltage low. The current draw required by a starter motor is sufficiently high that an under-charged battery may not have enough spare capacity to provide power for the ignition circuit during starting.
- ☐ Starter motor inefficient. A starter motor with worn brushes and a worn or dirty commutator will draw excessive amounts of current causing power starvation in the ignition system. See the preceding paragraph. Starter motor overhaul will be required.
- ☐ Spark plug failure. Clean the spark plug thoroughly and reset the electrode gap. Refer to the spark plug section in Chapter 1. If the spark plug shorts internally or has sustained visible damage to the electrodes, core or ceramic insulator it should be renewed. On rare occasions a plug that appears to spark vigorously will fail to do so when refitted to the engine and subjected to the compression pressure in the cylinder.
- ☐ Spark plug cap or high tension (HT) lead faulty. Check condition and security. Replace if deterioration is evident.
- ☐ Spark plug cap loose. Check that the spark plug cap fits securely over the plug and, where fitted, the screwed terminal on the plug end is secure.
- ☐ Shorting due to moisture. Certain parts of the ignition system are susceptible to shorting when the machine is ridden or parked in wet weather. Check particularly the area from the spark plug cap back to the ignition coil. A water dispersant spray may be used to dry out waterlogged components. Recurrence of the problem can be prevented by using an ignition sealant spray after drying out and cleaning.
- ☐ Ignition or stop switch shorted. May be caused by water, corrosion or wear. Water dispersant and contact cleaning sprays may be used. If this fails to overcome the problem dismantling and visual inspection of the switches will be required.
- ☐ Shorting or open circuit in wiring. Failure in any wire connecting any of the ignition components will cause ignition malfunction. Check also that all connections are clean, dry and tight.
- ☐ Ignition coil failure. Check the coil, referring to Chapter 5.
- ☐ Pulser coil failure. Check the coil(s), referring to Chapter 5.
- ☐ IC ignitor unit failure. Check the unit as described in Chapter 5.

### Weak spark at plug

- ☐ Feeble sparking at the plug may be caused by any of the faults mentioned in the preceding sub-section other than those items in paragraphs 1 to 3. Check first the spark plugs, these being the most likely culprits.

### Compression low

- ☐ Spark plug loose. This will be self-evident on inspection, and may be accompanied by a hissing noise when the engine is turned over. Remove the plug and check that the threads in the cylinder head are not damaged. Check also that the plug sealing washer is in good condition.
- ☐ Cylinder head gasket leaking. This condition is often accompanied by a high pitched squeak from around the cylinder head and oil loss, and may be caused by insufficiently tightened cylinder head fasteners, a warped cylinder head or mechanical failure of the gasket material. Re-torquing the fasteners to the correct specification may seal the leak in some instances but if damage has occurred this course of action will provide, at best, only a temporary cure.
- ☐ Valve not seating correctly. The failure of a valve to seat may be caused by insufficient valve clearance, pitting of the valve seat or face, carbon deposits on the valve seat or seizure of the valve stem or valve gear components. Valve spring breakage will also prevent correct valve closure. The valve clearances should be checked first and then, if these are found to be in order, further dismantling will be required to inspect the relevant components for failure.
- ☐ Cylinder, piston and ring wear. Compression pressure will be lost if any of these components are badly worn. Wear in one component is invariably accompanied by wear in another. A top end overhaul will be required.
- ☐ Piston rings sticking or broken. Sticking of the piston rings may be caused by seizure due to lack of lubrication or heating as a result of poor carburation or incorrect fuel type. Gumming of the rings may result from lack of use, or carbon deposits in the ring grooves. Broken rings result from over-revving, overheating or general wear. In either case a top-end overhaul will be required.

## 3 Engine stalls after starting

### General causes

- ☐ Improper cold start mechanism operation. Check that the operating controls function smoothly and, where applicable, are correctly adjusted. A cold engine may not require application of an enriched mixture to start initially but may balk without choke once firing. Likewise a hot engine may start with an enriched mixture but will stop almost immediately if the choke is inadvertently in operation.
- ☐ Ignition malfunction. See 'Weak spark at plug'.
- ☐ Carburettor incorrectly adjusted. Maladjustment of the mixture strength or idle speed may cause the engine to stop immediately after starting. See Chapter 4.
- ☐ Fuel contamination. Check for filter blockage by debris or water which reduces, but does not completely stop, fuel flow or blockage of the slow speed circuit in the carburettor by the same agents. If water is present it can often be seen as droplets in the bottom of the float bowl. Clean the filter and, where water is in evidence, drain and flush the fuel tank and float bowl.
- ☐ Intake air leak. Check for security of the carburettor mounting and hose connections, and for cracks or splits in the hoses. Check also that the carburettor top is secure and that the vacuum gauge adaptor plug (where fitted) is tight.
- ☐ Air filter blocked or omitted. A blocked filter will cause an over-rich mixture; the omission of a filter will cause an excessively weak mixture. Both conditions will have a detrimental effect on carburation. Clean or renew the filter as necessary.
- ☐ Fuel filler cap or vent blocked. Usually caused by dirt or water. Clean the vent orifice.



## 4 Poor running at idle and low speed

### Weak spark at plug or erratic firing

- ☐ Battery voltage low. In certain conditions low battery charge, especially when coupled with a badly sulphated battery, may result in misfiring. If the battery is in good general condition it should be recharged; an old battery suffering from sulphated plates should be renewed.
- ☐ Spark plug fouled, faulty or incorrectly adjusted. See 'No spark at plug' in Section 2 or refer to Chapter 1.
- ☐ Spark plug cap or high tension lead shorting. Check the condition of both these items ensuring that they are in good condition and dry and that the cap is fitted correctly.
- ☐ Spark plug type incorrect. Fit plug of correct type and heat range as given in Specifications. In certain conditions a plug of hotter or colder type may be required for normal running.
- ☐ Faulty ignition coil. Partial failure of the coil internal insulation will diminish the performance of the coil. No repair is possible, a new component must be fitted.

### Compression low

- ☐ See Section 2.

### Fuel/air mixture incorrect

- ☐ Intake air leak. See Section 3.
- ☐ Mixture strength incorrect. Adjust slow running mixture strength using pilot adjustment screw.
- ☐ Carburettor synchronisation.
- ☐ Pilot jet or slow running circuit blocked. The carburettor should be removed and dismantled for thorough cleaning. Blow through all jets and air passages with compressed air to clear obstructions.
- ☐ Air cleaner clogged or omitted. Clean or fit air cleaner element as necessary. Check also that the element and air filter cover are correctly seated.
- ☐ Cold start mechanism in operation. Check that the choke has not been left on inadvertently and the operation is correct. Check the operating cable free play as described in Chapter 1.
- ☐ Fuel level too high or too low. Check the float height and adjust as necessary. See 'Engine flooding' in Section 2.
- ☐ Fuel tank air vent obstructed. Obstruction usually caused by dirt or water. Clean vent orifice.
- ☐ Valve clearance incorrect. Check, and if necessary, adjust, the clearances.

## 5 Acceleration poor

### General causes

- ☐ All items as for previous Section.
- ☐ Sticking throttle vacuum piston. Examine carburettors, referring to Chapter 4.

- ☐ Brakes binding. Usually caused by maladjustment or partial seizure of the operating mechanism due to poor maintenance. Check brake adjustment (where applicable). A bent wheel spindle or warped brake disc can produce similar symptoms.

## 6 Poor running or lack of power at high speeds

### Weak spark at plug or erratic firing

- ☐ All items as for Section 4.
- ☐ HT lead insulation failure. Insulation failure of the HT lead and spark plug cap due to old age or damage can cause shorting when the engine is driven hard. This condition may be less noticeable, or not noticeable at all at lower engine speeds.

### Compression low

- ☐ See Section 2.

### Fuel/air mixture incorrect

- ☐ All items as for Section 4, with the exception of items 2 and 4.
- ☐ Main jet blocked. Debris from contaminated fuel, or from the fuel tank, and water in the fuel can block the main jet. Clean the fuel filter, the float bowl area, and if water is present, flush and refill the fuel tank.

- ☐ Main jet is the wrong size. The standard carburettor jetting is for sea level atmospheric pressure. For high altitudes, usually above 5000 ft, a smaller main jet will be required.
- ☐ Jet needle and needle jet worn. These can be renewed individually but should be renewed as a pair. Renewal of both items requires partial dismantling of the carburettor.
- ☐ Air bleed holes blocked. Dismantle carburettor and use compressed air to blow out all air passages.
- ☐ Reduced fuel flow. A reduction in the maximum fuel flow from the fuel tank to the carburettor will cause fuel starvation, proportionate to the engine speed. Check for blockages through debris or a kinked fuel line.
- ☐ Vacuum diaphragm split. Renew.

## 7 Knocking or pinking

### General causes

- ☐ Carbon build-up in combustion chamber. After high mileages have been covered a large accumulation of carbon may occur. This may glow red hot and cause premature ignition of the fuel/air mixture, in advance of normal firing by the spark plug. Cylinder head removal will be required to allow inspection and cleaning.
- ☐ Fuel incorrect. A low grade fuel, or one of poor quality may result in compression induced detonation of the fuel resulting in knocking and pinking noises. Old fuel can cause similar problems. A too highly leaded fuel will reduce detonation but will accelerate deposit

- formation in the combustion chamber and may lead to early pre-ignition as described in item 1.
- ☐ Spark plug heat range incorrect. Uncontrolled pre-ignition can result from the use of a spark plug the heat range of which is too hot.
- ☐ Weak mixture. Overheating of the engine due to a weak mixture can result in pre-ignition occurring where it would not occur when engine temperature was within normal limits. Maladjustment, blocked jets or passages and air leaks can cause this condition.



## 8 Overheating

### Firing incorrect

- ☐ Spark plug fouled, defective or maladjusted. See 'No spark at plug' in Section 2.
- ☐ Spark plug type incorrect. Refer to the Specifications and ensure that the correct plug type is fitted.

### Lubrication inadequate

- ☐ Engine oil too low. Not only does the oil serve as a lubricant by preventing friction between moving components, but it also acts as a coolant. Check the oil level and replenish.
- ☐ Engine oil overworked. The lubricating properties of oil are lost slowly during use as a result of changes resulting from heat and also contamination. Always change the oil at the recommended interval.
- ☐ Engine oil of incorrect viscosity or poor quality. Always use the recommended viscosity and type of oil.
- ☐ Oil filter and filter by-pass valve blocked. Renew filter and clean the bypass valve.

### Fuel/air mixture incorrect

- ☐ Slow speed mixture strength incorrect. Adjust pilot air screw.
- ☐ Main jet wrong size. The carburettor is jetted for sea level atmospheric conditions. For high altitudes, usually above 5000 ft, a smaller main jet will be required.
- ☐ Air filter badly fitted or omitted. Check that the filter element is in place and that it and the air filter box cover are sealing correctly. Any leaks will cause a weak mixture.
- ☐ Induction air leaks. Check the security of the carburettor mountings and hose connections, and for cracks and splits in the hoses. Check also that the carburettor top is secure and that the vacuum gauge adaptor plug (where fitted) is tight.
- ☐ Fuel level too low. See 'Fuel not reaching cylinder' in Section 2.
- ☐ Fuel tank filler cap air vent obstructed. Clear blockage.

### Miscellaneous causes

- ☐ Radiator clogged. A build-up of mud in the radiator matrix will decrease the cooling capabilities of the fins. Clean the radiator as described in Chapter 3.

## 9 Clutch operating problems

### Clutch slip

- ☐ Excess fluid in reservoir. Check fluid level as described in 'Daily (pre-ride) checks' at the beginning of this Manual.
- ☐ Friction plates worn or warped. Overhaul clutch assembly, replacing plates out of specification.
- ☐ Steel plates worn or warped. Overhaul clutch assembly, replacing plates out of specification.
- ☐ Clutch springs broken or worn. Old or heat-damaged (from slipping clutch) springs should be replaced with new ones.
- ☐ Clutch centre and outer drum worn. Severe indentation by the clutch plate tangs of the channels in the centre and drum will cause snagging of the plates preventing correct engagement. If this damage occurs, renewal of the worn components is required.
- ☐ Lubricant incorrect. Use of a transmission lubricant other than that specified may allow the plates to slip.

### Clutch drag

- ☐ Insufficient fluid in reservoir. Top up as described in 'Daily (pre-ride) checks' at the beginning of this Manual.
- ☐ Air in hydraulic fluid. Bleed the system as described in Chapter 7.
- ☐ Clutch plates warped or damaged. This will cause a drag on the clutch, causing the machine to creep. Overhaul clutch assembly (Chapter 2).
- ☐ Clutch spring tension uneven. Usually caused by a sagged or broken spring. Check and replace springs (Chapter 2).

- ☐ Engine oil deteriorated. Badly contaminated engine oil and a heavy deposit of oil sludge and carbon on the plates will cause plate sticking. The oil recommended for this machine is of the detergent type, therefore it is unlikely that this problem will arise unless regular oil changes are neglected.
- ☐ Engine oil viscosity too high. Drag in the plates will result from the use of an oil with too high a viscosity. In very cold weather clutch drag may occur until the engine has reached operating temperature.
- ☐ Clutch centre and outer drum worn. Indentation by the clutch plate tangs of the channels in the centre and drum will prevent easy plate disengagement. If the damage is light the affected areas may be dressed with a fine file. More pronounced damage will necessitate renewal of the components.
- ☐ Clutch drum seized to shaft. Lack of lubrication, severe wear or damage can cause the drum to seize to the shaft. Overhaul of the clutch, and perhaps the transmission, may be necessary to repair damage (Chapter 2).
- ☐ Clutch slave cylinder defective. Worn or damaged piston can stick and fail to return correctly. Overhaul clutch cylinder components (Chapter 2).
- ☐ Loose clutch nut. Causes drum and hub misalignment, putting a drag on the engine. Engagement adjustment continually varies. Overhaul clutch assembly (Chapter 2).



# 10 Gear selection problems

## Gear lever does not return

- ☐ Weak or broken return spring. Renew the spring.
- ☐ Gearchange shaft bent or seized. Distortion of the gearchange shaft often occurs if the machine is dropped heavily on the gear lever. Provided that damage is not severe, straightening of the shaft is permissible.

## Gear selection difficult or impossible

- ☐ Clutch not disengaging fully. See 'Clutch drag' in Section 9.
- ☐ Gearchange shaft bent. This often occurs if the machine is dropped heavily on the gear lever. Straightening of the shaft is permissible if the damage is not too great.
- ☐ Gearchange arms, pawls or pins worn or damaged. Wear or breakage of any of these items may cause difficulty in selecting one or more gears. Overhaul the selector mechanism.
- ☐ Gearchange arm spring broken. Renew spring.
- ☐ Gearchange drum stopper cam or detent arm damage. Failure, rather than wear, of these items may jam the drum thereby preventing gearchanging. The damaged items must be renewed.
- ☐ Selector forks bent or seized. This can be caused by dropping the machine heavily on the gearchange lever or as a result of lack of lubrication. Though rare, bending of a shaft can result from a missed gearchange or false selection at high speed.
- ☐ Selector fork end and pin wear. Pronounced wear of these items and the grooves in the gearchange drum can lead to imprecise selection and, eventually, no selection. Renewal of the worn components will be required.
- ☐ Structural failure. Failure of any one component of the selector rod and change mechanism will result in improper or fouled gear selection.

## Jumping out of gear

- ☐ Detent assembly worn or damaged. Wear of the arms and the cam with which they locate or breakage of the detent springs can cause imprecise gear selection resulting in jumping out of gear. Renew the damaged components.
- ☐ Gear pinion dogs worn or damaged. Rounding off the dog edges and the mating recesses in adjacent pinion can lead to jumping out of gear when under load. The gears should be inspected and renewed. Attempting to reprofile the dogs is not recommended.
- ☐ Selector forks, gearchange drum and pinion grooves worn. Extreme wear of these interconnected items can occur after high mileages especially when lubrication has been neglected. The worn components must be renewed.
- ☐ Gear pinions, bushes and shafts worn. Renew the worn components.
- ☐ Bent gearchange shaft. Often caused by dropping the machine on the gear lever.
- ☐ Gear pinion tooth broken. Chipped teeth are unlikely to cause jumping out of gear once the gear has been selected fully; a tooth which is completely broken off, however, may cause problems in this respect and in any event will cause transmission noise.

## Overselection

- ☐ Pawl spring weak or broken. Renew the spring.
- ☐ Detent arm assemblies worn or broken. Renew the damaged items.
- ☐ Selector limiter claw components (where fitted) worn or damaged. Renew the damaged items.

# 11 Abnormal engine noise

## Knocking or pinking

- ☐ See Section 7.

## Piston slap or rattling from cylinder

- ☐ Cylinder bore/piston clearance excessive. Resulting from wear, partial seizure or improper boring during overhaul. This condition can often be heard as a high, rapid tapping noise when the engine is under little or no load, particularly when power is just beginning to be applied. Reboring to the next correct oversize should be carried out and a new oversize piston fitted.
- ☐ Connecting rod bent. This can be caused by over-revving, trying to start a very badly flooded engine (resulting in a hydraulic lock in the cylinder) or by earlier mechanical failure such as a dropped valve. Attempts at straightening a bent connecting rod from a high performance engine are not recommended. Careful inspection of the crankshaft should be made before renewing the damaged connecting rod.
- ☐ Gudgeon pin, piston boss bore or small-end bearing wear or seizure. Excess clearance or partial seizure between normal moving parts of these items can cause continuous or intermittent tapping noises. Rapid wear or seizure is caused by lubrication starvation resulting from an insufficient engine oil level or oilway blockage.
- ☐ Piston rings worn, broken or sticking. Renew the rings after careful inspection of the piston and bore.

## Valve noise or tapping from the cylinder head

- ☐ Valve clearance incorrect. Adjust the clearances with the engine cold.
- ☐ Valve spring broken or weak. Renew the spring set.
- ☐ Camshaft or cylinder head worn or damaged. The camshaft lobes are the most highly stressed of all components in the engine and are subject to high wear if lubrication becomes inadequate. The bearing surfaces on the camshaft and cylinder head are also sensitive to a lack of lubrication. Lubrication failure due to blocked oilways can occur, but over-enthusiastic revving before engine warm-up is complete is the usual cause.
- ☐ Rocker arm or spindle wear. Rapid wear of a rocker arm, and the resulting need for frequent valve clearance adjustment, indicates breakthrough or failure of the surface hardening on the rocker arm tips. Similar wear in the cam lobes can be expected. Renew the worn components after checking for lubrication failure.
- ☐ Worn camshaft drive components. A rustling noise or light tapping which is not improved by correct re-adjustment of the cam chain tension can be emitted by a worn cam chain or worn sprockets and chain. If uncorrected, subsequent cam chain breakage may cause extensive damage. The worn components must be renewed before wear becomes too far advanced.



# 11 Abnormal engine noise (continued)

## Other noises

- ☐ Big-end bearing wear. A pronounced knock from within the crankcase which worsens rapidly is indicative of big-end bearing failure as a result of extreme normal wear or lubrication failure. Remedial action in the form of a bottom end overhaul should be taken; continuing to run the engine will lead to further damage including the possibility of connecting rod breakage.
- ☐ Main bearing failure. Extreme normal wear or failure of the main bearings is characteristically accompanied by a rumble from the crankcase and vibration felt through the frame and footrests. Renew the worn bearings and carry out a very careful examination of the crankshaft.
- ☐ Crankshaft excessively out of true. A bent crank may result from over-revving or damage from an upper cylinder component or gearbox failure. Damage can also result from dropping the machine on either crankshaft end. Straightening of the crankshaft is not possible in normal circumstances; a replacement item should be fitted.

- ☐ Engine mounting loose. Tighten all the engine mounting nuts and bolts.
- ☐ Cylinder head gasket leaking. The noise most often associated with a leaking head gasket is a high pitched squeaking, although any other noise consistent with gas being forced out under pressure from a small orifice can also be emitted. Gasket leakage is often accompanied by oil seepage from around the mating joint or from the cylinder head holding down bolts and nuts. Leakage into the cam chain tunnel or oil return passages will increase crankcase pressure and may cause oil leakage at joints and oil seals. Also, oil contamination will be accelerated. Leakage results from insufficient or uneven tightening of the cylinder head fasteners, or from random mechanical failure. Retightening to the correct torque figure will, at best, only provide a temporary cure. The gasket should be renewed at the earliest opportunity.
- ☐ Exhaust system leakage. Popping or crackling in the exhaust system, particularly when it occurs with the engine on the overrun, indicates a poor joint either at the cylinder port or at the exhaust pipe/silencer connection. Failure of the gasket or looseness of the clamp should be looked for.

# 12 Abnormal transmission noise

## Clutch noise

- ☐ Clutch outer drum/friction plate tang clearance excessive.
- ☐ Clutch outer drum/spacer clearance excessive.
- ☐ Clutch outer drum/thrust washer clearance excessive.
- ☐ Primary drive gear teeth worn or damaged.
- ☐ Clutch shock absorber assembly worn or damaged.
- ☐ Balancer shaft incorrectly adjusted. Adjust as described in Chapter 2.

## Transmission noise

- ☐ Bearing or bushes worn or damaged. Renew the affected components.
- ☐ Gear pinions worn or chipped. Renew the gear pinions.
- ☐ Metal chips jammed in gear teeth. This can occur when pieces of metal from any failed component are picked up by a meshing pinion. The condition will lead to rapid bearing wear or early gear failure.

- ☐ Engine/transmission oil level too low. Top up immediately to prevent damage to gearbox and engine.
- ☐ Gearchange mechanism worn or damaged. Wear or failure of certain items in the selection and change components can induce mis-selection of gears (see Section 10) where incipient engagement of more than one gear set is promoted. Remedial action, by the overhaul of the gearbox, should be taken without delay.
- ☐ Loose gearbox chain sprocket. Remove the sprocket and check for impact damage to the splines of the sprocket and shaft. Excessive slack between the splines will promote loosening of the securing nut; renewal of the worn components is required. When retightening the nut ensure that it is tightened fully and that the lock washer is bent up against one flat of the nut.
- ☐ Chain snagging on cases or cycle parts. A badly worn chain or one that is excessively loose may snag or smack against adjacent components.

# 13 Exhaust smokes excessively

## White/blue smoke (caused by oil burning)

- ☐ Piston rings worn or broken. Breakage or wear of any ring, but particularly the oil control ring, will allow engine oil past the piston into the combustion chamber. Overhaul the cylinder barrel and piston.
- ☐ Cylinder cracked, worn or scored. These conditions may be caused by overheating, lack of lubrication, component failure or advanced normal wear. The cylinder barrel should be renewed or rebored and the next oversize piston fitted.
- ☐ Valve oil seal damaged or worn. This can occur as a result of valve guide failure or old age. The emission of smoke is likely to occur when the throttle is closed rapidly after acceleration, for instance, when changing gear. Renew the valve oil seals and, if necessary, the valve guides.
- ☐ Valve guides worn. See the preceding paragraph.
- ☐ Engine oil level too high. This increases the crankcase pressure and allows oil to be forced past the piston rings. Often accompanied by seepage of oil at joints and oil seals.
- ☐ Cylinder head gasket blown between cam chain tunnel or oil return passage. Renew the cylinder head gasket.

- ☐ Abnormal crankcase pressure. This may be caused by blocked breather passages or hoses causing back-pressure at high engine revolutions.

## Black smoke (caused by over-rich mixture)

- ☐ Air filter element clogged. Clean or renew the element.
- ☐ Main jet loose or too large. Remove the float chamber to check for tightness of the jet. If the machine is used at high altitudes rejetting will be required to compensate for the lower atmospheric pressure.
- ☐ Cold start mechanism jammed on. Check that the mechanism works smoothly and correctly and that, where fitted, the operating cable is lubricated and not snagged.
- ☐ Fuel level too high. The fuel level is controlled by the float height which can increase as a result of wear or damage. Remove the float bowl and check the float height. Check also that floats have not punctured; a punctured float will lose buoyancy and allow an increased fuel level.
- ☐ Float valve needle stuck open. Caused by dirt or a worn valve. Clean the float chamber or renew the needle and, if necessary, the valve seat.



# 14 Oil pressure indicator lamp goes on

## Engine lubrication system failure

- ☐ Engine oil defective. Oil pump shaft or locating pin sheared off from ingesting debris or seizing from lack of lubrication (low oil level) (Chapter 4).
- ☐ Engine oil screen clogged. Change oil and filter and service pick-up screen (Chapter 2 and Chapter 1).
- ☐ Engine oil level too low. Inspect for leak or other problem causing low oil level and add recommended lubricant (Chapter 2 and 'Daily (pre-ride) checks' at the beginning of this Manual).
- ☐ Engine oil viscosity too low. Very old, thin oil, or an improper weight of oil used in engine. Change to correct lubricant (Chapter 1).

- ☐ Camshaft or journals worn. High wear causing drop in oil pressure. Replace camshaft and/or head. Abnormal wear could be caused by oil starvation at high rpm from low oil level, improper oil weight or type, or loose oil fitting on upper cylinder oil line (Chapters 1 and 3).
- ☐ Crankshaft and/or bearings worn. Same problems as paragraph 5. Overhaul lower end (Chapter 2).
- ☐ Relief valve stuck open. This causes the oil to be dumped back into the sump. Repair or renew (Chapter 4).

## Electrical system failure

- ☐ Oil pressure switch defective. Check switch according to the procedures in Chapter 8. Replace if defective.
- ☐ Oil pressure indicator lamp wiring system defective. Check for pinched, shorted, disconnected or damaged wiring (Chapter 8).

# 15 Poor handling or roadholding

## Directional instability

- ☐ Suspension settings incorrect. Check and adjust as described in Chapter 1.
- ☐ Steering head bearing adjustment too tight. This will cause rolling or weaving at low speeds. Re-adjust the bearings.
- ☐ Steering head bearings worn or damaged. Correct adjustment of the bearing will prove impossible to achieve if wear or damage has occurred. Inconsistent handling will occur including rolling or weaving at low speed and poor directional control at indeterminate higher speeds. The steering head bearing should be dismantled for inspection and renewed if required. Lubrication should also be carried out.
- ☐ Bearing races pitted or dented. Impact damage caused, perhaps, by an accident or riding over a pot-hole can cause indentation of the bearing, usually in one position. This should be noted as notchiness when the handlebars are turned. Renew and lubricate the bearings.
- ☐ Steering stem bent. This will occur only if the machine is subjected to a high impact such as hitting a kerb or a pot-hole. The lower yoke/stem should be renewed; do not attempt to straighten the stem.
- ☐ Front or rear tyre pressures too low.
- ☐ Front or rear tyre worn. General instability, high speed wobbles and skipping over white lines indicates that tyre renewal may be required. Tyre induced problems, in some machine/tyre combinations, can occur even when the tyre in question is by no means fully worn.
- ☐ Swinging arm or linkage bearings worn. Difficulty in holding line, particularly when cornering or when changing power settings indicates wear in the swinging arm bearings. The swinging arm should be removed from the machine and the bearings renewed.
- ☐ Swinging arm flexing. The symptoms given in the preceding paragraph will also occur if the swinging arm fork flexes badly. This can be caused by structural weakness as a result of corrosion, fatigue or impact damage, or because the rear wheel spindle is slack.
- ☐ Wheel bearings worn. Renew the worn bearings.
- ☐ Tyres unsuitable for machine. Not all available tyres will suit the characteristics of the frame and suspension, indeed, some tyres or tyre combinations may cause a transformation in the handling characteristics. If handling problems occur immediately after changing to a new tyre type or make, revert to the original tyres to see whether an improvement can be noted. In some instances a change to what are, in fact, suitable tyres may give rise to handling deficiencies. In this case a thorough check should be made of all frame and suspension items which affect stability.

## Steering bias to left or right

- ☐ Rear wheel out of alignment. Caused by uneven adjustment of chain tensioner adjusters allowing the wheel to be askew in the fork ends. A bent rear wheel spindle will also misalign the wheel in the swinging arm.
- ☐ Wheels out of alignment. This can be caused by impact damage to the frame, swinging arm, wheel spindles or front forks. Although occasionally a result of material failure or corrosion it is usually as a result of a crash.
- ☐ Front forks twisted in the steering yokes. A light impact, for instance with a pot-hole or low curb, can twist the fork legs in the steering yokes without causing structural damage to the fork legs or the yokes themselves. Re-alignment can be made by loosening the yoke pinch bolts, wheel spindle and mudguard bolts. Re-align the wheel with the handlebars and tighten the bolts working upwards from the wheel spindle. This action should be carried out only when there is no chance that structural damage has occurred.

## Handlebar vibrates or oscillates

- ☐ Tyres worn or out of balance. Either condition, particularly in the front tyre, will promote shaking of the fork assembly and thus the handlebars. A sudden onset of shaking can result if a balance weight is displaced during use.
- ☐ Tyres badly positioned on the wheel rims. A moulded line on each wall of a tyre is provided to allow visual verification that the tyre is correctly positioned on the rim. A check can be made by rotating the tyre; any misalignment will be immediately obvious.
- ☐ Wheel rims warped or damaged. Inspect the wheels for runout as described in Chapter 1.
- ☐ Swinging arm bearings worn. Renew the bearings.
- ☐ Wheel bearings worn. Renew the bearings.
- ☐ Steering head bearings incorrectly adjusted. Vibration is more likely to result from bearings which are too loose rather than too tight. Re-adjust the bearings.
- ☐ Loose fork component fasteners. Loose nuts and bolts holding the fork legs, wheel spindle, mudguards or steering stem can promote shaking at the handlebars. Fasteners on running gear such as the forks and suspension should be checked tightened occasionally to prevent dangerous looseness of components occurring.
- ☐ Engine mounting bolts loose. Tighten all fasteners.



# 15 Poor handling or roadholding (continued)

## Poor front fork performance

- ☐ Suspension settings incorrect. Check and adjust front fork settings (as applicable) as described in Chapter 1.
- ☐ Damping fluid level incorrect. If the fluid level is too low, poor suspension control will occur, resulting in a general impairment of roadholding and early loss of tyre adhesion when cornering and braking. Too much oil is unlikely to change the fork characteristics unless severe overfilling occurs when the fork action will become stiffer and oil seal failure may occur.
- ☐ Damping oil viscosity incorrect. The damping action of the fork is directly related to the viscosity of the damping oil. The lighter the oil used, the less will be the damping action imparted. For general use, use the recommended viscosity of oil, changing to a slightly higher or heavier oil only when a change in damping characteristic is required. Overworked oil, or oil contaminated with water which has found its way past the seals, should be renewed to restore the correct damping performance and to prevent bottoming of the forks.
- ☐ Damping components worn or corroded. Advanced normal wear of the fork internals is unlikely to occur until a very high mileage has been covered. Continual use of the machine with damaged oil seals which allows the ingress of water, or neglect, will lead to rapid corrosion and wear. Dismantle the forks for inspection and overhaul. See Chapter 6.
- ☐ Weak fork springs. Progressive fatigue of the fork springs, resulting in a reduced spring free length, will occur after extensive use. This condition will promote excessive fork dive under braking, and in its advanced form will reduce the at-rest extended length of the forks and thus the fork geometry. Renewal of the springs as a pair is the only satisfactory course of action.
- ☐ Bent stanchions or corroded stanchions. Both conditions will prevent correct telescoping of the fork legs, and in an advanced

state can cause sticking of the fork in one position. In a mild form corrosion will cause stiction of the fork thereby increasing the time the suspension takes to react to an uneven road surface. Bent fork stanchions should be attended to immediately because they indicate that impact damage has occurred, and there is a danger that the forks will fail with disastrous consequences.

## Front fork judder when braking

- ☐ See 'Brake induced fork judder' in Section 17.
- ☐ Wear between the fork stanchions and the fork legs. Renewal of the affected components is required.
- ☐ Slack steering head bearings. Re-adjust the bearings.
- ☐ Warped brake disc. If irregular braking action occurs fork judder can be induced in what are normally serviceable forks. Renew the damaged brake components.

## Poor rear suspension performance

- ☐ Suspension settings incorrect. Check and adjust rear suspension settings as described in Chapter 1.
- ☐ Rear suspension unit damper worn out or leaking. The damping performance of most rear suspension units falls off with age. This is a gradual process, and thus may not be immediately obvious. Indications of poor damping include hopping of the rear end when cornering or braking, and a general loss of positive stability. See Chapter 6.
- ☐ Weak rear spring. If the suspension unit spring fatigues it will promote excessive pitching of the machine and reduce the ground clearance when cornering. If spring fatigue has occurred the suspension unit must be renewed.
- ☐ Swinging arm flexing or bearings worn. See Section 15.
- ☐ Bent suspension unit damper rod. This is likely to occur only if the machine is dropped or if seizure of the piston occurs. If either happens the suspension unit should be renewed.

# 16 Abnormal frame and suspension noise

## Front end noise

- ☐ Oil level low or too thin. This can cause a 'spurting' sound and is usually accompanied by irregular fork action. Change fork oil as described in Chapter 1.
- ☐ Spring weak or broken. Makes a clicking or scraping sound. Fork oil will have a lot of metal particles in it (Chapter 6).
- ☐ Steering head bearings loose or damaged. Clicks when braking. Check, adjust or replace (Chapter 6).
- ☐ Fork clamps loose. Make sure all fork clamp pinch bolts are tight (Chapter 6).
- ☐ Fork stanchion bent. Good possibility if machine has been dropped. Repair or replace tube (Chapter 6).

## Rear suspension noise

- ☐ Fluid level too low. Leakage of a suspension unit, usually evident by oil on the outer surfaces, can cause a spurting noise. The suspension unit should be renewed.
- ☐ Defective rear suspension unit with internal damage. Renew the suspension unit.

# 17 Brake problems

## Brakes are spongy or ineffective

- ☐ Air in brake circuit. This is only likely to happen in service due to neglect in checking the fluid level or because a leak has developed. The problem should be identified and the brake system bled of air.
- ☐ Pads worn. Check the pad wear as described in Chapter 1 and renew the pads if necessary.
- ☐ Contaminated pads. Cleaning pads which have been contaminated with oil, grease or brake fluid is unlikely to prove successful; the pads should be renewed.
- ☐ Pads glazed. This is usually caused by overheating. The surface of the pads may be roughened using glass-paper or a fine file.

- ☐ Brake fluid deterioration. A brake which on initial operation is firm but rapidly becomes spongy in use may be failing due to water contamination of the fluid. The fluid should be drained and then the system refilled and bled.
- ☐ Master cylinder seal failure. Wear or damage of master cylinder internal parts will prevent pressurisation of the brake fluid. Overhaul the master cylinder unit.
- ☐ Caliper seal failure. This will almost certainly be obvious by loss of fluid, a lowering of fluid in the master cylinder reservoir and contamination of the brake pads and caliper. Overhaul the caliper assembly.
- ☐ Rear brake pedal height incorrect. Adjust as described in Chapter 1.



## 17 Brake problems (continued)

### Brakes drag

- ☐ Disc warped. The disc must be renewed.
- ☐ Caliper piston, caliper or pads corroded. The brake caliper assembly is vulnerable to corrosion due to water and dirt, and unless cleaned at regular intervals and lubricated in the recommended manner, will become sticky in operation.
- ☐ Piston seal deteriorated. The seal is designed to return the piston in the caliper to the retracted position when the brake is released. Wear or old age can affect this function. The caliper should be overhauled if this occurs.
- ☐ Brake pad damaged. Pad material separating from the backing plate due to wear or faulty manufacture. Renew the pads. Faulty installation of a pad also will cause dragging.
- ☐ Wheel spindle bent. The spindle may be straightened if no structural damage has occurred.
- ☐ Brake lever or pedal not returning. Check that the lever or pedal works smoothly throughout its operating range and does not snag on any adjacent cycle parts. Lubricate the pivot if necessary.
- ☐ Twisted caliper support bracket. This is likely to occur only after impact in an accident. No attempt should be made to re-align the caliper; the bracket should be renewed.

### Brake lever or pedal pulsates in operation

- ☐ Disc warped or irregularly worn. The disc must be renewed.
- ☐ Wheel spindle bent. The spindle may be straightened provided no structural damage has occurred.

## 18 Electrical problems

### Battery dead or weak

- ☐ Battery faulty. Battery life should not be expected to exceed 3 to 4 years, particularly where a starter motor is used regularly. Gradual sulphation of the plates and sediment deposits will reduce the battery performance. Plate and insulator damage can often occur as a result of vibration. Complete power failure, or intermittent failure, may be due to a broken battery terminal. Lack of electrolyte will prevent the battery maintaining charge.
- ☐ Battery leads making poor contact. Remove the battery leads and clean them and the terminals, removing all traces of corrosion and tarnish. Reconnect the leads and apply a coating of petroleum jelly to the terminals.
- ☐ Load excessive. If additional items such as spot lamps, are fitted, which increase the total electrical load above the maximum alternator output, the battery will fail to maintain full charge. Reduce the electrical load to suit the electrical capacity.
- ☐ Regulator/rectifier failure.
- ☐ Alternator generating coils open-circuit or shorted.
- ☐ Charging circuit shorting or open circuit. This may be caused by frayed or broken wiring, dirty connectors or a faulty ignition switch. The system should be tested in a logical manner. See Section 18.

### Battery overcharged

- ☐ Rectifier/regulator faulty. Overcharging is indicated if the battery becomes hot or it is noticed that the electrolyte level falls repeatedly between checks. In extreme cases the battery will boil causing corrosive gases and electrolyte to be emitted through the vent pipes.
- ☐ Battery wrongly matched to the electrical circuit. Ensure that the specified battery is fitted to the machine.

### Total electrical failure

- ☐ Fuse blown. Check the main fuse. If a fault has occurred, it must be rectified before a new fuse is fitted.
- ☐ Battery faulty. See Section 18.

### Disc brake noise

- ☐ Brake squeal. Squealing can be caused by dust on the pads, usually in combination with glazed pads, or other contamination from oil, grease, brake fluid or corrosion. Persistent squealing which cannot be traced to any of the normal causes can often be cured by applying a thin layer of high temperature silicone grease to the rear of the pads. Make absolutely certain that no grease is allowed to contaminate the braking surface of the pads.
- ☐ Glazed pads. This is usually caused by high temperatures or contamination. The pad surfaces may be roughened using glass-paper or a fine file. If this approach does not effect a cure the pads should be renewed.
- ☐ Disc warped. This can cause a chattering, clicking or intermittent squeal and is usually accompanied by a pulsating brake lever or pedal or uneven braking. The disc must be renewed.
- ☐ Brake pads fitted incorrectly or undersize. Longitudinal play in the pads due to omission of the locating springs (where fitted) or because pads of the wrong size have been fitted will cause a single tapping noise every time the brake is operated. Inspect the pads for correct installation and security.

### Brake induced fork judder

- ☐ Worn front fork stanchions and legs, or worn or badly adjusted steering head bearings. These conditions, combined with uneven or pulsating braking as described in Section 17 will induce more or less judder when the brakes are applied, dependent on the degree of wear and poor brake operation. Attention should be given to both areas of malfunction. See the relevant Sections.

- ☐ Earth failure. Check that the earth strap from the battery is securely affixed to the engine and is making a good contact.
- ☐ Ignition switch or power circuit failure. Check for current flow through the battery positive lead to the ignition switch. Check the ignition switch for continuity.

### Circuit failure

- ☐ Wiring failure. Refer to the machine's wiring diagram and check the circuit for continuity. Open circuits are a result of loose or corroded connections, either at terminals or in-line connectors, or because of broken wires. Occasionally, the core of a wire will break without there being any apparent damage to the outer plastic cover.
- ☐ Switch failure. All switches may be checked for continuity in each switch position, after referring to the switch position boxes incorporated in the wiring diagram for the machine. Switch failure may be a result of mechanical breakage, corrosion or water.
- ☐ Fuse blown. Refer to the wiring diagram to check whether or not a circuit fuse is fitted. Replace the fuse, if blown, only after the fault has been identified and rectified.

### Bulbs blowing repeatedly

- ☐ Vibration failure. This is often an inherent fault related to the natural vibration characteristics of the engine and frame and is, thus, difficult to resolve. Modifications of the lamp mounting, to change the damping characteristics may help.
- ☐ Intermittent earth. Repeated failure of one bulb, particularly where the bulb is fed directly from the generator, indicates that a poor earth exists somewhere in the circuit. Check that a good contact is available at each earthing point in the circuit.
- ☐ Reduced voltage. Where a quartz-halogen bulb is fitted the voltage to the bulb should be maintained or early failure of the bulb will occur. Do not overload the system with additional electrical equipment in excess of the system's power capacity and ensure that all circuit connections are maintained clean and tight.



## Checking engine compression


● Low compression will result in exhaust smoke, heavy oil consumption, poor starting and poor performance. A compression test will provide useful information about an engine's condition and if performed regularly, can give warning of trouble before any other symptoms become apparent.

● A compression gauge will be required, along with an adapter to suit the spark plug hole thread size. Note that the screw-in type gauge/adapter set up is preferable to the rubber cone type.

● Before carrying out the test, first check the valve clearances as described in Chapter 1.

1 Run the engine until it reaches normal operating temperature, then stop it and remove the spark plug(s), taking care not to scald your hands on the hot components.

2 Install the gauge adapter and compression gauge in No. 1 cylinder spark plug hole (see illustration 1).




**Screw the compression gauge adapter into the spark plug hole, then screw the gauge into the adapter**

3 On kickstart-equipped motorcycles, make sure the ignition switch is OFF, then open the throttle fully and kick the engine over a couple of times until the gauge reading stabilises.

4 On motorcycles with electric start only, the procedure will differ depending on the nature of the ignition system. Flick the engine kill

switch (engine stop switch) to OFF and turn the ignition switch ON; open the throttle fully and crank the engine over on the starter motor for a couple of revolutions until the gauge reading stabilises. If the starter will not operate with the kill switch OFF, turn the ignition switch OFF and refer to the next paragraph.

5 Install the spark plugs back into their suppressor caps and arrange the plug electrodes so that their metal bodies are earthed (grounded) against the cylinder head; this is essential to prevent damage to the ignition system as the engine is spun over (see illustration 2). Position the plugs well



**All spark plugs must be earthed (grounded) against the cylinder head**

away from the plug holes otherwise there is a risk of atomised fuel escaping from the combustion chambers and igniting. As a safety precaution, cover the top of the valve cover with rag. Now turn the ignition switch ON and kill switch ON, open the throttle fully and crank the engine over on the starter motor for a couple of revolutions until the gauge reading stabilises.

6 After one or two revolutions the pressure should build up to a maximum figure and then stabilise. Take a note of this reading and on multi-cylinder engines repeat the test on the remaining cylinders.

7 The correct pressures are given in Chapter 2 Specifications. If the results fall within the specified range and on multi-cylinder engines all are relatively equal, the engine is in good condition. If there is a marked difference between the readings, or if the readings are

lower than specified, inspection of the top-end components will be required.

8 Low compression pressure may be due to worn cylinder bores, pistons or rings, failure of the cylinder head gasket, worn valve seals, or poor valve seating.

9 To distinguish between cylinder/piston wear and valve leakage, pour a small quantity of oil into the bore to temporarily seal the piston rings, then repeat the compression tests (see illustration 3). If the readings show



**Bores can be temporarily sealed with a squirt of motor oil**

a noticeable increase in pressure this confirms that the cylinder bore, piston, or rings are worn. If, however, no change is indicated, the cylinder head gasket or valves should be examined.


10 High compression pressure indicates excessive carbon build-up in the combustion chamber and on the piston crown. If this is the case the cylinder head should be removed and the deposits removed. Note that excessive carbon build-up is less likely with the used on modern fuels.

## Checking battery open-circuit voltage




**Warning:** The gases produced by the battery are explosive - never smoke or create any sparks in the vicinity of the battery. Never allow the electrolyte to contact your skin or clothing - if it does, wash it off and seek immediate medical attention.





Measuring open-circuit battery voltage



Float-type hydrometer for measuring battery specific gravity

● Before any electrical fault is investigated the battery should be checked.

● You'll need a dc voltmeter or multimeter to check battery voltage. Check that the leads are inserted in the correct terminals on the meter, red lead to positive (+ve), black lead to negative (-ve). Incorrect connections can damage the meter.

● A sound fully-charged 12 volt battery should produce between 12.3 and 12.6 volts across its terminals (12.8 volts for a maintenance-free battery). On machines with a 6 volt battery, voltage should be between 6.1 and 6.3 volts.

1 Set a multimeter to the 0 to 20 volts dc range and connect its probes across the battery terminals. Connect the meter's positive (+ve) probe, usually red, to the battery positive (+ve) terminal, followed by the meter's negative (-ve) probe, usually black, to the battery negative terminal (-ve) (see illustration 4).

2 If battery voltage is low (below 10 volts on a 12 volt battery or below 4 volts on a six volt battery), charge the battery and test the voltage again. If the battery repeatedly goes flat, investigate the motorcycle's charging system.

which has a small enough hose to insert in the aperture of a motorcycle battery.

● Specific gravity is simply a measure of the electrolyte's density compared with that of water. Water has an SG of 1.000 and fully-charged battery electrolyte is about 26% heavier, at 1.260.


● Specific gravity checks are not possible on maintenance-free batteries. Testing the open-circuit voltage is the only means of determining their state of charge.

1 To measure SG, remove the battery from the motorcycle and remove the first cell cap. Draw

some electrolyte into the hydrometer and note the reading (see illustration 5). Return the electrolyte to the cell and install the cap.

2 The reading should be in the region of 1.260 to 1.280. If SG is below 1.200 the battery needs charging. Note that SG will vary with temperature; it should be measured at 20°C (68°F). Add 0.007 to the reading for every 10°C above 20°C, and subtract 0.007 from the reading for every 10°C below 20°C. Add 0.004 to the reading for every 10°F above 68°F, and subtract 0.004 from the reading for every 10°F below 68°F.

3 When the check is complete, rinse the hydrometer thoroughly with clean water.



Digital multimeter can be used for all electrical tests

## Checking for continuity

● The term continuity describes the uninterrupted flow of electricity through an electrical circuit. A continuity check will determine whether an **open-circuit** situation exists.

● Continuity can be checked with an ohmmeter, multimeter, continuity tester or battery and bulb test circuit (see illustrations 6, 7 and 8).


## Checking battery specific gravity (SG)




**Warning:** The gases produced by the battery are explosive - never smoke or create any sparks in the vicinity of the battery. Never allow the electrolyte to contact your skin or clothing - if it does, wash it off and seek immediate medical attention.

● The specific gravity check gives an indication of a battery's state of charge.

● A hydrometer is used for measuring specific gravity. Make sure you purchase one




Battery-powered continuity tester




Battery and bulb test circuit





**9** Continuity check of front brake light switch using a meter - note split pins used to access connector terminals



**10** Continuity check of rear brake light switch using a continuity tester

- All of these instruments are self-powered by a battery, therefore the checks are made with the ignition OFF.
- As a safety precaution, always disconnect the battery negative (-ve) lead before making checks, particularly if ignition switch checks are being made.
- If using a meter, select the appropriate ohms scale and check that the meter reads infinity ( $\infty$ ). Touch the meter probes together and check that meter reads zero; where necessary adjust the meter so that it reads zero.
- After using a meter, always switch it OFF to conserve its battery.

### Switch checks

- 1 If a switch is at fault, trace its wiring up to the wiring connectors. Separate the wire connectors and inspect them for security and condition. A build-up of dirt or corrosion here will most likely be the cause of the problem - clean up and apply a water dispersant such as WD40.
- 2 If using a test meter, set the meter to the ohms  $\times 10$  scale and connect its probes across the wires from the switch (see illustration 9). Simple ON/OFF type switches, such as brake light switches, only have two

wires whereas combination switches, like the ignition switch, have many internal links. Study the wiring diagram to ensure that you are connecting across the correct pair of wires. Continuity (low or no measurable resistance - 0 ohms) should be indicated with the switch ON and no continuity (high resistance) with it OFF.

**3** Note that the polarity of the test probes doesn't matter for continuity checks, although care should be taken to follow specific test procedures if a diode or solid-state component is being checked.

**4** A continuity tester or battery and bulb circuit can be used in the same way. Connect its probes as described above (see illustration 10). The light should come on to indicate continuity in the ON switch position, but should extinguish in the OFF position.

### Wiring checks

- Many electrical faults are caused by damaged wiring, often due to incorrect routing or chaffing on frame components.
- Loose, wet or corroded wire connectors can also be the cause of electrical problems, especially in exposed locations.

**1** A continuity check can be made on a single length of wire by disconnecting it at each end

and connecting a meter or continuity tester across both ends of the wire (see illustration 11).


**2** Continuity (low or no resistance - 0 ohms) should be indicated if the wire is good. If no continuity (high resistance) is shown, suspect a broken wire.

### Checking for voltage


- A voltage check can determine whether current is reaching a component.
- Voltage can be checked with a dc voltmeter, multimeter set on the dc volts scale, test light or buzzer (see illustrations 12 and 13). A meter has the advantage of being able to measure actual voltage.
- When using a meter, check that its leads are inserted in the correct terminals on the meter, red to positive (+ve), black to negative (-ve). Incorrect connections can damage the meter.
- A voltmeter (or multimeter set to the dc volts scale) should always be connected in parallel (across the load). Connecting it in series will destroy the meter.
- Voltage checks are made with the ignition ON.



**11** Continuity check of front brake light switch sub-harness




**12** A simple test light can be used for voltage checks



**13** A buzzer is useful for voltage checks






**14** Checking for voltage at the rear brake light power supply wire using a meter . . .

**1** First identify the relevant wiring circuit by referring to the wiring diagram at the end of this manual. If other electrical components share the same power supply (ie are fed from the same fuse), take note whether they are working correctly - this is useful information in deciding where to start checking the circuit.

**2** If using a meter, check first that the meter leads are plugged into the correct terminals on the meter (see above). Set the meter to the dc volts function, at a range suitable for the battery voltage. Connect the meter red probe (+ve) to the power supply wire and the black probe to a good metal earth (ground) on the motorcycle's frame or directly to the battery negative (-ve) terminal (see illustration 14). Battery voltage should be shown on the meter



**15** . . . or a test light - note the earth connection to the frame (arrow)

with the ignition switched ON.

**3** If using a test light or buzzer, connect its positive (+ve) probe to the power supply terminal and its negative (-ve) probe to a good earth (ground) on the motorcycle's frame or directly to the battery negative (-ve) terminal (see illustration 15). With the ignition ON, the test light should illuminate or the buzzer sound.

**4** If no voltage is indicated, work back towards the fuse continuing to check for voltage. When you reach a point where there is voltage, you know the problem lies between that point and your last check point.

negative (-ve) terminal of the battery and also the main earth (ground) point on the wiring harness. If corroded, dismantle the connection and clean all surfaces back to bare metal.

**1** To check the earth on a component, use an insulated jumper wire to temporarily bypass its earth connection (see illustration 16). Connect one end of the jumper wire between the earth terminal or metal body of the component and the other end to the motorcycle's frame.

**2** If the circuit works with the jumper wire installed, the original earth circuit is faulty. Check the wiring for open-circuits or poor connections. Clean up direct earth connections, removing all traces of corrosion and remake the joint. Apply petroleum jelly to the joint to prevent future corrosion.

## Tracing a short-circuit

● A short-circuit occurs where current shorts to earth (ground) bypassing the circuit components. This usually results in a blown fuse.


● A short-circuit is most likely to occur where the insulation has worn through due to wiring chafing on a component, allowing a direct path to earth (ground) on the frame.

**1** Remove any bodypanels necessary to access the circuit wiring.

**2** Check that all electrical switches in the circuit are OFF, then remove the circuit fuse and connect a test light, buzzer or voltmeter (set to the dc scale) across the fuse terminals. No voltage should be shown.

**3** Move the wiring from side to side whilst observing the test light or meter. When the test light comes on, buzzer sounds or meter shows voltage, you have found the cause of the short. It will usually show up as damaged or burned insulation.

**4** Note that the same test can be performed on each component in the circuit, even the switch.



**16** A selection of jumper wires for making earth (ground) checks

## Checking the earth (ground)

● Earth connections are made either directly to the engine or frame (such as sensors, neutral switch etc. which only have a positive feed) or by a separate wire into the earth circuit of the wiring harness. Alternatively a short earth wire is sometimes run directly from the component to the motorcycle's frame.

● Corrosion is often the cause of a poor earth connection.

● If total failure is experienced, check the security of the main earth lead from the



## A

**ABS (Anti-lock braking system)** A system, usually electronically controlled, that senses incipient wheel lockup during braking and relieves hydraulic pressure at wheel which is about to skid.

**Aftermarket** Components suitable for the motorcycle, but not produced by the motorcycle manufacturer.

**Allen key** A hexagonal wrench which fits into a recessed hexagonal hole.

**Alternating current (ac)** Current produced by an alternator. Requires converting to direct current by a rectifier for charging purposes.

**Alternator** Converts mechanical energy from the engine into electrical energy to charge the battery and power the electrical system.

**Ampere (amp)** A unit of measurement for the flow of electrical current. Current = Volts ÷ Ohms.

**Ampere-hour (Ah)** Measure of battery capacity.

**Angle-tightening** A torque expressed in degrees. Often follows a conventional tightening torque for cylinder head or main bearing fasteners (see illustration).



Angle-tightening cylinder head bolts

**Antifreeze** A substance (usually ethylene glycol) mixed with water, and added to the cooling system, to prevent freezing of the coolant in winter. Antifreeze also contains chemicals to inhibit corrosion and the formation of rust and other deposits that would tend to clog the radiator and coolant passages and reduce cooling efficiency.

**Anti-dive** System attached to the fork lower leg (slider) to prevent fork dive when braking hard.

**Anti-seize compound** A coating that reduces the risk of seizing on fasteners that are subjected to high temperatures, such as exhaust clamp bolts and nuts.

**API** American Petroleum Institute. A quality standard for 4-stroke motor oils.

**Asbestos** A natural fibrous mineral with great heat resistance, commonly used in the composition of brake friction materials. Asbestos is a health hazard and the dust created by brake systems should never be inhaled or ingested.

**ATF** Automatic Transmission Fluid. Often used in front forks.

**ATU** Automatic Timing Unit. Mechanical device for advancing the ignition timing on early engines.

**ATV** All Terrain Vehicle. Often called a Quad.

**Axial play** Side-to-side movement.

**Axle** A shaft on which a wheel revolves. Also known as a spindle.


## B

**Backlash** The amount of movement between meshed components when one component is held still. Usually applies to gear teeth.

**Ball bearing** A bearing consisting of a hardened inner and outer race with hardened steel balls between the two races.

**Bearings** Used between two working surfaces to prevent wear of the components and a build-up of heat. Four types of bearing are commonly used on motorcycles: plain shell bearings, ball bearings, tapered roller bearings and needle roller bearings.

**Bevel gears** Used to turn the drive through 90°. Typical applications are shaft final drive and camshaft drive (see illustration).



Bevel gears are used to turn the drive through 90°

**BHP** Brake Horsepower. The British measurement for engine power output. Power output is now usually expressed in kilowatts (kW).

**Bias-belted tyre** Similar construction to radial tyre, but with outer belt running at an angle to the wheel rim.

**Big-end bearing** The bearing in the end of the connecting rod that's attached to the crankshaft.

**Bleeding** The process of removing air from an hydraulic system via a bleed nipple or bleed screw.

**Bottom-end** A description of an engine's crankcase components and all components contained therein.

**BTDC** Before Top Dead Centre in terms of piston position. Ignition timing is often expressed in terms of degrees or millimetres BTDC.

**Bush** A cylindrical metal or rubber component used between two moving parts.

**Burr** Rough edge left on a component after machining or as a result of excessive wear.

## C

**Cam chain** The chain which takes drive from the crankshaft to the camshaft(s).

**Canister** The main component in an evaporative emission control system (California market only); contains activated charcoal granules to trap vapours from the fuel system rather than allowing them to vent to the atmosphere.

**Castellated** Resembling the parapets along the top of a castle wall. For example, a castellated wheel axle or spindle nut.

**Catalytic converter** A device in the exhaust system of some machines which converts certain

pollutants in the exhaust gases into less harmful substances.

**Charging system** Description of the components which charge the battery, ie the alternator, rectifier and regulator.

**Circlip** A ring-shaped clip used to prevent endwise movement of cylindrical parts and shafts. An internal circlip is installed in a groove in a housing; an external circlip fits into a groove on the outside of a cylindrical piece such as a shaft. Also known as a snap-ring.

**Clearance** The amount of space between two parts. For example, between a piston and a cylinder, between a bearing and a journal, etc.

**Coil spring** A spiral of elastic steel found in various sizes throughout a vehicle, for example as a springing medium in the suspension and in the valve train.

**Compression** Reduction in volume, and increase in pressure and temperature, of a gas, caused by squeezing it into a smaller space.

**Compression damping** Controls the speed the suspension compresses when hitting a bump.

**Compression ratio** The relationship between cylinder volume when the piston is at top dead centre and cylinder volume when the piston is at bottom dead centre.

**Continuity** The uninterrupted path in the flow of electricity. Little or no measurable resistance.

**Continuity tester** Self-powered beeper or test light which indicates continuity.

**Cp** Candlepower. Bulb rating commonly found on US motorcycles.

**Crossply tyre** Tyre plies arranged in a criss-cross pattern. Usually four or six plies used, hence 4PR or 6PR in tyre size codes.

**Cush drive** Rubber damper segments fitted between the rear wheel and final drive sprocket to absorb transmission shocks (see illustration).



Cush drive rubbers dampen out transmission shocks

## D

**Degree disc** Calibrated disc for measuring piston position. Expressed in degrees.

**Dial gauge** Clock-type gauge with adapters for measuring runout and piston position. Expressed in mm or inches.

**Diaphragm** The rubber membrane in a master cylinder or carburettor which seals the upper chamber.

**Diaphragm spring** A single sprung plate often used in clutches.

**Direct current (dc)** Current produced by a dc generator.



**Decarbonisation** The process of removing carbon deposits - typically from the combustion chamber, valves and exhaust port/system.

**Detonation** Destructive and damaging explosion of fuel/air mixture in combustion chamber instead of controlled burning.

**Diode** An electrical valve which only allows current to flow in one direction. Commonly used in rectifiers and starter interlock systems.

**Disc valve (or rotary valve)** A induction system used on some two-stroke engines.

**Double-overhead camshaft (DOHC)** An engine that uses two overhead camshafts, one for the intake valves and one for the exhaust valves.

**Drivebelt** A toothed belt used to transmit drive to the rear wheel on some motorcycles. A drivebelt has also been used to drive the camshafts. Drivebelts are usually made of Kevlar.

**Driveshaft** Any shaft used to transmit motion. Commonly used when referring to the final driveshaft on shaft drive motorcycles.

## E

**Earth return** The return path of an electrical circuit, utilising the motorcycle's frame.

**ECU (Electronic Control Unit)** A computer which controls (for instance) an ignition system, or an anti-lock braking system.

**EGO** Exhaust Gas Oxygen sensor. Sometimes called a Lambda sensor.

**Electrolyte** The fluid in a lead-acid battery.

**EMS (Engine Management System)** A computer controlled system which manages the fuel injection and the ignition systems in an integrated fashion.

**Endfloat** The amount of lengthways movement between two parts. As applied to a crankshaft, the distance that the crankshaft can move side-to-side in the crankcase.

**Endless chain** A chain having no joining link. Common use for cam chains and final drive chains.

**EP (Extreme Pressure)** Oil type used in locations where high loads are applied, such as between gear teeth.

**Evaporative emission control system** Describes a charcoal filled canister which stores fuel vapours from the tank rather than allowing them to vent to the atmosphere. Usually only fitted to California models and referred to as an EVAP system.

**Expansion chamber** Section of two-stroke engine exhaust system so designed to improve engine efficiency and boost power.

## F

**Feeler blade or gauge** A thin strip or blade of hardened steel, ground to an exact thickness, used to check or measure clearances between parts.

**Final drive** Description of the drive from the transmission to the rear wheel. Usually by chain or shaft, but sometimes by belt.

**Firing order** The order in which the engine cylinders fire, or deliver their power strokes, beginning with the number one cylinder.

**Flooding** Term used to describe a high fuel level in the carburettor float chambers, leading to fuel overflow. Also refers to excess fuel in the combustion chamber due to incorrect starting technique.

**Free length** The no-load state of a component when measured. Clutch, valve and fork spring lengths are measured at rest, without any preload.

**Freeplay** The amount of travel before any action takes place. The looseness in a linkage, or an assembly of parts, between the initial application of force and actual movement. For example, the distance the rear brake pedal moves before the rear brake is actuated.

**Fuel injection** The fuel/air mixture is metered electronically and directed into the engine intake ports (indirect injection) or into the cylinders (direct injection). Sensors supply information on engine speed and conditions.

**Fuel/air mixture** The charge of fuel and air going into the engine. See **Stoichiometric ratio**.

**Fuse** An electrical device which protects a circuit against accidental overload. The typical fuse contains a soft piece of metal which is calibrated to melt at a predetermined current flow (expressed as amps) and break the circuit.

## G

**Gap** The distance the spark must travel in jumping from the centre electrode to the side electrode in a spark plug. Also refers to the distance between the ignition rotor and the pickup coil in an electronic ignition system.

**Gasket** Any thin, soft material - usually cork, cardboard, asbestos or soft metal - installed between two metal surfaces to ensure a good seal. For instance, the cylinder head gasket seals the joint between the block and the cylinder head.

**Gauge** An instrument panel display used to monitor engine conditions. A gauge with a movable pointer on a dial or a fixed scale is an analogue gauge. A gauge with a numerical readout is called a digital gauge.

**Gear ratios** The drive ratio of a pair of gears in a gearbox, calculated on their number of teeth.

**Glaze-busting** see **Honing**

**Grinding** Process for renovating the valve face and valve seat contact area in the cylinder head.

**Gudgeon pin** The shaft which connects the connecting rod small-end with the piston. Often called a piston pin or wrist pin.

## H

**Helical gears** Gear teeth are slightly curved and produce less gear noise than straight-cut gears. Often used for primary drives.



Installing a Helicoil thread insert in a cylinder head

**Helicoil** A thread insert repair system. Commonly used as a repair for stripped spark plug threads (see illustration).

**Honing** A process used to break down the glaze on a cylinder bore (also called glaze-busting). Can also be carried out to roughen a rebored cylinder to aid ring bedding-in.

**HT (High Tension)** Description of the electrical circuit from the secondary winding of the ignition coil to the spark plug.

**Hydraulic** A liquid filled system used to transmit pressure from one component to another. Common uses on motorcycles are brakes and clutches.

**Hydrometer** An instrument for measuring the specific gravity of a lead-acid battery.

**Hygroscopic** Water absorbing. In motorcycle applications, braking efficiency will be reduced if DOT 3 or 4 hydraulic fluid absorbs water from the air - care must be taken to keep new brake fluid in tightly sealed containers.

## I

**lbf ft** Pounds-force feet. An imperial unit of torque. Sometimes written as ft-lbs.

**lbf in** Pound-force inch. An imperial unit of torque, applied to components where a very low torque is required. Sometimes written as in-lbs.

**IC** Abbreviation for Integrated Circuit.

**Ignition advance** Means of increasing the timing of the spark at higher engine speeds. Done by mechanical means (ATU) on early engines or electronically by the ignition control unit on later engines.

**Ignition timing** The moment at which the spark plug fires, expressed in the number of crankshaft degrees before the piston reaches the top of its stroke, or in the number of millimetres before the piston reaches the top of its stroke.

**Infinity (∞)** Description of an open-circuit electrical state, where no continuity exists.

**Inverted forks (upside down forks)** The sliders or lower legs are held in the yokes and the fork tubes or stanchions are connected to the wheel axle (spindle). Less unsprung weight and stiffer construction than conventional forks.

## J

**JASO** Quality standard for 2-stroke oils.

**Joule** The unit of electrical energy.

**Journal** The bearing surface of a shaft.

## K

**Kickstart** Mechanical means of turning the engine over for starting purposes. Only usually fitted to mopeds, small capacity motorcycles and off-road motorcycles.

**Kill switch** Handbar-mounted switch for emergency ignition cut-out. Cuts the ignition circuit on all models, and additionally prevent starter motor operation on others.

**km** Symbol for kilometre.

**kmh** Abbreviation for kilometres per hour.

## L

**Lambda (λ) sensor** A sensor fitted in the exhaust system to measure the exhaust gas oxygen content (excess air factor).



**Lapping** see **Grinding**.

**LCD** Abbreviation for Liquid Crystal Display.

**LED** Abbreviation for Light Emitting Diode.

**Liner** A steel cylinder liner inserted in a aluminium alloy cylinder block.

**Locknut** A nut used to lock an adjustment nut, or other threaded component, in place.

**Lockstops** The lugs on the lower triple clamp (yoke) which abut those on the frame, preventing handlebar-to-fuel tank contact.

**Lockwasher** A form of washer designed to prevent an attaching nut from working loose.

**LT Low Tension** Description of the electrical circuit from the power supply to the primary winding of the ignition coil.

## M

**Main bearings** The bearings between the crankshaft and crankcase.

**Maintenance-free (MF) battery** A sealed battery which cannot be topped up.

**Manometer** Mercury-filled calibrated tubes used to measure intake tract vacuum. Used to synchronise carburettors on multi-cylinder engines.

**Micrometer** A precision measuring instrument that measures component outside diameters (see illustration).



Tappet shims are measured with a micrometer

**MON (Motor Octane Number)** A measure of a fuel's resistance to knock.

**Monograde oil** An oil with a single viscosity, eg SAE80W.

**Monoshock** A single suspension unit linking the swingarm or suspension linkage to the frame.

**mph** Abbreviation for miles per hour.

**Multigrade oil** Having a wide viscosity range (eg 10W40). The W stands for Winter, thus the viscosity ranges from SAE10 when cold to SAE40 when hot.

**Multimeter** An electrical test instrument with the capability to measure voltage, current and resistance. Some meters also incorporate a continuity tester and buzzer.

## N

**Needle roller bearing** Inner race of caged needle rollers and hardened outer race. Examples of uncaged needle rollers can be found on some engines. Commonly used in rear suspension applications and in two-stroke engines.

**Nm** Newton metres.

**NOx** Oxides of Nitrogen. A common toxic pollutant emitted by petrol engines at higher temperatures.

## O

**Octane** The measure of a fuel's resistance to knock.

**OE (Original Equipment)** Relates to components fitted to a motorcycle as standard or replacement parts supplied by the motorcycle manufacturer.

**Ohm** The unit of electrical resistance. Ohms = Volts ÷ Current.

**Ohmmeter** An instrument for measuring electrical resistance.

**Oil cooler** System for diverting engine oil outside of the engine to a radiator for cooling purposes.

**Oil injection** A system of two-stroke engine lubrication where oil is pump-fed to the engine in accordance with throttle position.

**Open-circuit** An electrical condition where there is a break in the flow of electricity - no continuity (high resistance).

**O-ring** A type of sealing ring made of a special rubber-like material; in use, the O-ring is compressed into a groove to provide the sealing action.

**Oversize (OS)** Term used for piston and ring size options fitted to a rebored cylinder.

**Overhead cam (sohc) engine** An engine with single camshaft located on top of the cylinder head.

**Overhead valve (ohv) engine** An engine with the valves located in the cylinder head, but with the camshaft located in the engine block or crankcase.

**Oxygen sensor** A device installed in the exhaust system which senses the oxygen content in the exhaust and converts this information into an electric current. Also called a Lambda sensor.

## P

**Plastigauge** A thin strip of plastic thread, available in different sizes, used for measuring clearances. For example, a strip of Plastigauge is laid across a bearing journal. The parts are assembled and dismantled; the width of the crushed strip indicates the clearance between journal and bearing.

**Polarity** Either negative or positive earth (ground), determined by which battery lead is connected to the frame (earth return). Modern motorcycles are usually negative earth.

**Pre-ignition** A situation where the fuel/air mixture ignites before the spark plug fires. Often due to a hot spot in the combustion chamber caused by carbon build-up. Engine has a tendency to 'run-on'.

**Pre-load (suspension)** The amount a spring is compressed when in the unloaded state. Preload can be applied by gas, spacer or mechanical adjuster.

**Premix** The method of engine lubrication on older two-stroke engines. Engine oil is mixed with the petrol in the fuel tank in a specific ratio. The fuel/oil mix is sometimes referred to as 'petrol'.

**Primary drive** Description of the drive from the crankshaft to the clutch. Usually by gear or chain.

**PS** Pfedestärke - a German interpretation of BHP.


**PSI** Pounds-force per square inch. Imperial measurement of tyre pressure and cylinder pressure measurement.

**PTFE** Polytetrafluoroethylene. A low-friction substance.

**Pulse secondary air injection system** A process of promoting the burning of excess fuel present in the exhaust gases by routing fresh air into the exhaust ports.

## Q

**Quartz halogen bulb** Tungsten filament surrounded by a halogen gas. Typically used for the headlight (see illustration).



Quartz halogen headlight bulb construction

## R


**Rack-and-pinion** A pinion gear on the end of a shaft that mates with a rack (think of a geared wheel opened up and laid flat). Sometimes used in clutch operating systems.

**Radial play** Up and down movement about a shaft.

**Radial ply tyres** Tyre plies run across the tyre (from bead to bead) and around the circumference of the tyre. Less resistant to tread distortion than other tyre types.

**Radiator** A liquid-to-air heat transfer device designed to reduce the temperature of the coolant in a liquid cooled engine.

**Rake** A feature of steering geometry - the angle of the steering head in relation to the vertical (see illustration).



Steering geometry



**Rebore** Providing a new working surface to the cylinder bore by boring out the old surface. Necessitates the use of oversize piston and rings.

**Rebound damping** A means of controlling the oscillation of a suspension unit spring after it has been compressed. Resists the spring's natural tendency to bounce back after being compressed.

**Rectifier** Device for converting the ac output of an alternator into dc for battery charging.

**Reed valve** An induction system commonly used on two-stroke engines.

**Regulator** Device for maintaining the charging voltage from the generator or alternator within a specified range.

**Relay** A electrical device used to switch heavy current on and off by using a low current auxiliary circuit.

**Resistance** Measured in ohms. An electrical component's ability to pass electrical current.

**RON (Research Octane Number)** A measure of a fuel's resistance to knock.

**rpm** revolutions per minute.

**Runout** The amount of wobble (in-and-out movement) of a wheel or shaft as it's rotated. The amount a shaft rotates 'out-of-true'. The out-of-round condition of a rotating part.

## S

**SAE (Society of Automotive Engineers)** A standard for the viscosity of a fluid.

**Sealant** A liquid or paste used to prevent leakage at a joint. Sometimes used in conjunction with a gasket.

**Service limit** Term for the point where a component is no longer useable and must be renewed.

**Shaft drive** A method of transmitting drive from the transmission to the rear wheel.

**Shell bearings** Plain bearings consisting of two shell halves. Most often used as big-end and main bearings in a four-stroke engine. Often called bearing inserts.

**Shim** Thin spacer, commonly used to adjust the clearance or relative positions between two parts. For example, shims inserted into or under tappets or followers to control valve clearances. Clearance is adjusted by changing the thickness of the shim.

**Short-circuit** An electrical condition where current shorts to earth (ground) bypassing the circuit components.

**Skimming** Process to correct warpage or repair a damaged surface, eg on brake discs or drums.

**Slide-hammer** A special puller that screws into or hooks onto a component such as a shaft or bearing; a heavy sliding handle on the shaft bottoms against the end of the shaft to knock the component free.

**Small-end bearing** The bearing in the upper end of the connecting rod at its joint with the gudgeon pin.

**Spalling** Damage to camshaft lobes or bearing journals shown as pitting of the working surface.

**Specific gravity (SG)** The state of charge of the electrolyte in a lead-acid battery. A measure of the electrolyte's density compared with water.

**Straight-cut gears** Common type gear used on gearbox shafts and for oil pump and water pump drives.

**Stanchion** The inner sliding part of the front forks, held by the yokes. Often called a fork tube.

**Stoichiometric ratio** The optimum chemical air/fuel ratio for a petrol engine, said to be 14.7 parts of air to 1 part of fuel.

**Sulphuric acid** The liquid (electrolyte) used in a lead-acid battery. Poisonous and extremely corrosive.

**Surface grinding (lapping)** Process to correct a warped gasket face, commonly used on cylinder heads.

## T

**Tapered-roller bearing** Tapered inner race of caged needle rollers and separate tapered outer race. Examples of taper roller bearings can be found on steering heads.

**Tappet** A cylindrical component which transmits motion from the cam to the valve stem, either directly or via a pushrod and rocker arm. Also called a cam follower.

**TCS** Traction Control System. An electronically-controlled system which senses wheel spin and reduces engine speed accordingly.

**TDC** Top Dead Centre denotes that the piston is at its highest point in the cylinder.

**Thread-locking compound** Solution applied to fastener threads to prevent slackening. Select type to suit application.

**Thrust washer** A washer positioned between two moving components on a shaft. For example, between gear pinions on gearshaft.

**Timing chain** See **Cam Chain**.

**Timing light** Stroboscopic lamp for carrying out ignition timing checks with the engine running.

**Top-end** A description of an engine's cylinder block, head and valve gear components.

**Torque** Turning or twisting force about a shaft.

**Torque setting** A prescribed tightness specified by the motorcycle manufacturer to ensure that the bolt or nut is secured correctly. Undertightening can result in the bolt or nut coming loose or a surface not being sealed. Overtightening can result in stripped threads, distortion or damage to the component being retained.

**Torx key** A six-point wrench.

**Tracer** A stripe of a second colour applied to a wire insulator to distinguish that wire from another one with the same colour insulator. For example, Br/W is often used to denote a brown insulator with a white tracer.

**Trail** A feature of steering geometry. Distance from the steering head axis to the tyre's central contact point.

**Triple clamps** The cast components which extend from the steering head and support the fork stanchions or tubes. Often called fork yokes.

**Turbocharger** A centrifugal device, driven by exhaust gases, that pressurises the intake air. Normally used to increase the power output from a given engine displacement.

**TWI** Abbreviation for Tyre Wear Indicator. Indicates the location of the tread depth indicator bars on tyres.

## U

**Universal joint or U-joint (UJ)** A double-pivoted connection for transmitting power from a driving to a driven shaft through an angle. Typically found in shaft drive assemblies.

**Unsprung weight** Anything not supported by the bike's suspension (ie the wheel, tyres, brakes, final drive and bottom (moving) part of the suspension).

## V

**Vacuum gauges** Clock-type gauges for measuring intake tract vacuum. Used for carburettor synchronisation on multi-cylinder engines.

**Valve** A device through which the flow of liquid, gas or vacuum may be stopped, started or regulated by a moveable part that opens, shuts or partially obstructs one or more ports or passageways. The intake and exhaust valves in the cylinder head are of the poppet type.

**Valve clearance** The clearance between the valve tip (the end of the valve stem) and the rocker arm or tappet/follower. The valve clearance is measured when the valve is closed. The correct clearance is important - if too small the valve won't close fully and will burn out, whereas if too large noisy operation will result.

**Valve lift** The amount a valve is lifted off its seat by the camshaft lobe.

**Valve timing** The exact setting for the opening and closing of the valves in relation to piston position.

**Vernier caliper** A precision measuring instrument that measures inside and outside dimensions. Not quite as accurate as a micrometer, but more convenient.

**VIN** Vehicle Identification Number. Term for the bike's engine and frame numbers.

**Viscosity** The thickness of a liquid or its resistance to flow.

**Volt** A unit for expressing electrical "pressure" in a circuit. Volts = current x ohms.


## W

**Water pump** A mechanically-driven device for moving coolant around the engine.

**Watt** A unit for expressing electrical power. Watts = volts x current.

**Wear limit** see **Service limit**

**Wet liner** A liquid-cooled engine design where the pistons run in liners which are directly surrounded by coolant (see illustration).



Wet liner arrangement

**Wheelbase** Distance from the centre of the front wheel to the centre of the rear wheel.

**Wiring harness or loom** Describes the electrical wires running the length of the motorcycle and enclosed in tape or plastic sheathing. Wiring coming off the main harness is usually referred to as a sub harness.

**Woodruff key** A key of semi-circular or square section used to locate a gear to a shaft. Often used to locate the alternator rotor on the crankshaft.

**Wrist pin** Another name for gudgeon or piston pin.