


## EMISSION CONTROL (5VZ-FE)

### RECOMMENDED TOOLS

PP014-01

|   |                                       |
|---|---------------------------------------|
|  | 09082-00040 TOYOTA Electrical Tester. |
|---|---------------------------------------|