




# STARTING (5VZ-FE)

## SST (Special Service Tools)

PP024-01

	09286-4601 1 Injection Pump Spline Shaft Puller	Armature bearing
	09201-41020 Valve Stem Oil Seal Replacer	Armature front bearing
	09810-38140 Starter Magnet Switch Nut Wrench 14	Terminal kit