











PROPELLER SHAFT

SST (Special Service Tools)

PP0AH-03

	09325-20010	Transmission Oil Plug	2-joint type: Transmission oil leakage prevention
	09325-40010	Transmission Oil Plug	3-joint type: Transmission oil leakage prevention
	09330-00021	Companion Flange Holding Tool	Flange
	09332-25010	Universal Joint Bearing Remover & Replacer	Spider bearing
	09950-3001 1	Puller A Set	
	(09951-03010)	Upper Plate	
	(09953-03010)	Center Bolt	
	(09954-03010)	Arm	
	(09955-03030)	Lower Plate 130	
	(09956-03020)	Adapter 18	