


























SUSPENSION AND AXLE














SST (Special Service Tools)














PP3HC-01

	09214-7601 1	Crankshaft Pulley Replacer	Rear differential (3RZ-FE, 5VZ-FE w/ Diff. lock)
	09223-15020	Oil Seal & Bearing Replacer	Front differential
	09223-15030	Oil Seal & Bearing Replacer	Front axle (4WD and pre runner)
	09223-56010	Crankshaft Rear Oil Seal Replacer	Rear axle
	09226-10010	Crankshaft Front & Rear Bearing Replacer	Front differential
	09240-00020	Wire Gauge Set	Front drive shaft (4WD)
	09308-00010	Oil Seal Puller	Front differential Rear axle Rear differential (3RZ-FE, 5VZ-FE w/ Diff. lock)
	09309-37010	Transmission Bearing Replacer	Front differential Front suspension (4WD and pre runner)
	09316-12010	Transfer Bearing Replacer	Rear differential (Except 2RZ-FE)
	09316-6001 1	Transmission & Transfer Bearing Replacer	
	(09316-0001 1)	Replacer Pipe	Rear differential
	(09316-00021)	Replacer "A"	Rear differential














	(09316-00051) Replacer "D"	Rear axle Rear differential (3RZ-FE, 5VZ-FE w/ Diff. lock)
	09318-12010 Transfer Bearing Adjusting Nut Wrench	Front axle (4WD and pre runner)
	09330-00021 Companion Flange Holding Tool	Front differential Rear differential
	09350-20015 TOYOTA Automatic Transmission Tool Set	Front differential
	(09369-20040) Piston Spring Compressor Set	
	09350-32014 TOYOTA Automatic Transmission Tool Set	Front differential Rear differential
	09308-10010 Oil Seal Puller	
	09502-12010 Differential Bearing Replacer	Front differential
	09504-0001 1 Differential Side Bearing Adjusting Nut Wrench	Rear differential (2RZ-FE and 3RZ-FE, 5VZ-FE w/ Diff. lock)
	09504-2201 1 Differential Side Bearing Replacer	Rear differential (3RZ-FE, 5VZ-FE w/o Diff. lock)
	09506-30012 Differential Drive Pinion Rear Bearing Cone Replacer	Front differential Rear differential
	09506-35010 Differential Drive Pinion Rear Bearing Replacer	Front suspension (4WD and pre runner) Rear differential (3RZ-FE, 5VZ-FE w/o Diff. lock)
	09515-30010 Rear Wheel Bearing Replacer	Rear axle














PREPARATION - SUSPENSION AND AXLE

	09521-24010	Drive Shaft Boot Clamping Tool	Front drive shaft (4WD)
	09521-2501 1	Rear Axle Shaft Puller	Rear axle
	09523-36010	Rear Axle Hub Guide Tool	Rear differential (3RZ-FE, 5VZ-FE w/o Diff. lock)
	09527-1701 1	Rear Axle Shaft Bearing Remover	Front axle
	09550-10013	Replacer Set "B"	
	(09252-10010)	No. 1 Replacer Handle-	Rear differential Rear suspension
	(09553-10010)	Differential Side Bearing Replacer	Rear suspension
	(09557-1001 1)	Differential Drive Pinion Front Bearing Replacer	Rear differential (2RZ-FE)
	09554-22010	Differential Oil Seal Replacer	Front differential
	09554-3001 1	Differential Oil Seal Replacer	Rear differential (2RZ-FE)
	09556-22010	Drive Pinion Front Bearing Remover	Front differential Rear differential
	09564-3201 1	Differential Preload Adaptor	Front differential
	09570-2201 1	Differential Mounting Cushion Remover & Replacer	Front differential














	09608-32010	Steering Knuckle Oil Seal Replacer	Front differential
	09610-20012	Pitman Arm Puller	Front suspension
	09612-65014	Steering Worm Bearing Puller	Front differential
	(09612-01020)	Claw "B"	
	(09612-01050)	Hanger Pin with Nut	
	09628-6201 1	Ball Joint Puller	Front axle (2WD) Front drive shaft (4WD) Front suspension
	09631-10030	Oil Seal Remover	Front drive shaft (4WD)
	09632-36010	Steering Vane Pump Bearing Replacer	Front suspension (4WD and pre runner)
	09636-20010	Upper Ball Joint Dust Cover Replacer	Front differential Rear differential
	09649-17010	Steering Knuckle Tool	Front axle (4WD and pre runner) Rear differential (3RZ-FE, 5VZ-FE w/o Diff. lock)
	09650-1701 1	Hub Bolt Remover	Front axle (4WD) Rear axle
	09710-28012	Front Suspension Bushing Tool Set	Rear suspension
	(09710-07062)	Bushing Replacer	














PREPARATION - SUSPENSION AND AXLE

	09710-30021	Suspension Bushing Tool Set	
	(09710-03031)	Bushing Remover	Front suspension (2WD)
	(09710-03051)	Bushing Replacer	Front axle (4WD)
	(09710-03071)	Remover	Front suspension (2WD)
	(09710-03101)	Bushing Replacer	Front suspension (2WD)
	(09710-03141)	Bushing Remover Base	Front suspension (2WD)
	09710-30041	Rear Suspension Bushing Tool Set	Rear suspension
	(09710-0321 1)	Remover	
	09726-40010	Lower Control Shaft Bearing Replacer	Rear differential (3RZ-FE, 5VZ-FE w/ Diff. lock)
	09727-2201 1	Front Spring Compressor	Front suspension (2WD)
	(09727-23010)	Hook Set	
	(09727-23020)	Spacer	
	(09727-23030)	Rod Set	









	<p>(09727-23040) Attachment Set</p>	
	<p>09727-30021 Coil Spring Compressor</p>	<p>Front suspension (4WD and pre runner)</p>
	<p>09751-3601 1 Brake Line Union Nut Wrench</p>	<p>Rear axle</p>
	<p>09922-10010 Variable Open Wrench</p>	<p>Front suspension (4WD and pre runner)</p>
	<p>09950-00020 Bearing Remover</p>	<p>Front differential Rear differential</p>
	<p>09950-3001 1 Puller A Set</p>	
	<p>(09951-03010) Upper Plate</p>	<p>Front differential Rear differential</p>
	<p>(09953-03010) Center Bolt</p>	<p>Front differential Rear differential</p>
	<p>(09954-03010) Arm</p>	<p>Front differential Rear differential</p>
	<p>(09955-03030) Lower Plate 130</p>	<p>Front differential Rear differential</p>
	<p>(09956-03020) Adapter 18</p>	<p>Front differential Rear differential (2RZ-FE, 3RZ-FE, 5VZ-FE w/ Diff. lock)</p>
	<p>(09956-03050) Adapter 24</p>	<p>Rear differential (3RZ-FE, 5VZ-FE w/o Diff. lock)</p>
	<p>09950-4001 1 Puller B Set</p>	

PREPARATION - SUSPENSION AND AXLE

	(09951-04010) Hanger 150	Front axle (4WD and pre runner), Fron differential, Front suspension (4WD and pre runner), Rear differential
	(09951-04020) Hanger 200	Front axle (4WD and pre runner)
	(09952-04010) Slide Arm	Front axle (4WD and pre runner), Fron differential, Front suspension (4WD and pre runner), Rear differential
	(09953-04020) Center Bolt 150	Front axle (4WD and pre runner), Fron differential, Front suspension (4WD and pre runner), Rear differential
	(09954-04010) Arm 25	Front axle (4WD and pre runner), Fron differential, Front suspension (4WD and pre runner), Rear differential
	(09955-0401 1) Claw No.1	Front differential
	(09955-04031) Claw No.3	Front axle (4WD and pre runner), Front suspension (4WD and pre runner)
	(09955-04061) Claw No.6	Front differential Rear differential
	(09957-04010) Attachment	Front axle (4WD and pre runner), Fron differential, Front suspension (4WD and pre runner), Rear differential
	(09958-0401 1) Holder	Front axle (4WD and pre runner), Fron differential, Front suspension (4WD and pre runner), Rear differential
	09950-60010 Replacer Set	
	(09951-00350) Replacer 35	Rear suspension
	(09951-00380) Replacer 38	Front differential

	(09951-00450) Replacer 45	Rear differential (2RZ-FE)
	(09951-00480) Replacer 48	Front differential Rear differential (Except 2RZ-FE)
	(09951-00490) Replacer 49	Front axle (2WD)
	(09951-00540) Replacer 54	Front differential
	(09951-00550) Replacer 55	Rear differential (3RZ-FE, 5VZ-FE w/ Diff. lock)
	(09951-00560) Replacer 56	Rear axle
	(09951-00610) Replacer 61	Rear axle
	(09951-00640) Replacer 64	Front axle (2WD) Rear differential (3RZ-FE, 5VZ-FE w/o Diff. lock)
	(09951-00650) Replacer 65	Front axle (4WD and pre runner) Front differential
	09950-60020 Replacer Set No.2	
	(09951-00710) Replacer 71	Front axle (2WD) Rear axle Rear differential
	(09951-00730) Replacer 73	Rear differential (3RZ-FE, 5VZ-FE w/ Diff. lock)
	(09951-00790) Replacer 79	Front differential Rear differential

PREPARATION - SUSPENSION AND AXLE

	<p>(09951-00810) Replacer 81</p>	<p>Front axle (4WD)</p>
	<p>(09951-00890) Replacer 89</p>	<p>Rear axle</p>
	<p>(09951-00910) Replacer 91</p>	<p>Front axle (4WD and pre runner) Rear differential (3RZ-FE, 5VZ-FE w/o Diff. lock)</p>
	<p>09950-70010 Handle Set</p>	<p>Front axle Front differential Rear axle Rear differential</p>
	<p>(09951-07150) Handle 150</p>	
	<p>09960-10010 Variable Pin Wrench Set</p>	<p>Rear differential (3RZ-FE, 5VZ-FE w/ Diff. lock)</p>
	<p>(09962-01000) Variable Pin Wrench Arm Assy</p>	
	<p>(09963-00700) Pin 7</p>	