







CLIP REPLACEMENT







BO06W-02

The removal and installation methods of typical clips used in body parts are shown in the table below.

HINT:

If the clip is damaged during the operation, always replace it with a new clip.

Shape (Example)	Removal/Installation
	
	
	

Shape (Example)	Removal/Installation	
	<p data-bbox="895 309 1007 338">Removal</p> 	<p data-bbox="1257 309 1385 338">Installation</p> 
	<p data-bbox="895 808 1007 837">Removal</p> 	<p data-bbox="1246 808 1374 837">Installation</p> 

V00012