

REMOVAL

REMOVE FRONT SEAT

Remove the 4 bolts and front seat.

NOTICE:

Be careful not to damage the body.