

## REMOVAL


### 1. REMOVE BACK PANEL UPPER GARNISH AND REAR SEAT BACK

(a) Using a screwdriver, remove the garnish.

HINT:

Tape the screwdriver tip before use.

(b) Remove the 3 bolts and rear seat back.



### 2. REMOVE BACK PANEL LOWER GARNISH

Using a screwdriver, remove the garnish.

HINT:

Tape the screwdriver tip before use.

### 3. REMOVE REAR SEAT CUSHIONS

Remove the 4 bolts and rear seat cushions.

### 4. REMOVE SEAT TURN TABLE