

## REASSEMBLY

Reassembly is in the reverse order of disassembly. (See page [MT-14](#))

HINT:

Coat all of the sliding and rotating surfaces with gear oil before reassembly.