
















MANUAL TRANSMISSION (R150, R150F)

SST (Special Service Tools)

PP0A2-04

	09309-35010	Transmission Rear Bearing Replacer	2WD: Output shaft rear bearing Output shaft center bearing
	09316-60011	Transmission & Transfer Bearing Replacer	
	(09316-00011)	Replacer Pipe	Output shaft rear bearing Gear spline piece No.5
	(09316-00031)	Replacer "B"	5th gear
	(09316-00071)	Replacer "F"	4WD: Output shaft rear bearing Output shaft center bearing
	09506-35010	Differential Drive Pinion Rear Bearing Replacer	Input shaft bearing
	09950-00020	Bearing Remover	
	09950-40011	Puller B Set	Output shaft rear bearing
	09950-50013	Puller C Set	Gear spline piece No. 5
	09950-60010	Replacer Set	
	(09951-00510)	Replacer 51	Front bearing retainer oil seal
	(09951-00570)	Replacer 57	Extension housing oil seal Transfer adaptor oil seal

	<p>(09951-00620) Replacer 62</p>	<p>Counter rear bearing</p>
	<p>09950-70010 Handle Set</p>	
	<p>(09951-07150) Handle 150</p>	