





STARTING (5VZ-FE)

SST (Special Service Tools)

PP3VZ-01

	<p>09286-46011 Injection Pump Spline Shaft Puller</p>	<p>Armature bearing</p>
	<p>09201-41020 Valve Stem Oil Seal Replacer</p>	<p>Armature front bearing</p>
	<p>09810-38140 Starter Magnet Switch Nut Wrench 14</p>	<p>Terminal kit</p>
	<p>09820-00031 Starter Magnet Switch Nut Wrench 14</p>	<p>Armature rear bearing</p>