

INSTALLATION

Installation is in the reverse order of removal (See page [SA-24](#)).

HINT:

After installation, bleed the brake system (See page [BR-4](#)), check the front wheel alignment (See page [SA-10](#)) and ABS speed sensor signal (See page [DI-534](#)).