

INSTALLATION

Installation is in the reverse order of removal (See page [SA-129](#)).

HINT:

After installation, bleed the brake system (See page [BR-4](#)) and check the ABS speed sensor signal (See page [DI-534](#)).