



AIR-FUEL RATIO (A/F) SENSOR COMPONENTS

SF10D-03

2RZ-FE (Bank 1 Sensor 1)



3RZ-FE (Bank 1 Sensor 1)



N·m (kgf·cm, ft·lbf) : Specified torque

◆ Non-reusable part

B15545