


AIR-FUEL RATIO (A/F) SENSOR COMPONENTS

SF10G-01

(Bank 1 Sensor 1)



N·m (kgf·cm, ft·lbf) : Specified torque

◆ Non-reusable part

B09852