

DTC	C1243 / 43, C1245 / 45	Malfunction in Deceleration Sensor
------------	-------------------------------	---

CIRCUIT DESCRIPTION

DTC No.	DTC Detecting Condition	Trouble Area
C1243 / 43	While vehicle speed becomes 0 km/h (0 mph) from 30 km/h (18 mph), and the condition that GL1 signals of ECU terminals do not change 40 mV or less continues in a sequence 16 times.	<ul style="list-style-type: none"> • ABS deceleration sensor • Wire harness for deceleration sensor system
C1245 / 45	At the vehicle speed of 30 km/h (18 mph) or more, and the condition that the difference between acceleration and deceleration values of computation from ABS deceleration sensor and vehicle speed becomes more than 0.35 G continues for 60 sec. or more.	

WIRING DIAGRAM

See page [DI-567](#).

INSPECTION PROCEDURE

HINT:

Start the inspection from step1 in case of using the hand-held tester and start from step 2 in case of not using the hand-held tester.

1	Check output value of the deceleration sensor.
----------	---

PREPARATION:

- (a) Connect the hand-held tester to the DLC3.
- (b) Turn the ignition switch ON and push the hand-held tester main switch ON.
- (c) Select the DATA LIST mode on the hand-held tester.

CHECK:

Check that the deceleration value of the deceleration sensor displayed on the hand-held tester is changing when tilting the vehicle.

OK:

Deceleration value must be changing.



2	Check ABS deceleration sensor (See page DI-534).
----------	---



3

Check for open or short circuit in harness and connector between deceleration sensor and skid control ECU (See page [IN-28](#)).

NG

Repair or replace harness or connector.

OK

Check and replace brake actuator ASSY.